

C-Soft 7.700

C-Soft

en Technical Manual

C-Soft 7.700 Table of contents | en 3

## **Table of contents**

1	Notices	11
1.1	Proprietary notice	11
1.2	Copyright notice	11
1.3	Warranty notice (limited)	11
1.4	Factory service center	11
1.5	Contact information	11
1.6	Claims	11
1.7	Warning	12
1.8	OpenSSL project	12
2	Overview	13
3	License and optional features	14
4	C-Soft Application Software	16
5	Installation and setup	17
5.1	Install the C-Soft Runtime software	17
5.2	Install the C-Soft Designer software	24
5.3	ADHB-4 driver installation	29
5.4	Telex License Server setup	31
5.5	Initial volume control settings	37
5.5.1	Playback volumes	37
5.5.2	Recording volumes	39
5.6	Position settings	41
6	Communications system design	43
6.1	Communication control	43
6.1.1	Tone remote control	43
6.1.2	VoIP radio control	43
6.2	PC & Network Security Considerations	44
6.3	Network requirements	44
6.3.1	IP operation overview	44
6.3.2	Ethernet as physical layer	45
6.3.3	Bandwidth	45
6.3.4	Multicast	45
6.3.5	IP PIM query-interval	45
6.3.6	Internet group management protocol	46
6.3.7	Network performance	46
6.3.8	TCP/IP and UDP/IP	46
6.3.9	Multicast UDP/IP	47
6.3.10	Telex Radio Dispatch port-centric method	48
7	C-Soft Designer program	49
7.1	Starting the C-Soft Designer program	49
8	C-Soft Designer window	50
9	User interface element configuration	53
10	File menu	57
10.1	Design Errors window	57
10.2	File Information window	58
10.3	Telex Design Archive (TDA) files	59
11	Edit menu	60
12	Per Line Parameters window	61
12.1	Line Options Setup window	64

4 en | Table of contents C-Soft 7.700

12.2	Frequency Parameters window	67
12.3	Frequency Parameters windows - MOTOTRBO	69
12.4	Signaling Parameters window	72
12.5	Signal system types	75
12.5.1	Generic system type	75
12.5.2	5-6 Tone/DTMF ANI system type	75
12.5.3	FleetSync system type	83
12.5.4	Telex-Serial system type	86
12.5.5	MDC-1200 system type	88
12.5.6	MOTOTRBO system type	92
12.5.7	Sprint Direct Connect system type	96
12.5.8	Telex-Enhanced-ANI system type	98
12.5.9	Phone system type	100
12.6	AutoFill Line Parameters window	105
12.7	Configure SIP Settings window	108
12.8	SIP Phone line configuration	111
12.8.1	SIP features	112
12.8.2	Configure SIP for recording or monitoring	112
13	Global Parameter Setup window	114
13.1	Appearance page	114
13.2	Audio page	120
13.3	Control Settings page	124
13.4	IRR Recording page	127
13.5	Local Consoles page	129
13.6	Peripherals page	131
13.7	Recording page	135
14	Language Customization	137
14.1	General page	137
14.2	Button Labels window	139
14.3	Button Images window	141
14.4	Column Headings page	143
14.5	Text Labels window	146
14.6	Window Titles window	147
15	Paging Settings window	149
15.1	2 Tone 100 Page Setup window	151
15.2	2 Tone 1000 Setup window	153
15.3	DTMF Paging Setup window	157
15.4	Knox Paging Setup window	158
16	Tone Levels window	161
17	Global SIP Configuration window	163
17.1	SIP Network page	163
17.2	Audio page	166
17.3	Behavior page	169
18	Setup P25	171
19	GPS Mapping Setup window	172
20	NEXEDGE	174
21	Setup External Systems	175
21.1	API Setup	175
22	AIS	176

5

23	Filter List Setup window	177
24	User ID List window	179
25	Group ID List window	183
26	Status Message ID List window	187
27	Text Message ID List window	190
28	Edit System List window	192
28.1	File menu - Edit System List	193
28.2	Edit System List window - System Menu	196
28.2.1	New System window	196
28.2.2	Copy System window	197
28.2.3	System configuration	198
28.2.4	Auto Build System command	199
29	Insert menu	207
30	UI Element Setup window	209
30.1	Type page	209
30.2	Colors page	210
30.3	Options page	210
31	UI Element Functions configuration	213
31.1	Active Emergency Window	219
31.2	ADHB-4 Auxiliary Audio Control button	220
31.3	ADHB-4 Mic Control	222
31.4	ADHB-4 NENA-Hold	223
31.5	ADHB-4 NENA-Hook Control function	224
31.6	ADHB-4 NENA-Indication	224
31.7	ADHB-4 NENA-Mute	225
31.8	ADHB-4 Select Speaker Control	225
31.9	Alert	225
31.10	Annunciation	228
31.11	Auto-Dial	231
31.12	Backup Line	232
31.13	Call List Window	233
31.13.1	Call List window	233
31.13.2	Status List window	236
31.14	Call Priority button	238
31.15	Call Queue window	239
31.15.1	Call Queue Setup page	240
31.15.2	Call Queue Columns page	241
31.15.3	Group Statuses page	243
31.15.4	Call Queue window	244
31.16	Crosspatch	246
31.17	Crosspatch Block	247
31.18	Crosspatch Clear	248
31.19	Crosspatch Programmed	248
31.20	Crosspatch PTT	250
31.21	Dial	251
31.22	DTMF Digit	251
31.23	Emergency ACK	252
31.24	Emergency Clear	253
31.25	Emergency History Window	253

**6** en | Table of contents C-Soft 7.700

31.26	Encryption	254
31.27	Event Logger	254
31.28	FleetSync	255
31.28.1	FleetSync Dispatching window	256
31.29	Frequency Change	265
31.30	GPS Read button	266
31.31	GPS Trigger Off button	267
31.32	GPS Trigger On button	267
31.33	Group Programmed	269
31.34	Group Select	273
31.35	Group Select Limited	273
31.36	Input Indication	274
31.37	Instant Recall	278
31.37.1	Duration page	279
31.38	Instant Recall - Last Call button	280
31.39	Intercom	281
31.40	Intercom-Per Line	281
31.41	Knox Digit	282
31.42	Launch Application	282
31.42.1	Launch Application Setup page	282
31.42.2	Application Triggers page	283
31.43	Manual Call List	285
31.43.1	Manual Call List window	286
31.44	Marker Tone	287
31.45	MDC-1200	291
31.45.1	MDC-1200 Dispatching window	294
31.45.2	History page	300
31.46	Monitor	303
31.47	MOTOTRBO Radio Setup page	303
31.47.1	Dispatch Window	306
31.47.2	MOTOTRBO Dispatching window	312
31.48	Mute Group	319
31.49	Mute Main	320
31.50	Mute-Per Line	321
31.50.1	Per Line Mute Button Setup page	321
31.51	P25-DFSI window	322
31.52	Page	324
31.53	Page Cancel	328
31.54	Page Manual Entry	328
31.54.1	Manual Page Setup	328
31.55	Page Send	331
31.56	Page Stack	332
31.56.1	Page Stack Setup	332
31.57	Page Stack Programmed	333
31.57.1	Programmed Stack Setup page	333
31.58	Per Line Call History	335
31.58.1	Per Line Call History window	337
31.58.2	Per Line Call History window - 5/6 Tone line	339
31.58.3	IRR Playback Control window	341

C-Soft 7.700 Table of contents | en 7

31.58.4	Comments window	342
31.59	Phone-Flashhook	343
31.60	Phone-Hold	343
31.61	Phone-On/Offhook	343
31.61.1	Remote Phone Line Select page	344
31.62	PTT-Group Call	345
31.63	PTT-Main	346
31.64	PTT-Per Line	346
31.64.1	Per Line PTT Setup page	346
31.65	PTT-Private Call	347
31.66	PTT-Talk Back	348
31.67	Radio Call Alert	348
31.68	Radio Call Type	349
31.69	Radio Check	349
31.70	Radio Disable	349
31.71	Radio Enable	350
31.72	Radio Regroup	350
31.73	Radio Ungroup	351
31.74	Radio Remote Monitor	351
31.75	Radio Status	352
31.76	Radio Status Request	352
31.77	Radio Select Call	353
31.78	Radio-On/Offhook	353
31.79	Relay Control Button	354
31.79.1	Relay Control Setup page	354
31.79.2	Text Message Control page	359
31.79.3	Status Control page	361
31.80	RX All	363
31.81	Scan	364
31.82	Select	364
31.83	SIP Call Control	368
31.83.1	SIP Window page	369
31.83.2	SIP Speed Dial page	372
31.83.3	SIP Calls window	375
31.83.4	Call page	375
31.83.5	History page	391
31.83.6	Missed page	392
31.83.7	Misc page	393
31.83.8	Forward page	394
31.84	Status Stack Programmed	396
31.85	Status Stack window	398
31.85.1	Window Appearance group box	399
31.85.2	Failed Attempts group box	399
31.85.3	Status Stack window	400
31.86	Supervisor	401
31.87	Talk Around button	402
31.88	Text button	402
31.89	TX AII	403
32	UI Element Setup window - Add button	404

Bosch Security Systems, LLC Technical Manual 2021-06 | 14 | F.01U.218.561

en | Table of contents C-Soft 7.700

32.1	Type page	404
32.2	Colors page	407
32.3	Radio Command buttons	409
33	UI Element Setup window - Add Clock	412
33.1	Clock Control page	412
34	UI Element Setup window - Add Frame	416
35	UI Element Setup window - Add Frequency Control	418
35.1	Colors page	419
35.2	Frequency Control page	422
36	UI Element Setup window - Add Keypad	425
36.1	Common page	425
36.2	Contact Tab page	428
36.3	Manual Tab page	430
36.4	History Tab page	432
36.5	Keypad	433
37	UI Element Setup window - Add Popup Button	439
37.1	Popup Window Setup page	440
37.1.1	Window Options group box	441
37.1.2	Button Options group box	441
37.1.3	Logo group box	442
37.2	Popup Webpage	442
37.2.1	Popup Webpage Setup page	442
37.3	Type page	443
37.4	Popup Global Call History	444
37.4.1	Call List Options page	445
37.5	Global Call History window	447
38	UI Element Setup window - Add Text	449
39	UI Element Setup window - Add Text Message Control	450
40	UI Element Setup window - Add Volume Control	453
40.1	Type page	453
40.2	Vol. Control page	454
41	UI Element Setup window - Add VU Meter	457
41.1	VU Meter Control page	457
42	View menu	458
43	Configure menu	459
44	Device Setup	460
45	Global Key Mapping	461
46	Run menu	463
47	About C-Soft Designer	464
48	C-Soft Runtime program	465
48.1	C-Soft Console	466
49	Appendix A - Telex Tone Group Numbers and Paging Plans	473
49.1	Telex Tone Group Numbers	473
49.2	Tone and Gap Durations for Standard Paging Plans	474
50	Appendix B - 2 Tone 1000 Plan Numbers	475
51	Appendix C - Supported Tone Frequencies	477
52	Appendix D - Echo Packets Diagram	478
53	Appendix E - P25-DFSI (Digital Fixed Station Interface)	479
53.1	P25-DFSI C-Soft Architecture	479

8

53.2	P25 DFSI Global Setup window	480
53.2.1	Console Type group box	481
53.2.2	Backup Server Ping Address group box	482
53.2.3	Heartbeats group box	483
53.2.4	Radio/Repeater Control Signals group box	483
53.2.5	Packet Controls group box	484
53.3	Console Type Setup	484
53.3.1	Stand Alone Console	484
53.4	Backup FS Setup window	486
53.5	Server Console	488
53.6	Backup FS Setup window	489
53.7	Client Console	492
53.8	Client Console with Server Backup	494
53.9	Backup FS Setup window	495
53.9.1	Client Connections group box	496
53.9.2	Control Address of Server group box	496
53.9.3	Voice Address of Server group box	496
53.10	Channel Table window	497
53.11	Setting Up Additional P25-DFSI lines	500
53.12	P25-DFSI window and C-Soft Runtime	504
53.12.1	Main Control page	504
53.12.2	Unit Control page	506
53.12.3	Voting page	508
53.12.4	Repeater page	509
53.12.5	History page	510
53.13	System features and requirement for DFSI Interface	511
53.14	Frequently Asked Questions	511
54	Appendix F - P25 Encryption	513
54.1	Encryption configuration	514
54.2	Encryption Setup window	516
54.3	Encryption Profile Edit window	518
54.4	Registering keys	519
54.5	Connecting a key fill device	521
54.6	Group encryption options into encryption profiles	522
54.7	Link P25-DFSI Channels to an encryption profile	<b>52</b> 3
54.7.1	Activate Key Fill Device serial port	524
54.8	Add an Encryption Option Select button	524
54.9	Loading keys to C-Soft Runtime	525
54.10	Receiving encrypted calls	526
54.11	Transmitting encrypted calls	526
55	Appendix G - CSSI Interface	529
55.1	Supported features	529
55.2	Theory of operation	530
55.2.1	Distribution of receive audio to the lines	531
55.2.2	Individual Call line	532
55.3	CSSI Call types	532
55.3.1	Group Call	532
55.3.2	Individual Call	534
55.4	C-Soft Setup parameters	535

Bosch Security Systems, LLC Technical Manual 2021-06 | 14 | F.01U.218.561

**10** en | Table of contents C-Soft 7.700

EE	Signaling Parameters	537
55.5 55.6	Signaling Parameters CSSI System setup	538
55.7	Global P25 CSSI Parameters	540
56. <i>1</i>	Appendix H - Kenwood NEXEDGE Direct IP interface	544
56.1	Supported features	544
56.2	Theory of operation	544
56.2.1	Distribution of receive audio to the lines	546
56.2.2	Group Call line	547
56.3	NEXEDGE Call types	547
56.3.1	Conference call	547
56.3.2	Unit call	549
56.4	C-Soft Setup parameters	550
56.5	NEXEDGE Trunking System setup	551
56.5.1	NEXEDGE Trunking Parameters page	553
56.6	Console Global Setup	554
56.6.1	Local Consoles button	556
56.7	NEXEDGE Conventional IP system configuration	557
56.8	NEXEDGE Conventional Parameters window	558
56.9	Global NEXEDGE Conventional Parameters window	561
56.10	NEXEDGE Conventional RANs window	563
56.11	NEXEDGE Conventional IP set up	565
56.12	C-Soft NEXEDGE Conventional IP interface	567
56.13	NEXEDGE System configuration	569
56.13.1	NEXEDGE System configuration type 1 - No signaling with RAN	569
56.13.2	NEXEDGE System configuration type 2 - Signaling without RAN	573
56.13.3	NEXEDGE System configuration type 3 - Signaling and RAN	575
56.14	NEXEDGE System manager parameters	577
56.15	Kenwood radio programming software	580
56.16	NEXEDGE Encryption window	581
56.17	Scrambler/Encrypt Key Select button	584
57	Appendix I - Telex License Activation tool	585
57.1	Telex Licensing Server setup	585
57.2	Installation activation	586
57.2.1	View current licensing information	587
57.2.2	Add Fulfillment	588
57.2.3	Return Fulfillment	590
57.2.4	Repair	591
57.2.5	Process Response Message	591
58	Appendix J - DMR-AIS	593
58.1	Supported features	593
58.2	AIS Global Setup window	596
58.3	C-Soft Designer setup	597
59	Appendix K - C-Soft API Installation notes	604
59.1	Supported features	604
59.2	Setup External Systems window	605
59.2.1	API Setup	605
60	Appendix L - End user license agreement	608

C-Soft 7.700 Notices | en 11

### 1 Notices

## 1.1 Proprietary notice

The product information and design disclosed herein were originated by and are the property of Bosch Security Systems, LLC. Bosch reserves all patent, proprietary design, manufacturing, reproduction, use and sales rights thereto, and to any article disclosed therein, except to the extent rights are expressly granted to others.

### 1.2 Copyright notice

Copyright 2021 by Bosch Security Systems, LLC. All rights reserved. Reproduction, in whole or in part, without prior written permission from Bosch is prohibited.

- \*All other trademarks are property of their respective owners.
- \*\*MOTOROLA, MOTOTRBO, and the Stylized M logo are registered in the U.S. Patent and Trademark Office.

### 1.3 Warranty notice (limited)

For warranty and service information, see http://www.telex.com/warranty.

## 1.4 Factory service center

Factory Service Center Bosch Security Systems, LLC Radio Dispatch Products 8601 East Cornhusker Highway Lincoln, Nebraska, 68507

#### 1.5 Contact information

#### Sales

E-mail: TelexDispatch@us.bosch.com

Phone: (800) 752-7560 Fax: (402) 467-3279

#### **Customer service repair**

E-mail: repair@us.bosch.com Phone: (800) 553-5992

#### **Technical support**

E-mail: TelexDispatchtechsupport@us.bosch.com

Knowledge database: http://knowledge.boschsecurity.com/

Web: www.telex.com

#### 1.6 Claims

No liability will be accepted for damages directly or indirectly arising from the use of our materials or from any other causes. Our liability shall be expressly limited to replacement or repair of defective materials.

12 en | Notices C-Soft 7.700

#### Mototrbo claim

Motorola Solutions, Inc and its subsidiaries make no express or implied representation or warranty with respect to: (i) any of the Products references herein; (ii) the information provided herein (including without limitation the key findings and test results regarding the Products and the functionality or interoperability thereof) ("Information") or any solution, combination or system that may be created with the use thereof. The information is offered "as is" with all faults and does not constitute professional, technical, legal or other advice to the user.

## 1.7 Warning



#### Notice!

This is a class A product. In a domestic environment this product may cause radio interference, in which case the user may be required to take adequate measures.



#### Warning!

Do not open the unit. No user serviceable parts are contained within. Bosch cannot be responsible for damage. If the unit is opened, the warranty can be voided.

## 1.8 OpenSSL project

- This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit (https://www.openssl.org/).
- This product includes cryptographic software written by Eric Young (eay@cryptsoft.com).
- This product includes cryptographic software written by Tim Hudson (tjh@cryptsoft.com).

C-Soft 7.700 Overview | en 13

## 2 Overview

The Telex C-Soft Console Software is a Microsoft Windows application (refer to *Copyright notice*, *page 11*) that enables a PC with a network connection to monitor and control 2-way radios connected to the network. Utilized in conjunction with an infrastructure of Telex VoIP (Voice Over Internet Protocol) products, the C-Soft application offers a powerful and convenient method for controlling a radio network using standard computer equipment. The software console can support up to 200 lines and is fully compatible with popular touch screen monitors. In addition, standard desk microphones, headsets, and foot-switches are supported through the use of the ADHB-4 headset adapter panel.



#### Notice!

Application Notes containing instructions for specific product installation are available for download at <a href="https://www.telex.com">www.telex.com</a>.

#### **Computer system requirements**

Operating system	Microsoft Windows 8.1 and Windows 10 (supports both 32-bit and 64-bit)
Sound system	Full-duplex Microsoft Windows compatible sound system
Network connection	10Mbps or 100Mbps, full-duplex TCP/IP connection. Static IP address preferred to DHCP
Processor speed	Intel Core i3 2.80GHz processor
Random access memory	Minimum of 8GB recommended

 Bosch Security Systems, LLC
 Technical Manual
 2021-06 | 14 | F.01U.218.561

# 3 License and optional features

Part number	Description	Model number
F.01U.307.023	C-Soft 2-line SOFTWARE v7	C-Soft7 2L
F.01U.307.024	C-Soft 6-line SOFTWARE v7	C-Soft7 6L
F.01U.307.025	C-Soft 12-line SOFTWARE v7	C-Soft7 12L
F.01U.307.026	C-Soft 24-line SOFTWARE v7	C-Soft7 24L
F.01U.307.027	C-Soft 50-line SOFTWARE v7	C-Soft7 50L
F.01U.307.028	C-Soft 100-line SOFTWARE v7	C-Soft7 100L
F.01U.307.029	C-Soft 150-line SOFTWARE v7	C-Soft7 150L
F.01U.307.030	C-Soft 200-line SOFTWARE v7	C-Soft7 200L
F.01U.307.031	Upgrade Previous C-Soft to C-Soft v7	C-Soft7 Upgrade
***Each C-Soft li	cense includes 2 lines of SIP and 1 line	e of Per Line Playback
F.01U.307.047	SIP Enhanced 6-line	SIP 6L
F.01U.307.048	SIP Enhanced 12-line	SIP 12L
F.01U.307.032	Line Call Playback 2-line	Playback 2L
F.01U.307.033	Line Call Playback 6-line	Playback 6L
F.01U.307.034	Line Call Playback 12-line	Playback 12L
F.01U.307.035	Line Call Playback 24-line	Playback 24L
F.01U.307.036	Line Call Playback 50-line	Playback 50L
F.01U.307.037	Line Call Playback 100-line	Playback 100L
F.01U.307.038	NEXEDGE Direct IP 2-line	NEXEDGE IP 2L
F.01U.307.039	NEXEDGE Direct IP 6-line	NEXEDGE IP 6L
F.01U.307.040	NEXEDGE Direct IP 12-line	NEXEDGE IP 12L
F.01U.307.041	NEXEDGE Direct IP 24-line	NEXEDGE IP 24L
F.01U.307.042	DFSI Direct IP 2-line	P25 DFSI 2L
F.01U.307.043	DFSI Direct IP 6-line	P25 DFSI 6L
F.01U.307.044	DFSI Direct IP 12-line	P25 DFSI 12L
F.01U.307.045	DFSI Direct IP 24-line	P25 DFSI 24L
		1

F.01U.343.866	AES Encryption Option, per seat	Encryption Seat
F.01U.343.860	Direct IP Interface, DMR AIS, 2-line	DMR AIS IP 2L
F.01U.343.861	Direct IP Interface, DMR AIS, 6-line	DMR AIS IP 6L
F.01U.343.862	Direct IP Interface, DMR AIS, 12-line	DMR AIS IP 12L
F.01U.343.863	Direct IP Interface, DMR AIS, 24-line	DMR AIS IP 24L
F.01U.343.864	Application Programming Interface SDK	API SDK
F.01U.343.865	Application Programming Interface, per seat	API Seat
F.01U.343.856	P25 CSSI Direct IP 2-line License	P25 CSSI 2L
F.01U.343.857	P25 CSSI Direct IP 6-line License	P25 CSSI 6L
F.01U.343.858	P25 CSSI Direct IP 12-line License	P25 CSSI 12L
F.01U.343.859	P25 CSSI Direct IP 24-line License	P25 CSSI 24L

## 4 C-Soft Application Software

#### **C-Soft Designer program**

The **C-Soft Designer** program provides the ability to create custom dispatch screen designs. Console operators with differing requirements can be given different screen designs. Once the screen layout is created, the C-Soft Designer program generates a file read by the C-Soft Runtime program.



#### Notice!

A software-based license key is not required to operate C-Soft Designer.

#### **C-Soft Runtime program**

The **C-Soft Runtime** program does the actual network communications with the other radio elements available on the network. This single screen design file makes it easy for the designer to send updates to users wherever they may be located.

## 5 Installation and setup

This chapter includes information on the installation of and the initial system setup requirements for the C-Soft program.

#### Sections include:


- Install the C-Soft Runtime Software
- Install the C-Soft Designer Software
- Install the ADHB-4 Driver
- Install the Telex License Server
- Configure the initial Volume Control settings

#### 5.1 Install the C-Soft Runtime software

**Important:** The C-Soft Installation package is downloadable from <u>www.telex.com</u>. Contact the technical support team to get access.


#### To install the C-Soft software, do the following:

- 1. Download the **C-Soft installation package** and copy it to your computer.
- 2. Navigate to and double-click the **C-Soft Setup\_vXXXX.exe** file. The C-Soft Runtime Setup wizard appears.




3. Click Next.

The License Agreement window appears.




- 4. To agree with the agreement, select the "I accept the agreement" radio button.
- 5. Click the **Next button**.

The Information window appears.




6. Follow the instructions in the window and click **Next**. The Select Destination Location window appears.



Click **Next** to accept the default folder location for C-Soft (recommended).
 The Select Additional Tasks window appears.
 OR

Click **Browse** to select a different folder location for C-Soft.


The Browse window appears.



8. From the Additional shortcuts list, select **check boxes** for the shortcuts you want to create.


9. Click Next.

The C-Soft Settings window appears.




Click Next to accept the default C-Soft Directory settings (recommended).
 The C-Soft Settings TSM Setup window appears.
 OR

Click the **Browse button** to navigate to the folder as desired for each Directory setting.




- 11. Enter the TSM Username desired.
- 12. Select the Reset Password check box to reset the password that logs into the device with TSM.
- 13. Enter the **TSM Ping TTL** to set the TTL (Time to Live) value, which is TSM device detection feature.
- 14. Click Next.

The C-Soft Settings Position Name window appears.



- 15. Enter the Position Name.
- 16. Click Next.

The C-Soft Settings Summary window appears.




17. Select the Confirm Position settings to continue check box.

#### 18. Click Next.


The Ready to Install window appears.

NOTE: The destination location and start menu folder paths appear in this window.



#### 19. Click Install.

C-Soft installs. The C-Soft Runtime Setup Wizard finish window appears.



20. Click Finish, when complete.

## 5.2 Install the C-Soft Designer software

**Important:** The C-Soft Installation package is downloadable from <u>www.telex.com</u>. Contact the technical support team to get access.


To install the C-Soft Designer software, do the following:



#### Notice!


The C-Soft Designer installer launches during the C-Soft Runtime installer. It has already downloaded to your machine.

Navigate to and double-click the C-SoftDesigner\_Setup\_vXXXX.exe file.
 The C-Soft Designer Setup wizard appears.



Click Next.

The License Agreement window appears.




- 3. To agree with the agreement, select the "I accept the agreement" radio button.
- Click the **Next button**.
   The Upgrade Design window appears.
- 5. (Optional) Select the Upgrade default design check box to have C-Soft Designer automatically upgrade the current design to a version compatible with the C-Soft Designer version being installed.




#### Notice!

If selected, a backup of the default design is saved prior to upgrade. It exists in the same folder, but a version suffix is added to the file's name. For example, if the designs name is MyDesign.veg, MyDesign.veg is the first backed up to MyDesign\_X.XXX.veg. and then MyDesign.veg is upgraded to the new C-Soft version.



Click Next.
 The Information window appears.



Follow the instructions in the window and click Next.
 The Select Destination Location window appears.




Figure 5.1:


1. Click **Next** to accept the default folder (recommended).

The Select Additional Tasks window appears.

OR

Click **Browse** to select a different folder location for the program's files.


The Browse window appears



- 2. From the Additional icons list, select **check boxes for shortcuts** you want to create.
- 3. Click Next.


The Ready to Install window appears.

NOTE: The destination location and start menu folder paths appear in this window.



4. Click Install.

C-Soft Designer installs.



5. Click **Finish**, when complete.


## 5.3 ADHB-4 driver installation

The **ADHB-4 Device Installer** wizard appears automatically at the end of the C-Soft installation process.

To install the ADHB-4 driver, do the following:


From the Welcome to the ADHB-4 Installer wizard, click the **Next button**.
 The Windows Security message appears.

 Bosch Security Systems, LLC
 Technical Manual
 2021-06 | 14 | F.01U.218.561




#### 2. Click Next.

The Windows Security window appears.



#### 3. Click Install.

The Congratulations! You are finished Installing the ADHB-4 window appears.



#### 4. Click Finish.

The ADHB-4 driver installation is complete.

#### Note:

- When the installation is finished, the C-Soft executable files are located at: C:\Program Files\Telex Communications\C-Soft.
- The cposi.txt, keyset.dat, and DefaultVeg.txt files are located at: C:\Programdata\Telex Communications\design\_folder.


## 5.4 Telex License Server setup

The **Telex License Server Installer** wizard appears automatically at the end of the ADHB-4 installation process.


For more information about the Telex License process, refer to "Appendix I - Telex License Activation tool, page 585".


#### To install the Telex License Server, do the following:

From the Welcome to the Telex License Server Setup Wizard, click the **Next button**.
 The License Agreement window appears.





2. To accept the agreement, select the "I accept the agreement" radio button.
The Select Destination window appears.





- 3. Follow the instructions in the window and click Next.
  - The Select Destination Location window appears.
- Click the **Next button** to accept the default folder location for C-Soft (recommended).
   The Select Start Menu Folder window appears.
   OR
  - Click the **Browse button** to select a different folder location for C-Soft. The Browse window appears.





1. Click the **Next button** to accept the default folder (recommended).


The Select Additional Tasks window appears.

OR

Click the **Browse button** to select a different folder location for the program's shortcut


files.

The Browse window appears.



- 2. From the Additional icons list, select **check boxes** for the shortcuts you want to create.
- 3. Click the Next button.

The Ready to Install window appears.




4. Click the **Install** button.

The Microsoft Visual C++ 2012 window appears.



- 5. Select the I agree to the license terms and conditions check box.
- 6. Click the Install button.


Once installed, the Setup Successful window appears.



C-Soft 7.700 Installation and setup | en 37

# 7. Click the Close button.

The Completing the Telex License Server Setup Wizard appears.



8. Click the Finish button.

# 5.5 Initial volume control settings

There are two sets of volume control settings on the computer crucial to the operation of the C-Soft programs. The first set controls playback volumes, and the second set controls recording volumes. Before using the C-Soft applications, these settings need to be checked and adjusted, if necessary.

These steps are only necessary when not using the ADHB-4.

# 5.5.1 Playback volumes

To set the playback volume, do the following:

1. Click the **speaker** icon in the system tray. The Mixer window appears.

38 en | Installation and setup C-Soft 7.700

# 2. Click **Mixer**.

The Volume Mixer window appears.





3. Set the **Device Volume to the maximum level**.

The C-Soft Console volume slider moves to maximum.


4. Click the **Device Speaker's** icon.

The Speaker Properties window appears.

C-Soft 7.700 Installation and setup | en 39

# 5. Click **Levels**.

The Levels page appears.



6. If a universal no symbol does not appear on the Microphone's speaker icon, click the **microphone** icon.

The universal no symbol appears on the icon.

OR

If the universal no symbol appears on the **microphone icon**, go to the next step.

7. Click **OK**.

The window closes.

# 5.5.2 Recording volumes

To set the recording volumes, do the following:

1. Right-click the **speaker** icon in the system tray.

40 en | Installation and setup C-Soft 7.700

2. From the shortcut menu, select **Recording Devices**.



3. Click Microphone.

The Configure Button is Enabled.

4. Click the Configure Button.

The Configure Speech Recognition screen appears.



C-Soft 7.700 Installation and setup | en 41

### 5. Click Set up microphone.

The Microphone Setup Wizard appears.



- 6. Select the type of **microphone** you want to configure.
- 7. Click Next.

The Set up your microphone window appears.

- 8. Follow the **instructions** in the window.
- 9. Click Next.

The Adjust Volume window appears.

- 10. Follow the **instructions** in the window.
- 11. Click **OK**.

The Sound window closes.

12. Close the Volume Mixer window.

# 5.6 Position settings

These position settings are stored in the devices ProgramData and are used on any design file ran on the device. These settings are configurable when running the C-Soft Installer (7.700 or greater). They can also be configured using TSM for both C-Soft Desktop installations and IP-30XX devices.

Audio Recording Directory: Location of recorded audio

Images Directory: Global location for images Sounds Directory: Global location for sounds GPS Directory: Global location for GPS kml files

**TSM Username:** Username for accessing device from TSM **TSM Password:** Password for accessing device from TSM

**TSM Ping TTL:** TTL for TSM network connection **Position Name:** Name of the dispatch position

**42** en | Installation and setup C-Soft 7.700

#### **Communications system design** 6

Designing a C-Soft console requires an understanding of the radio network and how the various radios and other communication equipment are connected.

Before you begin to design the C-Soft console, create a road map of the radio, console, and any other communication equipment locations.

This road map must include the following:

- Multicast Addresses for each channel of TX (Transmit) and RX (Receive) communication.
- Port numbers for each channel of TX and RX communication.
- Base IP Addresses assigned to each console or radio on the network and the number of frequencies each radio operates on.
- The number of channels each radio may operate on.

#### 6.1 Communication control

#### 6.1.1 Tone remote control

Telex Radio Dispatch sells a full line of tone control consoles and radio adaptors. This technology requires an analog connection between console and radio. Each console needing to control an individual radio is wired in parallel to allow multiple operator positions to monitor and control the same radio. For a large system with multiple console positions and multiple radio channels, an entire rack might be devoted to bridging audio to all interested parties. In addition, due to loading of multiple consoles on a particular circuit, additional bridging hardware might be required, increasing wiring and tuning of the system for acceptable performance. The Ethernet-based IP network solves many of these issues and provides for a number of other services not previously possible.

#### 6.1.2 VoIP radio control

VoIP is referred to generically throughout this document to mean RoIP (Radio Over Internet Protocol). RoIP terminology is a subset of VoIP and referred to as VoIP generically throughout this document. VoIP is a method of breaking analog audio up into packets to be transferred over a computer data network. Because Ethernet delivers information packets, audio is generally broken into 10-40ms chunks of audio, compressed, and placed on the Ethernet. The nodes of the network are then free to utilize or ignore any combination of packets. If a particular audio stream is of interest, the stream of audio packets are captured, decompressed, converted back to analog, and played on available speakers.

Given the popularity of the Ethernet-based networks, many companies and agencies already have an existing network or LAN (Local Area Network). Beyond that, a large number of companies exist to provide WAN (Wide Area Network) connections between sites with significant distances between them. The WAN connections can be used to connect offices across the street from one another, around the world, or anywhere in between. Possibly the best thing about these connections is they may already exist. In many cases, WAN links are less expensive than a comparable leased analog line and they can carry more conversations simultaneously.

The most compelling reason to consider basing the next radio control system upgrade on VoIP technology is the simplification in wiring requirements. Instead of needing to bring a pair or more of wires, per channel, to each console, only a single connection to the Ethernet is required. Since Ethernet can easily handle dozens of simultaneous connections, it becomes the only pipeline required for all communications.

#### 6.2 **PC & Network Security Considerations**

No system can be 100% protected against security threats. However, there are measures both manufacturers and users can do to help reduce the likelihood of a malicious attack resulting in either the loss of data or system takeover. We evaluate and improve our products continuously to protect against such attacks. This is only one safeguard used to reduce the likelihood of such an event. There are many more considerations needed to implement measures to strengthen your network security.

We strongly recommend the following considerations:

- Deploy Dispatch products and software on isolated networks that do not connect to other networks, when possible.
- Apply the latest Windows updates and install up-to-date IT security software.
- User rights should be properly administered using group policies to prevent unauthorized use of USB connected devices.
- If the Dispatch network must connect to other networks, install and properly maintain firewalls and intrusion detection systems.
- If Dispatch devices or computers use the Internet to connect, a VPN or tunnel connection should be utilized. Examples of such products are those made by DCB (Data Communications for Business), Cisco, and others.

### Notice!



Bosch recommends utilizing the services of IT professionals knowledgeable about network design and security when designing, installing, and configuring dispatch networks and deploying PCs. By default, the Telex Dispatch products using the Windows operating system has Windows Update enabled along with Windows Defender (firewall and anti-virus). Disabling these features is not recommended unless it is part of an internal IT security program that uses customized security policies along with appropriate anti-virus and firewall software.

#### 6.3 **Network requirements**

#### 6.3.1 IP operation overview

The network options today have essentially converged on Ethernet. A local electronics store may sell many of the components for both a wired or wireless network solution. For more advanced network applications, an in-house or external network hardware source may be required. These sources of information can also help with the design of the network, as well as provide sources for advanced networking equipment, such as routers and hubs from Cisco and other network vendors. This section is an overview of the protocols operating on the top of the Ethernet network.

# 6.3.2 Ethernet as physical layer

Ethernet is a network and has a low level method for transferring data from one location to another. Source and destinations are based on the MAC (Media Access Control) which is embedded in the Ethernet interface. The MAC Address is unique for all devices in the world and cannot be changed. The IEEE (Institute of Electrical and Electronics Engineers) controls the allocation of the MAC Addresses. The definition for Ethernet includes requirements for inter-operation at speeds of 10 and 100 Mbps. Higher speeds are available, but generally have not filtered down into end-user equipment.

# 6.3.3 Bandwidth

Each VoIP channel requires 50kBit of bandwidth while active. Full-duplex conversation requires 100kBit of bandwidth.

Some radio systems transmit go-ahead beeps when it is clear to talk. In order for the console operator to hear the beeps, the system must support full-duplex communication. Full-duplex bandwidth may only be required for the first few seconds of a conversation, due to the brief nature of the go-ahead beeps at the beginning of the transmission.

When using Telex's IP-223 with a PIB (Phone Interface Box) or TDI (Telephone Dispatch Interface) adapter, C-6200, or a NI-223 for a telephone connection, a full 100kBit is required since it is a full-time, full-duplex conversation.

Additional vocoders available: Telex 32K (50 kbits/sec simplex), G.726 16K (34 kbits/sec simplex), G.726 32K (50 kbits/sec simplex), G.711 (82 kbits/sec simplex).

## 6.3.4 Multicast

In general, Telex Dispatch Systems require Multicast to function. The network must be able to create a static Multicast Address, accessible at all times.

Once an IGMP (Internet Group Management Protocol) join message is sent out, networks typically enable Multicast and then prune branches after a period of time. Due to intermittent usage patterns of 2-way radios, such a system can appear to work flawlessly for a period of time and then no longer work.

When using Cisco technology, IP PIM dense mode is recommended. Generally speaking, sparse-dense-mode can also be implemented effectively. We recommend explicitly joining the Multicast group with an IP IGMP static-join X.X.X.X command. For more information on Cisco and IGMP, visit www.cisco.com.

If running Sparse mode, by design Telex equipment only sends a IGMP join message when powered up or queried by routers. The routers need to be configured with a PIM Interval Timer to keep the Multicast group active. (See example below.)

# 6.3.5 IP PIM query-interval

To configure the frequency of PIM (Protocol Independent Multicast) router query messages, use the ip pim query-interval command in interface configuration mode.

To return the default interval, use the no form of this command:

ip pim query-interval seconds

no ip pim query-interval [seconds]

# 6.3.6 Internet group management protocol

IGMP can be used to control where Multicast is allowed to propagate. This should be limited to subnets utilizing the C-Soft program as the dispatch console and only when used on an intermittent basis (when the C-Soft program is used for a period of time and then shut down). When a console on the subnet is expected to be continually operational, Multicast must be active for the subnet at all times.

# 6.3.7 Network performance

Networks should perform well under any loading conditions. The default audio delay is 120ms, plus any delay added by the network. While delay alone does not cause issues, variable delay (also known as jitter) does. Jitter, in a network, cannot exceed the maximum packet buffer of any individual product buffer. Refer to the individual product manuals for these specifications. For example, the IP-223 or IP-224 can handle approximately 600ms of network jitter.



#### Notice!

Losing more than 5% of the total packets transmitted compromises audio quality and system performance. Optimally, packet loss should be less than 1%.

# 6.3.8 TCP/IP and UDP/IP

TCP/IP (Transmission Control Protocol/Internet Protocol) is the best-known protocol for use in computer communications. It is the basis for communications on the Internet and World Wide Web. It is a guaranteed method of transferring data between two computers. Being guaranteed means for every packet of information transferred from one computer to another an acknowledgement packet is returned. Additional handshaking is utilized from the outset of the data communications to ensure both ends of the connection. Because of this guaranteed communications and its implementation utilizing handshaking (no other method is available), TCP/IP adds a great deal of overhead to data communications is not desirable for audio traffic over a network. This is where UDP/IP finds its acceptance.

UDP/IP (Universal Datagram Protocol/Internet Protocol) has existed as long as TCP/IP as an unreliable method of data communications. The term unreliable should not be thought of as a problem for audio communications over a network connection. UDP allows for a computer to send a packet of data to another computer without the handshaking sequence required within TCP/IP. Because of this, the computer sending the packet has no confirmation the packet arrived at its destination. While the loss of packets can be a problem, it generally is accounted for when the UDP application is developed. In the case of VoIP, the loss of a packet, which only contains 10-40ms of audio, is not a problem, as the human ear generally ignores the small chunk of lost audio. The largest single factor in the loss of UDP/IP packets is network design and loading. UDP applications use algorithms which makes the loss of information the largest single factor in UDP/IP network design and loading. As long as a network is well designed with

capacity for all of its chartered requirements, packet loss can be a non-issue. Because of its lower overhead and its ability to Multicast, UDP/IP is the protocol of choice for VoIP development.

#### Multicast UDP/IP 6.3.9

Multicast is an extension to UDP/IP. It enables one computer to broadcast data packets to multiple recipients. This is an ideal model for radio communications when multiple people need to monitor the audio. A single VoIP connected radio is set up to broadcast Multicast VoIP packets when receiving audio. Since the Multicast packets can be received by any interested party, all consoles monitoring the audio can receive and decode the packets for playback. In addition to simplifying monitoring of audio traffic by multiple listeners, Multicast also greatly reduces the bandwidth requirement on the network. Instead of having to regenerate the received audio into a UDP/IP data stream to each individual monitor, which uses the bandwidth times the number of monitoring consoles, a single data stream is generated and monitored by all.

Implementation of a Multicast protocol requires a few things for seamless use on a network. First, clients must all support the protocol. This is accepted as given since all Telex Radio Dispatch products utilize Multicast for audio communications. Second, consider if the network infrastructure supports Multicast.

Multicast packets are defined to be all packets with a destination address between 224.0.0.0 and 239.255.255.255. Some of these addresses are commonly used for broadcast audio and are not necessarily available. When a computer opens a UDP/IP port within this address range, it also joins the group. By joining the group, a packet is sent out to all addresses saying it is interested in seeing the traffic on this Multicast address. Routers that receive this broadcast message to join a particular Multicast Address then pass packets through because the router is now aware a listener is interested in this traffic. The routers utilized in the network must support this. The protocol used to alert routers to parties who are interested in certain Multicast Address traffic is IGMP (Internet Group Management Protocol). Telex radio Dispatch products support IGMPv1, as defined in RFC 1112.

In addition to the joining of Multicast broadcast groups, clients on the network can also specify a packet TTL (Time To Live). The TTL is the number of routers the packet goes through before being stopped. As an example, the TTL for a particular broadcasting node on the network is set to 3. This means when a packet is transmitted, it arrives at the first router in the network. This router examines the TTL value in the packet and determines if it should pass it through since it is not zero. When it passes the packet, the router decrements the TTL value by 1 to a value of 2. The next router encountered by packets does the same, reducing the value of TTL to 1. The next router does the same and the TTL is reduced to 0. The next router the packet reaches examines the TTL value, sees it is zero, and the packet is not to be retransmitted. Setting a large TTL value may allow for packets to get from one host to another on a large network, but also adds additional bandwidth requirements due to the larger number of packets being transferred.

# 6.3.10 Telex Radio Dispatch port-centric method

As mentioned earlier, Telex utilizes Multicast for all audio communications. Typically only one Multicast is used for all traffic. In addition to a valid Multicast Address, a port number is required. The port is an additional two bytes of information ranging between 1054 and 65535 that further specifies how the data traffic should be handled. For example, assume the base Multicast Address chosen is 225.8.11.81. Port 1054 is used to distinguish channel 1's RX traffic. Port 1072 is used to specify channel 1's TX traffic. Channel 2 might use 1055 for RX and 1073 for TX traffic. By making each channel's TX and RX ports different and unique, full-duplex audio can be supported and many channels of traffic can be supported using only one Multicast Address (full-duplex data transmission means data can be transmitted in both directions on a signal carrier at the same time). It is through this method a single console can pick and choose the particular radio resources available on the network without concern for what the console right next to it is utilizing.

#### **C-Soft Designer program** 7

The C-Soft Designer program is a console designer application used by system specialists to design and configure custom dispatch windows. Various combinations of buttons, sliders, text, and popup windows can be included in a window design. These elements are then configured to operate on specific lines.

The designer can place elements in any desired location, and can include or omit functions based on the requirements of the system and the console operator.

When you are finished designing your VoIP system, the C-Soft console can be created. Before you begin, determine the TX and RX port of each radio, the multicast group(s) used, the number of radios to control, and the frequencies used by each radio.

#### 7.1 Starting the C-Soft Designer program

To start the C-Soft Designer program, do the following:

Double-click the **C-Soft Designer desktop shortcut** created during program installation. The C-Soft Designer program appears.

# 8 C-Soft Designer window

When the **C-Soft Designer program** is started, the console window, shown in the Figure below, appears. This window is the workspace. It contains the commands and tools needed to design and configure a customized software console.

The C-Soft Designer workspace includes the following components:

- Title Bar
- Menu Bar
- Toolbar
- Console window
- Status Bar




Figure 8.1: C-Soft Designer workspace

#### Title Bar

The **Title Bar** is located across the top of each window. When a file is opened, the path sequence and file name appear on the title bar.

#### Menu Bar

The **Menu Bar** is located directly below the title bar and displays menus that contain commands for accessing the C-Soft Designer functions. For example, the Insert menu contains commands to add UI Element Buttons, Volume Sliders, Text, Popup Windows, and more.

# **Toolbar**

The **Toolbar** is located directly below the menu bar and provides quick, easy access to commonly used tasks. Refer to the Table below for a brief description of each button on the toolbar and the action taken when the button is selected.

To move the toolbar, do the following:

 Click, hold, and drag the move handle on the toolbar or the title bar (blue bar on a floating toolbar) to a new location.

The toolbar can be docked on any side of the window or as a floating toolbar, inside or outside the workspace.

Icon	Tool name	Description
------	-----------	-------------

<b>≧</b>	Open	Open an existing console design. You can also use File   Open.
H	Save	Save the current console design. You can also use File   Save.
Ж	Cut	Delete the selected item(s). You can also use Edit   Cut or the Delete key on the keyboard. This does not place the cut item on the clipboard. After information is cut, you can not retrieve it.
	Сору	Copy the selected item(s). You can also use Edit   Copy or CTRL+C. This places the copied item on the clipboard.
	Paste	Insert the item(s) on the clipboard into the console design. You can also use Edit   Paste CTRL+V
8	About	Display the software version, company contact information, and various statistics about the console design. You can also use Help   About C-Soft Designer.
+	Increase Width	Increase the width of the selected element. Proportionally increase the size of the selected text.
<u>_</u>	Decrease Width	Decrease the width of the selected element. Proportionally decrease the size of the selected text.
+1	Increase Height	Increase the height of the selected element. Proportionally increase the size of the selected text.
-1	Decrease Height	Decrease the height of the selected element. Proportionally decrease the size of the selected text.
5	Rotate Window	Rotate the selected popup window 90° counter- clockwise around the selected popup button. Rotate the selected text 90° counter-clockwise.
$\rightarrow$	Move Right	Move the selected item(s) to the right.
+	Move Left	Move the selected item(s) to the left.
1	Move Up	Move the selected item(s) up.
1	Move Down	Move the selected item(s) down.
	Start C-Soft Runtime	Run C-Soft Runtime with the current .veg file loaded in C-Soft Designer.

Tab. 8.1: C-Soft Designer toolbar

# **Console window**

The Console window displays the open console design. The console window contains a grid for easy alignment of elements on the window. The grid is a window alignment tool and is not displayed on the console position window.

# **Status Bar**

The **Status Bar** is located at the bottom of the workspace window.

To display or hide the status bar, do the following:

From the View menu, select **Status Bar**.

The status bar view toggles on and off. If there is a check mark next to Status bar in the view menu, the Status bar is visible.

# 9 User interface element configuration

The C-Soft Designer program is heavily dependent on the mouse for interacting with the elements that comprise the console window design. The mouse is used for selecting and moving objects, to access a form or window, and to perform actions on the displayed element or text.

Several standard Windows shortcuts are supported and are listed next to the command on the menu. This section describes C-Soft Designer features available to assist in component manipulation on the console window.

## To select a single item, do the following:

Click the desired item.


A red target is displayed on the selected element or in the case of text, there is a bounding outline around the selected text.

# To select a group of items, do the following:

- 1. Position the **mouse pointer** at the top and to the side of the objects to be selected.
- Press and hold the **left mouse button** while dragging the mouse over the objects to be selected.
  - This draws a box around the items selected.
- 3. When all items are included within the box, release the **mouse button**.

A red target appears on the selected element(s), and, in the case of text, there is a box around the selected text.

You can select all items by pressing Ctrl+A.



A group of items cannot be moved using the mouse. When selected, use either the positioning tools

 $\stackrel{\leftarrow}{\longleftrightarrow} \stackrel{-}{\longleftrightarrow} \stackrel{+}{\updownarrow} \stackrel{-}{\lnot}$  on the toolbar or the arrow keys on your keyboard to move the items.

# To move an individual item, do the following:


- Select the item to be moved.
- 2. Drag the **item** to its new location on the window.


To copy and move an individual item at the same time, do the following:

- 1. Select the **item** while holding down the **Ctrl** key.
- 2. Drag the **item** to its new location on the window.

This moves the copied item into the new location with all the parameters of the copied item intact. When a popup button is copied using the Ctrl key, the popup window is also copied.

The Ctrl key copies items to allow for large sections of the console window to be designed, copied, and then modified slightly to quickly design the console window.





# To change the line number associated with a group of items, do the following:

- 1. Select a group of items.
- 2. Right-click an **element** within the selected group.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Group Line Number**.
  - The UI Group Properties window appears.
- 4. From the Line to Associate Function With drop down menu, select the **line** to associate with the selected group.
- 5. Click OK.

The line number for the group is changed.

# To change the border color of a group of items, do the following:

- 1. Select a group of items.
- 2. Right-click an **element** within the selected group.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Group Border Color**.
  - The UI Group Border Color window appears.
- 4. From the Border Color drop down menu, select the **color** to associate to the group.
- 5. Click OK.

The border color for the group of items is changed.

## To change the font used on the elements in the group, do the following:

- 1. Select a group of items.
- 2. Right-click an **element** within the selected group.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Group Font Change**.

The Font window appears.

- Select the Font, Font style, and Size you want to display on the elements.
   A sample of the selected style displays in the Sample field at the bottom of the Font window.
- 5. Click OK.

The position of the popup window in relation to the popup button can be changed. The border color of a group can also be changed.

# To change the position of a popup window, do the following:


- 1. Right-click a **UI element popup button**.
  - A shortcut menu appears.
- 2. From the shortcut menu, select **Open popup**.
  - A popup window appears.
- 3. From the toolbar, select the **rotate** icon. Each click on the tool rotates the window 90° counter-clockwise around the selected popup button.

  OR

Use the arrow keys or directional buttons to **move** the popup window.

# To change a text string, do the following:

- Select the **text** you want to change.
   A bounding outline appears around the text.
- Right-click on the **text**.The Font window appears.
- 3. In the Enter Text field, make the changes to the text.



4. Click **OK** to accept the changes.

The text is changed.

OR

Click Cancel.

To change the size of a button, volume control or text string, do the following:

- 1. Select an item or group of items.
- From the menu bar, select the **increase** or **decrease width** and **height** icons. 2.

OR


Press the Ctrl key while pressing the arrow keys on your keyboard.

# To change the size of a popup window, do the following:

- 1. Right-click a **UI element popup button**.
  - A shortcut menu appears.
- 2. From the shortcut menu, select **Open popup**.
  - A popup window appears.
- 3. Select the **popup button**.
- window.

OR

Press the Ctrl key while pressing the arrow keys on your keyboard to size the popup window.



For more information, refer to the table on "Toolbar".

C-Soft 7.700 File menu | en **57** 

# 10 File menu

The File menu contains commands for working with files.

### Open

Only files in the C-Soft Designer file format (\*.veg) or Telex Design Archive (.tda) can be opened by the C-Soft Designer program.

NAVIGATION: Select File | Open from the menu bar.

#### Save

C-Soft Designer saves the active design to the C-Soft Designer file format (\*.veg), or the Telex Design Archive (\*.tda) file format. If the active design has not yet been saved to a file, the Save menu opens the Save As dialog to select a destination file name and type.

NAVIGATION: Select File | Save from the menu bar.

#### Save As

The **Save As...** menu option opens the Save As dialog to select a destination file name, file type, and sets the active design to the specified file.

To save a file by a different name, do the following:

- 1. From the File menu, select **Save As...** . The Save dialog opens.
- 2. Navigate to the desired folder.
- 3. In the File Name field, enter the new file name.

# **Import SIP Contacts**

To include SIP Phone contacts in your TDA file use the **Import SIP Contacts** menu to open a file chooser to select a SIP Contacts (\*.csv or .veg) file. After selecting the file, the file is copied and named to the expected Design Data location corresponding to the current design. As a result, when saving the current Design as a Telex Design Archive, the SIP contacts file is included in the Design Archive and can be deployed to an IP-30XX device.

### **File Information**

The **File Information** menu opens the File Information window. For more information, see *File Information window*, page 58.


# 10.1 Design Errors window

The **Design Errors** window appears when a file is saved and C-Soft Designer detects potential errors in the design.

When the file is saved, the C-Soft Designer program performs a validation on the console design. The results of the validation are displayed in the Design Errors window.

 Bosch Security Systems, LLC
 Technical Manual
 2021-06 | 14 | F.01U.218.561

58 en | File menu C-Soft 7.700



When not all the results can be displayed within the window, scroll bars are provided to navigate through all of the test results.

#### **Close button**

The **Close** button is used to close the Design Errors window.

# 10.2 File Information window

The **File Information** menu is used to open the File Information window. This window displays:

- The file path for the currently open file.
- The version of C-Soft Designer used to last save the .veg file, total number of buttons, popups, and sliders used in the current design.
- The Licensing Requirements group box lists the number of lines configured for each feature and lists the minimum C-Soft License Feature that meets the specification.

C-Soft 7.700 File menu | en 59




Figure 10.1: File Information window

#### Refer to

- File Information window, page 58

# 10.3 Telex Design Archive (TDA) files

C-Soft Designer allows the export of a container file called the **TDA** (Telex Design Archive), which contains all the resource files referenced in a given design. The media contents of a design file are not stored in the design and use static addressing to display them in C-Soft Runtime. The TDA container allows creating a design on a separate device that then deploying it to an IP-30XX, which unpacks and copies the resources to the designated storage locations.




Figure 10.2: TDA Contents

60 en | Edit menu C-Soft 7.700

# 11 Edit menu

The **Edit** menu, shown in the Figure below, contains commands for the setup and revision of per line and global parameters for your VoIP network. This menu also contains commands to create and modify individual elements of the console position design.



Figure 11.1: Edit Menu

# 12 Per Line Parameters window

The **Per Line Parameters** window, shown in the Figure below, is used to configure line types, addresses, port information, and line frequencies for the VoIP network. This window allows configuration of up to 200 separate entries.

The frequency, vocoder, backup IP, and signaling parameters for all lines included in the console design must be set up on this window. If the line is not set up on this window, the line is not available as an option when setting up the user interface elements.

Additions and changes can be made to the Per Line Parameters window at any time. However, make sure all UI Elements, assigned to the line, are updated.

NAVIGATION: Select Edit | Setup Per Line Parameters from the menu bar.




Figure 12.1: Per Line Parameters window

### **Line Number Field**

The **Line Number** field displays the number of the line. This number is used for identification purposes in the design of the console position.

# Line Type Drop Down Menu

The **Line Type** drop down menu identifies the type of line being configured. When a selection is made in the line type field, the fields necessary to enter the setup information for that line type are enabled.

Available selections for this field are:

- Disabled Line is not enabled. When the line is configured, it can be disabled without losing configuration settings. Note that Line 1 cannot be disabled.
- Telex Compatible with Telex VoIP radio dispatch products, such as the C-6200, IP-223 or IP-224. Select Telex for FleetSync, Sprint Direct Connect, MDC-1200, or MOTOTRBO (refer to "Copyright notice, page 11") Professional Digital Two-Way Radio System.
- Phone Allows the console to access a telephone line from across the network. Phone configurations require the use of Telex's PIB or TDI adapter. For more information, see the IP-223 Phone Interface Box Technical Manual (F.01U.188.265) or the Telephone Dispatch Interface Technical Manual (F.01U.196.107) available for download at www.telexradiodispatch.com.

- SIP Phone Each C-Soft 7.000 License comes with two SIP lines. Additional lines can be purchased as an additional feature, and are available in 6, and 12 line increments. For more information refer to SIP (Session Initiation Protocol) configuration, and to "SIP Phone line configuration, page 111".
- P25-DFSI For more information, refer to "Setting up a P25-DFSI Line".
- NEXEDGE For more information, refer to "NEXEDGE Trunking System Setup".
- AIS For more information, refer to "DMR-AIS".
- P25-CSSI For more information, refer to "CSSI Interface".

#### Line Name Field

The Line Name field is used to enter a descriptive name for the line. This name is used for identification purposes in the console position design.

This field can contain up to 30 characters.

#### **RX Multicast Address Fields**

The **RX Multicast Address** fields identify the broadcast address for all audio traffic. This dotted quad number must be between 224.0.0.2 and 239.255.255.255. Devices can have the same or different Multicast Address for RX channels. Telex VoIP enabled equipment can use one Multicast Address for all lines with the port number defining the RX channels.

#### Note:

- Unicast addressing (point-to-point communications) is also supported. Enter a static IP address of the receiving gateway device.
- The RX Multicast Address must match the RX Multicast Address setup on the IP-223, IP-224, or a C-6200 if it is the gateway.

## **RX Port Fields**

The RX Port fields identify the RX port numbers. These numbers must be unique per channel and must be between 1054 and 65535.

The RX port number must match the port number set up on the IP-223, IP-224, or a C-6200 if it is the gateway.

# TX Multicast Address Fields

The TX Multicast Address fields identify the broadcast address for all audio traffic. This dotted quad number must be between 224.0.0.2 and 239.255.255.255. Devices can have the same or different Multicast Address for TX channels. Telex VoIP enabled equipment can use one Multicast Address for all lines with the port number defining the TX channels.

#### Note:


- Unicast addressing (point-to-point communications) is also supported. Enter a static IP address of the receiving gateway device.
- The TX Multicast Address must match the TX Multicast Address setup on the IP-223, IP-224, or a C-6200 if it is the gateway.

#### **TX Port Fields**

The TX Port fields identify the TX port numbers. These numbers must be unique per channel and must be between 1054 and 65535.

The TX port number must match the port number set up on the IP-223, IP-224, or a C-6200 if it is the gateway.

EXAMPLE: In the Figure below, the RX Port is 1054 and the TX Port is 1254 for Line 1. All consoles monitoring receive audio for channel 1 must share the same Multicast Address, as well as the same RX port number. Any console transmitting on the network must set its port number to 1254 to cause the radio to key up.



# **Base Radio IP Field**

The Base Radio IP field identifies the IP Address of the IP-223 or IP-224 used by the C-Soft program to create a TCP connection to the specified address. This address is required for the C-Soft program to create an internal ping command. It is also required for full-duplex mode (i.e., telephone mode) and to generate encoded message strings (i.e., 5/6 Tone). We recommend you include a base radio IP Address for all lines within your system design.

The base radio IP Address can be configured to periodically ping the IP gateway to determine if a network connection still exists for a particular radio. If there is no response received from the ping, the backup IP radio address is used.

A backup button is available for the console design. This button is used to force a switch, or to monitor whether the primary or backup channel is used. Additional information on this feature is provided in "Backup Line, page 232".

#### TTL Field

The TTL field identifies the number of routers the Multicast audio packets go through before being stopped. The network design dictates this value. If audio is not reaching a particular node on the network, increasing this value may correct the problem.

The range for this field is 1 to 99.

### **Packet Delay Field**

The Packet Delay field identifies the length of delay before playback, in 20ms packets. Some buffering of these packets must occur before playback to help absorb network delays, jitters, and lost packets. The typical entry for this field is 6, which translates to a delay of 120ms before playback (each packet is 20ms of audio). Larger values may be required for complicated networks, smaller values for simpler networks.

The range for this field is 4 to 64.

#### **Echo Packets Enable Check Box**

The Echo Packets Enable check box indicates the system operates on networks that do not support multicast. The C-Soft program must be running at all times to translate and transfer packets from one IP subnet to another.

A typical application has a number of radios spread throughout a network without multicast. In this case, the radio adapters (IP-223s, IP-224s or C-6200s) are programmed to send packets to the IP Address of the PC running the C-Soft program with Echo Packets enabled.

An example of an Echo Packet system, where three different radios are connected through a WAN, is shown in Appendix D - Echo Packets Diagram, page 478. In each of the subnets, a single copy of the C-Soft program is used to communicate to the radio in its subnet. A second console is used to echo the audio traffic to other copies of the C-Soft program. The C-Soft program also echoes all traffic to a Multicast Address within its subnet so additional consoles can be added to the system by specifying the Multicast Address.

## **Options Button**

The Options button opens the Line Options Setup window, shown in the Figure below, for the selected line.

# Fregs Button

The Freqs button opens the Frequency Parameters window for the selected line. For more information, refer to "Frequency Parameters window, page 67".

## Signal Setup Button

The **Signal Setup** button opens the Signaling Parameters window. For more information, refer to "Signaling Parameters window, page 72".

# **SIP Button**

The **SIP** button opens the Configuration SIP Settings window. For more information, refer to "Configure SIP Settings window, page 108".

#### 12.1 **Line Options Setup window**

The Line Options Setup window is used to configure the monitoring capabilities, digital format in the line setup options and the backup IP to use if network resources of the primary radio interface identified for the line fail.




Figure 12.2: Line Options Setup window



#### Notice!

Vocoder configurations must be the same across devices.

# To open the Line Options Setup window, do the following:

- 1. Select Edit | Per Line Parameter. The Per Line Setup window appears.
- 2. Click Options.

The Line Options window appears.

# **Line Setup Options group box**

# Vocoder Type drop down menu

The Vocoder Type drop down menu indicates the bit rate at which audio is converted into digital format. This feature is used to configure communication between C-Soft and an IP-223 or IP-224.

Available selections for this field are:

TELEX 32K, G.726 16K, G726 32K (IP224 Only), and G.711 64K (IP224 Only).

The G.726 32K (IP224 Only) and G.711 64K (IP224 Only) vocoders are only supported on C-Soft version 6.000 or higher, Network Recorder version 4.500 or higher, and the IP-224.




Figure 12.3: Vocoder Type drop down menu - Line Options Setup



### Notice!

The TELEX 32K is the same as the previous ADPCM 32K, and the G.726 16K is the same as the previous ADPCM 16K.

#### TX Monitor Enable check box

The **TX Monitor Enable** check box indicates the console operator can monitor TX traffic from other console operators.

#### Scannable check box

The **Scannable** check box indicates the console operator is allowed to control the scan list of a particular radio. The frequency button is used in C-Soft Runtime to add or delete radio channels from the scan list.



# Notice!

This feature is not supported on all radios, only Kenwood TK-x80, TK-x150/180, TX-5x10, and NEXEDGE support.

## Packet Delay for Satellite Mode check box

The **Packet Delay for Satellite Mode** check box enables Satellite Mode which means if there is an issue with play out audio within the correct timing (burst of packets instead of consistent 20ms packets) no packets are dropped, but there is an audio delay based on how inconsistently the packets are received.

If not selected, Normal mode is enabled meaning if there is an issue with playing audio within the correct timing, packets are dropped so the audio delay is no longer than the Packet Delay plus 80ms.

# Backup IP Setup group box

# **RX Multicast Address and Port fields**

The **RX Multicast Address and Port** fields identify the receive Multicast Address and port to use if the primary receive path fails.

#### TX Multicast Address and Port fields

The **TX Multicast Address and Port** fields identify the transmit Multicast Address and port to use if the primary transmit path fails.

#### **Base Radio IP field**

The **Base Radio IP** field identifies the backup IP Address of the base radio, should the primary address fail.

#### **Buttons**

The **OK** button saves the entries and closes the window.

The Cancel button discards any changes made and closes the window.

# 12.2 Frequency Parameters window

The **Frequency Parameters** window, shown in the Figure below, is used to enter the parameters for the individual function tones available for the selected line.

Additions and changes can be made to the Frequency Parameters window at any time. However, if any user interface elements have been placed on the console window, the changes made to a line must also be changed on the individual elements, if needed.




Figure 12.4: Frequency Parameters window

## **Enable Check Box**

The **Enable** check box indicates the corresponding frequency numbers are available to the console operator for selection on the line.

# **Frequency Name Field**

The **Frequency Name** field is used to enter a descriptive name for the frequency. This name is used to identify the frequency for the elements used in the design of the console position and is made available for selection in a list of variables.

When a frequency name is changed, a Frequency Change button's text does not automatically update. This is done separately.

This field can contain up to 20 characters.

#### **OK Button**

The **OK** button saves the entries and closes the window.

#### **Load File Button**

The **Load File** button is used to load a .csv file into the current frequency window.



#### Notice!

When the .csv file is loaded, all items in the current list are overwritten.

# To load a saved frequency .csv file, do the following:

1. Click Load File.

The Open window appears.

- 2. In the Open window, select the file you want to load.
- 3. Click Open.

The file is loaded, the Frequency Name field is populated and the Enable check box is selected.

### Save File Button

The **Save File** button is used to save the current frequency names to a .csv file.

### To save the currently enabled frequency names to a .csv file, do the following:

1. Click Save File.

The Save As window appears.

- 2. In the Filename field, enter a **name**.
- 3. Click Save.

The .csv file is saved in the current folder.

# Pair Mode Setup Check Boxes

The **Pair Mode Setup** check boxes allow function tones to have control functions not used for actual control of the radio. There are four wildcard groups available per line. Function tones 1 and 2 are not allowed in a wildcard group and a function tone may not be selected in more than one group. One function tone from each group can be active at a time, plus either F1 or F2.

#### **RX Block Lines Display Box**

The **RX Block Lines** display box contains a list of all the lines in the system. Each line selected in the list has its received audio blocked from the speaker when the line you are currently configuring is selected. This allows the console operator to transmit on a radio that has overlapping coverage with other radios without getting feedback from the radios receiving the transmitted signal. This function also operates when a parallel console is transmitting on the line.

# To mute a line during transmission, do the following:

- Select the line(s) in the display box.
   The line is highlighted.
- 2. Click the **line**(s) a second time to clear the selection.

The line is no longer highlighted.



#### Notice!

Individual lines must have Mute Per-Line buttons associated with them for this feature to

#### 12.3 Frequency Parameters windows - MOTOTRBO

# **Channel Setup Page**

When the Freq button for a Telex line configured for a system type of MOTOTRBO line is clicked, the Frequency Parameters window opens to the Channel Setup page. The Channel **Setup** page, shown in the Figure below, is used to enter the MOTOTRBO line's channel, zone, channel name, pair mode setup and RX block.



### Notice!

The General Signal Setup window must be configured for MOTOTRBO system type before MOTOTRBO parameters are available on this page. Refer to "Signaling Parameters Window".




Figure 12.5: Frequency Parameters - Channel Setup Page

# **Enable check box**

The **Enable** check box indicates the corresponding frequency numbers are available to the console operator for selection on the line.

#### Zone field

The **Zone** field is used to enter a MOTOTRBO zone number. The same zone number must also be configured in the radio.

#### Chan field

The **Chan** (Channel) field is used to enter a MOTOTRBO channel number. The same channel number must also be configured in the radio.

#### **Channel Name field**

The **Channel Name** field is used to enter a user-recognizable name for the frequency. This name identifies the frequency for elements used in the console design and is available for selection in C-Soft Runtime.

This field can contain up to 20 characters.



#### Notice!

If the Channel Name field is changed, the Channel Name button's text does not automatically update. This is done separately.

### All Call Check box

The **All Call** check box indicates the All Call function is enabled in C-Soft for the associated channel. The MOTOTRBO radio must be configured for All Call.

## **Zone Setup Page**

When the **Zone Setup** tab is clicked from the Frequency Parameters window, the Zone Setup page appears. The Zone Setup page, shown in the Figure below, is used to set up zone names. The Zone Setup window supports up to 250 different zone names.




Figure 12.6: Frequency Parameters window - Zone Setup Page

#### **Zone Name field**

The **Zone Name** field is used to enter a user-recognizable name for the zone. The name should match the zone name configured in the radio.

This field can contain up to 20 characters.



#### Notice!

A Zone is a place channels are stored in a radio.

#### **Channel Pool Zone field**

The **Channel Pool Zone** field indicates the zone number used for a channel pool.

REFERENCE: If there is a fixed zone for channel pool programmed in the MOTOTRBO radio, the zone must be entered in this field. For more information, refer to Motorola's technical documentation.

## **OK** button

The **OK** button saves the entries and closes the window.

#### **Load File button**

The Load File button is used to load a .csv file into the current frequency window.



### Notice!

When the .csv file is loaded, all items in the current list are overwritten.

# To download a saved frequency .csv file, do the following:

1. Click Load File.

The Open window appears.

- 2. In the Open window, select the desired file.
- Click Open.

The file is loaded, the Frequency Name field is populated and the Enable check box is selected.

# Save File button

The Save File button is used to save the current frequency names to a .csv file.

# To save the currently enabled frequency names to a .csv file, do the following:

1. Click Save File.

The Save As window appears.

- 2. In the Filename field, enter a name.
- 3. Click Save.

The .csv file is saved in the current folder.

#### Pair Mode Setup check boxes

The Pair Mode Setup check boxes allow function tones to have control functions not used for actual control of the radio. There are four wildcard groups available per line. Function tones 1 and 2 are not allowed in a wildcard group and a function tone may not be selected in more than one group. One function tone from each group can be active at a time, plus either F1 or F2.

# **RX Block Lines display box**

The RX Block Lines display box contains a list of all the lines in the system. Each line selected in the list has its received audio blocked from the speaker when the line you are currently configuring is selected. This allows the console operator to transmit on a radio that has overlapping coverage with other radios without getting feedback from the radios receiving the transmitted signal. This function also operates when a parallel console is transmitting on the line.

# To mute a line during transmission, do the following:

- Select the **line**(s) in the display box. The line is highlighted.
- Click the **line**(s) a second time to clear the selection.

The line is no longer highlighted.




#### Notice!

Individual lines must have Mute Per-Line buttons associated with them for this feature to work.

#### 12.4 Signaling Parameters window

When Telex is selected in the Line Type drop down menu, and the Signal Setup button on the Per Line Parameters window is clicked, the General Signal Setup page, shown in the Figure below, appears.



#### **System Settings Group Box**

#### System Type drop down menu

The **System Type** drop down menu is used to configure the signaling type for the individual line.

Available selections for Telex Line Type are:

- Generic For more information, refer to "Generic system type, page 75".
- 5/6 Tone/DTMF ANI For more information, refer to "5-6 Tone/DTMF ANI system type, page 75".
- FleetSync For more information, refer to "FleetSync system type, page 83".
- iDEN For more information, refer to "iDEN System Type".
- Telex-Serial For more information, refer to "Telex-Serial system type, page 86".
- MDC-1200 For more information, refer to "MDC-1200 system type, page 88".
- MOTOTRBO For more information, refer to "MOTOTRBO system type, page 92".
- Sprint Direct Connect For more information, refer to "Sprint Direct Connect system type, page 96".
- Telex-Enhanced-ANI For more information, refer to "Telex-Enhanced-ANI system type, page 98".

Available selections for Phone Line Type are:

- Generic For more information, refer to "Generic system type, page 75".
- Phone For more information, refer to "Phone system type, page 100".

Available selections for P25-DFSI Line Type are:

P25-DFSI - For more information, refer to Appendix E, "Setting up a P25-DFSI Line".

Available selections for NEXEDGE Line Type are:

NEXEDGE - For more information, refer to Appendix F, "NEXEDGE Trunking System Setup".

Available selections for P25-CSSI Line Type are:

P25-CSSI For more information, refer to Appendix G, "CSSI Interface".



#### Notice!

The Signaling Setup button is disabled for lines types of Disabled and SIP.

# System Name drop down menu

The System Name drop down menu is used to select a system for the selected line. If the System Type field is set to FleetSync, MDC-1200, MOTOTRBO or Telex-Serial, this field becomes active.



#### Notice!

Systems are configured by the user. Refer to "Edit System List Window".

### **Edit System button**

The **Edit System** button is used to open the Edit System window. From this window, you can modify the systems included in the Per Line Parameter configuration. For more information, refer to "Edit System List Window".

## Signaling Autofill Setup group box

## **Enable Signaling Autofill check box**

The Enable Signaling Autofill check box indicates the signaling parameters configured on the current line are copied and then pasted into the corresponding line numbers.

# Starting Line Number field

The Starting Line Number field is used to indicate the first line to which signaling parameters are copied.



#### Notice!

The Enable Signaling Autofill check box must be selected to enable autofill.

#### **Ending Line Number field**

The Ending Line Number field is used to indicate the last line to which signaling parameters are copied.



#### Notice!

The Enable Signaling Autofill check box must be selected to enable autofill.

## **Call Logging group box**

## Display All Calls check box

The **Display All Calls** check box allows you to choose to display all calls in the Per-Line Call History window, regardless of the call's destination ID. If cleared, only calls sent to the console or a group containing the console's ID are displayed in the Per-Line Call History Window.



#### Notice!

The Display All Calls check box is only enabled when the following System Types are selected: Generic, 5/6 Tone/DTMF ANI, FleetSync, and MDC-1200. For other system types, the Display All Calls check box is not applicable.

#### **OK** button

The **OK** button saves the entries and closes the window.

#### **Cancel button**

The **Cancel** button discards any settings made and closes the window.

# 12.5 Signal system types

# 12.5.1 Generic system type

The **Generic** system type option is used to configure the line for a system type other than those listed.

To configure the line for a Generic system, do the following:

- 1. Select Edit | Per Line Parameters from the menu bar.
  - The Per Line Parameters window appears.
- 2. From the Line Type drop down menu, select **Telex**.
- 3. Click Signal Setup.
  - The Signaling Parameters window appears.
- 4. From the System Type drop down menu, select **Generic**.
- 5. Select **Display All Calls**, to display all calls in the Per-Line Call History window.

# 12.5.2 5-6 Tone/DTMF ANI system type

The **5/6 Tone/DTMF ANI** (Automatic Number Identification) system type option is used to set the line type signal to 5/6 tone or DTMF signaling.



#### Notice

The IP-224 does not support 5/6 Tone or DTMF encoding or decoding functions.

## To configure the line for a 5/6 DTMF ANI type, do the following:

- Select Edit | Per Line Parameters from the menu bar. The Per Line Parameters window appears.
- 2. From the Line Type drop down menu, select **Telex**.
- Click Signal Setup. The Signaling Parameters window appears.
- From the System Type drop down menu, select 5-6 Tone/DTMF ANI.

The 5/6 Tone DTMF ANI Setup tab and Call Setup tab appear.

## 5/6 Tone DTMF ANI Setup page

When 5/6 Tone DTMF ANI is selected from the System Type drop down menu, the 5/6 Tone/ DTMF ANI Setup page appears, as shown in the Figure below.




Figure 12.7: 5/6 Tone/DTMF ANI Setup Page - Signaling Parameters

### Per Line Console ID group box

# **Unit ID field**

The Unit ID field is used to assign a numeric identifier to the console's line. The unit ID appears when a radio is called from the specified console line.

This field can contain up to 8 digits.

## Signaling Setup group box

## Signaling Type drop down menu

The Signaling Type drop down menu identifies the signaling type used when generating a call.

Available selections for this field are:

- CCIR1
- CCIR2
- **DTMF**
- **DZVEI**
- **EEA**
- EIA
- **EURO**
- **KENWOOD 5-TONE**
- MODAT
- **NATEL**
- **PCCIR**
- **PDZVEI**
- **PZVEI**
- ZVEI1
- ZVEI2

### **Digit Duration field**

The Digit Duration field represents the length of time, in ms, the digit tone plays when it is active.

The range for this field is 25 to 9999ms.

## **Interdigit Duration field**

The Interdigit Duration field represents the length of time, in ms, between the digit tones within a group.

The range for this field is 25 to 9999ms.

#### Pause Duration field

The Pause Duration field represents the length of time, in ms, allowed between transmitted groups.

The range for this field is 25 to 9999ms.



# Notice!

The pause duration must be at least the sum of the Digit and Interdigit Duration fields.

# **Preamble Duration field**

The Preamble Duration field represents the length of time, in ms, the first tone digit plays. With some radio systems, the first tone needs to be longer than subsequent tones. For example, the first tone may be used to activate a dormant (battery saving) state.

The range for this field is 25 to 9999ms.



#### Notice!

The preamble duration must be at least the amount of the Digit Duration field.

#### Level field

The **Level** field represents the relative level, in dB, the encoded message sends.

The range for this field is -20dB to +12dB.

#### Twist Level field

The **Twist Level** field represents the relative level difference, in dB, of high and low tones generated when using DTMF tone types. This field is only active when DTMF is the selected tone type.

The range for this field is -10dB to +10dB.

## **Group Digit field**

The **Group Digit** field represents the group identification defined by the radio system. Typically this digit is not used anywhere else in the system.

This range for this field is 0-9 or A-D, # and \*.

# **Repeat Digit field**

The **Repeat Digit** field identifies a repeat digit. Repeat digits are used to signal a digit has been repeated. Repeat digits are used to maintain tone transitions at appropriate intervals, which simplifies the decode function.

EXAMPLE: The repeat digit is E and the subscriber ID is 23335. The encoder string would actually send a tone string of 23E35.

### **Defaults button**

The **Defaults** button resets all the signal parameters back to the default values.

## Auto Ack Setup group box

#### Auto Ack Type drop down menu

The **Auto Ack Type** drop down menu allows you to choose the signaling type desired to acknowledge receipt of a call.

Available selections for this field are:

- Disabled Indicates no acknowledgement is sent after receiving a call.
- Single-Tone Indicates a single tone is sent after receiving a call.
- Signaling Indicates the Auto Ack field is available for formatting.

For more information, refer to "Auto Ack Field" in "Auto Ack Field".

#### **Auto Ack Delay field**

The **Auto Ack Delay** field allows you to configure the lead-in delay, in ms, for receiving messages configured to transmit acknowledgements back to the calling radio.

The range for this field is 0 to 9999ms.

## Single Tone Auto Ack Setup group box

## Frequency field

The **Frequency** field represents the frequency, in Hz, generated during a single tone acknowledgement.

The range for this field is 0 to 4000Hz.

#### **Duration field**

The **Duration** field represents the duration, in ms, of the single tone acknowledgement.

The range for this field is 25 to 9999ms.

#### Level field

The **Level** field represents the relative level, in dB, the encoded message sends. The range for this field is -20dB to +12dB.

## Signaling Delays group box

## **Initial Delay field**

The Initial Delay field represents the lead-in delay, in ms, for console-generated messages transmitted to the field radios.

The range for this field is 0 to 9999ms.

#### **End Delay field**

The End Delay field identifies the delay, in ms, at the end of transmitted messages to the field. It delimits the tone string.

The range for this field is 0 to 9999ms.



# Notice!

A value is required for this field. Do not leave blank.

# Call Setup page

When 5/6 Tone/DTMF Tone ANI is selected from the System Type drop down menu the Call Setup page appears, shown in the Figure below.




Figure 12.8: Call Setup Page - Signaling Parameters

## **Call Setup group box**

## **Auto Ack field**

The **Auto Ack** field represents an automatically generated acknowledgement message that is sent to the field after receiving a select call. First, configure the "Auto Ack Type drop down menu", then configure this field using the proper format.

This field can contain up to 32 characters.

Field values can be: Low or High.

- DTMF Format Allows for 0-9, \*, #, A-D, G, I, K, P, R, and S.
- 5-Tone Format Allows for 0-9, A-F, G, I, K, P, R, and S.

For more information, refer to the table "Call setup group format descriptions" below.

# **Emerg Resolved field**

The **Emerg Resolved** (Emergency Resolved) field represents the message sent each time an emergency is acknowledged (for example, when the Emergency Ack button is pressed in the Active Emergency window).

This field can contain up to 32 characters.



# Notice!

A message is sent only if the emergency is active.

Field values can be: Low or High.

- DTMF Format Allows for 0-9, \*, #, A-D, G, I, K, P, R, and S.
- 5-Tone Format Allows for 0-9, A-F, G, I, K, P, R, and S.

For more information, refer to the table "Call setup group format descriptions" below.

#### PTT BOT field

The PTT BOT (Push-To-Talk Beginning Of Transmit) field represents the message sent each time the PTT button is pressed on the console at the beginning of transmit.

This field can contain up to 32 characters.

Field values can be: Low or High.

- DTMF Format Allows for 0-9, \*, #, A-D, G, I, K, P, R, and S.
- 5-Tone Format Allows for 0-9, A-F, G, I, K, P, R, and S.

For more information, refer to the table "Call setup group format descriptions" below.

#### PTT EOT field

The PTT EOT (Push-To-Talk End Of Transmit) field represents the message sent each time the PTT button is pressed on the console at the end of transmit.

This field can contain up to 32 characters.

Field values can be: Low or High.

- DTMF Format Allows for 0-9, \*, #, A-D, G, I, K, P, R, and S.
- 5-Tone Format Allows for 0-9, A-F, G, I, K, P, R, and S.

For more information, refer to the table "Call setup group format descriptions" below.

# Call (1-10) Format field

The Call (1-10) Format fields represent the message sent when selected by the console operator on the Per Line Call History, Call List Window, or the Manual Call List window. Refer to the Figure below.

This field can contain up to 32 characters.

Field values can be: Low or High.

- DTMF Format Allows for 0-9, \*, #, A-D, G, I, K, P, R, and S.
- 5-Tone Format Allows for 0-9, A-F, G, I, K, P, R, and S.

For more information, refer to the table "Call setup group format descriptions" below.

#### Call (1-10) Label field

The Call (1-10) Label fields represent the label applied to the button on the Per Line Call History, the Manual Call Window, and the Call List Window popup button, shown in the Figure below.

This field can contain up to 31 alphanumeric characters.

# **Defaults button**

The **Defaults** button resets the fields to their default values.

Value	Description		
I	Stands for Console ID. Use the "Unit ID Field" on page 75 or "User ID Field" on page 83 to configure the Console ID. This value must match the number of digits in the Console ID.  For example, the Console ID is 123, the value entered in the format field would be III.		
G	Stands for Group. This is used to make a Group Call. The Group ID is configured on the "Edit System List Window - System Menu" on page 180 to configure Group IDs. This value must match the number of digits in the Group ID. For example, the Group ID is 5000A, the value entered in the format field would be GGGGG.  NOTE: Not applicable for iDEN setup.		
S	Stands for Status. Use the "Status Message ID List Window" on page 172 to configure Status IDs.		
Р	Stands for Pause. When you want to format a pause into the string being sent out, use a P. Pause Duration is set up in Signaling Setup.		
R	Stands for Radio ID. You must enter the exact number of digits in the radio ID. For example, if you pick User ID 12356, you must enter RRRRR.		
K	Takes all the digits in the User ID of the type of call being made. In this format, you can enter a K, which enters all numbers associated with the User ID column.		
NOTE: You can use any combination of these values with the numerical digits to create formats.			

Tab. 12.2: Call setup group format descriptions




Figure 12.9: Per Line Call History Window for 5/6 Tone or iDEN Line

#### 12.5.3 FleetSync system type

The **FleetSync** system type option is used to configure the line used to encode/decode FleetSync IDs and status codes.




Figure 12.10: FleetSync System Type

To set the system type to FleetSync, do the following:

- 1. Select Edit | Per Line Parameters from the menu bar.
  - The Per Line Parameters window appears.
- 2. From the Line Type drop down menu, select **Telex**.
- Click Signal Setup.
  - The Signaling Parameters window appears.
- 4. From the System Type drop down menu, select **FleetSync**. The FleetSync Setup tab appears.
- 5. From the System Name drop down menu, select a **system** for the line.

# FleetSync Setup page

When FleetSync is selected from the System Type drop down menu, the **FleetSync Setup** page appears, shown in the Figure below.




Figure 12.11: FleetSync Setup Page—Signaling Parameters

#### Per Line Console ID group box

The Per Line Console ID group box is used to define the Fleet ID and User ID. The Fleet ID is added to the front of the User ID to create the Per Line Console ID. This ID appears on radio when receiving data/audio from that console line.

EXAMPLE: To create console ID 1234567, enter 123 as the Fleet ID and 4567 as the User ID. Whenever the operator presses the PTT button or send a FleetSync data message, the receiving radios display the console ID configured for the line.

#### Fleet ID field

The Fleet ID field is used to enter the 3-digit Fleet ID number of a group of FleetSync radios and is assigned per line.

The range for this field is 100 to 349.

#### **Unit ID field**

The User ID field is used to identify the console's 4-digit User ID to FleetSync radios programmed for Over-The-Air-Protocol.

The range for this field is 1000 to 4999.

# Note:

- The IP-223 or IP-224 must be configured for FleetSync Encode.
- The Console ID does not appear if the mobile radio connected to the IP-224 is configured for FleetSync Signaling.

#### **Call Permission Setup group box**

#### Allow Broadcast Calls on this Line check box

The **Allow Broadcast Calls on this Line** check box is used to grant the line permission to place FleetSync broadcast calls.

#### Allow InterFleet Calls on this Line check box

The **Allow InterFleet Calls on this Line** check box is used to grant the line permission to place calls to fleets or units outside the console's fleet.

#### **User Display Options group box**

#### Only Display Filters check box

The **Only Display Filters** check box indicates, in addition to the system name, that only filters containing fleets and units display in the C-Soft Runtime FleetSync Dispatching window's system list, refer to the Figure below. All components in the system are visible including groups and individuals, otherwise only filters and their components are visible.



#### Notice!

The Only Display Filters check box controls the system list appearance only. Component permissions are controlled per line, refer to "FleetSync system type, page 83".




Figure 12.12: FleetSync System List Filters Display in C-Soft Runtime

# 12.5.4 Telex-Serial system type

The **Telex-Serial** system type option is used to configure the line for serial radio control. The System Type is used for a variety of radio brands. Consult the IP-224 user manual for a full list of radios utilizing the Telex-Serial Type option.




Figure 12.13: Telex-Serial System Type

## To set the system type to Telex-Serial, do the following:

- Select Edit | Per Line Parameters from the menu bar.
  - The Per Line Parameters window appears.
- 2. From the Line Type drop down menu, select **Telex**.
- 3. Click Signal Setup.
  - The Signaling Parameters window appears.
- 4. From the System Type drop down menu, select **Telex-Serial**.
  - The Telex-Serial Setup tab appears.
- From the System Name drop down menu, select a **system** for the line. 5.
- Click the Telex-Serial Setup Tab.
  - The Telex-Serial Setup page appears.
- 7. In the Console ID field, enter the console ID.

# **Telex-Serial Setup page**

The Telex-Serial Setup page, shown in the Figure below, is used to define the Per Line Console ID.




Figure 12.14: Telex-Serial Setup Page

## Per Line Console ID group box

The **Per Line Console ID** group box is used to define the Console ID. This ID appears on the radio when receiving data/audio from that console line.

#### Console ID field

The **Console ID** field is used to enter the console ID for the Telex-Serial Line.

# 12.5.5 MDC-1200 system type

The MDC-1200 system type option is used to configure the line for MDC-1200 use.




Figure 12.15: MDC-1200 System Type

To configure the line for a MDC-1200 type, do the following

- 1. Select Edit | Per Line Parameters from the menu bar.
  - The Per Line Parameters window appears.
- 2. From the Line Type drop down menu, select **Telex**.
- 3. Click Signal Setup.
  - The Signaling Parameters window appears.
- 4. Select **MDC-1200** from the System Type drop down menu.
- The MDC-1200 Setup tab appears.
- 5. From the System Name drop down menu, select a **system** for the line.

# MDC-1200 Setup page

When MDC-1200 is selected from the System Type drop down menu, the MDC-1200 Setup page appears, shown in the Figure below.




Figure 12.16: MDC-1200 Page - Signaling Parameters

# Per Line Console ID group box

# Group ID: (In Hex) field

The **Group ID: (In Hex)** field is used to identify the group ID for the console.

This field requires a 3-digit hexadecimal number (0-EEE).



### Notice!

Do not use the letter F in this field. It is reserved as a wild card digit used to create MDC-1200 custom call groups.

## Unit ID (In Hex) field

The Unit ID (In Hex) field is used to identify the MDC-1200 unit for the line.

This field requires a 4-digit hexadecimal number (1-DEEE).

Call type	ID range
Unit call	0001-DEEE
Group call	E000-EEEE
System call	FFFF

Tab. 12.3: MDC-1200 unit ID ranges

#### Note:

- Apply the ID numbers as given in the Table above.
- The letter F is reserved as a wild card digit used to create MDC-1200 custom call groups.
- A call sent to an ID containing the letter F is received by all units that match all the non-F characters.

EXAMPLE: A call sent to D1FF is received by all units with an ID between D100 and D1EE.

# **PTT ID Options**

#### PTT ID Options drop down menu

The **PTT ID Options** drop down menu is used to indicate when an ID is sent while transmitting.

Available selections for this field are:

- None No PTT ID is sent when transmitting from the console.
- Pre Only The console's PTT ID is sent before the voice stream begins.
- Post Only The console's PTT ID is sent after the voice stream ends.
- Pre and Post The console's PTT ID is sent both before and after the voice stream begins and ends.




Figure 12.17: PTT ID Options Drop Down Menu

#### **Call Permission Setup group box**

#### Allow Broadcast Calls on the Line check box

The Allow Broadcast Calls on the Line check box indicates the console operator is allowed to place call alerts, and place select calls to the entire system.

The system user ID is FFFF.

# **User Display Options group box**

# Only Display Filters check box

The Only Display Filters check box indicates, in addition to the system name, only groups and units contained in the filter display in the system list in C-Soft Runtime's MDC-1200 Dispatch window, shown in Figure 329. When selected, only filters and their components are visible. Otherwise, all components in the system appear in the system list.



## Notice!

The Only Display Filters check box controls the system list appearance. Component permissions are controlled per line. For more information, refer to "Call Permission Setup Group Box".




Figure 12.18: MDC-1200 System List Filters Display in C-Soft Runtime

#### 12.5.6 **MOTOTRBO** system type

The MOTOTRBO system type option is used to configure the line for MOTOTRBO use.



## Notice!

There is a 10 console limit to each SOIP line.




Figure 12.19: MOTOTRBO System Type

## To configure the line for MOTOTRBO type, do the following:

- 1. Select Edit | Per Line Parameters from the menu bar.
  - The Per Line Parameters window appears.
- 2. From the Line Type drop down menu, select **Telex**.
- 3. Click Signal Setup.
  - The Signaling Parameters window appears.
- 4. From the System Type drop down menu, select **MOTOTRBO**. The MOTOTRBO Setup tab appears.
- 5. From the System Name drop down menu, select a **system** for the line.

## **MOTOTRBO Setup page**

When MOTOTRBO is selected from the System Type drop down menu, the **MOTOTRBO Setup** page appears, shown in the Figure below.




Figure 12.20: MOTOTRBO Setup Page

# **Interface Type group box**

#### MTRBi radio button

The **MTRBi** radio button is used to select signaling using the MTRBi interface option to IP-224 or IP-223.

## **MOTOTRBO** radio button

The **MOTOTRBO** radio button is used to select signaling using the MOTOTRBO interface option to IP-224.

# **SOIP Setup group box**

The **SOIP Setup** group box is used to set up communication between the IP-223 or IP-224 and C-Soft to send and receive serial data. The fields in this section must match the same fields for the specified line on the IP-223 or IP-224.

For more information, refer to the MTRBi Installation Manual (F.01U.247.183). For MOTOTRBO support, refer to the MOTOTRBO Application Guide (F.01U.298.170).

#### **RX Multicast Address field**

The RX Multicast Address field indicates the Multicast Address used to receive serial data over the network. This is the same Serial Over IP RX Multicast Address set up in the IP-223's or IP-224's Multicast Address Setup window for the associated MOTOTRBO line.

#### **RX Port field**

The **RX Port** field indicates the RX port number used to receive serial data. This is the same Serial Over IP RX port number set up on the IP-223 or IP-224 for the associated MOTOTRBO line.

#### TX Multicast Address field

The TX Multicast Address field indicates the Multicast Address used to send serial data. This is the same Serial Over IP TX Multicast Address set up in the IP-223's or IP-224's Multicast Address Setup window for the associated MOTOTRBO line.

#### **TX Port field**

The TX Port field indicates the TX port number used to send serial data. This is the same Serial Over IP TX port number set up on the IP- 223 or IP-224 for the associated MOTOTRBO line.

# **Control Line Setup group box**

The **Control Line Setup** group box section is used to set up multiple C-Soft consoles to communicate with the same MOTOTRBO radio.

#### **Multicast Address field**

The Multicast Address field indicates the Multicast Address used by the console to communicate with MOTOTRBO radio. The Multicast Address is configured for the line in the Per Line Parameters window.

This field is not editable.

# **Control Port feld**

The Control Port field indicates the port used to communicate with the MOTOTRBO radio.

The default value for this field is 1000 more than the TX Port value configured for the line on the Per Line Parameters window.

#### To change the TX Port value, do the following:

- 1. Clear the **Default** check box. The Control Port field becomes editable.
- 2. In the Control Port field, enter a port number.

#### **Default check box**

The **Default** check box is used to accept the control port's default value. The default value is calculated by adding 1000 to the TX Port number for the line. When the check box is selected, this value is automatically entered in the field. Clear the check box to enter a different value.

## **Network Setup group box**

The **Network Setup** group box section is used to set up the MOTOTRBO radio to send text messages and allow GPS (Global Positioning System) to work in C-Soft.



#### Notice!

The CAI (Common Air Interface) Network and CAI Group Network fields in C-Soft Designer must match the CAI network and CAI Network Group configured in the MOTOTRBO CPS software.

For more information, refer to the Motorola's technical documentation.

#### CAI Network field

The CAI Network field is used to enter the value for the CAI network configured on the radio.

The range for this field is 1 to 126.

#### **CAI Group Network field**

The **CAI Group Network** field is used to enter the value for the CAI Group Network configured on the radio.

The range for this field is 225 to 239.

# 12.5.7 Sprint Direct Connect system type

# **Sprint Direct Connect Setup page**

When Sprint Direct Connect is selected from the System Type drop down menu, the **Sprint Direct Connect Setup** page appears.

To configure the line for Sprint Direct Connect type, do the following:

- 1. Select Edit | Per Line Parameters from the menu bar.
  - The Per Line Parameters window appears.
- 2. From the Line Type drop down menu, select **Telex**.
- 3. Click Signal Setup.
  - The Signaling Parameters window appears.
- 4. From the System Type drop down menu, select **Sprint Direct Connect**.

The Sprint Direct Connect Setup tab appears.




Figure 12.21: Signaling Parameters - Sprint Direct Connect Setup

#### **SOIP Setup group box**

#### **RX Multicast Address field**

The RX Multicast Address field indicates the Multicast Address used to receive serial data over the network. This is the same Serial Over IP RX Multicast Address set up in the IP-223's or IP-224's Multicast Address Setup window for the associated Sprint Direct Connect line.

#### **RX Port field**

The **RX Port** field indicates the RX port number used to receive serial data. This is the same Serial Over IP RX port number set up on the IP-223 or IP-224 for the associated Sprint Direct Connect line.

#### **TX Multicast Address field**

The TX Multicast Address field indicates the Multicast Address used to send serial data. This is the same Serial Over IP TX Multicast Address set up in the IP-223's or IP-224's Multicast Address Setup window for the associated Sprint Direct Connect line.

#### TX Port field

The TX Port field indicates the TX port number used to send serial data. This is the same Serial Over IP TX port number set up on the IP-223 or IP-224 for the associated Sprint Direct Connect line.

# **Emergency Setup group box**

#### **Enable Emergency on Call Alert check box**

The Enable Emergency on Call Alert check box enables C-Soft to treat incoming SDC call alerts containing the message index specified in the Call Alert Message Index field as an Emergency. C-Soft plays emergency alert tones, performs the Emergency button flash actions on the receiving line's Select button, and creates an entry in the Active Emergency window.

# Call Alert Message Index drop down menu

The **Call Alert Message Index** drop down menu is used to select the Call Alert message triggered by an Emergency in C-Soft. The Sprint Direct Connect handsets contain 21 preset Call Alert messages.

Index	Message	Index	Message
0	<no message=""></no>	11	I'll be there shortly
1	Can't talk right now	12	I love you
2	Will call you back	13	Meeting still on?
3	I'm in a meeting	14	Are you free?
4	Call me	15	Please stop by
5	Direct Connect me	16	Can I call you?
6	Yes	17	In the office?
7	No	18	On my way
8	Where are you?	19	Need help
9	Let's get lunch	20	Where you at?
10	The meeting has been cancelled		

# 12.5.8 Telex-Enhanced-ANI system type

The **Telex-Enhanced-ANI** system type option is used to configure the line for serial radio control. Consult the IP-224 user manual for full list of radios utilizing the Telex-Enhanced-ANI Type option.

#### Signaling Parameters: Sonim




Figure 12.22: Telex-Enhanced-ANI System Type

## To set the system type to Telex-Enhanced-ANI, do the following:

- 1. Select **Edit | Per Line Parameters** from the menu bar.
  - The Per Line Parameters window appears.
- 2. From the Line Type drop down menu, select **Telex**.
- 3. Click Signal Setup.
  - The Signaling Parameters window appears.
- 4. From the System Type drop down menu, select **Telex-Enhanced-ANI**. The Telex-Enhanced-ANI Setup tab appears.
- 5. From the System Name drop down menu, select a **system** for the line.
- Click the Telex-Enhanced-ANI Setup Tab.
   The Telex-Enhanced-ANI Setup page appears.
- 7. Select the **Enable Callback check box**, if applicable.

# **Telex-Enhanced-ANI Setup page**

The **Telex-Enhanced-ANI Setup** page is shown in the Figure below.

# Signaling Parameters: Sonim




Figure 12.23: Telex-Enhanced-ANI Setup Page

# Per Line Settings group box

The **Callback** feature allows Line PTT and Main PTT buttons to send group/private call commands depending on the last call made. This is needed on protocols that need to differentiate between the two call types.

#### **Enable Callback check box**

The **Enable Callback** check box is used to enables or disables the Callback feature.

# 12.5.9 Phone system type

The **Phone** system type option is used to configure the line for standard phone use, as shown in the Figure below.

Available selections for this field are:

- Generic If Generic is selected no additional signaling is being used. For more information, refer to "Generic system type, page 75".
- Phone Phone enables the ability to send additional DTMF signaling to IP-223. For more information, refer to "Phone Setup Page" below.




Figure 12.24: Phone System Type

# To configure the line for a Phone type, do the following:

- Select Edit | Per Line Parameters from the menu bar.
   The Per Line Parameters window appears.
- 2. From the Line Type drop down menu, select **Phone**.
- Click Signal Setup.
   The Signaling Parameters window appears.
- 4. From the System Type drop down menu, select **Phone**.

The Phone Setup tab and the Call Setup tab appear.

# **Phone Setup page**

When Phone is selected from the System Type drop down menu, the **Phone Setup** page appears, shown in the Figure below.




Figure 12.25: Phone Setup Page - Signaling Parameters

# Signaling Setup group box

## Signaling Type drop down menu

The **Signaling Type** drop down menu, shown in the Figure above, identifies the signaling type used when generating a phone call. DTMF is the default field value and can not be changed.

## **Digit Duration field**

The **Digit Duration** field represents the length of time, in ms, the digit tone plays when it is active.

# **Interdigit Duration field**

The **Interdigit Duration** field represents the length of time, in ms, between the digit tones within a group.

#### **Pause Duration field**

The **Pause Duration** field represents the length of time, in ms, allowed between transmitted groups.



#### Notice!

The pause duration must be at least the sum of the Digit and Interdigit Duration fields.

#### **Preamble Duration field**

The **Preamble Duration** field represents the length of time, in ms, the first tone digit plays. With some radio systems, the first tone needs to be longer than subsequent tones. For example, the first tone may be used to activate a dormant (battery saving) state.



#### Notice!

The preamble duration must be at least the amount of the Digit Duration field.

#### Level field

The **Level** field represents the relative level, in dB, the encoded message sends.

The range for this field is -20dB to +12dB.

### **Twist Level field**

The **Twist Level** field represents the relative level difference, in dB, of high and low tones generated when using DTMF tone types. This field is only active when DTMF is the selected tone type.

The range for this field is -10dB to +10dB.

# Signaling Delays group box

# **Initial Delay field**

The **Initial Delay** field represents the lead-in delay, in ms, for console-generated messages transmitted to the field radios.

The range for this field is 0 to 9999ms.

## **End Delay field**

The **End Delay** field identifies the delay, in ms, at the end of transmitted messages to the field. It delimits the tone string.

The range for this field is 0 to 9999ms.

When Phone is selected from the System Type drop down menu, the Call Setup page appears, shown in the Figure below.




Figure 12.26: Call Setup Page - Signaling Parameters Phone

## **Call Setup group box**

# **Auto Ack field**

The Auto Ack field for phone setup is disabled.

## **Emerg Resolved field**

The **Emerg Resolved** field for Phone Setup is disabled.

## **PTT BOT field**

The **PTT BOT** field for Phone Setup is disabled.

## **PTT EOT field**

The **PTT EOT** field for Phone Setup is disabled.

# Call (1-10) Format field

The **Call (1-10) Format** fields represent the message sent when selected by the console operator on the Per Line Call History, Call List Window, or the Manual Call List window. Refer to the Figure below.

This field can contain up to 32 characters.

Field values can be: Low or High.

- DTMF Format - Allows for 0-9, \*, #, A-D, G, I, K, P, R, and S.

For more information, refer to the table "Call setup group format descriptions" below.

## Call (1-10) Label field

The **Call (1-10) Label** fields represent the label applied to the button on the Per Line Call History, the Manual Call Window, and the Call List Window popup button, shown in the Figure below.

This field can contain up to 31 alphanumeric characters.



Figure 12.27: Per Line Call History Window

#### Refer to

- Generic system type, page 75

# 12.6 AutoFill Line Parameters window

The **AutoFill Line Parameters** window, shown in the Figure below, is used to eliminate repetitious data entry by automatically populating the corresponding fields on the Per Line Parameters window with the entries shown in the AutoFill Line Properties window. The RX and TX entry automatically increment by one for each filled line.

#### **AutoFill button**

The AutoFill button, shown in the Figure below, opens the AutoFill Line Parameters window.

Figure 12.28: Per Line Parameters AutoFill Button




Figure 12.29: AutoFill Line Parameters Window

#### **RX IP Address check box**

The RX IP Address check box indicates the IP Address is selected for the Autofill feature.

# **RX IP Address field**

The RX IP Address field indicates the IP Address used to receive data over the network.

### TX IP Address check box

The TX IP Address check box indicates the IP Address is selected for the Autofill feature.

#### TX IP Address field

The TX IP Address field indicates the IP Address used to send data over the network.

# Line Type check box

The **Line Type** check box indicates the Line Type is selected for the Autofill feature.

# Line Type drop down menu

The **Line Type** drop down menu is used to select the type of line for the Autofill feature.

Available selections for this field are Disabled, Telex, Phone, SIP Phone, P25-DFSI, NEXEDGE, and AIS.

## **RX Port Start check box**

The RX Port Start check box indicates the RX Port Number is selected for the Autofill feature.

#### TX Port Start check box

The TX Port Start check box indicates the TX Port Number is selected for the Autofill feature.

#### TTL check box

The TTL check box indicates the TTL number is selected for the Autofill feature.

#### TTL field

The **TTL** field is used to enter the number of routers the Multicast audio packets go through before being discarded. Network design dictates this value.

The range for this field is 1 to 100.

## Packet Delay check box

The **Packet Delay** check box indicates the Packet Delay number is selected for the Autofill feature

#### **Packet Delay field**

The Packet Delay field is sued to enter a packet delay number.

The range for this field is 4 to 27.

# Vocoder Type check box

The **Vocoder Type** check box indicates the Vocoder Type is selected for the Autofill feature.

# Vocoder Type drop down menu

The **Vocoder Type** drop down menu is used to select the vocoder to use for the Autofill feature.

Available selections for this field are: TELEX 32K, G.726 16K, G.726 32K (IP224 Only), and G.711 64K (IP224 Only).

# **Starting Line Number field**

The **Starting Line Number** field is used to enter a starting line number.

The range for this field is 1 to 200.

# **Ending Line Number field**

In the **Ending Line Number** field is used to enter an ending line number.

The range for this field is 1 to 200.

# To fill line parameters with the autofill feature, do the following:

1. From the menu bar, select File | Setup Per Line Parameters.

#### Click Autofill.

The AutoFill Line Parameters window appears.

- 3. In the RX IP Address field, enter an RX IP Address.
- 4. In the TX IP Address, enter a **TX IP Address**.
- 5. In the Line Type drop down menu, select a **Line Type**.
- 6. In the RX Port Start field, enter an RX Port start number.
- 7. In the TX Port Start field, enter a **TX Port start number**.
- 8. In the TTL field, enter a TTL.
- 9. In the Packet Delay field, enter a Packet Delay number.
- 10. In the Starting Line Number filed, enter a **starting line** number.
- 11. In the Ending Line Number field, enter an **ending line** number.
- 12. Click **OK**.

The IP Addresses, port numbers and TTL automatically fill in the appropriate fields starting and ending with line numbers entered in the AutoFill Line Parameters window.

#### **OK** button

The **OK** button applies the selected settings and closes the window.

#### **Cancel button**

The Cancel button closes the window.

# 12.7 Configure SIP Settings window

The **Configure SIP Settings** window, shown in the Figure below, is used to register the SIP Address.

Global SIP settings are available in the SIP Global Configuration window. To open this window, select Edit | Global SIP Phone. For more information, refer to "Global SIP Configuration window, page 163".




Figure 12.30: Configure SIP Settings Window

### **SIP Account Credentials group box**

### **Extension field**

The **Extension** field is used to enter the SIP extension number (for example, 211).

### Domain/Server IP field

The **Domain/Server IP** field is used to enter the Domain or Server IP address (for example, 172.19.50.20).

### **Authorization Name field**

The **Authorization Name** field is used to specify the user name used to register the SIP account on the SIP Server.

### **Password field**

The **Password** field is used to specify the password used to register to the SIP server. This is typically known as secret on the SIP server.

### Registrar group box

### Registrar Compatibility drop down menu

The **Registrar Compatibility** field is used to specify the compatibility level of the specified registrar server with RFC 3581 (SIP Symmetric Response Routing).

The default selection is Fully Compliant.

Available selections for this field are:

- Fully Compliant Registrar is fully compliant with RFC 3581 and will register any number and all types of listeners in the SIP packet header's Contact field.
- Cannot Use Multiple Contacts Registrar is able to register only one contact in the SIP packet header's Contact field.
- Cannot Use Private Contacts Registrar is unable to register any contacts in the SIP packet header's Contact field.
- Has Application Layer Gateway Network address translations will be handled externally by a router with an Application Layer Gateway. Network address translations should not be performed by C-Soft.

For more information refer to "SIP Phone line configuration, page 111".

### To configure the line for a SIP phone, do the following:

- 1. From the menu bar, select Edit | Setup Per Line Parameters.
  - The Per Line Parameters window appears.
- 2. From the Line Type drop down menu, select **SIP phone**.
  - The SIP button is active.
- 3. In the Line Name field, enter a **name** for the line.
- 4. Select the **Echo Packets** check box (optional).

NOTE: this can be used to stream audio to a recorder.

- In the RX Multicast Address field, enter the desired echo destination.
- In the RX port field, enter the desired Port number.
- 5. In the TTL field, enter a value between 1 and 99.
- 6. Click SIP

The Configure SIP Setting For Line X - (where X is the line number) window appears.

### Ring Settings group box

### Ring Sound drop down menu

The **Ring Sound** drop down menu is used to select different ring tones for individual SIP Extensions. One of four ring tones can be assigned to a SIP Extension.

Available selections for this field are: Ring 1, Ring 2, Ring 3, and Ring 4.



### Notice!

If the Default option is selected, C-Soft uses the Ring Sound set in Global Settings (Edit | Setup Global Parameters | Peripherals tab | Ring Sound).

### **Proxy Server group box**

### Use Outbound SIP Proxy check box

The **Use Outbound SIP Proxy** check box indicates traffic is initially sent through the proxy server entered in the Use Outbound SIP Proxy field. If the Use Outbound SIP Proxy check box is selected, the specified proxy settings override the Global SIP Proxy settings found in the Global SIP Configuration window for the specific line.



### Notice!

The Server Address field must also be configured.

### Server Address field

The **Server Address** field is used to enter the proxy server's address.



### Notice!

The Use Outbound SIP Proxy check box must also be selected.

### **Backup Address field**

The **Backup Address** field is used to specify a backup proxy server address. If the parameter is set and C-Soft fails to register using the primary Proxy Server address, C-Soft switches to the backup proxy address and attempts to re-register.

### **User Name field**

The **User Name** field is used to enter the proxy server User Name.

### Password field

The **Password** field is used to enter the proxy server password.

### **Voicemail Settings group box**

### **Enable Voicemail Notification check box**

The **Enable Voicemail Notification** check box enables C-Soft to subscribe to voicemail notification messages from the SIP server.

### 12.8 SIP Phone line configuration

C-Soft supports **SIP Phone** lines. SIP (Session Initiation Protocol) provides an alternative method of telephone line installation into your dispatch system. With SIP you can easily adapt and configure many telephone lines into a C-Soft console position without having to connect external hardware.

Each C-Soft 7.000 License comes with two SIP lines. Additional lines can be purchased as an additional feature and are available in 6, and 12 line increments.

### 12.8.1 SIP features

The SIP option is used to access the following features:

- Crosspatch
- Outbound DTMF
- Per line call history
- Call directory editing on-the-fly
- Auto-answer incoming calls
- Stun and proxy server
- Auto adjustments
- Silence detection
- Network recording or monitoring
- Call hold
- Do not disturb
- 3-way-calls
- Microphone mute
- Line conference
- Consultant transfer
- Blind transfer
- Missed call history
- Call waiting
- Conditional forwarding

### To configure your system for SIP calls, do the following:

- 1. Obtain a SIP account through your IT system administrator or internet service provider.
- 2. Configure a **SIP phone line** in C-Soft Designer, refer to *SIP Phone line configuration, page* 111.
- 3. If using a network recorder or monitor, **configure echo packets** in C-Soft Designer, refer to *Configure SIP for recording or monitoring, page 112*.
- 4. Set up **global SIP configurations** in C-Soft Designer, refer to "*Global SIP Configuration window, page 163*".
- 5. Create a SIP Call Control button in C-Soft Designer, refer to SIP Call Control, page 368.
- 6. Test the **registration parameters** in C-Soft Runtime, refer to "Test the SIP Registration".

### 12.8.2 Configure SIP for recording or monitoring

The SIP Phone line can be recorded or monitored. This is configured in the Per Line Parameters window.

For more information, refer to "Per Line Parameters window, page 61".



Figure 12.31: SIP Line Type - Per Line Parameters

### To configure the SIP line for network recording or monitoring, do the following:

- 1. From the Per Line Parameters window, select the **Echo Packets Enable** check box.
- 2. In the RX Multicast Address field, enter an IP Address.

- 3. In the RX Port field, enter an **RX port number**.
- 4. Click **OK**.

The Per Line Parameters window closes.

## 13 Global Parameter Setup window

The **Global Parameter** window, shown in the Figure below, is used to navigate to the Appearance, Audio, Control Settings, Local Consoles, Peripherals, and Recording pages to configure global settings.

NAVIGATION: Select Edit | Setup Global Parameters from the menu bar.

### 13.1 Appearance page

The **Appearance** page, shown in the Figure below, is used to configure various C-Soft appearance settings. This includes Unit/ID Display behavior, background display options, and button style.




Figure 13.1: Appearance Page - Global Parameters Setup

### **ANI Setup group box**

### **Enable Sticky ANI check box**

The **Enable Sticky ANI** check box indicates the ANI displayed on the select button remains visible until the next call is received.

#### **Enable Residual ANI check box**

The **Enable Residual ANI** check box indicates the previous caller's ANI continues to display after receiving a call from a user without ANI capabilities; otherwise, the caller's ANI disappears when the call is ended.

### Clear ANI on PTT check box

The **Clear ANI on PTT** check box indicates the ANI, normally displayed on the select button, is cleared when a PTT operation is selected.

### Alias Setup group box

### Always Display Unit # check box

The **Always Display Unit** # check box indicates the Unit ID # (ANI) is displayed on the receiving line's Select button in addition to the unit's Alias. Selecting this check box causes both the user's alias and number to appear on the button.

### **Group ANI Setup group box**

### **Hide Group ANI check box**

The **Hide Group ANI** check box indicates the Group ANI information is not displayed on the receiving line's Select button when receiving a Group call on a line configured for either Sprint Direct Connect, P25-DFSI, NEXEDGE, or iDEN operation.

### Logo group box

### Image Filename field

The **Image Filename** field identifies the file path of a image to be displayed in the background of the Console window.

C-Soft supports 1-bit, 4-bit, 8-bit and 24-bit bitmaps, .png, .jpg, and .gif file formats.

This field can contain up to 255 characters.

### **Browse button**

The **Browse** button opens the Open window, which is used to navigate to the logo image file.

### To change the image file, do the following:

- 1. Click Browse.
  - The Open window appears.
- 2. Select the **file** you want to use for the image.
- 3. Click Open.

The path to the image file appears in the field.

### Position drop down menu

The **Position** drop down menu is used to select the location of the image logo on the console window.

Available selections for this field are: Upper-Left, Upper-Right, Lower-Left, Lower-Right, Center and Stretch.

### **Button Style group box**

The **Button Style** group box is used to select a button style.

### Style drop down menu

The **Style** drop down menu is used to select the button style.

Available options are: Classic, Glossy Circle, Glossy Rectangle, Modern, and Vista.

### **Classic Option**

The Classic option, if selected, indicates the buttons are displayed in a classic style.




Figure 13.2: Classic Option Style

### **Glossy Circle Option**

The **Glossy Circle Option**, if selected, indicates the buttons are displayed in a glossy circle style.




Figure 13.3: Glossy Circle Option Style

### **Glossy Rectangle Option**

The Glossy Rectangle option, if selected, indicates the buttons are displayed in a glossy rectangle style.




Figure 13.4: Glossy Rectangle Option Style

### **Modern Style Option**

The Modern Style option, if selected, indicates the buttons are displayed in a glossy rectangle style.




Figure 13.5: Modern Style Option

### **Vista Style Option**

The Vista Style option, if selected, indicates the buttons are displayed in a vista style.




Figure 13.6: Vista Button Style

### **Button Border group box**

The **Button Border** group box is used to select the thickness of the border of various UI Controls. This setting applies to all buttons, popup buttons, and frequency controls.

### Thickness spin box

The **Thickness** spin box is used to set the thickness of the border around the UI button. The higher the value, the thicker the border.

The range for this field is 0 to 10.

The default is 5.

### **Button Flash Color group box**

The **Button Flash Color** group box is used to set the blink color for Select buttons when receiving one of the following call types.

### Call Alert drop down palette

The **Call Alert** drop down palette is used to set the button color when a Call Alert is being received. The button blinks when an alert is received.

### **Group Call drop down palette**

The **Group Call** drop down palette is used to set the button color when a Group Call is being received. The button blinks when a Group Call is received.

### **Emergency drop down palette**

The **Emergency** drop down palette is used to set the button color when an Emergency call is being received. The button blinks when an Emergency call is received.

### Select Call drop down palette

The **Select Call** drop down palette is used to set the button color when a Select call is being received. The button blinks when a Select call is received.

### **Background Color group box**

### **Background Color drop down palette**

The **Background Color** drop down palette displays the background color for the console and popup windows. Use the drop down button to open a palette to select the desired color.

The default color is black.

### **Window Options group box**

### **Keep Information Windows As Top Layer check box**

The **Keep Information Windows As Top Layer** check box indicates all C-Soft information windows are always displayed above C-Soft popup windows or any other application running on the PC.

The C-Soft information windows include:

- Active Emergency Window
- Call List Window
- Call Queue Window
- Emergency History Window
- Event Logger Window
- FleetSync Window
- Global Call History
- HB4 Global Parameters Setup Window
- HB4 Volume Window
- HB4 Speaker Select Window
- HB4 IRR Speaker Select Window
- License Dialog
- Manual Call List Window
- Manual Page Entry

- MDC-1200 Window
- MOTOTRBO Window
- P25-DFSI Window
- Per Line Call History Window
- SIP Call Window
- Status List Window
- Supervisor
- Web Page Popup

### **Popup Options group box**

### Close Using drop down menu

The **Close Using** drop down menu is used to select the closure method used by all popup windows.

### Available options are:

- Use the "X" in the top right
- Use the "Done" in the bottom right corner
- Use the button toggle to close. The button toggle closes the window even when using "X" or "Done"

### 13.2 Audio page

The Audio page, shown in the Figure below, is used to configure audio routing and blocking.




Figure 13.7: Audio Page - Global Parameters Setup

### **Audio Muting and Routing group box**

### Sum Unselect to Headset when On check box

The **Sum Unselect to Headset when On** check box indicates when an ADHB-4 is active, select and unselect audio is combined and routed to the headset.

### **Mute Select Audio During PTT check box**

The **Mute Select Audio During PTT** check box indicates select audio is muted when PTT is used.

### **Mute Unselect Audio During PTT check box**

The **Mute Unselect Audio During PTT** check box indicates unselect audio is muted when PTT is used.

### Mute Lines When Unselected check box

The **Mute Lines When Unselected** check box indicates unselected lines are automatically muted (only selected line is heard).

### Allow Muting Selected Lines check box

The **Allow Muting Selected Lines** check box indicates the console operator is able to mute selected lines on the console.

#### Mute Selected Channels with RX Block check box

The **Mute Selected Channels with RX Block** check box indicates the console operator is able to mute channels on which RX Block is enabled.

### Disable Local Talk Permit Tones check box

The **Disable Local Talk Permit Tones** check box indicates the console does not generate talk permit tones. Instead, the talk permit tones are generated by a communication device attached to the system.

### **Lines Remain Muted for Emergencies check box**

The **Lines Remain Muted for Emergencies** check box indicates the console will not transmit emergency call audio when the console is muted. When the check box is not selected, a muted console will transmit emergency call audio.

### **Audio Blocking group box**

### **RX Block Delay field**

The **RX Block Delay** field identifies the amount of time, in ms, the release of the RX blocked line is delayed. The RX blocked lines are selected on the Per Line Frequency Setup window, refer to "RX Block Lines Display Box". This delay allows any IP- and/or system-delayed audio to end before releasing the muted lines.

The range for this field is 300 to 5000ms.

The default is 0.

### To disable this feature, do the following:

- In the RX Block Delay field, enter **0 ms**.

### **DTMF Setup group box**

### Flywheel field

The **Flywheel** field identifies the amount of time, in ms, allowed to pass between clicks of different DTMF keypad keys before the radio is keyed down by the console.

The range for this field is 300 to 5000ms.

The default is 2000.

### Level field

The Level field identifies, in dB, the relative audio level to be transmitted. The actual level transmitted by the radio varies depending on the system. This field allows the console designer to adjust the relative level up or down after the remainder of the system is aligned and operational.

The range for this field is -30 to 10dB.

### **SOIP Audio Setup group box**

### **PTT Hang Timer field**

The **PTT Hang Timer** field is used to enter the amount of time to delay the PTT off command for SOIP protocols. This delay allows the IP-223/4 to complete processing any transmit audio before C-Soft sends a command to the serial device to stop transmitting. To calculate the Hang Timer Delay, use the following equation:

Hang Timer Delay = IP-224 Packet Delay \* 20ms + IP-224 TX Delay (EQ 1)

Currently, only Sprint Direct Connect lines are affected by this feature.

### MIC AGC group box

The **MIC AGC** (Automatic Gain Control) group box indicates the C-Soft program supports a software based microphone AGC.

### **Enable check box**

The **Enable** check box is used to help equalize speech level variations caused by the use of different microphones, different speaking distances to the microphone, and different volumes of speech.

### **Target Level field**

The Target Level field identifies the audio level, in dB, the MIC AGC packets are adjusted to.

- If the measured audio level is above the target level, the audio is reduced in gain.
- If the incoming level is below the target, up to 6dB of gain is applied to bring the level up.

The range for this field is -30dB to 6dB.

### Min Active field

The **Min Active** field identifies the audio level, in dB, at which the AGC software stops trying to adjust the audio level. If audio below this level is detected, the AGC software does not attempt to adjust the audio. This prevents open mics from amplifying background noise onto the transmit channel.

The range for this field is -60 to 0 dB.

### **Audio Filtering**

### Disable Audio Bandpass Filter check box

The **Disable Audio Bandpass Filter** check box indicates the audio bandpass filter is disabled. When selected, audio transmitted from C-Soft is not passed through the vocoder specific bandpass filter before being encoded. Disabling the bandpass filter results in the transmit audio sounding warmer (more bass) than filtered audio.

### **Direct IP Line Gain group box**

### **Enable Line Gain check box**

The **Enable Line Gain** is used to help balance receive audio levels between IP-224s and the Direct IP system. When enabled, the selected amount of gain is applied to all receive audio of every Direct IP Lines (AIS, NEXEDGE, P25-DFSI, and P25-CSSI).

Available gain levels are 3 dB, 6 dB, 9 dB, and 12 dB.

### 13.3 Control Settings page

The **Control Settings** page, shown in the Figure below, is used to enable various console controls, a supervisor password and points to FleetSync, MDC1200 and MOTOTRBO system files.




Figure 13.8: Control Settings Page - Global Parameters Setup

### **User Control options**

### Allow Freq Update Anytime check box

The **Allow Freq Update Anytime** check box indicates frequency updates are accepted at any point in the RX stream. Otherwise, frequency updates are accepted at the beginning of a call, before audio playback begins.

### Ignore Freq Updates check box

The **Ignore Freq Updates** check box is used to ignore frequency change updates from remote sources, such as parallel consoles or IP-224s. A line's transmit frequency can only be changed on the local console using either Frequency Change button or the Frequency Control.

### Disable Spacebar PTT check box

The Disable Spacebar PTT check box indicates the spacebar is not used for PTT.

### Kill Lines on Crosspatch check box

The **Kill Lines on Crosspatch** check box indicates the console operator cannot transmit on a line included in crosspatch by a parallel console operator. Otherwise, the console operator is allowed to transmit on the lines even if another console operator has included the lines in a crosspatch.

### **Control Timeouts group box**

### Supervisor field

The **Supervisor** field controls the parallel console crosspatch timeout. The timeout is controlled by the Supervisor console initiating the action.

The range for this field is 0 to 3600 seconds.

EXAMPLE: Console 1 has supervisor timeout set to 10 seconds.

Console 2 has supervisor timeout set to 2 seconds.

- Case 1: If console 1 initiated the action, then both consoles timeout after 2 seconds.
- Case 2: If console 2 initiated the action, then console 2 times out in 2 seconds and console 1 times out in 10 seconds.

### To disable supervisor timeout, do the following:

In the Supervisor field, enter 0.

### **Crosspatch field**

The **Crosspatch** field indicates the amount of time, in seconds, a crosspatch is allowed to remain inactive before it is dropped.

The range for this field is 0 to 3600 seconds.

### To disable crosspatch inactivity, do the following:

- In the Crosspatch field, enter **0**.

### **Save Runtime Setting group box**

### Save Runtime Status on Close check box

The **Save Runtime Status on Close** check box indicates the console size, position, settings, and selections are saved to the cposi.txt when the program is closed. Otherwise, the size position, and selections are not saved when C-Soft Runtime is closed.

For more information, refer to "Window Sizing" on "C-Soft Console, page 466".



### Notice!

C-Soft opens only the current version of the cposi.txt file.

### System List group box

#### Filename field

The **Filename** field identifies the system file used by C-Soft Runtime when it opens the veg file. If left blank, the Edit System window opens to a blank system. The filename identifies the path to the saved FleetSync, MDC-1200, MOTOTRBO, Telex-Serial and P25-DFSI systems.

For more information, refer to "Edit System List window, page 192".

### **Browse button**

The **Browse** button is used to select the system list file to use. When clicked, a file chooser menu opens and allows the user to browse to the desired System List file.

### Logging Setup group box

### **Enable Logging check box**

The Enable Logging check box indicates logging is active and the console creates an event log file when C-Soft Runtime is started.

By default the Enable Logging check box is not selected.

If the Enable Logging check box is selected, then a log file is created.

The location of the log file is C:\ProgramData\Telex Communications\C-Soft\Logs.



### Notice!

The log file is named SystemLog\_[Date][Time]\_[.veg file name].txt. For example, a system log started on June 3rd at 1:05 PM from the Denton Fire.veg file is named, SystemLog 06-03 13:05:13 Denton Fire.txt. A new file is created anytime C-Soft Runtime is started or when the current log file reaches a file size of 3 Mb.

Event log files are kept for at least seven days. C-Soft deletes any files older than seven days at boot-up, or when creating a new event log file because the existing file has reached its maximum size.

### Log Level drop down menu

The Log Level drop down menu is used to select type of messages to be saved in the event log file and the event log window, if available.

Available options are:

- Error Used for events that could cause or indicate a service failure.
- Warning Used for minor user-level exceptions not expected during normal operation.
- Information Used for normal user-level events (for example, incoming calls, starting a call, etc.)
- Debug Used for debugging purposes.



### Notice!

Error, Warning, and Debug are used by Sprint Direct Connect only. All other types use Information only.

### **Supervisor Password**

### Supervisor Password field

The **Supervisor Password** field is used to assign a password for the supervisor function and any other password protected functions.

This field can contain up to 16 alphanumeric characters.

### **Window Controls group box**

#### Window Controls check boxes

The **Window Controls** check boxes indicate the standard window controls are included on the dispatch console window.

Available selections for this field are:

- Allow Minimize allows the console operator to minimize the dispatch window to a button on the toolbar.
- Allow Maximize allows the console operator to maximize the dispatch window.
- Allow Resize allows the console operator to resize the dispatch window.
- Allow Move allows the console operator to move a dispatch window that has been resized.
- Allow Close allows the console operator to close a dispatch window. If this selection is not enabled, the only way to shut down the dispatch console position is to use the Windows Task Manager (press Ctrl+Alt+Delete to open Windows Task Manager).

### **Keyboard Dual-Tone Format group box**

### **DTMF** radio button

The **DTMF** radio button indicates DTMF tones are used when keyboard number keys are pressed.

### **Knox radio button**

The **Knox** radio button indicates Knox tones are used when keyboard number keys are pressed. Knox tones are specific tones used to unlock Knox boxes. These boxes are used primarily by fire departments.

### 13.4 IRR Recording page

The **IRR Recording** page, shown in the Figure below, is used to assign the lines to be recorded by Per Line Recording and Per Line Recording options.




Figure 13.9: IRR Recording Page - Global Parameters Setup

### **Line Recording Setup group box**

When checked the last 60 minutes of received audio will be recorded and available for playback from the both the Per Line History or Global Call History Window. Up to 100 lines can be selected for IRR recording.

The recorded audio storage directory is specified in C:\ProgramData\Telex Communications C-Soft\Settings\ClientSettings.xml and by default is C:\ProgramData\Telex Communications C-Soft\Audio Archive. Change the recorded audio storage directory by using Telex System Manager.

### **Recording Settings group box**

### Output Speaker drop down menu

The **Output Speaker** drop down menu is used to designate the speaker used to playback per line call recording audio.

### Minimum Record Duration drop down menu

The **Minimum Record Duration** drop down menu is used to set the minimum length of time a call must last for the audio to be recorded.

Calls lasting less than the minimum duration are not recorded and will not be available for playback.

Default is 0.5 sec.

### Options are:

- 0.5 sec
- 1.0 sec
- 1.5 sec
- 2.0 sec

### Log Outgoing Calls check box

The **Log Outgoing Calls** check box sets C-Soft's logging behavior in both the Per Line History and Global Call History windows.

By default, C-Soft only logs incoming calls. If the Log Outgoing Calls check box is selected, outgoing calls are also logged in these windows. Note, the line must be configured in the Line Recording Setup Box to record outgoing traffic.

Additionally, if Per Line Recording is enabled for a given line and the Log Outgoing Calls check box is checked, outgoing transmissions made on that line are recorded and available for playback.

### Populate Keypad on Selection check box

The **Populate Keypad on Selection** check box indicates the user can select an entry in the per line call history window and have the keypad automatically populate with the ID of the call. By default, this option is disabled.

### 13.5 Local Consoles page

The **Local Consoles** page, shown in the Figure below, is used to configure the IP Addresses of local consoles.

Figure 13.10: Local Consoles Page - Global Parameters Setup

### Local Console IP Addresses group box

### **Local Console IP Address fields**

The **Local Console IP Address** fields identify up to 10 base IP Addresses of the Hardware IP Console (IP-2002, IP-1616, IP-3000 series and C-6200) and C-Soft consoles that reside in the same room.

OK

Cancel

The C-Soft program examines the source of the audio, and, if the source is from a console in this list, the audio is muted. An exception to the muting rule is, if an ADHB-4 is connected and the headset is turned on. In this case, the received audio is routed to the headset earpiece and is played, ignoring the crossmute condition.



### Notice!

Individual lines must have Mute Per-Line buttons associated with them for this feature to work.

### **Direct IP Console Subscriber IDs field**

The **Direct Console Subscriber IDs** field is only used for the NEXEDGE IP, AIS, and P25 CSSI interfaces. If an ID is entered into this field, the console treats all audio received from the entered ID as a parallel console transmission.

### **Crossmute File**

The **Crossmute File** is used to allow each position to have its own crossmute settings without requiring a different design file by populating the Local Console IP Address fields with a .txt file.

### To create a crossmute file, do the following:

- 1. In a .txt file, enter up to 200 IP Addresses (one per line).
- Select File | Save from the menu bar. The Save window opens.
- 3. In the File Name field, enter csoft crossmutes.txt.
- 4. From the Look in drop down menu, select C:\ProgramData\Telex Communications\C-Soft\DesignData.
- 5. Click Save.

The IP Addresses are loaded from this file and replace the entries in the Global Properties Setup window.



#### Notice!

The Crossmute File feature does not apply to either the AIS, CSSI, or NEXEDGE IP interfaces.

# Crossmute Direct IP Console Subscriber IDs check box (for NEXEDGE, AIS, and CSSI Lines Only)

The **Crossmute Direct IP Console Subscriber IDs** check box is used to allow crossmute for the NEXEDGE IP, AIS, CSSI interfaces in a parallel console. This means when C-Soft detects a parallel console transmit with a console ID on the list, it mutes the transmit audio.

### To enable Crossmute Direct IP Console Subscribers, do the following:

- In the Direct IP Console Subscribers ID field, enter the IDs for all NEXEDGE, AIS, and CSSI consoles present in the system.
- 2. Select the Crossmute direct IP console subscribers IDs check box.

### 13.6 Peripherals page

The **Peripherals** page, shown in the Figure below, is used to configure network settings, phone, and peripheral devices.




Figure 13.11: Peripherals Page - Global Parameters Setup

### **Network Settings group box**

### IP Interface spin box

The **IP Interface** spin box is used to select the network interface. The C-Soft program can be configured to use any of the first four interfaces.

### If no traffic is detected on the selected interface, do the following:

- 1. From the IP Interface spin box, select a **different interface** (0-3).
- 2. Save the C-Soft Designer.exe file.
- 3. Restart the C-Soft Runtime console.



### Notice!

If at least one Ethernet connection is present, the value always defaults to zero, often resulting in no traffic detected. If your computer has an Ethernet connection not being used to run C-Soft Runtime, we recommend turning off that connection or setting the value in the field to 1, 2, or 3.



#### Caution!

If you choose to run an Ethernet connection and C-Soft at the same time, you might lose your C-Soft Ethernet connection.

EXAMPLE: The wireless connection is located at interface 0 and the C-Soft Ethernet connection is located at interface 1. If the computer becomes disconnected from the wireless connection, Windows automatically moves the C-Soft Ethernet connection from interface 1 to interface 0. In this case, C-Soft is disconnected from the Ethernet.

### Radio Ping Interval field

The **Radio Ping Interval** field identifies the time, in seconds, between ping attempts on the base radio IP Address. The typical amount of time is 300 seconds or five minutes. A value of zero disables the function.

The range for this field is 0 to 9999 seconds.

### **TCP/IP Time Out field**

The **TCP/IP Time Out** field indicates the amount of time, in ms, before the TCP/IP connection times out.

The range for this field is 1000 to 20000ms.

### **Enable RX Multicast Loopback check box**

The **Enable RX Multicast Loopback** check box is used to enable the current console configuration to receive Multicast audio sent from the same PC currently running C-Soft.

### Phone group box

### **Ring Multicast field**

The **Ring Multicast** field identifies the IP Address to which the ring signal is broadcast. The entry in this field should correspond to the values set in a C-6200 console with an actual phone card interface, or to an IP-223 with Telex's PIB or attached TDI Adapter.

### **Ring Port field**

The **Ring Port** field is used to identify the port number to which the ring signal is broadcast. The entry in this field should correspond to the values set in a C-6200 console with an actual phone card interface, or to an IP-223 with Telex's PIB or attached TDI Adapter.

### Ring Sound drop down menu

The **Ring Sound** drop down menu is used to select the ring sound heard when a call is received.

Available selections for this field are: Ring 1, Ring 2, Ring 3, and Ring 4.

### Ring Speaker drop down menu

The **Ring Speaker** drop down menu is used to select which speaker plays incoming phone ring tones.

Available selections for this field are Speaker 1, Speaker 2, Speaker 3, Speaker 4, Speaker 5, or Speaker 6.

#### Auto Hold Phone Line on PTT check box

The **Auto Hold Line on PTT** check box is used to indicate any phone currently offhook is put on hold when any PTT button is pressed.



### Notice!

Feature supported in both Line Types: Phone and SIP Phone.

### **NEO-10** group box

The **NEO-10** device sends out a UDP packet anytime one of its inputs or outputs changes state. The C-Soft program monitors this traffic and allows all users of the equipment to see input and output status changes.

### Multicast field

The Multicast field identifies the Multicast Address of the NEO-10 device.

The entry in this field should correspond to the entry on the NEO-10 Multicast Setup window.

### **Update Port field**

The **Update Port** field identifies the port number of the NEO-10 device.

The entry in this field should correspond to the entry on the NEO-10 Multicast Setup window.

### License Server group box

### IP Address/Name fields

The **IP Address/Name** fields are used to specify the IP address or name of one or two Telex Licensing Servers. Address specifications are expected in the following formats:

- <port>@<host IP>
- <port>@<servername>
- <host IP>

The default port is 27000.



### Notice!

In C-Soft Runtime, the token "@localhost" will automatically be added to the license server specification to instruct the license libraries to additionally connect to a locally-running license server. As a result, for configurations using a local license server, no additional parameters need to be set in C-Soft Designer.

### ADHB-4 Speaker Volume group box

### Speaker 1-6 Min Volume field

The **Speaker 1-6 Min Volume** field indicates the minimum selectable volume level for speakers connected to jacks 2-6. During C-Soft operation, the volume for the specified speaker cannot be set lower than the percentage configured for the speaker in this field.

This field ranges from 0% to 100%.

Speaker 1's volume is controlled with the Volume Master Select button. Refer to "UI Element Function Drop Down Menu".

### 13.7 Recording page

The **Recording** page, shown in the Figure below, is used to configure a recording with Telex's Network Recorder.

For more information, refer to the Telex Network Recorder Technical Manual and Archive Database Reviewer (F.01U.188.143).




Figure 13.12: Recording Page - Global Parameters Setup



### Notice!

The microphone only records during activity, such as a telephone call or PTT.

### Enable check box

The **Enable** check box is used to enable the Select speaker, Unselect speaker, speakers 3-6, microphone, NENA, Aux Track Left, and Aux Track Right for recording from the indicated IP Address and port.



### Notice!

Speakers 3-6 and NENA are used when an ADHB-4 is connected to the PC. Aux Track Left is the left channel audio received by the Aux In port on the ADBH-4 Gen 2. Aux Track Right is the right channel audio received by the Aux In port on the ADBH-4 Gen 2.

### Vocoder Type drop down menu

The **Vocoder Type** drop down menu indicates the bit rate at which audio is converted into digital format. This feature is used to configure communication between C-Soft and an IP-223 or IP-224.

Available selections for this field are: TELEX 32K, G.726 16K, G.726 32K (IP224 Only), and G.711 64K (IP224 Only).

### Multicast field

The **Multicast** field indicates the console's Multicast Address for the selected speaker, microphone, or NENA.



### Notice!

If multiple consoles are in use, this option requires a separate configuration for each console.

### Port field

The **Port** field indicates the port used for the selected speaker, microphone or NENA audio.

The port number must be unique from all other ports configured on the console.

### TTL field

The **TTL** field indicates the lifespan of data in a computer or network.

### 14 Language Customization

The **Language Customization** window, shown in the Figure below, is used to configure call window names, buttons, button labels, button color codes, column labels, fonts, and the number of lines to display in the window.



### Notice!

The Language Customization window was formerly known as "Global Call Parameters."

NAVIGATION: Select Edit | Language Customization from the menu bar.




Figure 14.1: Language Customization Window - General Page

### 14.1 General page

The **General** page is used to set the list entry font size, maximum entry limit, formatting, and to restore default settings.

### **List Entry Font Size group box**

### **Active Emergency Font Size field**

The **Active Emergency Font Size** field is used to specify text size for the Active Emergency Call History window.

The range for this field is 1 to 72.

#### Call List Font Size field

The Call List Font Size field is used to specify the text size for the Call List window.

The range for this field is 1 to 72.

### **Emergency Call History Font Size field**

The **Emergency Call History Font Size** field is used to specify the text size for the Emergency Call History window.

The range for this field is 1 to 72.

### Per Line Call History Font Size field

The **Per Line Call History Font Size** field is used to specify the text size for the Per Line Call History window.

The range for this field is 1 to 72.

### **Status List Font Size field**

The Status List Font Size field is used to specify the text size for the Status List window.

The range for this field is 1 to 72.

### **Maximum Entry Limit group box**

### **Emergency Call History Window Lines field**

The **Emergency Call History Window Lines** field is used to set the number of lines displayed in the Emergency Call History window. When the Call History window is full, the oldest call is removed.

The range for this field is 1 to 500 lines.

### Per Line Call History Window Lines field

The **Per Line Call History Window Lines** field is used to set the number of lines displayed in the Per Line Call History window. When the Call History window is full, the oldest call is removed.

The range for this field is 1 to 500 lines.

### Formatting group box

### Call-to-Console Color drop down menu

The **Call-to-Console Color** drop down menu is used to set the Call-To-Console background color. The background color can be changed by selecting options from the drop down menu.



### Notice!

The Call-to-Console color is used as the background color for calls directed to C-Soft consoles in the FleetSync, MDC-1200, Call List and Per Line Call History windows.

### Date Format drop down menu

The **Date Format** drop down menu is used to select the date format displayed in the call logs.

Available selections for this menu are:

- MM/DD/YYYY
- DD/MM/YYYY

### **Default Setting group box**

### **Restore Default button**

The **Restore Default** button is used to reset all parameter settings to their default values.

The Restore Default button will reset all parameters in the Language Customization setup.

### 14.2 Button Labels window

The **Button Labels** group box contains fields to enter custom labels appearing on buttons in the Call List, Per Line, Manual Call List, Set Status and Active Emergency windows.




Figure 14.2: Language Customization Window - Button Labels Page

### General Button group box

### **ACK field**

The **ACK** field creates a button label that displays in the Active Emergency window. When the button is clicked in C-Soft Runtime, the emergency is acknowledged by sending a message to the radio that initially declared the emergency.

This field can contain up to 10 characters.

### **Backspace field**

The **Backspace** field creates a button label that displays in the Manual Call window. When the button is clicked in C-Soft Runtime, the last character entered in the User ID field is cleared.

This field can contain up to 10 characters.

### Cancel field

The **Cancel** field creates a button label that displays in the Set Status window. When the button is clicked in C-Soft Runtime, changes are discarded and the window closes.

This field can contain up to 10 characters.

### Clear field

The **Clear** field creates a button label that displays in the Manual Call List window. When the button is clicked in C-Soft Runtime, the User ID field is cleared.

This field can contain up to 10 characters.

#### Done field

The **Done** field creates a button label that displays in all call windows. When the button is clicked in C-Soft Runtime, the window closes.

This field can contain up to 10 characters.

### **Emergency Clear field**

The **Emergency Clear** field creates a button label that displays in the Active Emergency window. When the button is clicked in C-Soft Runtime, the Emergency is cleared from the list.

This field can contain up to 10 characters.

#### Set Status field

The **Set Status** field creates a button label that displays in the Per Line Call History, Manual Call List and Call List windows. When the button is clicked in C-Soft Runtime, the Status List window appears and a status ID can be selected and sent.

This field can contain up to 10 characters.

### **DTMF Buttons group box**

### **Digit A-F fields**

The **Digit A-F** fields create a button label that displays in the Manual Call window. When the button is clicked in C-Soft Runtime, the digit it is assigned to is entered in the User ID field.

This field can contain up to 10 alphanumeric characters.

### 14.3 Button Images window

The Button Images group box contains fields to enter the file path of an image file (.bmp, .jpg, .gif, and .png) to display custom images on the specified buttons. Each button image contains the following two buttons:

### **Browse button**

The **Browse** button opens the Open window, which is used to navigate to the image file.

### **Clear button**

The Clear button resets the current file path to the default file path.



### Notice!

To create a transparent background when using a 24-bit bitmap image, use RGB color 192, 192, 192.




Figure 14.3: Button Images window

### Activity

The **Activity** icon is displayed on a Popup button when audio traffic is detected on a line contained in the popup window and the popup window is closed (see *UI Element Setup window - Add Popup Button, page 439*). The default image is activity.bmp.

### **IC LED**

The **IC LED** icon is displayed on a Select button when intercom traffic is detected on the Select button's line (see *Select, page 364*). The default image is icled.bmp.

### Link Fail

The **Link Fail** icon is displayed on Select buttons when C-Soft fails to detect a device at the Select button's base radio IP (see *Select, page 364*). The default image is Ifled.bmp.

### **Mute LED**

The **Mute LED** icon is displayed on Select buttons when the Select button's line is muted (see *Select, page 364*). The default image is muton.bmp.

### **Paging**

The **Paging** icon is displayed on Page and Manual Pages buttons while the page is being sent. The default image is paging.bmp.

### **Page Done**

The **Page Done** icon is displayed on Page and Manual Pages buttons when the page has been completed and the "Manually confirm pages are done sending" option has been enabled in Paging Setup see *Paging Settings window, page 149*The default image is pagedone.bmp.

### **RX LED**

The **RX LED** icon is displayed on Select buttons when receive traffic is detected on the Select button's line (see *Select, page 364*). The default image is rxled.bmp.

### **TX LED**

The **TX LED** is displayed on Select buttons when parallel console transmit traffic is detected on the Select button's line (see *Select*, *page 364*). The default image is txled.bmp.

### **XTX LED**

The **XTX LED** icon is displayed on Select buttons when parallel console transmit traffic, which has been crossmuted, is detected on the Select button's line (see *Local Consoles page, page 129* and *Select, page 364*). The default image is xtxled.bmp.

### 14.4 Column Headings page

The **Heading Labels** group box contains fields to enter custom labels appearing on column headings in the Call List, Per Line, Manual Call List, Set Status and Active Emergency windows.




Figure 14.4: Language Customization Window - Column Heading Page

### **Heading Labels group box**

### **Date field**

The **Date** field is used to create the column label applied to the date column in call windows.

This field can contain up to 31 characters.

### Time field

The **Time** field is used to create the column label applied to the time column in call windows.

This field can contain up to 31 characters.

### **Channel field**

The **Channel** field is used to create the column label applied to the channel column in call windows.

This field can contain up to 31 characters.

### Freq field

The **Freq** field is used to create the column label applied to the frequency column in call windows.

This field can contain up to 31 characters.

#### Status field

The **Status** field is used to create the column label applied to the status column in call windows.

This field can contain up to 31 characters.

### Talkgroup field

The **Talkgroup** field is used to create the column label applied to the talkgroup column in call windows.

This field can contain up to 31 characters.

### **User ID field**

The **User ID** field is used to create the column label applied to the user ID column in call windows.

This field can contain up to 31 characters.

### **Calling ID field**

The **Calling ID** field is used to create the column label applied to the calling ID column in call windows.

This field can contain up to 31 characters.

### Status ID field

The **Status ID** field is used to create the column label applied to the status ID column in call windows.

This field can contain up to 31 characters.

### **Duration field**

The **Duration** field is used to create the column label applied to the duration column in call windows.

This field can contain up to 31 characters.

### **Comments field**

The **Comments** field is used to create the column label applied to the comments column in call windows.

This field can contain up to 31 characters.

# 14.5 Text Labels window

The **Text Labels** group box contains fields to enter custom labels appearing in text fields in the Call List, Per Line, Manual Call List, Set Status and Active Emergency windows.




Figure 14.5: Language Customization Window - Text Labels Page

# **Text Labels group box**

### Alias field

The Alias field is used to create the column label applied to the alias column in call windows.

This field can contain up to 31 characters.

### **ID Type field**

The **ID Type** field is used to create the column label applied to the ID type column in call windows.

This field can contain up to 31 characters.

### Filters field

The **Filters** field is used to create the filters label applied to the Call List window.

This field can contain up to 31 characters.

### No Filters field

The **No Filters** field is used to create the label applied when no filters are selected in the filters display in the Call List window.

This field can contain up to 31 characters.

### No Status field

The **No Status** field is used to create the label applied when no statuses are selected in the status display in call windows.

This field can contain up to 31 characters.

# 14.6 Window Titles window

The **Window Titles** group box contains fields to enter custom titles appearing on windows in the Call List, Per Line, Manual Call List, Set Status and Active Emergency windows.




Figure 14.6: Language Customization Window - Window Titles Page

### Window Titles group box

### **Active Emergency field**

The **Active Emergency** field allows you to name the window that appears when the Active Emergency button is clicked in the C-Soft Runtime program.

This field can contain up to 10 characters.

#### **Call List field**

The **Call List** field allows you to name the window that appears when the Call List button is clicked in the C-Soft Runtime program.

This field can contain up to 10 characters.

### **Emergency History field**

The **Emergency History** field allows you to name the window that appears when the Emergency History button is clicked in the C-Soft Runtime program.

This field can contain up to 10 characters.

### **Global Call History field**

The **Global Call History** field allows you to name the window that appears when the Global Call History button is clicked in the C-Soft Runtime program.

This field can contain up to 10 characters.

### Per Line Call History field

The **Per Line Call History** field allows you to name the window that appears when the Per Line Call History button is clicked in the C-Soft Runtime program.

This field can contain up to 10 characters.

# **Manual Call List field**

The **Manual Call List** field allows you to name the window that appears when the Manual Call List button is clicked in the C-Soft Runtime program.

This field can contain up to 10 characters.

### Status List field

The **Status List** field allows you to name the window that appears when the Status List button is clicked in the C-Soft Runtime program.

This field can contain up to 10 characters.

# 15 Paging Settings window

The **Paging Settings** window, shown in the Figure below, is used to configure pager settings for both individual and group pages. Up to 10 predefined pages can be configured.

NAVIGATION: Select Edit | Setup Pagers from the menu bar.




Figure 15.1: Pagers Window

# **Page Setup**

### Page Type drop down menu

The **Page Type** drop down menu, to the right of the pager number, is used to select a predefined pager from a list.

Available selections for this field are:

2 Tone 100 (Quickcall II 100)

- 2 Tone 1000 (Quickcall II 1000)
- **DTMF**
- Knox

In addition to the pager selections provided on this window, a UI element is provided.

### Setup button

The Setup button is used to open the appropriate window for the type of pager selected in the drop down menu.

For more information, refer to:

- "2 Tone 100 Page Setup window, page 151".
- "2 Tone 1000 Setup window, page 153".
- "DTMF Paging Setup window, page 157".
- "Knox Paging Setup window, page 158".

### Page Send Topology

### Sequential radio button

The **Sequential** radio button indicates the paging codes are sent on a line by line basis. The pages for one line are completely sent before the pages on the next line are started.

#### Parallel radio button

The Parallel radio button indicates the paging codes are sent on different lines at the same time.

### **Tone Options**

### **Correct Low Frequency Tone Levels (Flatten Levels)**

The Correct Low Freq Tone Levels (Flatten Levels) check box indicates tones across 300kHz to 3kHz spectrum are flattened for better level adjustment. Depending on the load being driven, it is possible additional roll-off of the lower frequency tone (sub 1kHz) levels can occur.

### **Delay Between Stacked Pages field**

The Delay Between Stacked Pages field is used to set the amount of time, in ms, C-Soft waits between stacked pages. This feature enables page decoders to distinguish between different pages.

The range for this field is 0 to 9999ms.



### Notice!

This field is global and affects all stacked pages regardless of page type or format. This field is added to the Inter-Page Delay configured for the individual Page Formats.

### **User Control Options Group Box**

Allow Programmed Page Stack Buttons to be Stacked check box The Allowed Programmed Page Stack Buttons to be Stacked check box indicates programmed page stack buttons can be stacked.

### Always Stack Page Buttons check box

The Always Stack Page Buttons check box indicates that Page buttons are always stacked.

### Manual Confirm Pages Are Done Sending check box

The **Manual Confirm Pages Are Done Sending** check box indicates the Page, Manual Page, and Programmed Page Stack buttons display the Done icon once all pages generated by a page button have been sent by the console. The Done icon remains visible on the page buttons until the Page Cancel button is clicked.

### Revert to Initial Frequency After Sending Page check box

The **Revert to Initial Frequency After Sending Page** check box indicates the console returns to the original frequency configured before sending the page.

### **OK** button

The **OK** button saves the entries and closes the window.

# 15.1 2 Tone 100 Page Setup window

The **2 Tone 100 Page Setup window**, shown the Figure below, is used to configure a 2-digit code paging sequence for this format. To open this window, select 2 Tone 100 from the Page Type drop down menu.




Figure 15.2: 2 Tone 100 Page Setup Window

### Page Name field

The Page Name field is used to enter a descriptive name to associate with the paging sequence for this encoder. The name, when assigned, is displayed in the Pager Setup window next to the Pager Number field, and is included for selection in a list of variables for the user interface element page function.

### Page Level field

The Page Level field identifies the output, in dB, of the relative paging tone.

The range for this field is -60 to 10dB.

### Initial Page Delay field

The Initial Page Delay field identifies the amount of time, in ms, allowed from PTT until the first tone is played.

The range for this field is 0 to 9999ms.

# Inter-Page Delay field

The Inter-Page Delay field is used to set the amount of time, in ms, C-Soft waits between stacked pages using the paging format.

The range for this field is 0 to 9999ms.



### Notice!

This field only affects stacked pages using this page format. The field is added to Delay Between Stacked Pages field on the Paging Setting window.

## Tone 1 Group and Tone 2 Group fields

The Tone 1 Group and Tone 2 Group fields identify which two frequencies are played in succession.

The range for this field is 1 to 15.

### To determine the entry for each field, do the following:

Using the table on "Telex Tone Group Numbers, page 473", find the desired Telex Tone Group number for the first and second tones.

### Tone 1 Time field

The **Tone 1 Time** field identifies the duration, in ms, of tone 1. The tone and gap durations for standard paging plans are shown in "Tone and Gap Durations for Standard Paging Plans, page *474*".

The range for this field is 0 to 10000ms.

### Gap Duration field

The Gap Duration field identifies the duration, in ms, of the gap duration. The tone and gap durations for standard paging plans are shown in "Tone and Gap Durations for Standard Paging Plans, page 474".

The range for this field is 0 to 15000ms.

### **Tone 2 Time field**

The **Tone 2 Time** field identifies the duration, in ms, of tone 2. The tone and gap durations for standard paging plans are shown in "*Tone and Gap Durations for Standard Paging Plans, page 474*".

The range for this field is 0 to 10000ms.

### **Group Tone Time field**

The **Group Tone Time** field identifies the duration, in ms, of the group tone. The tone and gap durations for standard paging plans are shown in "*Tone and Gap Durations for Standard Paging Plans*, page 474".

The range for this field is 0 to 10000ms.

### **Enable Diagonal check box**

The **Enable Diagonal** check box indicates the tone specified in the Diag Tone Freq field is used in place of either the first or second tone depending on the selection in the Diag Location check box. Otherwise, the group tone is played for the diagonal tone duration period.

### **Diag Tone Freq field**

The **Diag Tone Freq** field identifies the frequency, in Hz, of the diagonal tone when the Enable Diagonal check box is selected.

The range for this field is 0 to 3000Hz.

### Diag Location check box

The **Diag Location** check box indicates the diagonal tone is used in place of the first tone; otherwise, the group tone is used.

### **OK** button

The **OK** button saves the entries and closes the window.

# **Cancel button**

The **Cancel** button discards any changes made and closes the window.

# 15.2 2 Tone 1000 Setup window

The **2 Tone 1000 Setup** window, shown in the Figure below, is used to configure a 3-digit paging code. To open this window, select 2 Tone 1000 from the Page Type drop down menu.




Figure 15.3: 2 Tone 1000 Setup Window

### Page Name field

The **Page Name** field is used to enter a descriptive name to associate with the setup for this encoder. The name, once assigned, is displayed on the Pager Setup window next to the Pager Number field, and is included for selection in a list of variables for the user interface element page function.

# Page Level field

The **Page Level** field identifies the output of the relative paging tone.

The range for this field is -60 to 10dB.

### **Initial Page Delay field**

The **Initial Page Delay** field identifies the amount of time allowed from PTT until the first tone is played.

The range for this field is 0 to 9999ms.

# Inter-Page Delay field

The **Inter-Page Delay** field is used to set the amount of time, in ms, C-Soft waits between stacked pages using the paging format.



### Notice!

This field only affects stacked pages using this page format. The field is added to Delay Between Stacked Pages field on the Paging Setting window.

The range for this field is 0 to 9999ms.

### **Tone Plan Number field**

The **Tone Plan Number** field is used to configure the first and second page tones. Refer to "*Telex Tone Group Numbers, page 473*".

The range for this field is 1 to 25.

EXAMPLE: If the pager to be reached is N349, the Telex Code Plan Number would be set to 12 which corresponds to group Mot N. The Pager Capcode 3 corresponds to the line (3+3), in Group N (Tone Plan Number 12), from which the 2 Tone Group Frequencies are selected.

From using Telex Code Plan #12, Tone Group #3, and Tone Group #3 for N349, the first tone (Telex Tone Group Number 3 and Tone Group 4) sent would be 313.0, followed by the second tone (Telex Tone Group Number 3 and Tone Group 9) 1063.2.

Table "Example tone plan number locator" shows the break down of each digit in the pager number N349 and a description of the encoder parameters identified by the digit.

Digit	Identifies	Description	
N	Pager	Locate the Mot N	Where the Telex code
		group pagers in "2	plan # (12) and the
		Tone 1000 Plan	Pager Capcode (3xx)
		Numbers" on page	intersect in the table
		427.	to identify the Telex
			Group No. (3+3). This
		Enter the Telex	identifies the
		Codeplan # from the	frequencies for tone 1
		top row in the Tone	and Tone 2.
		Plan Number (12)	
		(this digit can also	
		identify the entries	
		for the Tone 1 Time,	
		Gap Duration, Tone 2	
		Time and Group Tone	
		Time fields, refer to	
		"Tone and Gap	
		Durations for	
		Standard Paging	
		Plans" on page 426).	
3	Pager Capcode	Locate the Pager	In the table's left
		Capcode (3xx) in "2	column.
		Tone 1000 Plan	
		Numbers" on page	
		427.	

4	Tone 1 Frequency	Using the first number identified above (3), locate the Telex Group No. 3 and Tone Group 4 (second digit in pager number), from "Telex Tone Group Numbers" on page 425.	Where these two items intersect in the table identifies the frequency of tone 1 (313.0).
9	Tone 2 Frequency	Using the second number in the Telex Group number (3), locate the Telex Group No. 3 and Tone Group 9 (third digit in pager number) from "Telex Tone Group Numbers" on page 425.	Where these two items intersect in the table identifies the frequency of tone 2 (1063.2).

Tab. 15.4: Example tone plan number locator

#### **Tone 1 Time field**

The **Tone 1 Time** field identifies the amount of time of the duration for tone 1. The tone and gap durations for standard paging plans are shown in "*Tone and Gap Durations for Standard Paging Plans, page 474*".

The range for this field is 1 to 10000ms.

### **Gap Duration field**

The **Gap Duration** field identifies the amount of time of the gap duration. The tone and gap durations for standard paging plans are shown in "*Tone and Gap Durations for Standard Paging Plans, page 474*".

The range for this field is 1 to 15000ms.

### Tone 2 Time field

The **Tone 2 Time** field identifies the amount of time of the duration for tone 2. The tone and gap durations for standard paging plans are shown in "*Tone and Gap Durations for Standard Paging Plans, page 474*".

The range for this field is 1 to 10000ms.

# **Group Tone Time field**

The **Group Tone Time** field identifies the amount of time of the tone duration for the group tone. The tone and gap durations for standard paging plans are shown in "*Tone and Gap Durations for Standard Paging Plans, page 474*".

The range for this field is 1 to 10000ms.

### **Enable Diagonal check box**

The **Enable Diagonal** check box indicates the frequency entered in the Diag Tone Freq field is used in place of either the first or second tone depending on the selection made in the Diag Location check box. Otherwise, the second tone is played for the diagonal tone duration period.

### **Diag Tone Freq field**

The **Diag Tone Freq** field identifies the frequency of the diagonal tone when the Enable Diagonal check box is selected.

The range for this field is 0 to 3000Hz.

### **Diag Location check box**

The **Diag Location** check box indicates the diagonal tone is used in place of the first or second tone. If selected, the diagonal tone overrides either the first or second group tone. Otherwise, group tone is used.

### **OK** button

The **OK** button saves the entries and closes the window.

#### **Cancel button**

The Cancel button discards any changes made and closes the window.

# 15.3 DTMF Paging Setup window

The **DTMF Paging Setup** window, shown in the Figure below, is used to configure standard paging tones level, delay, time length and string length.

To open this window, select DTMF from the Page Type drop down menu.




Figure 15.4: DTMF Paging Setup Window

### **Page Name field**

The **Page Name** field is used to enter a descriptive name to associate with the setup for this encoder. The name, once assigned, is displayed on the Pager Setup window next to the Pager Number field, and is included for selection in a list of variables for the user interface element page function.

### Page Level field

The **Page Level** field identifies the output of the relative paging tone.

The range for this field is -60 to 10dB.

### **Initial Page Delay field**

The **Initial Page Delay** field identifies the amount of time allowed from PTT until the first tone is played.

The range for this field is 0 to 9999ms.

### Inter-Page Delay field

The **Inter-Page Delay** field is used to set the amount of time, in ms, C-Soft waits between stacked pages using the paging format.

The range for this field is 0 to 9999ms.



### Notice!

This field only affects stacked pages using this page format. The field is added to Delay Between Stacked Pages field on the Paging Setting window.

### **DTMF On Time field**

The **DTMF On Time** field identifies the amount of time the DTMF digit is played.

The range for this field is 20 to 2000ms.

#### **DTMF Off Time field**

The **DTMF Off Time** field identifies the amount of time in between the time each DTMF digit is played.

The range for this field is 20 to 2000ms.

### **DTMF Digits field**

The **DTMF Digits** field identifies the number of digits in a standard page. The number of digits specified are expected by all pages using this option.

The range for this field is 1 to 16.

### **OK** button

The **OK** button saves the entries and closes the window.

### **Cancel button**

The Cancel button discards any changes made and closes the window.

# 15.4 Knox Paging Setup window

The **Knox Paging Setup** window, shown in the Figure below, is used to configure the pager name, output level, digit duration, pause times, and digits required in the page. To open this window, select Knox from the Page Type drop down menu.




Figure 15.5: Knox Paging Setup Window

### **Page Name field**

The **Page Name** field is used to enter a descriptive name to associate with the paging sequence for this encoder. The name, when assigned, is displayed in the Pager Setup window next to the Pager Number field, and is included for selection in a list of variables for the user interface element page function.

### Page Level field

The **Page Level** field identifies the output of the relative paging tone.

The range for this field is -60 to 10dB.

### **Initial Page Delay field**

The **Initial Page Delay** field identifies the amount of time allowed from PTT until the first tone is played.

The range for this field is 0 to 9999ms.

# **Inter-Page Delay field**

The **Inter-Page Delay** field is used to set the amount of time, in ms, C-Soft waits between stacked pages using the paging format.



### Notice!

This field only affects stacked pages using this page format. The field is added to Delay Between Stacked Pages field on the Paging Setting window.

The range for this field is 0 to 9999ms.

### **Knox On Time field**

The **Knox On Time** field identifies the amount of time the knox digit is played.

The range for this field is 20 to 2000ms.

### **Knox Off Time field**

The Knox Off Time field identifies the amount of time in between the time each Knox Digit is played.

The range for this field is 20 to 2000ms.

# **Knox Digits field**

The Knox Digits field identifies the number of digits in a standard page. The number of digits specified are expected by all pages using this option.

The range for this field is 1 to 16.

### **OK** button

The **OK** button saves the entries and closes the window.

### **Cancel button**

The Cancel button discards any changes made and closes the window.

# 16 Tone Levels window

The **Tone Levels** window, shown the Figure below, is used to configure the tone level, in dB, of individual tones heard by the operator.

NAVIGATION: Select Edit | Setup Tone Level from the menu bar.



Figure 16.1: Tone Levels Window

### **Emergency Tone field**

The **Emergency Tones** field indicates the tone level at which the emergency tone is heard.

The range for this field is -60 to 0 dB.

### **Group Call Tones field**

The Group Call Tones field indicates the tone level at which the group call tones are heard.

The range for this field is -60 to 0 dB.

### **Talk Permit Tones field**

The Talk Permit Tones field indicates the beep level at which the iDEN beeps are heard.

The range for this field is -60 to 0 dB.

# **Input Beeps field**

The **Input Beeps** field indicates the beep level at which the input beeps are heard.

The range for this field is -60 to 0 dB.

### Page Beeps field

The Page Beeps field indicates the beep level at which the page beeps are heard.

The range for this field is -60 to 0 dB.

### **Phone Rings field**

The **Phone Rings** field indicates the ring level at which the phone rings are heard.

162 en | Tone Levels window C-Soft 7.700

The range for this field is -60 to 0 dB.

# **Select Call Tones field**

The **Select Call Tones** field indicates the tone level at which select call tones are heard.

The range for this field is -60 to 0 dB.

# Sidetones field

The **Sidetones** field indicates the level at which sidetones are heard.

The range for this field is -60 to 0 dB.

### **OK** button

The **OK** button saves the entries and closes the window.

### **Cancel button**

The Cancel button discards any changes made and closes the window.

# 17 Global SIP Configuration window

The **Global SIP Configuration** window, shown in the Figure below, provides access to SIP Network settings and SIP Audio settings.

SIP extension settings are configured on a Per Line basis. For more information, see *Configure SIP Settings window*, page 108.

NAVIGATION: Select Edit | Setup SIP Phone from the menu bar.

# 17.1 SIP Network page

The **SIP Network** page, shown in the Figure below, is used to enter Default Identity, STUN Settings, Proxy Server Settings, and various other advanced settings.




Figure 17.1: Network Page - Global SIP Configuration

### **Default Identity group box**

### **Display Name field**

The **Display Name** field is used to enter an alias name for the console for easy identification. The display name appears on the SIP phone if the SIP phone or SIP/PSTN gateway is capable and configured to display the alias.

### STUN Server group box

### Use STUN Server check box

The **Use STUN Server** check box indicates the STUN (Session Traversal Utilities for NAT [Network Address Translation]) server entered in the field is used to negotiate packet routing through NAT firewalls or NAT routers.

#### Server Address field

The Server Address field is used to enter a server address for packet routing.



#### Notice!

The Use Stun Server check box must also be selected.

Typically, if C-Soft is running on a computer running on a private IP network, then it is necessary to enable the use of STUN server option. The STUN protocol allows C-Soft to use a STUN server on the internet to determine how the NAT gateway translates the UDP addressing between the private network and the public internet.

### **Proxy Server group box**

### Use Outbound SIP Proxy check box

The **Use Outbound SIP Proxy** check box indicates traffic is initially sent through the proxy server entered in the Server Address field.



# Notice!

The Server Address field must also be configured.

### **Server Address field**

The **Server Address** field is used to enter the proxy server's address.



### Notice!

The Use Outbound SIP Proxy check box must also be selected.

### **User Name field**

The **User Name** field is used to enter the proxy server User Name.

### Password field

The **Password** field is used to enter the proxy server password.

### Advanced group box

### Listen on Specific IP Address check box

The **Listen on Specific IP Address** check box indicates the IP Address you enter in the Listen on Specific IP Address field is active.



### Notice!

The Listen on Specific IP Address field must also be configured.

### Listen on Specific IP Address field

The **Listen on Specific IP Address** field is used to enter the specific IP Address to use for sending and receiving phone calls. This feature is useful when the computer has multiple NICs (Network Interface Cards).



#### Notice!

The Listen on Specific IP Address check box must also be selected.

# Use Non-Standard Port check box

The **Use Non-Standard Port** check box indicates the port number entered in the field is used for SIP communication. Otherwise, the default port number 5060 is used.



## Notice!

The Use Non-Standard Port field must also be configured.

### **Use Non-Standard Port field**

The Use Non-Standard Port field is used to enter a port number for SIP communications.~



# Notice!

The Use Non-Standard Port check box must also be selected.

# **Enable Logging check box**

The **Enable Logging** check box enables logging for the SIP library in C-Soft. This check box is used for Debugging Purposes Only.

# 17.2 Audio page

The **Audio** page, shown in the Figure below, contains LAM, silence detection, and jitter buffering configuration.




Figure 17.2: Audio Page - Global SIP Configuration

### LAM Setup group box

The **LAM Setup** group box is used to control LAM (Line Activity Monitor) during SIP phone to radio crosspatch activity.

### LAM Level (dB) spin box

The **LAM Level (dB)** spin box is used to set the audio threshold at which the crosspatched line or echo packets begin to send audio packets over the network.

The range for this field is -60 to 0 dB.

## LAM Time (s) spin box

The **LAM Time** spin box is used to set the amount of time for radio crosspatch activity. The LAM time determines how long the SIP line is active after the audio level is below the LAM level threshold.

The range for this field is 0 to 60 sec.

### Silence Detection group box

### None radio button

The **None** radio button indicates there is no silence detection for any SIP phone line in the system. Audio continues to transmit, even if silent.

### Fixed Threshold radio button and Threshold spin box

The **Fixed Threshold** radio button is used to activate the minimum audio detection mode. When the audio level reaches the specified threshold configured in the spin box, it is no longer considered silent. Audio levels below the specified raw digital value in the spin box are ignored and considered silent.

This setting is used with the Voice Deadband and Silence Deadband spin boxes.

The range for this field is 0 to 8000.

### Adaptive Threshold radio button and Period spin box

The **Adaptive Threshold** radio button is used to activate the dynamic audio detection mode and is the recommended configuration for silence detection. The minimum audio is automatically adjusted after the software determines the average audio received over the amount of time specified in the Period spin box.

This setting is used with the Voice Deadband and Silence Deadband spin boxes.

The range for this field is 10 to 10000ms.

### Voice Deadband (ms) spin box

The **Voice Deadband (ms)** spin box is used to configure the minimum duration of audio above the threshold needed to start sending audio.

The range for this field is 10 to 10000ms.



### Notice!

If audio is choppy after setting the value, try setting to a shorter amount of time.

# Silence Deadband (ms) spin box

The **Silence Deadband (ms)** spin box is used to configure the minimum duration of audio below the threshold before the audio is considered silent. The time should be long enough so that gaps between spoken words are not detected as silence, otherwise the audio may sound choppy.

The range for this field is 10 to 10000ms.

### Jitter Buffering group box

The **Jitter Buffering** group box contains settings for buffering incoming audio packet delivery to reduce jitter. When the minimum and maximum are set, the duration of jitter buffer is dynamically adjusted between the two values. A longer duration can improve the audio quality if network latency is variable, but when the duration is set for too long, audio delay can interfere with conversation. Experimentation is the best way to optimize your settings.

### Min Duration (ms) spin box

The **Min Duration (ms)** spin box is used to configure minimum buffer duration for incoming audio.

The range for this field is 10 to 10000ms.

### Max Duration (ms) spin box

The **Max Duration (ms)** spin box is used to configure maximum buffer duration for incoming audio.

The range for this field is 10 to 10000ms.

#### **Restore Default button**

The **Restore Defaults** button is used to restore factory defaults. The default values appear in the Figure above.

### **OK button**

The **OK** button saves the entries and closes the window.

### **Cancel button**

The **Cancel** button discards any changes made and closes the window.

### **Operation Test**

Test the SIP registration to confirm successful connectivity and authentication to the SIP server. SIP Server status is recorded in the Global Call History page in C-Soft Runtime and a success or failure registration message appears in the status bar.



### Notice!

A SIP Call Control UI element is required for each SIP line. Before testing the SIP connection, you must create a SIP Call Control UI element button. Refer to "SIP Call Control" on page 342.

### To test the SIP connection in C-Soft Runtime, do the following:

Open the C-Soft console.

A message appears in the console status bar:

- If the connection is successful, a success message appears.
- If the connection fails a failure message appears.

# C-Soft Console

SIP Line: Diamond Card - Registered as 52420@usgw.ast.diamondcard.us

# C-Soft Console

SIP Line: SIPDiamondcard - Unable to Register as 52420@usgw.ast.diamondcard.us

#### 17.3 **Behavior page**

The Behavior page, shown in the figure below, contains settings for defining how C-Soft SIP operates. These settings are needed for interoperability with different SIP servers, which may have differing procedures for common SIP operations.




Figure 17.3: Global SIP Configuration - Behavior page

# **Hold Initiation Group Box**

The Hold Initiation group box is used to set how C-Soft initiates putting a call on hold. The default value is Allow independent stream states, and is only recommended to set Stop all streams in the case that C-Soft audio is leaking while on hold.

# Allow independent stream states Radio Button

The **Allow independent stream states radio button** indicates that C-Soft, upon putting a call on hold, sends an invite message with the parameter a=sendonly, which the SIP server and remote endpoint negotiate media streams, ultimately putting the call on hold.

### Stop all streams Radio Button

The **Stop all streams** radio button indicates that C-Soft, upon putting a call on hole, sends an invite message with the parameter a=inactive, immediately ending the streams without negotiation.

C-Soft 7.700 Setup P25 | en 171

# 18 Setup P25

NAVIGATION: Select Edit | Setup P25 from the menu bar.

For more information about setting up P25:

- **P25 DFSI Global Setup** is discussed in *P25 DFSI Global Setup window, page 480*
- Global P25 CSSI Parameters is discussed Global P25 CSSI Parameters, page 540
- **Encryption Setup** is discussed in *Encryption Setup window, page 516*

### Refer to

- P25-DFSI window, page 322
- Appendix E P25-DFSI (Digital Fixed Station Interface), page 479

 Bosch Security Systems, LLC
 Technical Manual
 2021-06 | 14 | F.01U.218.561

# 19 GPS Mapping Setup window

The **GPS Mapping Setup** window is used to enable GPS data to be received and stored by C-Soft, and to configure GPS settings, such as file name.

The .kml file is located in a directory specified in C:\ProgramData\Telex Communications C-Soft\Settings\ClientSettings.xml and by default is C:\ProgramData\Telex Communications C-Soft\DesignData. Change the GPS Mapping storage directory by using Telex System Manager. NAVIGATION: Select Edit | Setup GPS Mapping from the menu bar.




Figure 19.1: GPS Mapping Setup Window



### Notice!

GPS mapping is currently only available for the Kenwood NEXEDGE, MOTORBO, and Tait DMR Trunking systems.

### **KML File Setup group box**

### Store received GPS data in KML File check box

The Store received GPS data in KML File check box is used to create and store GPS file.



### Notice!

Google Earth functionality will only work if the Store received GPS data in KML File check box is selected.

### File Name field

The File Name field is used to define the file name.

# **Network Setup group box**

### **Enable GPS Output (NEXEDGE Only) check box**

The **Enable GPS Output** check box is used to enable GPS output. If selected, the GPS IP Address and GPS ports become active and can be modified. If the radios have GPS enabled, the console outputs the GPS information on the console's user selectable address and port. The format is in Degrees, Decimal Minutes.

The remote radio must be configured in the radio programming software to send the GPS coordinates to the console ID.



# Notice!

The Network GPS feature is only available for the NEXEDGE IP interface.

# **GPS IP Address field**

The GPS IP Address field indicates the console's GPS IP Address for transmitting GPS data.

# **GPS Port field**

The GPS Port field indicates the port used for GPS data.

The port number must be unique from all other ports configured on the console.

**174** en | NEXEDGE C-Soft 7.700

# 20 NEXEDGE

NAVIGATION: Select Edit | Setup NEXEDGE from the menu bar.

- NEXEDGE is discussed in Appendix H - Kenwood NEXEDGE Direct IP interface, page 544

- Global NEXEDGE Conventional Parameters window is discussed in Global NEXEDGE Conventional Parameters window, page 561
- Global NEXEDGE Trunking Parameters is discussed in NEXEDGE Trunking System setup, page 551
- NEXEDGE Encryption is discussed in NEXEDGE Encryption window, page 581

### **Setup External Systems** 21

Use **Setup External Systems** to configure and manage connections to external systems that C-Soft uses for various specialized operations.

#### 21.1 **API Setup**

For more information on the API Setup window, see

- Appendix K C-Soft API Installation notes, page 604
- Setup External Systems window, page 605

**176** en | AIS C-Soft 7.700

# 22 AIS

For more information, see AIS Global Setup window, page 596.

# 23 Filter List Setup window

The **Filter List Setup** window, shown in the Figure below, is used to create a list of filters for the console operator to use during FleetSync, MDC-1200, MOTOTRBO, P25-DFSI, and Telex-Serial system creation to sort and organize units and groups or fleets of user IDs in the system. The filters are also used by the console operator to filter units and groups while in the Call List window, the FleetSync Dispatching window, the MOTOTRBO Dispatching window, the P25-DFSI Dispatching window and Keypad Control.

This list can contain up to 60 filters.

NAVIGATION: Select Edit | Edit Filters from the menu bar.




Figure 23.1: Filter List Setup Window

# Filter List Setup group box

### Filter Entry field

The Filter Entry field is used to enter a label for a new filter.

This field can contain up to 16 alphanumeric characters.

### List field

The **List** field displays the list of all filters created in the system.

This list can contain up to 60 filters.

### Add Filter button

The Add Filter button is used to add the filter entry in the Filter Entry field to the list of filters.

To add a filter, do the following:

1. In the Filter Entry field, enter a **name** for the filter.

### 2. Click Add Filter.

The new filter appears in the Filter Entry field.

### **Delete Filter button**

The **Delete Filter** button is used to delete an unwanted entry from the list of filters.

To **delete a filter**, do the following:

- 1. In the Filter List field, **select** the filter name.
- 2. Click Delete Filter.

The filter is deleted from the list.

### **Clear List button**

The Clear List button is used to clear the entire list of filters from the Filter List.

### To clear all entries, do the following:

Click Clear List.

The list is cleared from the window.



### Notice!

If you accidentally click the clear list button and did not want to delete the entire list then click Cancel and reopen the window.

### **OK button**

The **OK** button saves any changes made and closes the window.

### **Cancel button**

The Cancel button discards any changes made and closes the window.

# 24 User ID List window

The **User ID List** window, shown in the following Figures, is used to create a list of individual users in the system for recall later. It is used in conjunction with the ANI features of certain radios. When the window is closed and reopened, the user IDs are sorted by Name in ascending order. Refer to the Figure below.

NAVIGATION: Select Edit | Edit User ID List from the menu bar.




Figure 24.1: User ID List Window



# Notice!

When the User ID List is closed and opened again, the blank rows are deleted and the list is sorted in ascending order by Name.

### Name field

The Name field is used to enter a descriptive name to associate with the User ID.

When the ANI is received, this name appears on the select button for the line and in the User ID column of the Per Line Call History window, Call List window, and the Manual Call List window. If no name is associated with a User ID, the User ID appears on the line's button and in the history and call list windows.

This field can contain up to 16 characters.

For more information about ANI display configuration, refer to "ANI Setup Group Box".

### **Sort By Name button**

The **Sort By Name** button is used to sort the User ID List by Name in ascending order.

### **User ID field**

The **User ID** field is used to configure the user ID number transmitted by the radio.

### User ID Types:

- Generic: Up to 31 hexadecimal digits, \*, and #
- FleetSync: Up to 31 decimal digits.
- iDen: Up to 31 decimal digits, \*, and #
- Telex-Serial: Up to 31 decimal digits
- MDC-1200: Up to 31 hexadecimal digits
- MOTOTRBO: Up to 31 decimal digits
- NEXEDGE: Up to 5 decimal digits
- NEXEDGE All Call: The ID is 65535
- P25-DFSI: Up to 31 decimal digits
- P25-CSSI: Up to 31 decimal digits
- Phone: Up to 31 decimal digits, \*, and #
- Sprint DC: Up to 31 decimal digits
- AIS: Up to 8 decimal digits
- Telex-Enhanced-ANI: Up to 32 alphanumeric characters

Some of these system types do expect certain User ID formats or ranges, which are as follows:

- Generic: This applies to many different systems, so there is no additional specification
- FleetSync: 7 decimal digits: in range of 1001000-3494999
- iDen: "<number>\*<number>\*<number>"
- Telex-Serial: applies to many different systems, so no additional specification
- MDC-1200: 4 hexadecimal digits 0 FFFF
- MOTOTRBO: decimal number 0-16776125
- NEXEDGE: decimal number 0-65519
- P25-DFSI: decimal number 0-65535
- P25-CSSI: decimal number 0-65535
- Phone: decimal number of up to 15 digits
- Sprint DC: decimal number of 10 digits for an individual phone number and 15 digits for a TeamDC group ID
- AIS: Decimal number 1 16777215
- Telex-Enhanced-ANI:A-Z, a-z, and 0-9

This field can contain up to 32 characters.



### Notice

Up to 6000 user IDs can be created.

### **Sort By ID button**

The **Sort By ID** button is used to sort the User ID List by User ID in ascending order.

### Type drop down menu

The **Type** drop down menu is used to select the system type the user ID is associated with.

Available selections for this field are: Generic, FleetSync, iDEN, Telex-Serial, MDC-1200, MOTOTRBO, P25-DFSI, Phone, Sprint DC, NEXEDGE-TRUNK, NEXEDGE-CONV, CSSI and AIS.




Figure 24.2: User ID List - Type Drop Down Menu

#### TX Inhibit check box

The **TX Inhibit** check box indicates the caller's alias displays when received, but does not display as an available destination in the Call List, FleetSync Dispatch window, MDC-1200 Dispatch window, MOTOTRBO Dispatch window, P25-DFSI Dispatch window, or Keypad.

#### **Filters button**

The **Filters** button is used to assign one or more filters to the ID. When the filter button is clicked, the Select Filters window appears and displays all filters you created earlier. Refer to "Filter List Setup window, page 177".

#### To assign filters to the user ID, do the following:

- 1. Click the Filter Button.
  - The Select Filter window appears.
- Select the **filters** you want to add the User ID to.
   All the filters you want to include the User ID in are selected.
- 3. Click OK

The User IDs are added to the selected filters.

# To **deselect a filter**, do the following:

Click the filter.

#### **Select Filters window**

The **Select Filters** window is used to select filters to associate the user with. You can assign multiple filters to a single User ID.

#### **Load File button**

The **Load File** button is used to load a .csv file containing User ID information into the User ID List window.



#### Notice!

When the .csv file is loaded, all items in the current list are overwritten.

# To load a saved User ID .csv file, do the following:

1. Click Load File.

The Open window appears.

- 2. In the Open window, select the file you want to load.
- 3. Click Open.

The file is loaded, the Username, ID, and Type field are populated. If configured in the file, TX inhibit and filters are also populated.

#### Save File button

The Save File button is used to save the current User IDs to a .csv file.

#### To save the User ID List to a .csv file, do the following:

1. Click Save File.

The Save As window appears.

- 2. In the Filename field, enter a name.
- 3. Click Save.

The .csv file is saved in the current folder.

#### **OK** button

The **OK** button saves any changes made and closes the window.

#### **Cancel button**

The **Cancel** button discards any changes made and closes the window.

# 25 Group ID List window

The **Group ID List** window, shown in the Figure below, is used to configure both the decode and encode group IDs for group ANIs. By default, the Group ID List is sorted by Group Name in ascending order (refer to the Figure below).

Up to 5000 Group IDs can be created.

NAVIGATION: Select Edit | Edit Group ID List from the menu bar.



#### Notice!

When the Group ID List is closed and opened again, the blank rows are deleted and the list is sorted by Group Name in ascending order.




Figure 25.1: Group ID List Window

#### **Group field**

The **Group** field is used to enter a descriptive name to associate with the Group ID. This name is displayed on the Select button of the line when the ANI is received and in the Per Line Call History Window, Call List Window, Manual Call List Window, System-specific Dispatch Windows, and the Keypad Module. If no name is associated with a Group ID, the Group ID appears.

This field can contain up to 16 characters.

# **Sort By Name button**

The Sort By Name button is used to sort the Group ID List by Group Name in ascending order.

#### **Group ID Field**

The **Group ID** field is used to enter the particular resource group's identification number which is used for aliasing incoming and addressing outgoing group-related operations.

This field can contain up to 8 characters.

#### ID number format:

- Generic Up to 8 hexadecimal digits, \*, and #.
- FleetSync Up to 8 decimal digits.
- iDEN Up to 8 decimal digits, \*, and #.
- Telex-Serial Up to 8 decimal digits.
- MDC-1200 Up to 8 hexadecimal digits.
- MOTOTRBO Up to 8 decimal digits.
- NEXEDGE Up to 5 decimal digits.
- P25-DFSI Up to 8 decimal digits.
- P25-CSSI Up to 8 decimal digits.
- AIS Up to 8 decimal digits., 1-16777215
- Telex-Enhanced-ANI: Up to 32 alphanumeric characters

#### Sort By ID button

The Sort By ID button is used to sort the Group ID List by Group ID in ascending order.

### Type drop down menu

The **Type** drop down menu is used to select the system type for the assigned group.

Available selections for this field are Generic, FleetSync, iDEN, Telex-Serial, MDC-1200, MOTOTRBO, P25-DFSI, NEXEDGE-TRUNK, NEXEDGE-CONV, P25-CSSI and AIS

# To assign the system type to the group, do the following:

- From the Type drop down menu, select the **type of system** associated to the group.



Figure 25.2: Group ID List Window - Type Drop Down Menu

#### TX Inhibit check box

The **TX Inhibit** check box indicates the caller's alias displays when received, but does not display as an available destination in the FleetSync Dispatch Window, MDC-1200 Dispatch Window, or Keypad module.

#### **Set Color check box**

The **Set Color** check box is used to set a color for the group ID. When the set color check box is selected, the Set Color button can be used to assign a color to the selected items. For more information, refer to "Set Color Button".




Figure 25.3: Color Window

#### **Filters button**

The **Filters** button is used to assign a filter(s) to the group. When a filter is assigned, the group is included any time the selected filter(s) is chosen.

#### **Load File button**

The Load File button is used to load a .csv file into the current Group ID List window.



#### Notice!

When the .csv file is loaded, all items in the current list are overwritten.

# To load a saved group ID .csv file, do the following:

- 1. Click Load File.
  - The Open window appears.
- 2. In the Open window, select the file you want to load.
- 3. Click Open.

The file loads, the Group name and Group ID fields populate. If included in the saved file, the group color, filters and TX Inhibit also populate.

# Save File button

The Save File button is used to save the current Group ID List to a .csv file.

#### To save the Group ID List to a .csv file, do the following:

- 1. Click Save File.
  - The Save As window appears.
- 2. In the Filename field, enter a name.
- 3. Click Save.

The .csv file is saved in the current folder.

#### **Uncheck All button**

The Uncheck All button clears all Set Color check boxes.

#### **Set Color button**

The **Set Color** button opens the color palette. With this palette you can assign a color to display as the background for the group and group ID in C-Soft Runtime's system-specific dispatch windows, and the Per Line Call History window. The colors allow for customization and quick visual recognition of configured groups.

#### To set a color for the group ID, do the following:

- Select the **Set Color** check box for each group you want to assign a color. Each group ID you want to color is selected.
- 2. Click Set Color.

The Color window appears.

3. Select a color.

The color appears in preview box.

4. Click **OK**, to apply the color in the preview box.

The color is applied to the selected group(s).

Click Cancel to close the window and discard changes.

#### **Reset Colors button**

The Reset Colors button sets all Group ID background colors to white.

#### **OK** button

The **OK** button saves any changes made and closes the window.

#### Cancel button

The Cancel button discards any changes made and closes the window.

# 26 Status Message ID List window

The **Status Message ID List** window, shown in the Figure below, is used to configure status messages and status IDs that are either sent of received by the console.

This list can contain up to 5000 status messages.

#### Note:

- When the window is closed and reopened, the list is sorted in descending Status ID
- Any row left unfilled is deleted and the list is sorted by descending group ID number when the Status Message ID List is closed and opened again.

NAVIGATION: Select Edit | Edit Status Message ID List from the menu bar.




Figure 26.1: Status Message ID List Window

#### Status Message field

The **Status Message** field creates an alias or descriptive message to associate with the Status ID. This message appears in the Per Line Call History window, Global Call History window, System-specific Dispatch windows, Status window, Send Status button, and on the Select button upon receiving a Status Message.

This field can contain up to 32 characters.

#### Status ID field

The **Status ID** field identifies the message transmitted by the radio. For example, using the Figure above, if status 98 is sent to the console, the console displays "Mandown".

This field can contain up to 8 characters.

#### Password Protected check box

The **Password Protected** check box is used to indicate the supervisor password is required before the status ID can be sent. Refer to "Supervisor Password Field".

#### Set Color check box

The **Set Color** check box is used to select specific Status Message entries to which the Set Color button applies.

#### Load File button

The Load File button is used to load a .csv file into the current Status ID window.



#### Notice!

When the .csv file is loaded, all items in the current list are overwritten.

# To load a saved status message .csv file, do the following:

- On the Status Message ID List window, click Load File.
   The Open window appears.
- 2. In the Open window, select the **file** you want to download.
- 3. Click Open.

The file is loaded, the Status Message and ID fields are populated. If configured in the saved file, status color and password protection is also populated.

#### Save File button

The Save File button is used to save the current Status Message ID List to a .csv file.

#### To save the Status Message ID List to a .csv file, do the following:

- On the Status Message ID List window, click Save File.
   The Save As window appears.
- 2. In the Filename field, enter a name.
- Click Save.

The .csv file is saved in the current folder.

#### **Uncheck All button**

The Uncheck All button clears all Set Color check boxes.


#### **Set Color button**

The **Set Color** button is used to set a color for any entries for which the Set Color check box is selected.

# To set the Status ID color, do the following:

- L. Select the **Set Color** check box for all messages you want to assign a color.
- On the Status Message ID List window, click Set Color.
   The Color window appears.
- 3. From the Basic colors group box or the palette, select a **color**.
- 4. Click OK.

The selected Status IDs are colored.



#### **Reset Colors button**

The **Reset Colors** button sets all Status ID background colors to white.

The **OK** button saves any changes made and closes the window.

# **Cancel button**

The **Cancel** button discards any changes made and closes the window.

#### **Text Message ID List window** 27

The Text Message ID List window, shown in the Figure below, is used to configure static text messages (aliases) and an associated ID. The Text Message ID List is used to associate sent or received TextID codes to a readable Text Message.

This list can contain up to 500 text messages.

NAVIGATION: Select Edit | Edit Text Message ID List from the menu bar.




Figure 27.1: Text Message ID Window

### **Text Message field**

The Text Message field is used to create a descriptive message for the Text ID. This message can be selected by the console operator from the Per Line Call History window, MDC-1200 Dispatching window, MOTOTRBO Dispatching window and P25-DFSI Dispatching window while in C-Soft Runtime.

This field can contain up to 48 characters.

#### **Text ID field**

The **Text ID** field indicates the ID number entered on the radio to send the text message. This ID number also appears in the Quick Text drop down menu on the MOTOTRBO Dispatching window in C-Soft Runtime for selecting a text message to send to the radio.

This field can contain 1 to 3 digits.

#### Load File button

The Load File button is used to load a .csv file in to the current Text Message ID List window.



#### Notice!

When the .csv file is loaded, all items in the current list are overwritten.

# To load a saved text message .csv file, do the following:

- In the Text Message ID List window, click Load File.
   The Open window appears.
- 2. In the Open window, select the **file** you want to load.
- 3. Click Open.

The file is loaded, the Text Message and ID fields are populated.

#### Save File button

The Save File button is used to save the Text Message ID List to a .csv file.

# To save the Text Message ID List to a .csv file, do the following:

- 1. Click Save File.
  - The Save As window appears.
- 2. In the Filename field, enter a name.
- 3. Click Save.

The .csv file is saved in the current folder.

#### **OK** button

The **OK** button saves any changes made and closes the window.

#### **Cancel button**

The Cancel button discards any changes made and closes the window.

# 28 Edit System List window

The **Edit System List** window, shown in the Figure below, is used to create and manage units, groups, and fleets included in your FleetSync, MDC-1200, MOTOTRBO, P25-DFSI, NEXEDGE IP, or Telex-Serial system. This list can contain up to 200 systems.

#### Reference

For more information about creating a UI Element button for a FleetSync, NEXEDGE IP, MDC-1200, MOTOTRBO, Telex Serial, or P25 DFSI system:

- Refer to "FleetSync, page 255".
- Refer to "MDC-1200, page 291".
- Refer to "MOTOTRBO Radio Setup page, page 303".
- Refer to "P25-DFSI window, page 322".
- Refer to "CSSI System setup, page 538".
- Refer to "Telex-Serial Setup page" on "Telex-Serial system type, page 86".
- Refer to "Appendix H Kenwood NEXEDGE Direct IP interface, page 544".

For more information about using the dispatching window that appears when the console operator selects a FleetSync, MDC-1200, MOTOTRBO, or P25 DFSI dispatching window button in C-Soft Runtime:

- Refer to "FleetSync Dispatching window, page 256".
- Refer to "MDC-1200 Dispatching window, page 294".
- Refer to "MOTOTRBO Dispatching window, page 312".
- Refer to "P25-DFSI window, page 322".
- Refer to "CSSI System setup, page 538".

NAVIGATION: Select Edit | Edit System from the menu bar.





Figure 28.1: Edit System List Window - Blank

To create a new system, do the following:

- 1. From the File menu, select New.
- 2. From the Edit System List window, select **System | New System**. The New System window appears.
- 3. In the New System Name field enter a **name**.

A new system with empty filters and empty statuses appears in the System List field.

System names cannot contain the characters shown in the following table:



Tab. 28.5: Characters not permitted in system names

# 28.1 File menu - Edit System List

The **File** menu, in the **Edit System List** window, shown in the Figure below, is used to create new, open existing, save the current system list, or close the current window.

Available selections for this field are New, Open, Save, and Close.




Figure 28.2: File Menu - Edit System List Window

#### New menu

The **New** menu clears the current System List field display so you can create a new system list in the window.

# To create a new system list from the Edit System List window, do the following:

- 1. From the File menu, select New.
  - A prompt to save the current system appears, if one already exists.
- 2. From the System menu, select **New System**.
  - The New System window appears.
- 3. In the name field, enter a **name** for your new system.
- 4. From the System Type drop down menu, select a **system type**.

#### Note:

- If a system(s) is currently displayed in the System List field, then you are prompted to save changes to the current system before the window refreshes.
- If no system is currently displayed, selecting File | New has no affect. Click System | New System, to begin to create a new system

# Open menu

The **Open** menu opens a window to select a file from.


# To open an existing system list, do the following:

- 1. From the File menu, select **Open**.
  - NOTE: If a system is currently displayed in the System List field, then you are prompted to save changes to the current system before the window refreshes.
- 2. From the Open window, select the **system file** you want to add to the System List field. The system file is highlighted.
- Click Open.

The system is loaded in the System List field and system components are available for selection.

OR

Click **Cancel** to exit without selecting a system list file.



#### Save menu

The **Save** menu saves the currently displayed system to a file.

### To save a system list file, do the following:

- From the File menu, click Save.
   The Save As window appears.
- 2. In the name field, enter a name for the system list.  $\mathsf{OR}$ 
  - Verify the **filename** is the name you want to use.
- 3. Click Save.



# Notice!

If this is the first time you are saving the system list, click the Save button, the Save As window appears. Choose a filename and path to save the file or click the cancel button.

# Save as Default XML File check box

The **Save as Default xml File** check box indicates the selected system list file is designated as the default system list for the console position.

# To save the current system list as the default .xml file, do the following:

- 1. From the File menu, click Save.
  - The Save As window appears.
- 2. In the name field, enter a **name** for the system list.
  - Verify the **filename** is the name you want to use.
- 3. Select the Save as Default xml File check box.
- 4. Click Save.

The system list is saved as default and appears the next time the Edit System window opens. Also, this system list is used by Runtime the next time the .veg file is run.

This feature works in conjunction with the Filename field on "Filename Field".

#### Close menu

The Close menu closes the Edit System List window.

#### To close the Edit System window, do the following:

- 1. From the File Menu, select Close.
  - A C-Soft Designer window appears.
- 2. Click **Save** to save changes.

OR

Click No to discard changes and close the window.

OR

Click Cancel to discard changes.

# 28.2 Edit System List window - System Menu

The **System Menu**, shown in the Figure below, is used to select a new system, copy from an existing system, or automatically build a system with filters, groups, statuses, and units you defined earlier.

Available selections for this field are: New System, Copy System, and Auto Build System.




Figure 28.3: System Drop Down Menu - System List

# 28.2.1 New System window

The **New System** window, shown in the Figure below, is used configure the system type and name the new system.

# **New System Setup group box**

The **New System Setup** group box is used to enter a System Name and select a System Type.

#### **System Name field**

The **System Name** field is used to enter a name for your new system.

This field can contain up to 23 characters.

#### System Type drop down menu

The System Type drop down menu is used to select the type of system you want to configure.

Available selections for this field are: FleetSync, Telex-Serial, MDC-1200, MOTOTRBO, NEXEDGE-CONV, NEXEDGE-TRUNK, and P25-DFSI.




Figure 28.4: System Type Drop Down Menu - New System

To **create a new system**, do the following:

- From the Edit menu, select Edit System List.
   The Edit System List Window appears.
- From the System menu, select **New System**.The New System window appears.
- 3. In the System Name field, enter a **name** for the new system.
- 4. From the System Type drop down menu, select the **system type** (for example, FleetSync).
- 5. Click OK.

The system is added to the System List field.



#### Notice!

If the system already appears in the System List field, the copied system is added to the current system list and placed at the bottom of the list. If you are creating a new system, it is placed in the System List field with empty filters and status containers.

# **OK** button

The **OK** button creates the new system and closes the window.

#### **Cancel button**

The **Cancel** button closes the window without creating a new systems.



#### Notice!

The new system is not saved until the system file is saved.

# 28.2.2 Copy System window

The **Copy System** window, shown in the Figure below, is used to specify one system (source system) to copy to another system (destination system).

NAVIGATION: Select File | Copy System from the System List menu bar.




Figure 28.5: Copy System Window

#### Source System drop down menu

The **Source System** drop down menu is used to select an existing system to copy. The list is populated with systems defined and saved earlier. For more information, refer to "*Edit System List window, page 192*".

# **Destination System field**

The **Destination System** field is used to enter a name for the new system being created.

#### OK button

The **OK** button copies the selected source system to the newly created destination system and closes the window.

#### **Cancel button**

The Cancel button closes the window without copying any systems.

To copy a system, do the following:

- 1. From the Source System drop down menu, select a **system** to copy.
- 2. In the Destination System field, enter a **name** for the new system.
- Click OK.

The system is added to the System List field.

If systems already appear in the System List field, the copied system is added to the current system list and placed at the bottom of the list.

If you are creating a new system, it is placed in the System List field with empty filters and status containers.

### 28.2.3 System configuration

C-Soft supports Telex-Serial, FleetSync, MDC-1200, MOTOTRBO, and P25-DFSI signaling protocols. In C-Soft Designer, systems are created to help manage permissions, organize units and groups, and set up status message. In C-Soft Runtime the system is accessible through the FleetSync, MDC-1200, MOTOTRBO or P25-DFSI Dispatching windows.

For more information, refer to "FleetSync Dispatching window, page 256".

For more information, refer to "MDC-1200 Dispatching window, page 294".

For more information, refer to "MOTOTRBO Dispatching window, page 312".

For more information, refer to "P25-DFSI window, page 322".

#### To configure a system, follow these steps:

- 1. Plan your system.
- 2. Create the **system filters**, refer to "Filter List Setup window, page 177".
- 3. Set up a user ID List, refer to "User ID List window, page 179".
- 4. Set up a **group ID list**, refer to "*Group ID List window*, page 183".
- 5. Set up a **status ID list**, refer to "Status Message ID List window, page 187".
- 6. Create the **system**, refer to "Edit System List window, page 192", use filters and lists created in steps 2-5.
- 7. Set up **Per Line Parameters**, refer to "Per Line Parameters window, page 61".
- 8. Add the required **UI elements for the selected signaling protocol**, refer to "*UI Element Setup window Add button, page 404*".
- 9. Manage default system file, refer to "Filename Field on "Filename Field".

If you create more than one system file you can manage which system appears, by default, in the Edit System List window.

# 28.2.4 Auto Build System command

The **Auto Build System** from the File menu is used to automatically create a new system based on the current console configuration.

### To build a system with the Auto Build command, do the following:

- 1. From the System menu, click **New System**.
  - A New System window appears.
- 2. In the New System Name field, enter a **name** for the new system.
- 3. From the System Type drop down menu, select the **system type**.
- 4. Click OK.
  - The new system is added to the system list field with empty filters and status containers.
- 5. In the system list field, select the **check box for the new system**.
- 6. From the System window, select **Auto Build System**.
  - The new system is populated with all Filters, User IDs, Status IDs, Group IDs, and Units IDs saved while completing steps 2-5 in "*System configuration, page 198*". Only users and groups of the same system type are added to the new system.

Delete unwanted filters, IDs, and statuses, as needed.

#### **System List group box**

The **System List** group box is used to display the current system and its components.

To change the system list view, do one of the following:

- Click the expand button to view components.
- Click the collapse button to hide components.

# 28.2.4.1 System List group box

#### **System List check boxes**

The **System List** check boxes indicate the component is selected for removal. For more information, refer to "Remove From List Button" on "*System Components group box, page 200*".

# System Components check boxes

The **System Components** check boxes indicate the component is selected to add to the system list. For more information, refer to "Add to List Button" on "*System Components group box, page 200*".

# **System Components group box**




Figure 28.6: Component Type Drop Down Menu - System List

# 28.2.4.2 System Components group box

#### Component Type drop down menu

The Component Type drop down menu, shown in the Figure above, is used to select a category to pull data from.

Available selections for this field are Filters, Groups, Statuses, Text Messages and Units.

#### **Filters component**

The **Filters** component is used to select a filter. You must create filters, refer to "Filter List Setup window, page 177", before a list is available for selection.

When the filter component is selected, the filter aliases you created appear in the list.




Figure 28.7: Filter Alias List Example

#### **Groups components**

The **Groups** component is used to select groups to include in your system. You must create groups, refer to "*Group ID List window, page 183*", before a list of groups is available for selection.

When the Groups component is selected, the group aliases you created appear in the list. See the Figure below.

#### Group Alias Column

The Group Alias column displays the alias for available groups.

# - Group ID Column

The Group ID column displays the ID number used to connect to the group.

# Group Type Column

The Group Type column displays the signaling type configured for the group.




Figure 28.8: Groups Alias List

# **Statuses components**

The **Statuses** components is used to select statuses to include in your system. You must create statuses, refer to "*Status Message ID List window, page 187*", before a list is available for selection.

When the Status component is selected, the status aliases you create appear in the list. See the Figure below.

# Status Alias Column

The Status Alias column displays the alias configured for the status message.

#### - Status ID Column

The Status ID column displays the ID used to send the status message.




Figure 28.9: Status Alias List Example

#### **Text Messages**

The **Text Messages** component is used to select text messages to include in your system. You must create text messages, refer to "*Text Message ID List window, page 190*", before a list is available for selection.

When the Text message component is selected, the text messages you create appear in the list. Refer to the Figure below.

Text Message Column

The Text Message column displays the text message.

Text Message ID Column

The Text Message ID column displays the ID used to send the message.

**Technical Manual** 




Figure 28.10: Text Messages List Example

#### **Units components**

The **Units** component is used to select units (individual users) to add to either a system or an MDC-1200 group. The unit becomes a child when added to an MDC-1200 group. This helps organize users in the system list. You must create units, refer to "*User ID List window, page 179*", before a list of units is available for selection.

#### To add units to a group, do the following:

- From the Component Type drop down menu, select **Units**.
   The list of units you created appears.
- 2. Select units to add to the system list.
- 3. Select the **group's** check box to which you want to add the unit.
- 4. Click Add to List.

The selected units are added to the group.

#### Unit Alias column

The **Unit Alias** column displays the alias for each configured unit.

#### **Unit ID column**

The **Unit ID** column displays the individual ID to which the message is sent.

# **Unit Type column**

The **Unit Type** column displays the unit's signaling system type.

Figure 28.11: Units List Example

#### Add to List button

The **Add to List** button is used to add components selected in the System Component field, to the currently selected system.

# To add a component to the current system, do the following:

- 1. From the System List, select the **system** you want to add the component to.
- 2. In the System Component field, select the **items** you want to add to the system. The selected items are highlighted in the System Component field.
- 3. Click Add to List.

The highlighted components are added to the selected system in the System List field.

#### Remove From List button

The Remove From List button is used to remove components from the System List.

# To remove a component from a system list, do the following:

- From the System List, select the system component you want to remove from the system.
- 2. Click Remove From List.

The highlighted components are removed from the selected system in the System List field.

#### Select All button

The **Select All** button is used to select each component currently listed in the System Components list. When clicked, all component's check boxes are selected.

#### **Deselect All button**

The **Deselect All** button is used to deselect all components currently listed in the System Components list. When clicked, all component's check boxes are cleared.

#### Window Design Edit commands

The **Window Design Edit** commands include several standard Windows commands. The shortcut key for the command is listed next to the command on the menu. Most of the Edit menu commands can be accessed by the toolbar buttons described in the table C-Soft Designer Toolbar on "C-Soft designer window". A shortcut menu with a list of commands relevant to the selected item can also be displayed by right-clicking a user interface element.

Additional details for these commands are provided in "User interface element configuration, page 53".

# To select all elements on the window, do the following:

Click Ctrl+A.

All elements are selected.

# To **deselect all**, do the following:

- Click the console window background.

All elements are deselected.

Command	Description
Cut	Select Cut from the Edit menu to delete the selected item.  NOTE that the Cut command does not place the selected item(s) into the clipboard. Also, the Delete key on the keyboard can be used to delete design elements from the window.
Сору	Selecting Copy from the Edit menu copies the selected item(s) to the clipboard.
Paste	Select Paste from the Edit menu to insert the item(s) in the clipboard onto the console window. The clipboard is specific to the C-Soft Designer program and cannot be used to exchange data with other applications. Any item(s) in the clipboard can be pasted multiple times. Each succeeding paste appears as a cascading item off the original item pasted to allow for easy selection and placement of the object(s).
Increase Width	Select Increase Width from the Edit menu to increase the width of the selected element. When text is selected, the size of the selected text is proportionally increased.
Decrease Width	Select Decrease Width from the Edit menu to decrease the width of the selected element. When text is selected, the size of the selected text is proportionally decreased.
Increase Height	Select Increase Height from the Edit menu to increase the height of the selected element. When text is selected, the size of the selected text is proportionally increased.
Decrease Height	Select Decrease Height from the Edit menu to decrease the height of the selected element. When text is selected, the size of the selected text is proportionally decreased.
Rotate Window	Select Rotate Window form the Edit menu to rotate the popup window counter-clockwise around the selected popup button.
Move Right	Select Move Right from the Edit menu to move the selected item(s) to the right.
Move Left	Select Move Left from the Edit menu to move the selected item(s) to the left.
Move Up	Select Move Up from the Edit menu to move the selected item(s) up.

Move Down	Select Move Down from the Edit menu to move the selected item(s) down.
Open popup	Select Open popup from the Edit menu to open the popup window for the selected popup button.
Properties	Select Properties from the Edit menu to open the UI Element Setup window for the selected item, or in the case of text, a window to enter a new text string.

# Refer to

- Filter List Setup window, page 177
- Group ID List window, page 183
- Status Message ID List window, page 187
- Text Message ID List window, page 190
- User ID List window, page 179
- User interface element configuration, page 53

C-Soft 7.700 Insert menu | en 207

# 29 Insert menu

The **Insert** menu contains commands to add controls and descriptive text to the console window.



#### Notice!

This menu also appears by right-clicking in the C-Soft Designer Workspace.

Available selections for this field are:

- Add Button
- Add Clock
- Add Frame
- Add Frequency Control
- Add Keypad
- Add Popup Button
- Add Text
- Add Text Message Control
- Add Volume Control
- Add VU Meter

When a command is selected, a button or control appears in the upper-left corner of the console window.



#### Notice!

All available UI Elements can also be placed inside popup windows.

Learn how to position items on the console window, refer to "User interface element configuration, page 53".

EXAMPLE: The Figure below, shows the console workspace after Add Button is selected from the Insert menu and the newly created button is right-clicked.

#### To insert a UI Element button, do the following:

- From the Insert menu, click **Add UI Button**.

The UI button appears in the upper left corner of the console window.

 Bosch Security Systems, LLC
 Technical Manual
 2021-06 | 14 | F.01U.218.561

208 en | Insert menu C-Soft 7.700




Figure 29.1: Button Properties Flyout Menu

# 30 UI Element Setup window

# 30.1 Type page

The **Type** page, shown in the Figure below, is used to select the button's filter, function and line.




Figure 30.1: UI Element Setup for Radio Command Button - Type Page

#### Filter drop down menu

The **Filter** drop down menu is used to refine the list of all available UI Element functions to a smaller subset of options available in the UI Element Function drop down menu.

# **UI Element Function drop down menu**

The **UI Element Function** drop down menu is used to select a function type. If a Radio Command Button function type is selected, the Global Radio Button check box appears.

### Line to Associate Function With drop down menu

The Line to Associate Function With drop down menu is used to select a desired line.

# **Global Radio Button check box**

The **Global Radio Button** check box, if enabled, indicates that a Radio Command Button function type is selected in the UI Element function drop down menu.

- Select the Global Radio Button check box to send the configured radio command on any selected line.
- If the Global Radio Button check box is not selected, the configured radio command is sent on the specified line only.

# 30.2 Colors page

The **Colors** page, shown in the Figure below, is used to setup the colors and text of the Radio Command Button.




Figure 30.2: UI Element Setup for Radio Command Button - Colors Page

For information on the Button Up and Button Down color and text options, refer to the "Global Parameter Setup window, page 114".

#### **Drop Down Direction group box**

The **Drop Down Direction** group box specifies the direction the drop down list containing the list of the available users or groups is displayed relative to the button.

#### Above radio button

The **Above** radio button indicates the drop down list displays above the button.

#### **Below radio button**

The **Below** radio button indicates the drop down list displays below the button.

#### Left radio button

The **Left** radio button indicates the drop down list displays to the left of the button.

### Right radio button

The **Right** radio button indicates the drop down list displays to the right of the button.

#### **OK** button

The **OK** button saves the entries and closes the window.

# 30.3 Options page

The **Options** page, shown in the Figure below, is used to select the settings for list and scroll settings.




Figure 30.3: Options Page - UI Element Setup

### **List Settings group box**

# **Background Color drop down menu**

The **Background Color** drop down menu displays the background color of the drop down list. The background color can be changed by selecting the drop down menu to open a color palette.

#### **Text Color drop down menu**

The **Text Color** drop down menu displays the color of the text in the drop down list. The text color can be changed by selecting the drop down menu to open a color palette.

### **Entry Spacing field**

The **Entry Spacing** field determines the amount of space in pixels between individual entries in the drop down list. The value entered for Entry Spacing and the font type determine the height of the individual entries in the drop down list. The entry spacing value can be increased to allow individual entries to be selected from a touch screen.

The range for this field is 0 to 99.

The default value for this field is 8.

#### **Visible Entries field**

The **Visible Entries** field determines the number of users visible in the drop down list without scrolling.

The default value for this field is 10.

# **Scrolling Settings group box**

# Scrollbar Width field

The Scrollbar Width field determines the width in pixels of the scrollbar in the drop down list.

The default value for this field is 17.

#### Minimum Slider Size field

The **Minimum Slider Size** field determines the minimum height of the scrollbar's thumbtack slider in the drop down list. The thumbtack slider is sized proportionally based on the total number of entries in the list and the number of entries which are displayed. The minimum slider size ensures the scrollbar is always as least as large as the entered value.

The default value for this field is 17.

# 31 UI Element Functions configuration

The **UI Element Functions** drop down menu, on the Type page, contains UI Element functions for selection. Configuration for each function is described in the following section and listed alphabetically, as it appears in the drop down menu.

UI ELEMENT	FUNCTION	CROSS REFERENCE		
Add button				
Active Emergency Window	Opens the Active Emergency window to display emergency calls.	Refer to "Active Emergency Window, page 219".		
ADHB-4 Auxiliary Audio Control	Allows the console operator to toggle the playing of audio received from the ADHB-4 Gen 2's Aux In port	Refer to "ADHB-4 Auxiliary Audio Control button, page 220".		
ADHB-4 Mic Control	Allows the user to switch between two mic control inputs when the ADHB-4 is connected to C-Soft.	Refer to "ADHB-4 Mic Control, page 222".		
ADHB-4 NENA-Hold	Places a hold on the NENA line.	Refer to "ADHB-4 NENA-Hold, page 223".		
ADHB-4 NENA-Hook Control	Indicates if the NENA line is off or on-hook.	Refer to "ADHB-4 NENA-Hook Control function, page 224".		
ADHB-4 NENA-Indication	Indicates the current on or offhook state of a NENA line.	Refer to "ADHB-4 NENA- Indication, page 224".		
ADHB-4 NENA-Mute	Mutes the NENA line.	Refer to "ADHB-4 NENA-Mute, page 225".		
ADHB-4 Select speaker Control	Allows the user to turn the selected speaker on and off when the ADHB-4 when the headset is connected.	Refer to "ADHB-4 Select Speaker Control, page 225".		
Alert	Configures tones and duration for alerts.	Refer to "Alert, page 225".		
Annunciation	Allows the user to send a pre- recorded .wav file.	Refer to "Annunciation, page 228".		
Auto-Dial	Assign a string to send when the button is clicked.	Refer to "Auto-Dial, page 231".		
Backup Line	Switches to backup IP Address.	Refer to "Backup Line, page 232".		
Call List Window	Opens the Call List window to display a list of user IDs.	Refer to "Call List Window, page 233".		

Call Priority	Sets an outgoing call's priority for AIS/DMR calls.	Refer to "Call Priority button, page 238".
Call Queue Window	Allows users to view calls added to call queue.	Refer to "Call Queue window, page 239".
Crosspatch	Crosspatches two or more lines.	Refer to "Crosspatch, page 246".
Crosspatch Block	Blocks a crosspatch line from transmitting.	Refer to "Crosspatch Block, page 247".
Crosspatch Clear	Clears a specific group from a crosspatch.	Refer to "Crosspatch Clear, page 248".
Crosspatch Programmed	Crosspatches a pre-defined group.	Refer to "Crosspatch Programmed, page 248".
Crosspatch PTT	Transmits from the console to crosspatched lines.	Refer to "Crosspatch PTT, page 250".
Dial	Dials the number specified in the Keypad Module.	Refer to "Dial, page 251".
DTMF Digit	Creates a DTMF digit button.	Refer to "DTMF Digit, page 251".
Emergency ACK	Acknowledges an active emergency.	Refer to "Emergency ACK, page 252".
Emergency Clear	Stops emergency tones from playing on the console.	Refer to "Emergency Clear, page 253".
Emergency History Window	Opens the Emergency History window to view received calls.	Refer to "Emergency History Window, page 253".
Encryption	Toggles encryption on/off.	Refer to "Encryption, page 254".
Encryption Key Select	Select transmit P25-DFSI encryption option and display incoming call's encryption information.	Refer to "P25 Encryption" on page 469.
Event Logger	Displays system log events.	Refer to "Event Logger, page 254".
FleetSync	Opens a FleetSync Dispatching window.	Refer to "FleetSync, page 255".
Frequency Change	Changes to a pre-defined frequency.	Refer to "Frequency Change, page 265".
GPS Read	Reads the GPS coordinates of a radio.	Refer to "GPS Read button, page 266".

GPS Trigger Off	Turns off the trigger reading of the GPS coordinates of a radio.	Refer to "GPS Trigger Off button, page 267".
GPS Trigger On	Reads the GPS coordinates of a radio at a set periodic time.	Refer to "GPS Trigger On button, page 267".
Group Programmed	Broadcasts to a pre-defined group.	Refer to "Group Programmed, page 269".
Group Select	Creates a pre-defined group.	Refer to "Group Select, page 273".
Group Select Limited	Limits the number of lines which can be selected simultaneously.	Refer to "Group Select Limited, page 273".
Input Indication	Monitors NEO-10, or ADHB-4 activity.	Refer to "Input Indication, page 274".
Instant Recall	Plays back audio.	Refer to "Instant Recall, page 278".
Intercom	Allows console to console communication.	Refer to "Intercom, page 281".
Intercom-Per Line	Allows pre-defined console to console communication.	Refer to "Intercom-Per Line, page 281".
Knox Digit	Creates a Knox digit button.	Refer to "Knox Digit, page 282".
Instant Recall - Last Call Button	Allows console operator to play back audio from last received call.	Refer to "Instant Recall - Last Call button, page 280".
Launch Application	Opens specified application.	Refer to "Launch Application, page 282".
Manual Call List Window	Opens the Manual Call List window.	Refer to "Manual Call List, page 285".
Marker Tone	Keys and sends a tone burst to a pre-defined radio channel.	Refer to " <i>Marker Tone, page 287</i> ".
MDC-1200 Window	Opens the MDC-1200 Dispatching window.	Refer to " <i>MDC-1200, page</i> 291".
Monitor	Sends packets to open squelch or ignore CTCSS tones.	Refer to "Monitor, page 303".
MOTOTRBO Window	Opens the MOTOTRBO Dispatching window.	Refer to "MOTOTRBO Window".
Mute Group	Mutes audio on a pre-defined group.	Refer to " <i>Mute Group, page 319</i> ".

Mute Main	Mutes all currently selected lines.	Refer to " <i>Mute Main, page</i> 320".
Mute-Per line	Toggles mute on a pre- defined line.	Refer to "Mute-Per Line, page 321".
P25-DFSI Window	Opens the P25-DFSI Dispatching Window.	Refer to "P25-DFSI window, page 322".
Page	Pages a specific line and frequency.	Refer to " <i>Page, page 324</i> ".
Page Cancel	Cancels an active page.	Refer to "Page Cancel, page 328".
Page Manual Entry	Sends a page to a pager number entered by the console operator.	Refer to "Page Manual Entry, page 328".
Page Send	Sends a group of pages, when stacked.	Refer to "Page Send, page 331".
Page Stack	Stacks pages.	Refer to "Page Stack, page 332".
Page Stack Programmed	Stacks a pre-defined group of pages.	Refer to "Page Stack Programmed, page 333".
Per Line Call History	Opens the Per line Call History window.	Refer to "Per Line Call History, page 335".
Phone Flashhook	Flashhooks a phone line.	Refer to "Phone-Flashhook, page 343".
PTT Group Call	Transmits audio to a group of radios.	Refer to "PTT-Group Call, page 345".
PTT -Main	Transmits audio to all selected lines.	Refer to " <i>PTT-Main, page</i> 346".
PTT Per Line	Keys a pre-defined line.	Refer to " <i>PTT-Per Line, page 346</i> ".
PTT Private Call	Transmits audio to a single radio.	Refer to "PTT-Private Call, page 347".
PTT - Talk Back	Transmits to the last line that received audio.	Refer to "PTT-Talk Back, page 348".
Radio Call Alert	Sends a Call alert to a Radio.	Refer to "Radio Call Alert, page 348".
Radio Call Type	Selects between Broadcast and Conference Call Types. (NEXEDGE IP Only).	Refer to "Radio Call Type, page 349".
Radio Check	Checks if a Radio is on/off.	Refer to "Radio Check, page 349".

Radio Disable	Disables a Radio.	Refer to " <i>Radio Disable, page</i> 349".	
Radio Enable	Enables a Radio.	Refer to " <i>Radio Enable, page 350</i> ".	
Radio Regroup	Temporarily reassigns Talkgroup.	Refer to " <i>Radio Regroup,</i> page 350".	
Radio Remote Monitor	Activates PTT on remote radio to monitor.	Refer to " <i>Radio Remote Monitor, page 351</i> ".	
Radio Ungroup	Resets Radio Talkgroup.	Refer to " <i>Radio Ungroup,</i> page 351".	
Radio Select Call	Sends a Select Call to a radio.	Refer to " <i>Radio Select Call,</i> page 353".	
Radio Status	Sends a Status Message to a radio.	Refer to " <i>Radio Status, page 352</i> ".	
Radio Status Request	Requests the Status of a Radio.	Refer to "Radio Status Request, page 352".	
Radio On/Offhook	Toggles radio on/off periodically to keep the radio active.	Refer to "Radio-On/Offhook, page 353".	
Relay Control Button	Controls an ADHB-4 or NEO-10 relay.	Refer to " <i>Relay Control</i> Button, page 354".	
RX AII	Disengages mute on selected lines.	Refer to "RX All, page 363".	
Scan	Scans the selected line.	Refer to "Scan, page 364".	
Scrambler/Encrypt Key Select	Selects active NEXEDGE encryption key	Refer to "Kenwood NEXEDGE Direct IP Interface" on page 503.	
Select	Selects a line.	Refer to "Select, page 364".	
SIP Call Control	Opens the SIP Calls window.	Refer to "SIP Call Control, page 368".	
Stack Status Programmed	Opens the Status Programmed window.	Refer to "Status Stack Programmed, page 396".	
Stack Status Window	Opens the Stack Status window.	Refer to "Status Stack window, page 398".	
Supervisor	Seizes control of a line or group of lines.	Refer to "Supervisor, page 401".	
Talk Around	Toggles the serial controlled radio that supports talk around feature on/off.	Refer to " <i>Talk Around button,</i> page 402".	

Text Button	Displays text on the console.	Refer to " <i>Text button, page</i>
TOXE Button	Displays text on the console.	402".
TX All	Selects all lines for TX.	Refer to "TX All, page 403".
Add Clock		
Clock	Displays the current time on the console.	Refer to "UI Element Setup window - Add Clock, page 412".
Add Frame		
Frame	Displays a configurable frame on the console.	Refer to "UI Element Setup window - Add Frame, page 416".
Add Frequency Control		
Frequency Control	Displays a customized frequency control on the console.	Refer to "UI Element Setup window - Add Frequency Control, page 418".
Add Keypad		
Keypad	Provides access to an on- screen keypad, allowing easy access to contacts, DTMF keypad, and operation history.	Refer to "UI Element Setup window - Add Keypad, page 425".
Add Popup Button		
Add Popup Button	Displays a Popup button.	Refer to "UI Element Setup window - Add Popup Button, page 439".
Popup Global Call History	Opens the Global Call History display.	Refer to "Popup Global Call History, page 444".
Popup Webpage	Opens a window that displays a pre-defined webpage.	Refer to "Popup Webpage, page 442".
Popup Window Control	Configures popup window controls	Refer to "Popup Window Setup page, page 440".
Add Text		
Font Window	Displays customizable text lines to console design.	Refer to "The Done button is used to close the window".
Add Text Message Control		
Text Message	Provides an interface for sending and receiving text messages.	Refer to "UI Element Setup window - Add Text Message Control, page 450".
Add Volume Control		

Volume-ADHB-4 NENA	Controls the NENA volume on an ADHB-4.	Refer to "Volume-NENA" on <i>Type page, page 453.</i>				
Volume-Auxiliary Track Left	Controls the left channel volume of the auxiliary audio when operating with an ADHB-4 Gen 2.	Refer to "Volume-Auxiliary Track Left" on <i>Type page,</i> page 453.				
Volume-Auxiliary Track Right	Controls the right channel volume of the auxiliary audio when operating with an ADHB-4 Gen 2.	Refer to "Volume-Auxiliary Track Right" on <i>Type page,</i> page 453.				
Volume-Master Select	Controls the volume on all select lines.	Refer to "Volume-Master Select" on <i>Type page, page</i> <i>453</i> .				
Volume-Master Unselect	Controls the volume on all unselected lines.	Refer to "Volume-Master Unselect" on <i>Type page, page</i> 453.				
Volume-Per Line	Controls volume per line.	Refer to "Volume-Per Line" on <i>Type page, page 453</i> .				
Add VU Meter						
VU Meter	Control Displays the volume level of a particular line.	Refer to "UI Element Setup window - Add VU Meter, page 457".				

Tab. 31.6: UI elements

#### Refer to

- UI Element Setup window - Add Text, page 449

# 31.1 Active Emergency Window

The **Active Emergency Window**, shown in the Figure below, function displays a list of current active emergencies.

When clicked in the C-Soft Runtime program, the Active Emergency window automatically appears, and the Select button on the line receiving the emergency blinks. The Active Emergency window is also accessible by clicking the Active Emergency button. For more information, refer to "Emergency Button" on page 282 and to "Emergency Type" on page 284.

When an emergency call is received, the Active Emergency window automatically appears, and the Select button on the line receiving the emergency blinks. The Active Emergency window is also accessible by clicking the Active Emergency button. One of two actions can be taken on an emergency call listed in the window:

 Clear the emergency - By clearing the emergency, the emergency entry turns orange and the tones stop. Pressing the Clear button clears all Active Emergencies in the list.

Acknowledge the emergency - By acknowledging the emergency, the selected emergency entry is removed from the Active Emergency window. The user can acknowledge only one emergency at a time. This can be accomplished without first clearing the emergency. For supported radio protocol the emergency acknowledge message is sent to the individual radio that declared the emergency.




Figure 31.1: Active Emergency Window Setup

#### Behavior group box

#### Automatically Populate Keypad On Acknowledgement check box

The Automatically Populate Keypad On Acknowledgement check box indicates when the Active Emergency Window's ACK button is pressed, the keypad's destination is set to a selected Emergency entry. Since the keypad's contents are context specific to the currently selected line, the keypad only updates if the currently selected line's Signaling/System type match those of the selected Emergency entry.

#### To add an Active Emergency button, do the following:

- From the Insert menu, select Add UI Button. A None button appears on the console window.
- 2. Right-click the None button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- From the UI Element drop down menu, select Active Emergency Window. The Active Emergency Window Setup tab appears.
- Click the Active Emergency Window Setup tab. The Active Emergency Window Setup page appears.
- 6. Select the Automatically populate keypad on acknowledgement check box, if desired.
- Click OK. 7.

The button color changes and Active Emergency appears on the button.

#### 31.2 ADHB-4 Auxiliary Audio Control button



#### Notice!

Unless specified, the ADHB-4 and the ADHB-4 Gen 2 function the same.

The **ADHB-4 Auxiliary Audio Control** button allows the console operator to toggle the playing of audio received from the ADHB-4 Gen 2's Aux In port. When the button is in the up state, the auxiliary audio is muted. When the button is in the down state, the selected auxiliary audio channel is played in the designated speaker. The button can be configured by the user to either the left or right track audio.

The ADHB-4 Auxiliary Audio Control buttons are muted when a Main Mute button is pressed and un-muted when an RX All button is pressed. The ADHB-4 Auxiliary Audio Control buttons can be added to a crosspatch, with the limitation of one ADHB-4 Auxiliary Audio Control button per crosspatch.


#### **ADHB-4 Auxiliary Audio Setup page**

The ADHB-4 Auxiliary Audio Setup page is used to setup which auxiliary track to use.

#### To open the ADHB-4 Auxiliary Audio Setup page, do the following:

- 1. From the Insert menu, select **Add UI Button**.
  - A None button appears on the console window.
- 2. Right-click the **None** button.
  - A shortcut menu appears.
- From the shortcut menu, select **Properties**.
   The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select **ADHB-4 Auxiliary Audio Control**. The Auxiliary Audio Setup tab appears.
- 5. Click the ADHB-4 Auxiliary Audio Setup tab.

The ADHB-4 Auxiliary Audio Setup page appears.



#### **Auxiliary Track selection**

#### Left radio button

The **Left** radio button indicates the ADHB-4 Auxiliary Audio Control button is controlling the Auxiliary Audio Left track.

#### Right radio button

The **Right** radio button indicates the ADHB-4 Auxiliary Audio Control button is controlling the Auxiliary Audio Right track.

#### 31.3 ADHB-4 Mic Control

The **ADHB-4 Mic Control** allows the user to switch between two microphone control inputs when the ADHB-4 is connected to C-Soft.



#### Notice!

The microphone source selected for the up state of the button is active when the button is in the up position; conversely, the microphone source selected for the down state is active when the button is depressed.

#### **ADHB-4 Mic Control Button Setup page**

When the ADHB-4 Mic Control is selected from the UI Element Function drop down menu, the **ADHB-4 Mic Control Button Setup** page appears.

The ADHB-4 Control button can operate in one of two behaviors: Toggle or Selectable.

When configured as a toggle button, C-soft uses the ADHB-4 Control button's up or down state to determine the active ADHB-4 input source. Upon pressing the button, C-Soft toggles between sources configured for the Up and Down states. Each state may select one of the following:

- Controller the headset/mic input on the main ADHB-4 unit.
- RHB1 remote headset box 1.
- RHB2 remote headset box 2.
- Desk Mic.

When configured as a selectable button, the ADHB-4 Mic Control Button is displayed as a Split Button. Pressing the button displays a drop down list of options, allowing the user to select which mic source to use.

The list is configurable by selecting the check box next to each option in the list of Available Options.




Figure 31.2: ADHB-4 Mic Control Button Setup

#### To add an ADHB-4 Mic Control button, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the **None** button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element Function drop down menu, select **ADHB-4 Mic Control**.
- The ADHB-4 Mic Control Button Setup tab appears.

  5. Click on the **ADHB-4 Mic Control Button Setup tab**.
- 6. From the ADHB-Mic Toggle States drop down menu, select **one** of the following for either or the up and/or down state:
  - Controller the headset/mic input on the main ADHB-4 Unit.
  - RHB1 remote headset box 1
  - RHB2 remote headset box 2
  - Desk Mic
- 7. Click OK.

The button color changes and ADHB-4 Mic Control appears on the button.

#### 31.4 ADHB-4 NENA-Hold

The **ADHB-4 NENA-Hold** function allows the console operator to place a NENA (National Emergency Number Association) audio line connected to an ADHB-4, on hold. If the NENA is on hold, the TX audio is not sent to the NENA and RX audio is routed to a specified speaker. Otherwise the TX and RX are sent from the NENA line.

To add a ADHB-4 NENA-Hold button, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the None button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select ADHB-4 NENA-Hold.
- 5. Click OK.

The button changes color and NENA Hold appears on the button.

# 31.5 ADHB-4 NENA-Hook Control function

The **ADHB-4 NENA-Hook Control** function allows the console operator to change the NENA phone line logic that is connected to an ADHB-4, on or off hook.

#### To add ADHB-4 NENA-Hook Control button, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the **None** button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select ADHB-4 NENA-Hook Control.
- 5. Click OK.

The button changes color and NENA On Hook Control appears on the button

#### 31.6 ADHB-4 NENA-Indication

The **ADHB-4 NENA-Indication** function indicates the current on- or offhook state of a NENA phone line connected to an ADHB-4. A speaker icon appears on the button to indicate audio routing for the NENA line.



#### Notice!

If the NENA Mute button is clicked (for example, line is muted) the mute icon appears on the NENA Indication button.

#### To add NENA-Indication button, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the **None** button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select ADHB-4 NENA-Indication.
- 5. Click OK.

The button changes color and NENA Indication appears on the button.

#### 31.7 ADHB-4 NENA-Mute

The **ADHB-4 NENA-Mute** function allows the console operator to mute the RX audio of a NENA phone line.

#### To add a NENA-Mute button, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the None button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select ADHB-4 NENA-Mute.
- 5. Click OK.

The button changes color and NENA Mute appears on the button.

# 31.8 ADHB-4 Select Speaker Control

The **ADHB-4 Select Speaker Control** allows the user to turn the selected speaker on and off when the headset is connected.

#### To add an ADHB-4 Select Speaker Control button, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the None button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select Properties.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select ADHB-4 Select Speaker Control.
- 5. Click OK.

The button color changes and Speaker Off appears on the button.

#### **31.9** Alert

The **Alert** function allows the console operator to send a tone to all selected lines.

In C-Soft Runtime, if PTT is not active when an Alert button is pressed, the PTT button is automatically activated to key the remote radios before the tones are generated.

#### **Alert Setup page**

When the Alert function is selected from the UI Element Function drop down menu, the **Alert Setup** page appears. Refer to the Figure below.




Figure 31.3: Alert Setup Page - UI Element Setup

#### Tone Type group box

The **Tone Type** group box identifies the type of tone to play. When a selection is made, the fields necessary to enter the setup information for the tone type are enabled on the page.

#### **Tone radio button**

The **Tone** radio button indicates a single steady tone is used as an alert tone.

#### To add a tone alert button, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the None button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select Alert.
  - The Alert Setup tab appears.
- 5. Click the **Alert Setup** tab.
  - The Alert Setup page appears.
- 6. In the Tone Type group box, select the **Tone** radio button.
- 7. In the Low Frequency field, enter the **frequency** (in Hz).
- 8. In the Tone Level field, enter the **tone level** (in dB).
- 9. Click OK.

The button changes color and Alert appears on the button.

#### **Pulsed Tone radio button**

The **Pulsed Tone** radio button indicates a pulsed tone is used as an alert tone.

#### To add a Pulsed Tone alert button, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the **None** button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.

The UI Element Setup window appears.

- 4. From the UI Element drop down menu, select **Alert**.
  - The Alert Setup tab appears.
- 5. Click the **Alert Setup** tab.
  - The Alert Setup page appears.
- 6. From the Tone Type group box, select the **Pulsed Tone** radio button.
- 7. In the Low Frequency field, enter the **frequency** (in Hz).
- 8. In the Low/On Duration field enter the **duration** (in ms).
- 9. In the Hi/Off Duration field, enter the duration in ms.
- 10. From the Tone Level field, enter the **tone level** (in dB).
- 11. Click **OK**.

The button changes color and Alert appears on the button.

#### Hi-Lo radio button

The **Hi-Lo** radio button indicates a Hi-Lo warble is used as an alert tone.

#### To add a Hi-Lo alert button, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the **None** button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select Alert.
  - The Alert Setup tab appears.
- 5. Click the Alert Setup tab.
  - The Alert Setup page appears.
- 6. From the Tone Type group box, select the **Hi-Lo** radio button.
- 7. In the Low Frequency field, enter the **frequency** (in Hz).
- 8. In the Low/On Duration field, enter a duration (in ms).
- 9. In the Hi Frequency field, enter a frequency (in Hz).
- 10. In the Hi/Off Duration field, enter the **duration** (in ms).
- 11. From the Tone Level field, enter the **tone level** (in dB).
- 12. Click **OK**.

The button changes color and Alert appears on the button.

#### Low Frequency field

The **Low Frequency** field identifies the frequency of the low tones sent when the button is pressed.

The range for this field is 0 to 3000Hz.

#### Low/On Duration field

The Low/On Duration field identifies the duration at which the frequency is played.

The range for this field is 0 to 2000ms.

# Hi Frequency field

The **Hi Frequency** field identifies the frequency of the high tones sent when the button is pressed.

The range for this field is 0 to 3000Hz.

### **Hi/Off Duration field**

The **Hi/Off Duration** field identifies the duration at which the frequency is stopped.

The range for this field is 0 to 2000ms.

#### **Tone Level field**

The **Tone Level** field identifies the relative change allowable in the level of the tone generated.

The range for this field is -30 to 0dB.

### 31.10 Annunciation

The **Annunciation** function allows the console operator to send a pre-recorded .wav file to radio users. When clicked the .wav file waits for all console TX and RX traffic to clear before sending the recording. If multiple annunciation buttons are clicked, the .wav files are sent in the order they were clicked.

#### **Annunciation Setup page**

When the Annunciation function is selected from the UI Element drop down menu the **Annunciation Setup** page appears.




Figure 31.4: Annunciation Setup Page - UI Element Setup

#### **Annunciation Setup group box**

#### File Path field

The **File Path** field is used to specify the path for the .wav file recording. When preparing the .wav file, ensure the file is saved with a 16-bit, 8.000kHz sample rate.



#### Notice!

We recommend using Audacity, an open source software application (http://audacity.sourceforge.net/), to make changes to your .wav files.

#### **Browse button**

The **Browse** button is used to browse for and select the .wav file to be used.

#### Level field

The **Level** field indicates the relative level change, in dB, for the .wav file.

The range for this field is -30dB to 10dB.

#### Send on Selected Lines check box

The **Send on Selected** check box indicates the console operator can select which line(s) the .way file can be sent on.

If unselected, the .wav file is sent only on the line associated to the UI Element button currently being configured. Otherwise, the .wav file is sent to all selected lines.

#### Frequency drop down menu

The **Frequency** drop down menu is used to select the frequency for the Annunciation. This field contains all the frequencies defined for "Frequency Parameters window, page 67".

#### Stay Selected After Annunciation check box

The Stay Selected After Annunciation check box indicates the line used for the annunciation is selected after the annunciation ends and unselect all other lines.



#### Notice!

This setting does not change the Select state of the line when the line is in a crosspatch.

#### Relay Setup group box

#### Active Relay With Annunciation check box

The Active Relay With Annunciation check box indicates a configured relay activates when an annunciation is sent.

#### Relay Destination group box

The Relay Destination radio buttons identify the relay to be controlled. When a selection is made, the fields necessary to enter the setup information for the relay are enabled.

#### ADHB-4 Settings group box

The ADHB-4 Settings radio buttons identify which ADHB-4 relay is activated when the Annunciation is sent.

#### None radio button

The **None** radio button indicates none of the ADHB-4 relays is activated.

#### Relay 1 radio button

The **Relay1** radio button indicates the first relay in the ADHB-4 is being controlled.

#### Relay 2 radio button

The Relay 2 radio button indicates the second relay in the ADHB-4 is being controlled.

#### **NEO Settings group box**

The **NEO Settings** field identifies the IP Address and the relay, if any, for the NEO-10.

#### IP field

The IP field identifies the IP Address of the NEO-10.

#### Relay drop down menu

The **Relay** drop down menu is used to select the desired relay.

Available selections for this field are None, Port 1, Port 2, Port 3, Port 4, Port 5, Port 6, Port 7, Port 8, Port 9 and Port 10.

#### Active Duration field

The Active Duration field is used to enter the length of time, in ms, the relay remains active from the start of the Annunciation.

The range for this field is 300-3000ms.

#### 31.11 Auto-Dial

The Auto-Dial function allows the console operator to quickly dial a pre-defined number.

#### **Auto-Dial String Entry page**

When the **Auto-Dial String Entry** function is selected from the UI Element drop down menu the Auto-Dial String Entry page appears. Refer to the Figure below.




Figure 31.5: Auto-Dial String Entry Page - UI Element Setup

#### To add an Auto-Dial button, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the None button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select Auto-Dial.
  - The Auto-Dial String Entry tab appears.
- 5. Click the **Auto-Dial String Entry** tab.
  - The Auto-Dial String Entry page appears.
- 6. In the Enter Dial String field, enter the **Auto-Dial number** for the button.
  - NOTE: Commas entered in this field add a 2 second delay.
- 7. Click OK.

The color of the button changes and Dial appears on the button.

#### **Enter Dial String field**

The **Enter Dial String** field indicates the number to dial when the button is clicked in C-Soft Runtime.

This field can contain up to 16 characters.

#### **Tone Standard group box**

#### **DTMF** radio button

The **DTMF** radio button indicates DTMF tones are transmitted to place the call.

#### **Knox radio button**

The **Knox** radio button indicates Knox tones are transmitted to place the call.

# 31.12 Backup Line

The **Backup Line** function forces the line to route packets to and from either the primary or secondary radio interface. If the ping routine fails to receive a reply from the Base Radio IP, it automatically switches to the Backup IP settings specified in the Per Line Parameters window.

In C-Soft Runtime, the button changes to show the current condition. If there is a failure on both the primary and secondary radio interfaces, LINK FAIL is displayed on the Select button.



#### Notice!

When the Backup Line function is selected, a line must be selected from the Line to Associate Function With drop down menu.

#### **Backup Control Line Setup page**

When the Backup Line function is selected from the UI Element drop down menu, the **Backup Control Line Setup** page appears. Refer to the Figure below.




Figure 31.6: Backup Control Line Setup Page - UI Element Setup

#### Allow User to Switch Primary/Backup check box

The **Allow User to Switch Primary/Backup** check box indicates the console operator is allowed to manually switch between the primary and secondary radios. Otherwise, the button functions as an indicator only, and the console operator cannot control the radio in use.



#### Notice!

The C-Soft program needs to be restarted to reset from the backup radio to the primary radio.

#### To add a Backup Line button, do the following:

- From the Insert menu, select Add UI Button.
   A None button appears on the console window.
- Right-click the **None** button.A shortcut menu appears.
- From the shortcut menu, select **Properties**.
   The UI Element Setup window appears.

- 4. From the UI Element drop down menu, select **Backup Line**.
  - The Backup Control Line Setup tab appears.
- 5. From the Line to Associate Function With drop down menu, select the **line** to setup the backup control.
- 6. Click the Backup Control Line Setup tab.
  - The Backup Control Line Setup page appears.
- 7. Select the Allow User To Switch Primary/Backup check box, if desired.
- 8. Click OK.

The button changes color and Primary appears on the button.

#### 31.13 Call List Window

The Call List Window function creates a button used to view a list of User IDs.

In C-Soft Runtime, if the console operator clicks the Call List button, the Call List window for the selected line, shown in the Figure below, appears. From this window, the user can make outgoing calls and send status messages based upon programming setup. The Call List displays generic, iDEN, and phone type users and groups.

#### To add a call list button, do the following:

- From the Insert menu, select Add UI Button.
   A None button appears on the console window.
- 2. Right-click the **None** button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select Call List.
- 5. Click **OK**.

The color of the button changes and Call List appears on the button.

#### 31.13.1 Call List window

The **Call List** window, shown in the Figure below, is used to view and select from a list of IDs. Default messages are configured by the console administrator and assigned to the buttons on the bottom of the window.

Figure 31.7: Call List Window - C-Soft Runtime

#### ID Type drop down menu

The **ID Type** drop down menu is used to select a sort type for the list.

Available selections for this field are:

- Alias Select Alias from the menu to sort the User IDs by alias in ascending alphabetical order.
- ID Select ID from the menu to sort the User IDs by ID number in ascending numerical order. The selected ID type determines the User ID drop down menu entries.

#### User ID drop down menu

The **User ID** drop down menu is used to select a user ID for placing a call. Either the alias or the ID number appears in the menu depending on the ID Type drop down menu selection. Alternatively, the status can be selected from the list at the bottom of the window.

#### Filters drop down menu

The **Filters** drop down menu is used to select a filter from the list. When selected, the list populates with users assigned to the filter by the console administrator.

Available selections for this field are:

- No Filter Displays a complete list of user IDs.
- User-defined System Filter Displays only user IDs belonging to the filter.

#### Status field

The **Status** field indicates the currently selected status. If no status is selected, No Status appears in the field.

#### Set Status button

The **Set Status** button is used to select a status to send. When clicked, the Status List window appears. Refer to the Figure below.

#### To view the Call List, do the following:

- 1. Click Call List.
- 2. From the Filter drop down menu, select a **filter** to sort the list.

OR

Select No Filter.

#### To select a user ID to place a call to, do the following:

- 1. Select the **line** you want to place the call from.
- 2. Click Call List.

The Call List window appears.

3. From the Filter drop down menu, select a **filter** to sort the list.

OR

Select No Filter.

4. From the User ID drop down menu, select an **alias** or **user ID**.

The selected user ID in the call list is highlighted.

5. Click Done.

If a password is required to send the status ID, the Password Entry window appears.

6. Using the monitor keypad or your keyboard, enter the **password**.

For each character you enter, asterisks fill the empty field at the top of the window.

OR

If the password is unknown, click **Cancel**.

The Password Window closes.

7. Click Done.

The Password Entry and Status List windows close and the selected status's alias appears in the Status Message field or, if the password is incorrectly entered, an error message appears.

#### To send a status ID from the Call List window in C-Soft Runtime, do the following:

- 1. While in C-Soft Runtime, select the **line** you want to place the call from.
- 2. Select a Call List button.

The Call List window appears.

3. From the ID Type drop down menu, select an alias or an ID number.

The selected User ID in the User List is highlighted.

4. Select **Set Status**.

The Status List window appears.

5. From the ID type drop down menu, sort the **list** by alias or status ID number.

The list is sorted depending on the selected type.

6. From the Status drop down menu, select a **status ID** to send.

The selected status ID is highlighted.

OR

From the status ID list, select a status ID to send.

The selected status ID is highlighted.

7. Click **Done**.

If a password is required to send the status ID, the Password Entry window appears.

8. Using the monitor keypad or your keyboard, enter the **password**.

For each character you enter, asterisks fill the empty field at the top of the window.

9. Click Enter.

The Password Entry window closes and the selected status's alias appears in the Status Message field. If the password is incorrectly entered, an error message appears. OR

Click Cancel.

10. Click a Call button to place the call.

The message is sent and a confirmation or error message appears in the dispatching status bar.

11. Click **Done** to close the window.

#### Call (1-10) buttons

The **Call (1-10)** buttons are used to place user-defined calls configured in the *5-6 Tone/DTMF ANI system type*, page 75. The labels configured on the 5/6 Tone/DTMF ANI Setup page appear on these buttons in the Call List window.



#### Notice!

The Call1-Call10 buttons may have different labels assigned by the console administrator.

#### To place a call from the Call List window, do the following:

- Select an ID from the list.
  - Available call buttons on the bottom of the window become active.
- 2. Select a call button.

The call is placed.

#### **Done button**

The **Done** button is used to close the Call List window.

#### 31.13.2 Status List window

The **Status List** window, shown in the Figure below, is used to select from a list of preprogrammed status IDs. When a status ID is selected and the window is closed, the selected status appears in the Status field located on the Status List window.




Figure 31.8: Status List Window

#### ID Type drop down menu

The **ID Type** drop down menu is used to select a sort type for the list.


Available selections for this field are:

- Alias Selecting Alias from the menu, sorts the status IDs by alias in alphabetical order.
- Status ID Selecting ID from the menu, sorts the status IDs by ID number in ascending numerical order.

#### Status drop down menu

The **Status** drop down menu is used to select the status to send. Either the alias or the ID number appear in the list and is determined by the selection in the ID Type drop down menu. Alternatively, the status can be selected from the list at the bottom of the window.

Refer to Call 1-10 Buttons on the "Call List window, page 233" or to "Per Line Call History Setup Page" on "Per Line Call History, page 335" to continue with sending a message to the selected ID.



#### **Cancel button**

The Cancel button discards any changes made and closes the window.

#### **Enter button**

The **Enter** button is used to close the Status List window.

#### Refer to

- Call List window, page 233

# 31.14 Call Priority button

The **Call Priority** button is used to set the transmit call priority for calls on AIS lines sent from the consoles.

There are five levels of priority:

- Off (0)
- Low (1)
- Normal (2)
- High (3)
- Emergency generates an emergency response on the radios

By default, all calls are set to a priority of Off (0).


#### 31.15 **Call Queue window**

The **Call Queue** window contains a list of calls that require a response from the dispatcher. The status of individual calls is updated across all consoles as dispatchers answer and complete calls.

Signalling/ Call Type	Call Alert	Group Call	Private Call	Select Call	Group Status
5/6 Tone, DTMF	N/A	Yes	N/A	Yes	N/A
Fleet Sync	N/A	Yes	Yes	Yes	N/A
Telex-Serial <sup>a</sup>	Yes <sup>a</sup>	Yes <sup>a</sup>	Yes <sup>a</sup>	Yes <sup>a</sup>	N/A
MDC-1200	Yes	Yes	Yes	N/A	N/A
MOTOTRBO	Yes	Yes	Yes	N/A	N/A
NEXEDGE Direct IP	Yes	Yes	Yes	Yes	Yes
AIS	Yes	Yes	Yes	N/A	N/A
Telex- Enhanced ANI	Yes	Yes	Yes	Yes	N/A

a. support varies based on attached mobile

The Call Queue Window Setup page is used to configure the Call Queue Window.



#### 31.15.1 Call Queue Setup page

#### 31.15.1.1 Event Selection group box

The **Event Selection** group box allows users to select call types to be added to the call queue window. When the C-Soft console receives one of the selected radio call events, an entry is created in the call queue window.

#### Call Alert check box

The Call Alert check box indicates call alerts can be added to the call queue window.

#### **Group Call check box**

The Group Call check box indicates group calls can be added to the call queue window.

#### Private and Selective Call check box

The **Private Call** check box indicates private and selective calls can be added to the call queue window.

#### **Group Statuses check box**

The **Group Statuses** check box indicates group statuses can be added to the call queue window.

#### 31.15.1.2 Behavior group box

#### Automatically Populate Keypad on Answer check box

The **Automatically Populate Keypad on Answer** check box indicates the user ID information for a call entry is automatically added to the User Entry field in the Keypad control when the call is answered. A call is answered when the Answer button is clicked.

#### **Play Audible Alert for Waiting Entries**

The **Play Audible Alert for Waiting Entries** check box indicates an audible alert is played on Speaker 1 when receiving a new call queue event. The audible alert serves as a notification, and is played each time a call event is added to the Call Queue Window.

#### **Remove Completed Entries from Window**

The **Remove Completed Entries from Window** check box indicates call entries with a call state of Completed are removed from the Call Queue window. A Call entry is removed from the window once the Clear button is clicked.

#### 31.15.1.3 Event Priority group box

The **Event Priority** group box is used to configure how call queue events are ordered in the Call Queue Window.

#### Time Event Received radio button

The **Time Event Received** radio button indicates the incoming call events are sorted by the time the event was received, with the most recently received events being displayed at the top of the window.

#### **Event Status ID - Ascending**

The **Event Status ID - Ascending** radio button indicates incoming call events are sorted by the value of the event's Status ID. An event with a lower numbered status ID will be displayed above an event with a higher status ID (i.e. Status #1 will be shown above Status #2).

#### **Event Status ID - Descending**

The **Event Status ID - Descending** radio button indicates incoming call events are sorted by the value of the event's Status ID. An event with a higher numbered status ID will be displayed above an event with a higher status ID (i.e. Status #2 will be shown above Status #1).

#### 31.15.1.4 Window Appearance group box

#### **Maximum Number of Visible Entries field**

The **Maximum Number of Visible Entries** field is used to enter and identify the number of call entries saved in the call queue window. Once the maximum number has been reached the last call entry is removed from the end of the list.

The range for this field is 1 to 50.

#### **Set Font button**

The **Set Font** button, when selected, opens the Font window. The Font window is used to select a font type and font size to use for the call queue window. When the format is changed, a preview of the text appears in the Sample field.





Figure 31.9: Font Window

#### 31.15.2 Call Queue Columns page

The Call Queue Window Setup page is used to configure which columns are visible in the Call Queue Window.



#### **Column Setup group box**

The Column Setup group box allows users to determine which columns are visible in the Call Queue window. The respective column will be displayed in the Call Queue window if checked and hidden if unchecked.

#### Call State check box

The Call State check box is used to add a call state column to the Call Queue window.

The possible call states are:

- Waiting
- Processing
- Complete

#### **Console ID check box**

The Console ID check box is used to add a console ID column to the Call Queue window.

#### Date check box

The Date check box is used to add a date column to the Call Queue window.

#### Frequency check box

The Frequency check box is used to add a frequency column to the Call Queue window.

#### Line Name check box

The Line Name check box is used to add a line name column to the Call Queue window.

#### Status check box

The **Status** check box is used to add a status column to the Call Queue window.

#### Time check box

The **Time** check box is used to add a time column to the Call Queue window.

#### User ID check box

The User ID check box is used to add a user ID column to the Call Queue window.


### 31.15.3 Group Statuses page

The **Group Statuses** page is used to configure which statuses trigger an entry in the Call Queue Window. The Group Statuses page is visible when the Group Statuses check box is checked in the Event Selection group box in the Call Queue Window Setup page.



#### Notice!

A maximum of 20 statuses can be configured for the Call Queue Window.



#### Available field

The **Available** field displays all statuses in the system. This list is used to select a status to add to the Enabled field.

#### **Enabled field**

The Enabled field displays statuses which will trigger an entry in the Call Queue Window.

#### **Move Right button**

The Arrow Right button is used to move statuses from the Available field to the Enabled field.

#### **Move Left button**

The Arrow Left button is used to move statuses from the Enabled field to the Available field.

#### 31.15.4 Call Queue window

The **Call Queue** window is used to view calls added to the call queue. In C-Soft Runtime, click the Call Queue Window button to open the Call Queue window. This window contains a Call Queue list. You can resize and move this window, as needed.




Figure 31.10: Call Queue Window

#### Answer button

The **Answer** button is used to change the call entry status from Waiting to Processing.

#### **Clear button**

The **Clear** button is used to change the call entry status from Processing to Complete.

#### Done button

The **Done** button is used to close the Call Queue window.

To use the Call Queue Window in C-Soft Runtime, do the following:

# Date Time Channel Console ID User ID Call State 08/22/2016 09:27:30 DISPATCH 44 Waiting Answer Clear Done

1. Select the call entry in the list.


2. Click the **Answer** button.

#### Note:

- Incoming calls are added to the Call Queue window. Call entries have a status of Waiting until answered by a dispatcher.
- Selecting the call entry causes the background color of the call entry to change to the selected color configured in Microsoft Windows.
- After the call has been answered, the call status updates to Processing. After a call has been answered, any dispatcher on a parallel console position can clear the call entry.
   Dispatchers on parallel console positions can determine the dispatcher who answers and clears a particular call by viewing the Console ID field for the call entry.


To clear a call, do the following:

Select the call entry in the list.



#### 2. Click the Clear button.

NOTE: Selecting the call entry causes the background color of the call entry to change to the selected color configured in Microsoft Windows.



The call event is complete. If the Remove Completed Entries from Window check box is unchecked, the call entry remains on the screen until the maximum number of viewable entries (configured in C-Soft Designer) is reached.

# 31.16 Crosspatch

The **Crosspatch** function allows the console operator to connect two or more radios/phone lines, enabling different lines to talk to other lines configured as full-duplex become simplex in operation when placed into a crosspatch.



#### Notice!

Only the console creating the crosspatch is able to clear the crosspatch. All other consoles display X-PATCH on lines in a patch group.

#### **Patch Group page**

When the Crosspatch function is selected from the UI Element drop down menu, the **Patch Group** page appears. Refer to the Figure below.




Figure 31.11: Patch Group Page - UI Element Setup

#### To add a Crosspatch button, do the following:

- 1. From the Insert menu, select **Add UI Button**.
  - A None button appears on the console window.
- Right-click the **None** button.A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select **Crosspatch**.
  - The Patch Group tab appears.
- 5. Click the Patch Group tab.
  - The Patch Group page appears.
- 6. From the Select Patch Group drop down menu, select the **number** of the crosspatch group (1-30).
- 7. Click OK.

The color of the button changes and Patch appears on the button.

# 31.17 Crosspatch Block

The **Crosspatch Block** function allows a particular crosspatch line to be blocked from transmitting.

EXAMPLE: If the line is stuck in receive mode due to noise, that line can be blocked, releasing its control of the crosspatch. After the line completes a transmit cycle, then it is eligible to transmit/receive as part of the patch.

#### Patch Group page

When the Crosspatch function is selected from the UI Element drop down menu, the **Patch Group** page appears. Refer to the Figure below.

#### To add a Patch Block button, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the **None** button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select **Crosspatch Block**.
  - The Patch Group tab appears.
- 5. Click the Patch Group tab.
  - The Patch Group page appears.
- 6. From the Select Patch Group drop down menu, select the crosspatch group number.
- Click OK.

The color of the button changes and a Patch Block button appears in the console window.

# 31.18 Crosspatch Clear

The **Crosspatch Clear** function allows the console operator to drop the patch for the crosspatch group.

#### **Patch Group page**

When the Crosspatch function is selected from the UI Element drop down menu, the **Patch Group** page appears. Refer to the Figure below.

#### To add a Patch Clear button, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the **None** button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select Crosspatch Clear.
  - The Patch Group tab appears.
- 5. Click the **Patch Group** tab.
  - The Patch Group page appears.
- 6. From the Select Patch Group drop down menu, select the **number** of the crosspatch group.
- 7. Click **OK**.

The color of the button changes and Patch Clear appears on the button.

# 31.19 Crosspatch Programmed

The **Crosspatch Programmed** function allows the console operator to create a crosspatch on a pre-defined group of lines.



#### Notice!

Telex recommends you assign a unique color to this button because it is applied to all lines in the crosspatch.

#### Line Group page

When the Crosspatch Programmed function is selected from the UI Element drop down menu, the **Line Group** page appears. Refer to the Figure below.




Figure 31.12: Line Group Page - UI Element Setup

#### **Select Lines for Group field**

The **Select Lines for Group** field contains a list of all the lines configured on "*Per Line Parameters window, page 61*". Selecting a line from this list assigns the line to the group.

#### **Group Patch Number drop down menu**

The **Group Patch Number** drop down menu is used to assign a unique crosspatch group number to the selected line.

#### **Autostart Crosspatch check box**

The **Autostart Crosspatch** check box indicates the crosspatch is automatically created when the C-Soft program is started.

#### To add a Crosspatch Programmed button, do the following:

- From the Insert menu, select Add UI Button.
   A None button appears on the console window.
- Right-click the **None** button.A shortcut menu appears.
- From the shortcut menu, select **Properties**.
   The UI Element Setup window appears.

- 4. From the UI Element drop down menu, select Crosspatch Programmed. The Line Group tab appears.
- 5. Click the **Line Group** tab.
  - The Line Group page appears.
- On the Line Group page, select the line(s) from the Select Lines for Group field.
- From the Group Patch Number drop down menu, select the group patch number.
- 8. From the Options field, select the Autostart Crosspatch check box to automatically start the crosspatch, if desired.
- 9. Click OK.

The color of the button changes and Preset Patch appears on the button.



#### Notice!

Autostart Crosspatch does not work for Phone or SIP lines.

#### Refer to

Per Line Parameters window, page 61

#### 31.20 Crosspatch PTT

The Crosspatch PTT function allows the console operator to transmit audio to all lines included in the crosspatch.

#### Patch Group page

When the Crosspatch PTT function is selected from the UI Element drop down menu, the **Patch Group** page appears. Refer to the Figure on "Crosspatch, page 246".

#### To add a Crosspatch PTT button, do the following:

- From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the None button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select Crosspatch PTT.
  - The Patch Group tab appears.
- 5. Click the Patch Group tab.
  - The Patch Group page appears.
- 6. From the Select Patch Group drop down menu, select the number of the crosspatch group.
- Click **OK**.

The color of the button changes and Crosspatch PTT appears on the button.

#### Refer to

Crosspatch, page 246

#### 31.21 Dial

The **Dial** function dials the user selected in the keypad. For more information on the Keypad Module, refer to "Dial" on page 234.

To add a Dial button, do the following:

- From the Insert menu, select Add UI Button.
   A None button appears on the console window.
- Right-click the **None** button.A shortcut menu appears.
- From the shortcut menu, select **Properties**.
   The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select Dial.
- 5. Click OK.

The color of the button changes and Dial appears on the button.

# 31.22 DTMF Digit

The **DTMF Digit** function adds one digit of a DTMF keypad. Multiple buttons can be added to the console to form a DTMF keypad. All 16 digits are supported.

#### **DTMF** Digit page

When the DTMF Digit function is selected from the UI Element drop down menu, the **DTMF Digit** page appears. Refer to the Figure below.



Figure 31.13: DTMF Digit Page - UI Element Setup

#### DTMF Digit drop down menu

The DTMF Digit drop down menu provides a list of numbers and letters for the DTMF keypad.

This range for this field is 0-9 or A-D, # and \*.

#### Note:

- Each digit must be assigned to its own button.
- When creating a telephone keypad, the corresponding letters for the keypad are automatically inserted.

In C-Soft Runtime, if a DTMF digit button is clicked, the digit is sent to all selected lines during a PTT operation, or it generates its own PTT if clicked outside of a PTT operation.

#### To assign a digit to a button, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the None button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select **DTMF Digit**.
  - The DTMF Digit tab appears.
- 5. Click the **DTMF Digit** tab.
  - The DTMF Digit page appears.
- 6. From the DTMF Digit drop down menu, select the **digit** you want to appear on the button.
- 7. Click OK.

The color of the button changes and the selected number (or letter) appears on the button.



# 31.23 Emergency ACK

The **Emergency ACK** function creates a button to indicate the emergency is acknowledged and stops the Select buttons blinking.



#### Notice!

When the Emergency ACK function is selected, a line must be selected from the Line to Associate Function With drop down menu.

In C-Soft Runtime, if an emergency signal is received, the C-Soft program sends an emergency Hi-Lo tone to the selected speaker to notify the console operator. In addition, the Select button for the line that received the emergency call blinks.

To add an Emergency ACK button, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the **None** button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select the **Emergency ACK button**.
- 5. From the Line to Associate Function With drop down menu, select the **desired line** to associate with this function.
- 6. Click OK.

The color of the button changes and Emergency ACK appears on the button.

# 31.24 Emergency Clear

The Emergency Clear function stops the Hi-Lo tone from playing on the selected speaker.

# To add an Emergency Clear button, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the **None** button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select **Emergency Clear**.
- 5. Click OK.

The color of the button changes and Emergency Clear appears on the button.

# 31.25 Emergency History Window

The **Emergency History Window** function creates a button to access the emergency call history list.

In C-Soft Runtime, if the Emergency History window button is clicked, the Emergency History window appears. From this window, you can view all emergencies, cleared emergencies, and acknowledged emergencies.

### To add an Emergency History Window button, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the None button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select Emergency History Window.
- 5. Click OK.

The color of the button changes and Emergency History appears on the button.

# 31.26 Encryption

The **Encryption** function allows the console operator to selectively turn on and off encryption message sent to an IP-223 or IP-224.



#### Notice!

When the Encryption function is selected, a line must be selected from the Line to Associate Function With drop down menu.

# **Encryption Setup page**

When the Encryption function is selected, the **Encryption Setup** page appears, shown in the Figure below.



Figure 31.14: Encryption Setup Page - UI Element Setup

### **Default Secure check box**

The **Default Secure** check box indicates encryption is enabled when C-Soft boots up.

# To configure encryption on a line, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the **None** button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select **Encryption**.
- 1. From the Line to Associate Function With drop down menu, select the **desired line** to associate with this function.
- 2. Click OK.

The color of the button changes and Clear appears on the button.

# 31.27 Event Logger

The **Event Logger** function opens a window that displays all the messages written to the Event Log file viewable by the dispatcher.

# Note:

- The Event Logger window only displays log messages if logging is enabled.
- To set the log level and which level of logging messages to record, see "Logging Setup Group Box".

### To add an Event Logger button, do the following:

- From the Insert menu, select Add UI Button.
   A None button appears on the console window.
- 2. Right-click the **None** button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**. The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select **Event Logger**.
- 5. Click **OK**.

A button with Event Logger on it appears.

# 31.28 FleetSync

The **FleetSync** function creates a button to open the FleetSync Dispatching window, shown in the Figure in "*FleetSync Dispatching window, page 256*".

In C-Soft Runtime, when the window is open the user can view the system list, call history and status history, send status IDs, voice messages and data messages, select groups and individuals to place calls.

# FleetSync Setup page

When the FleetSync function is selected from the UI element drop down menu, the **FleetSync Setup** page appears, shown in the Figure below.




Figure 31.15: FleetSync Setup Page - UI Element Setup

### **Console Requests group box**

### Timeout field

The **Timeout** field is used to configure the amount of time, in seconds, the console waits after sending a status request command before indicating a response was never received.

The range for this field is 1 to 10 seconds.

# To add a FleetSync button, do the following:

From the Insert menu, select Add UI Button.
 A None button appears on the console window.

- 2. Right-click the None button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select **FleetSync**.
- 5 Click OK

A button with FleetSync on it appears.

#### Refer to

- FleetSync Dispatching window, page 256

# 31.28.1 FleetSync Dispatching window

The **FleetSync Dispatching** window is used by the console operator in C-Soft Runtime to place calls, view call history, and send status and text messages. Console action feedback is provided in the Dispatching Status bar.




Figure 31.16: FleetSync Dispatching Window

### System Type drop down menu

The **System Type** drop down menu is used to change from the currently selected system to another system in the console position.

The default systems included in the drop down menu depend on the currently selected line's configuration.

Up to 200 systems can be created.

### **System List field**

The **System List** field populates with components that belong to the system currently selected from the System drop down menu. Filters components are listed next in the hierarchy. When a filter component is expanded, individual unit and fleet components are visible.

Systems can be configured, by the console admin, to display filters only. In that case, only components affiliated with a filter, shown in the Figure below, appear in the filter list. Otherwise, all components, including components with deny icons (permission to place calls is denied), shown in the Figure above, appear in the list.




Figure 31.17: System Displays Only Filters Example

Icon	Туре	Description
₽	Filter	The Filter icon indicates the component is a filter. Filters are used to group, sort, and label the components contained in the filter, refer to the Figure above.
		To view or hide filters, do one of the following:  - Click the expand button to view components.  - Click the collapse button to hide components.
<b>Ø</b>	Allow	The Allow icon indicates the component is available for selection.  The console operator can place calls and send status and text messages to these components, refer to the Figure above.
<b>&amp;</b>	Deny	The Deny icon indicates the component does not allow broadcast calls, when a system is tagged, or, does not allow interfleet calls when Fleets or Units are tagged, refer to the Figure above.

# System List flyout menu

The System List flyout menu, shown in the Figure below, is a quick method of accessing the Select Type commands also available in the Data Messaging Group Box.

Available selections for this field are Status, Text Messages, Select Calls and Request Status.




Figure 31.18: System List Flyout Menu

# To access the System List flyout menu, do the following:

In the System List, right-click the **unit** or **group** to send the call or message to. The System List flyout menu appears.

OR

In the System List, right-click the **system** to send the call or message to.

The System List flyout menu appears.

Click Status.

OR

Click Text Message.

OR

Click Select Call.

OR

Click Status Request.

### Reference

- For more information, refer to "Status Message Radio Button" on "Select Type Group Box".
- For more information, refer to "Text Message Radio Button" on "Select Type Group Box".
- For more information, refer to "Select Call Radio Button" on "Select Type Group Box".
- For more information, refer to "Request Status Radio Button" on "Select Type Group Box".

# Selected Items page

The **Selected Items** page is used to view the currently selected component's ID information. The selected item list is used to determine where the call or status message is sent.

Selection of only one component per system is allowed. Grayed out items with deny icon tags are not available for selection.

For more information, refer to "Manual Select Group Box".

# To add a component's ID to the Selected Items page, do the following:

- In the System list field, select the component.
   The component is highlighted.
- Click Add to Selected.

The item appears in the list.

### To remove an ID from the Selected Items page, do the following:

- 1. Right-click the unwanted component.
- 2. Click Remove Item.

The item disappears from the list.

### **Manual Select group box**

The **Manual Select** group box is used to manually enter Fleet and User ID numbers for placing calls, sending status messages and text messages.

### Fleet ID field

The **Fleet ID** field is used to enter the Fleet ID portion of the ID number for placing and sending interfleet calls and messages. The Fleet ID field is populated, by default, with the Fleet ID when the system is selected and broadcast calls are allowed on the line.

- If interfleet calls are not allowed on the selected line, the Fleet ID field is not editable for any component. It is possible, however, to place an individual intrafleet call manually. The selected line's Fleet ID-grayed out-is added on to the unit ID number you enter manually.
- If a Fleet ID and User ID are both 0, then the console displays the following message: Cannot add a system! Allow Broadcast Call option is disabled, appears.

### **User ID field**

The **User ID** field is used to manually enter the unit ID portion of the ID number. It is used to place a call or send a message when the ID is not available for selection from the system list.

The User ID field is also used to place broadcast calls using zeros, indicating it is a broadcast call, and is sent to all members of the fleet.

# **History page**

The **History** page is used to view past FleetSync calls and messages received by the console. Additionally, calls or messages can be sent by selecting the ID in the history log. When selected, the ID is added to the Selected Items page.

This list is configured by the console administrator. It can contain up to 500 IDs. For more information, refer to "Per Line Call History Window Lines Field" on "Per Line Call History Window Lines Field".

#### Note:

- Calls are not saved to the history list if C-Soft Runtime is closed.
- The FleetSync Call History list includes calls received from parallel console positions.




Figure 31.19: History Page - FleetSync Dispatching Window

# **Call History View group box**

The **Call History View** group box is used to control the log display.

# All Lines radio button

The **All Lines** radio button is used to display all calls and messages received by the console.

### Selected Line radio button

The Selected Line radio button is used to display all calls and messages received on the selected line.

# Call Details group box

The Call Details group box is used to display additional call information for the currently selected ID type.

### Add to Selected button

The Add to Selected button is used to add the manually entered Fleet and Unit ID to the selected items page. When the ID number displays in the Selected Items page, the call can be placed or message sent.

To manually place an individual call inside the current system, do the following:

In C-Soft Runtime, select a line.

2. Click the **FleetSync** button.

The FleetSync Dispatching window appears. The Fleet ID field is, by default, populated with the current system's fleet ID.

- 3. In the User ID field, enter the individual's unit ID number.
- 4. Click Add to Selected.

The system name you are currently working with appears in the Selected Items page.



#### Notice!

The name on the FleetSync button is configured by your console administrator. FleetSync is used generically to refer to any button configured for FleetSync functions.

# To manually place an interfleet call, do the following:

- 1. Select a **line** with interfleet calls allowed.
- 2. Click FleetSync.

The FleetSync Dispatching window appears.

- 3. In the Fleet ID field, enter the individual's fleet ID number.
- 4. In the User ID field, enter the individual's unit ID number.
- 1. Click Add to Selected.

The system name you are currently working with appears in the Selected Items page.

### To manually place a broadcast call, do the following:

- 1. Select a line with broadcast calls allowed.
- 2. Click FleetSync.

The FleetSync Dispatching window appears. The Fleet ID field contains the system Fleet ID number, and is not editable.

- 3. In the System List field, select the **system name**.
  - The system name is highlighted.
- 4. In the Unit ID field, enter **0000**.
- 5. Click Add to Selected.

The system name you are currently working with appears in the Selected Items page.

### Note:

- Lines can be configured to allow or deny both broadcast calls or interfleet calls.
- Permission to place calls can be determined by the window's appearance. Refer to the two Figures below.

Icon	Туре	Description
8	Deny	Broadcast calls are not allowed as indicated by the deny icon. When the system name is selected, the Selected Items page is empty and the Fleet ID field is grayed out, refer to the Figure below.
<b>Ø</b>	Allow	Broadcast calls are allowed as indicated by the allow icon. When the system name is selected the ID number appears in the Selected Items page and the Fleet ID field is active, refer to the Figure below.




Figure 31.20: Broadcast Call Permissions

Icon	Туре	Description
8	Deny	Interfleet calls are not allowed as indicated by the deny icon. When the Fleet name is selected, the Selected Items page is empty and the Fleet ID field is grayed out, refer to the Figure below.
<b>Ø</b>	Allow	Interfleet calls are allowed as indicated by the allow icon. When the Fleet name is selected, the ID appears in the Selected Items page and the Fleet ID field is active, see to the Figure below.




Figure 31.21: Interfleet Call Permission

# **Status Message field**

The **Status Message** field indicates the currently selected status message. If no status is selected, No Status appears in the field. The Set Status button is used to change the status ID.

### **Set Status button**

The **Set Status** button is used to select a status to send. When the Set Status button is clicked, the Status List window appears. Refer to the Figure on "*Status List window, page 236*".

To set the status ID, do the following:

- 1. Select Set Status.
  - The Status List window appears.
- 2. Select a Status ID from the list.
  - The ID is highlighted.

OF

From the Status drop down menu, select a **Status ID**.

The ID is highlighted.

3. Click Done.

The selected Status ID appears in the Status Message field.

### **Select Type group box**

The **Select Type** group box is used to select the type of message or call sent when the Send button is clicked.

### Status Message radio button

The Status Message radio button indicates the currently selected status message is sent to the ID number listed in the Selected Item page.

### To send the current status message, do the following:

- Select the **Status Message** radio button.
- 2. Click Send.

The message is sent and a confirmation appears in the status bar.



#### Notice!

Status ID codes must be between 10 and 99. See manufacturer's technical data for specific Status ID codes.

# Text Message radio button

The Text Message radio button indicates the current entry in the Enter Text Message text box is sent to the ID number listed in the Selected Item page.

# To send the current text message, do the following:

- Select the **Text Message** radio button.
- 2. Click Send.

The message is sent and a confirmation appears in the status bar.

Text messages can contain up to 48 characters.

### Select Call radio button

The Select Call radio button indicates a select call is placed to the current ID in the Selected Items page.

# To place a select call to the ID, do the following:

- 1. Select the Select Call radio button.
- Click Send.

The message is sent and a confirmation appears in the status bar.

# Request Status radio button

The **Request Status** radio button is used to send a request for status from the ID currently listed in the Selected Items page.

# To request a status from the ID, do the following:

- Select the **Request Status** radio button.
- Click Send.

The message is sent and a confirmation appears in the status bar.

### Send button

The Send button is used to send the currently selected call, status, or message to the ID listed on the Selected Items page. When selected, a confirmation or error message appears in the status bar at the bottom of the window.

#### **Done button**

The **Done** button is used to close the FleetSync Dispatching window.

# FleetSync Dispatching window status bar

The FleetSync Dispatching window status bar, shown in Figure on "FleetSync Dispatching window, page 256", indicates console activity. Confirmation and error messages appear when calls, statuses, or messages are sent.

# 31.29 Frequency Change

The **Frequency Change** function sends a burst of packets onto the Ethernet network requesting the remote radio change to the new frequency of the selected line. Additionally, all other consoles on the network change to display the new frequency of the radio on that particular line.



### Notice!

When the Frequency Change function is selected, a line must be selected from the Line to Associate Function with drop down menu.

### Freq Set page

When the Frequency Change function is selected from the UI Element drop down menu, the **Freq Set** page appears. Refer to the Figure below.




Figure 31.22: Freq. Set Page - UI Element Setup

Given that frequencies change, it is common to place frequency selection buttons in a popup window. The console operator opens the popup window to change frequencies and closes the window when they are done.

However, with the popup window closed, it becomes impossible to see exactly what frequency is currently selected for the line. By placing the variable \$FREQX\$, where X represents the line number, into the Button Up Text and Button Down Text field on the Colors page, the frequency for that line is automatically updated on the button when it changes.

When Scannable is selected for the line, refer to "Scannable Check Box" on "Line setup options group box", right-click the button to display a shortcut menu that provides the console operator the ability to add or remove this channel from the scan list.

When a frequency is in the scan list, a scan icon appears on the frequency change button. Parallel consoles are also alerted to update their display if a frequency is added or removed from the scan list.

### Select PTT Frequency drop down menu

The **Select PTT Frequency** drop down menu is used to select the frequency for the line. This field contains all the frequencies configured on "Freqs Button".

# To add or change a Frequency button, do the following:

- From the Insert menu, select Add UI Button.
   A None button appears on the console window.
- 2. Right-click the **UI button**.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select **Frequency Change**. The Freq Set tab appears.
- 5. From the Line to Associate Function With drop down menu, select the **desired line** to associate with this function.
- 6. Click the Freq Set tab.
  - The Freq Set page appears.
- 7. From the Select PTT Frequency drop down menu, select the **desired frequency** for the line selected.
- 8. Click OK.

The color of the button changes and FreqX (X representing the line of the frequency) appears on the button. Also, the frequency is changed for the line.

Additions and changes can be made to the Per Line Frequency Setup window at any time. However, if any user interface elements have been placed on the console window, the changes made to a line must also be changed on the individual elements, if needed.

# 31.30 GPS Read button

The **GPS Read** button is used to query the current GPS coordinates of the selected radio. This functionality is currently supported on lines using NEXEDGE or MOTOTRBO signaling only.

# To query a radio of its GPS coordinates, do the following:

From the GPS Read drop down list, select the unit you want to send this command.
 OR

If using the a Keypad, select the unit you want to send the GPS Read Request.

### 2. Click GPS Read.

The command is sent.

### To add a GPS Read button, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the None button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select **GPS Read**.
- 5. Click OK.

The color of the button changes and GPS Read appears on the button.

# **GPS Trigger Setup page**

The GPS Trigger Setup page is used to select the settings for the GPS Trigger.

# 31.31 GPS Trigger Off button

The **GPS Trigger Off** button is used to stop periodic GPS coordinate updates from the selected radio. The functionality is currently supported on lines using NEXEDGE or MOTOTRBO signaling only.

# To stop receiving periodic GPS coordinates from a radio, do the following:

 From the GPS Trigger Time drop down menu, select the unit you want to send the GPS Trigger Off command.

OR

If using a Keypad, select the unit you wish to send the GPS Trigger Off command.

2. Click GPS Trigger Off.

The command is sent.

### To add a GPS Trigger Off button, do the following:

- 1. From the Insert menu, select **Add UI Button**.
  - A None button appears on the console window.
- 2. Right-click the None button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select **GPS Trigger Off**.
- 5. Click **OK**.

The color of the button changes and GPS Trigger Off appears on the button.

# 31.32 GPS Trigger On button

The **GPS Trigger On** button is used to start periodic GPS coordinate updates from the selected radio. The functionality is currently supported on lines using NEXEDGE or MOTOTRBO signaling only.

To start receiving periodic GPS coordinates from a radio, do the following:

From the GPS Trigger Time drop down menu, select the unit you want to send the GPS Trigger On command.

OR

If using a Keypad, select the unit you wish to send the GPS Trigger On command.

Click GPS Trigger On.

The command is sent.

# **GPS Trigger Setup page**

When the GPS Trigger On Button function is selected from the UI Element drop down menu, the GPS Trigger Setup page appears. See the Figure below.

# **GPS Trigger Time drop down menu**

The GPS Trigger Time drop down menu is used to select the time duration between GPS coordinate updates.

The time duration between GPS coordinate updates is determined by the GPS Trigger Time drop down menu.




Figure 31.23: GPS Trigger Setup Page - UI Element Setup

Available options are:

- 30 Seconds
- 1 Minute
- 2 Minutes
- 4 Minutes
- 8 Minutes

### To add a GPS Trigger On button, do the following:

- From the Insert menu, select **Add UI Button**. A None button appears on the console window.
- 2. Right-click the None button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**. The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select **GPS Trigger On**.
- Click OK.

The color of the button changes and GPS Trigger On appears on the button.

# 31.33 Group Programmed

The **Group Programmed** function allows the console operator to broadcast to a pre-defined group.

### Line Group page

When the Group Programmed function is selected from the UI Element drop down menu, the **Line Group** page appears. Refer to the Figure below.




Figure 31.24: Line Group Page - UI Element Setup

# **Select Lines for Group field**

The **Select Lines for Group** field contains a list of all the lines configured on "*Per Line Parameters window, page 61*". Selecting a line from this list assigns it to the group. Pressing the Group Programmed button in the C-Soft Runtime program places the defined lines into a select condition.

### To add a group programmed button, do the following:

- From the Insert menu, select Add UI Button.
   A None button appears on the console window.
- 2. Right-click the **None** button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select **Group Programmed**. The Line Group tab appears.
- 5. Click the Line Group tab.
  - The Line Group page appears.
- 6. From the Select Lines for Group field, select the **line**(s) for the group.
- 7. Click **OK**.

The color of the button changes and Preset Group appears on the button.

To remove a line from the Group Programmed, deselect the line.

### **Group Programmed Enhanced button**

The **Group Programmed Enhanced** button allows the console operator to broadcast to a predefined group of lines and frequencies. The group's lines and transmit frequencies are configured in the Group Programmed Enhanced setup dialog.

Up to 25 selected lines can be stored in a pre-defined group.



### Notice!


The Allow Programmed Group to be changed in Runtime feature is not accessible with a mouse used on the IP-30XX devices.

# **Group Programmed Enhanced Setup page**

When Group Programmed Enhanced button is selected from the UI Element drop down menu, the **Group Programmed Enhanced Setup** page appears. This button has the ability to configure line and frequencies selected when the button is pressed.

# To open the Group Programmed Enhanced Setup page, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the None button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select **Group Programmed Enhanced**. The Group Programmed Enhanced Setup tab appears.
- 5. Click the Group Programmed Enhanced Setup page.



# **Available Lines and Frequencies group box**

The **Available Lines and Frequencies** group box displays the list of lines and the line's corresponding frequencies available in the design configuration file.

### Line drop down menu

The **Line** drop down menu identifies the desired line to be selected.

### Freq drop down menu


The **Freq** drop down menu identifies the desired frequency to use per selected line.

# **Programmed Group List**

The **Programmed Group List** displays the list of line/frequency combinations which are selected when the Group Programmed Enhanced button is pressed. To remove a line/frequency combination from the list, select the desired row in the list and then click the Delete button.

# **Group Programmed Enhanced Options page**

The **Group Programmed Enhanced Options** page is used to identify whether or not Programmed Groups can be changed in Runtime by the dispatcher.



# Allow Programmed Group to be changed in Runtime check box

The **Allow Programmed Group to be changed in Runtime** check box indicates the setup allows the defined group to be modified by the dispatcher in C-Soft Runtime.

# To edit the Group Programmed Enhanced button in Runtime, do the following:

- 1. Right-click the Group Programmed Enhanced button.
- 2. Select the **Edit option**.

The border of the Group Programmed Enhanced button blinks to signify the console is in Edit mode.

- 3. Select or unselect lines.
- 4. Set the desired **transmit frequency** for the selected lines.
- 5. Right-click the **Group Programmed Enhanced button**.
- 6. Select the Save Option.

The new group configuration is now saved to the button.

# To exit Edit mode without saving, do the following:

- 1. Right-click the **Group Programmed Enhanced button**.
- 2. Select the Cancel option or any button other than a select or frequency control.

# To clear a button's defined group, do the following:

- 1. Right-click the Group Programmed Enhanced button.
- 2. Select the Clear option.

# Refer to

- Per Line Parameters window, page 61

# 31.34 Group Select

The **Group Select** function creates a button used to create a group of users to call.



### Notice!

Group Select Limited and Group Select buttons cannot co-exist on the same console.

### To add a Group Select button, do the following:

- 1. From the Insert menu, select **Add UI Button**.
  - A None button appears on the console window.
- 2. Right-click the **None** button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select **Group Select**.
- 5. Click **OK**.

The color of the button changes and Group Select appears on the button.

When the button is selected in C-Soft Runtime, a group can be defined manually.

# To manually select a group of IDs to call, while in C-Soft Runtime, do the following:

- 1. In C-Soft Runtime, click the **Group Select** button.
- 2. Click the desired lines.
  - The lines are added to the group.
- 3. Click the **Group Select** button a second time.

The group clears.

# 31.35 Group Select Limited

The **Group Select Limited** function is similar to the Group Select function, except the number of lines the console operator can select is limited.



### Notice!

Group Select Limited and Group Select buttons cannot co-exist on the same console.

### **Group Select Limited page**

When the Group Select Limited function is selected from the UI element drop down menu, the **Group Select Limited** page appears. Refer to the Figure below.




Figure 31.25: Group Select Limited Page - UI Element Setup

### **Max Number of Simultaneous Selected Lines field**

The **Max Number of Simultaneous Selected Lines** field identifies the number of lines a console operator can select for a group.

The range for this field is 0 to 200 lines.

# To add a group select limited button, do the following:

- From the Insert menu, select Add UI Button.
   A None button appears on the console window.
- 2. Right-click the **None** button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select **Group Select Limited**. The Group Select Limited tab appears.
- 5. Click the Group Select Limited tab.
  - The Group Select Limited page appears.
- 6. From the Select Lines for Group field, enter the **maximum number of line**(s) for the group.
- 7. Click OK.

The color of the button changes and Group Limited appears on the button.

# 31.36 Input Indication

The **Input Indication** function allows the console operator to monitor an ADHB-4 or NEO-10 input, as well as configure the parameters particular to an input source.

# **Input Indication Setup page**

When the Input Indication function is selected from the UI element drop down menu, the **Input Indication Setup** page appears. Refer to the Figure below.




Figure 31.26: Input Indication Setup Page - UI Element Setup

### **Input Source group box**

The **Input Source** group box identifies the input source to be monitored. When either ADHB-4 or NEO is selected, the fields necessary to enter the setup information for input sources are enabled.

### **ADHB-4** radio button

The ADHB-4 radio button indicates an ADHB-4 device is used as the input source.

# **NEO** radio button

The **NEO** radio button indicates a NEO-10 is used as the input source.

# Polarity group box

### **Active High check box**

The **Active High** check box indicates the input is set to active high. If selected, the status button changes when the input goes to a positive (high) state.

### Annunciation of Input Change group box

# Beep for check box

The **Beep for** check box indicates a beep sound is played when there is a change in input. When the Beep for check box is selected, the Beep for seconds field becomes active. Otherwise, there is no beep sound when the input changes.

# Beep for seconds field

The **Beep for seconds** field is used to set the amount of time, in seconds, the indicator beeps after the input is changed. The Beep for radio button must be selected.

The range for this field is 0 to 20 seconds.

### Blink for check box

The **Blink for** check box indicates the border of the Input Indication button blinks when an input change is detected.

#### Blink for seconds field

The Blink for seconds field is used to enter the number of seconds the border of the Input Indication button blinks after a change in input is detected.

The range for this field is 0 to 30 seconds.

### Play check box

The Play check box indicates the .wav file configured for the selected annunciation button plays when the input changes.



### Notice!

When a system is configured with parallel consoles, only one console should be configured to play a .wav file on input change. This prevents multiple consoles attempting to transmit the .wav file simultaneously.

#### Play drop down menu

The Play drop down menu is used to select an annunciation button from a list that exist in the design file. The .wav file format is: X:text (where X represents the line number associated with the Annunciation button and text is the button name of the Annunciation button). When the input changes, the .wav file is played on the line the annunciation button is configured on.

The Play check box must be selected to activate the play function.

# Input Destination ADHB-4 group box

The Input Destination radio buttons identify the ADHB-4 input destination.

### None radio button

The None radio button indicates there is no input indication assigned to the button or there is no ADHB-4 connected.

# Input 1 radio button

The Input 1 radio button is used to configure the Input Indication button to signal the console operator if the first relay is currently in control of an ADHB-4.

# Input 2 radio button

The Input 2 radio button is used to configure the Input Indication button to signal the console operator if the second relay is in control of an ADHB-4.

# **NEO Settings group box**

### IP field

The **IP** field identifies the IP Address of the NEO-10.

### Input drop down menu

The **Input** drop down menu identifies the input port for relays.

Available selections for this field are None and Ports 1 through 10.

### **Relay Setup group box**

### **Active Relay With Input check box**

The **Active Relay With Input** check box indicates a configured relay activates when the input state changes to active.

# **Relay Destination group box**

The **Relay Destination** radio buttons identify the relay to be controlled. When a selection is made, the fields necessary to enter the setup information for the relay are enabled.

# **ADHB-4 Settings group box**

The **ADHB-4 Settings** radio buttons identify which ADHB-4 relay is activated when an input is active.

### None radio button

The **None** radio button indicates none of the ADHB-4 relays is activated.

### Relay 1 radio button

The **Relay1** radio button indicates the first relay in the ADHB-4 is being controlled.

### Relay 2 radio button

The Relay 2 radio button indicates the second relay in the ADHB-4 is being controlled.

# **NEO Settings group box**

The **NEO Settings** field identifies the IP Address and the relay, if any, for the NEO-10.

# **IP field**

The IP field identifies the IP Address of the NEO-10.

### Relay drop down menu

The **Relay** drop down menu is used to select the desired relay.

Available selections for this field are None, Port 1, Port 2, Port 3, Port 4, Port 5, Port 6, Port 7, Port 8, Port 9 and Port 10.

### **Active Duration field**

The **Active Duration** field is used to enter the length of time, in ms, the relay remains active after the input state changes to active.

The range for this field is 300-3000ms.

# To configure and add an ADHB-4 Input Indications button, do the following:

- 1. From the Insert menu, select **Add UI Button**.
  - A None button appears on the console window.
- Right-click the **None** button.
   A shortcut menu appears.

3. From the shortcut menu, select **Properties**.

The UI Element Setup window appears.

4. From the UI Element drop down menu, select **Input Indication**.

The Input Indication Setup tab appears.

5. Click the **Input Indication Setup** tab.

The Input Indication Setup page appears.

6. From the Input Source and Polarity group box, select ADHB-4.

The Input Destinations group box is active.

- 7. From the Input Destination area, select **None**, **Input1**, or **Input2**.
- 8. Select the **Active High** check box for active high inputs.
- 9. From the Annunciation of Input Change group box, select **No Audio**.

OR

Select Beep.

- 10. In the seconds field, enter **number of seconds** the beep is heard, if applicable.
- 11. From the Input drop down menu, select the desired input.

# To configure and add a NEO Input Indication button, do the following:

1. From the Insert menu, select Add UI Button.

A None button appears on the console window.

2. Right-click the None button.

A shortcut menu appears.

3. From the shortcut menu, select **Properties**.

The UI Element Setup window appears.

4. From the UI Element drop down menu, select **Input Indication**.

The Input Indication Setup tab appears.

5. Click the Input Indication Setup tab.

The Input Indication Setup page appears.

6. Select NEO.

The NEO Settings group box is active.

- 7. In the IP field, enter the **IP Address** of the NEO-10.
- 8. Select the **Active High** check box for active high inputs.
- 9. From the Annunciation of Input Change group box, select **No Audio**.

OR

Select Beep.

- 10. In the seconds field, enter **number of seconds** the beep is heard.
- 11. From the Input drop down menu, select the desired input.

# 31.37 Instant Recall

The **Instant Recall** function allows the console operator to play back a predetermined amount of receive audio only.

The recall starts with the oldest call first.

Multiple Instant Recall buttons can be placed on the console window with each button set to playback a certain amount of audio.

The button must be held down for the complete duration of the recording time to hear all audio in buffer.

The C-Soft program function constantly maintains a record of the last 600 seconds (or 10 minutes) of both parallel transmit and receive audio. The recorder only records the audio when the call is active, allowing for a long conversation to be replayed without the loss of audio.

# 31.37.1 Duration page

When the Instant Recall function is selected on the UI Element Setup window, the **Duration** page appears. Refer to the Figure below.




Figure 31.27: Duration Page - UI Element Setup

# **Audio Playback Start field**

The **Audio Playback Start** field identifies the amount of time to record from the end of the call backwards.

The field value can range from 0 to 600 seconds.

# Audio Source drop down menu

The **Audio Source** drop down menu determines the source from which the audio is recorded. Available selections for this field are:

- Select
- Unselect
- Speaker 3 [ADHB-4]
- Speaker 4 [ADHB-4]
- Speaker 5 [ADHB-4]
- Speaker 6 [ADHB-4]




Figure 31.28: Audio Source Drop Down Menu

# To configure and add an Instant Recall button, do the following:

- From the Insert menu, select Add UI Button.
- A None button appears on the console window.
- 2. Right-click the None button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- From the UI Element drop down menu, select **Instant Recall**. The Duration tab appears.
- Click the **Duration** tab.
  - The Duration page appears.
- 6. In the Audio Playback Start field, enter the number of seconds you want to play back audio.
- 7. From the Audio Source drop down menu, select the audio source to play back.
- Click OK.

The duration and audio source are configured. The color of the button changes and IRR Select 10 appears on the button.

#### **Instant Recall - Last Call button** 31.38

The Instant Recall - Last Call button allows users to play back audio from the last received call on the configured line.

Clicking the Last Call button prompts the audio from the last call to start playing. To stop the audio from playing, click the Last Call button again. The Last Call button is only available for lines that have Per Line Call Playback enabled.

### To add a Last Call button, do the following:

- 1. From the Insert menu, select Add UI Button. A None button appears on the console window.
- 2. Right-click the None button.
  - A shortcut menu appears.
- From the shortcut menu, select **Properties**. The UI Element Setup window appears.

- 4. From the UI Element drop down menu, select **Instant Recall Last Call**. The Line to Associate Function With drop down menu becomes active.
- 5. From the Line to Associate Function With drop down menu, select the **line** to associate the Last Call function.
- 6. Click OK.

The color of the button changes and Last Call appears on the button.

# 31.39 Intercom

The **Intercom** function allows communication between consoles without keying remote radios. The Intercom button works just like the PTT- Main button, except additional information is included in the transmission that prevents the generation of PTT and radio keying.

### To add an Intercom button, do the following:

- 1. From the Insert menu, select **Add UI Button**.
  - A None button appears on the console window.
- 2. Right-click the **None** button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select **Intercom**.
- 5. Click OK.

The color of the button changes and Intercom appears on the button.

# 31.40 Intercom-Per Line

The **Intercom-Per Line** function allows console operators to communicate with each other without keying up a radio connected to the line. This button is similar to the Intercom button, except it works only on the line selected in the Line to Associate Function With field, and it does not transmit on the selected line.

The Intercom Per Line function is usually activated on a non-priority channel so existing audio traffic is not interrupted.

### To add an Intercom-Per Line button, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the **None** button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select **Intercom-Per Line**.
  - The Line to Associate Function With drop down menu becomes active.
- 5. From the Line to Associate Function With drop down menu, select the **line** to associate the Intercom-Per Line function.
- 6. Click **OK**.

The color of the button changes and Intercom appears on the button.

# 31.41 Knox Digit

The **Knox Digit** function is used to assign a Knox tone to the button. These digits must be assigned to UI elements individually.

Available selections for this field are: 1, 2, 3, 4, 5, 6, 7, 8, 9, A, B, C, D, \*, and #.

To create a Knox digit button, do the following:

- From the Insert menu, select Add UI Button.
   A None button appears on the console window.
- 2. Right-click the None button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**. The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select **Knox Digit**. The Knox Digit tab appears.
- 5. Click the Knox Digit tab.
- 6. From the Know Digit drop down menu, select a digit.
- 7. Click OK.

The Knox Digit button is created.

# 31.42 Launch Application

The **Launch Application** function creates a button called Launch Application.

In C-Soft Runtime, if the Launch Application button is clicked, the specified application, such as a messaging software is started. The maximum number of Launch Application buttons in a design is 64.

# 31.42.1 Launch Application Setup page

When the Launch Application function is selected from the UI Element Setup window, the **Launch Application Setup** page and Application Triggers page appear. Refer to the Figure below.




Figure 31.29: Launch Application Setup Page - UI Element Setup

### File Path field

The **File Path** field displays the path to the application you want to launch. For example, F: \RadioDispatch\CSoftDesigner.exe. You can either find the file with the browse button or enter the path in the field.

#### Parameters field

The **Parameters** field is used to specify command line arguments to the application being started. The parameters that can be entered are dependent on the application.

### **EXAMPLES:**

- If the application is Internet Explorer and www.Telex.com is entered in the Parameters field, the Telex webpage opens in Internet Explorer.
- If the application file path is Notepad, and C:\Logs\notebook.txt is entered in the Parameters field, the notebook.txt file opens.

This field can contain up to 1024 characters.

#### **Browse button**

The **Browse** button opens a Windows folder from which you can navigate to the application you want to start with the Launch Application button.

# **Autostart Application check box**

The **Autostart Application** check box indicates the application automatically starts running the configured application when C-Soft is launched.

### To create a launch application button, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the **None** button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select Launch Application.
  - The Launch Application Setup tab appears.
- 5. Click the Launch Application Setup tab.
  - The Launch Application Setup page appears.
- 6. Click the **browse** button.
  - A Windows folder appears.
- 7. Navigate to the **application** you want to start when the Launch Application button is clicked.
- 8. Click OK.

The UI Properties window closes.

# 31.42.2 Application Triggers page

When the Launch Application function is selected from the UI Element Setup window, the Launch Application Setup page and **Application Triggers** page appear. Refer to the Figure below.




Figure 31.30: Application Triggers Page

# **Custom Text Message field**

The **Custom Text Message** field is used to enter a custom text message that can be added to the Open Application group box.

# **Text Message List field**

The **Text Message List** field is used to select text message that were pre-created in Text Message ID list.

# **Status List field**

The Status List field is used to select statuses that were pre-created in Status Message ID. list

### **Add button**

The **Add** button is used to add the selected text messages or status messages to the application launch list.

### Remove button

The **Remove** button is used to remove the selected text messages or status messages from the application launch list.

# **Open Application field**

The **Open Application** field displays the text messages and status messages that have been moved to the open application list. When text messages or status messages are received that are in the application list, the application specified on the Launch Application Setup page starts.

#### **OK** button

The **OK** button saves any changes made and closes the window.

### To create text message/status message application launch button, do the following:

1. From the Insert menu, select Add UI Button.

A None button appears on the console window.

2. Right-click the **None** button.

A shortcut menu appears.

3. From the shortcut menu, select **Properties**.

The UI Element Setup window appears.

4. From the UI Element Function drop down menu, select **Launch Application**.

The Launch Application Setup and Application Triggers tabs appear.

5. Click the Application Triggers tab.

The Application Triggers page appears.

6. In the Custom Text Message field, enter a custom text message that is not in the Text Message List.

OR

From the Text Message List group box, select the **text message** desired to launch the designated application.

The list of text messages are pulled from the Text Message ID List.

OR

From the Status List group box, select the **status** desired to launch the designated application.

The list of status messages are pulled from the Status Message ID List.

7. Click the **Add button** to add the text messages or status messages to the Open Applications group box.

OR

Click the **Remove button** to remove the text messages or status messages from the Open Applications group box.

IMPORTANT: Whenever the designated text/status is received in C-Soft Runtime, the designated application launches.

8. Click OK.

The color of the button changes and Text Message Control or Status Message Control appears on the button.

# 31.43 Manual Call List

The **Manual Call List** function creates a button called Manual Call List. The Manual Call List window is used to place calls by manually entering the user ID number.

In C-Soft Runtime, if the Manual Call List button is clicked, the manual call list for the selected line appears. From this window, the user can manually send calls or status messages on the selected line based on programming set up in "Signaling Parameters window, page 72".

### To add a Manual Call List button, do the following:

1. From the Insert menu, select **Add UI Button**.

A None button appears on the console window.

2. Right-click the **None** button.

A shortcut menu appears.

- From the shortcut menu, select **Properties**.
   The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select Manual Call List.
- 5. Click OK.

The color of the button changes and Manual Call List appears on the button.

### Refer to

- Signaling Parameters window, page 72

# 31.43.1 Manual Call List window

The **Manual Call List** window is used to manually send messages, alerts and statuses. The User ID is entered by the console operator.




Figure 31.31: Manual Call List Window - C-Soft Runtime Application

# **User ID field**

The **User ID** field is used to enter an ID number to call or send status to.

### **Graphic DTMF keypad**

The **Graphic DTMF** keypad is used to enter DTMF digits to place calls and send status messages.

#### Clear button

The Clear button is used to clear all digits from the User ID field.

### **Backspace button**

The **Backspace** button is used to backup one space to clear the last digit entered.

#### Set Status button

The **Set Status** button is used to select from a list of preprogrammed status IDs. When a status ID is selected and the window is closed, the selected status appears in the Status field in the Status List window.

For more information, refer to "Status List window, page 236".

### **A-F Buttons**

The **A-F** buttons are valid digits for 5/6 Tone. Each digit corresponds to a different tone frequency.

# Call (1-10) Buttons

The **Call (1-10)** buttons are used to place user-defined calls configured in the "5/6 Tone DTMF ANI Setup Page" on "5-6 Tone/DTMF ANI system type, page 75". The labels configured on the 5/6 Tone/DTMF ANI Setup page appear on these buttons in the call list window.

### To place a manual call, do the following:

- 1. Select a **line** to call from.
- 2. Select a Manual Call List button.

The Manual Call List window appears, refer to the Figure above.

- 3. Using the monitor keypad or your keyboard, enter a **user ID number**. The number appears in the User ID field.
- 4. Press a configured call button to place the call.

The call is placed.

### **Done button**

The **Done** button is used to close the Manual Call List window.

# Refer to

- Status List window, page 236
- 5-6 Tone/DTMF ANI system type, page 75

# 31.44 Marker Tone

The **Marker Tone** function controls a periodic automatic keyup of a radio channel, along with an associated tone burst transmission for a particular line.



#### Notice!

If the Marker Tone function is selected, a line must be selected from the Line to Associate Function With drop down menu on the Type page.

# **Marker Tone Setup page**

When the Marker Tone function is selected from the UI Element drop down menu, **the Marker Tone Setup** page appears. Refer to the Figure below.




Figure 31.32: Marker Tone Setup Page - UI Element Setup

# **Tone Type group box**

The **Tone Type** group box identifies the type of tone to play. When a selection is made, the fields necessary to enter the setup information for that tone type are enabled on the page.

### Tone radio button

The **Tone** radio button indicates a single steady tone is used as an alert tone.

# To add a marker tone button, do the following:

- From the Insert menu, select Add UI Button.
   A None button appears on the console window.
- 2. Right-click the **None** button.
  - A shortcut menu appears.
- From the shortcut menu, select **Properties**.
   The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select **Marker Tone**.
  - The Marker Tone Setup tab appears.
- 5. Click the Marker Tone tab.
  - The Marker Tone Setup page appears.
- 6. In the Tone Type group box, select the **Tone** radio button.
- 7. In the Low Frequency field, enter the **frequency** (in Hz).
- 8. In the Tone Level field, enter the **tone level** (in dB).
- 9. In the Key-up Duration field, enter the **duration** (in ms).

- 10. In the Time Between Tones field, enter a **time** (in seconds).
- 11. Click **OK**.

The Marker Tone button is created.

#### **Pulsed Tone radio button**

The **Pulsed Tone** radio button indicates a pulsed tone is used as an alert tone.

#### To add a pulsed marker tone button, do the following:

- 1. From the Insert menu, select **Add UI Button**.
  - A None button appears on the console window.
- 2. Right-click the **None** button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select **Marker Tone**.
  - The Marker Tone Setup tab appears.
- 5. Click the **Alert Setup** tab.
  - The Alert Setup page appears.
- 6. From the Tone Type group box, select the **Pulsed Tone** radio button.
- 7. In the Low Frequency field, enter the **frequency** (in Hz).
- 8. In the Low/On Duration field enter the **duration** (in ms).
- 9. In the Hi/Off Duration field, enter the **duration** (in ms).
- 10. In the Tone Level field, enter the **tone level** (in dB).
- 11. In the Key-up Duration field, enter the **duration** (in ms).
- 12. In the Time Between Tones field, enter a time (in seconds).
- 13. Click **OK**.

The Marker Tone button is created.

#### Hi-Lo radio button

The **Hi-Lo** radio button indicates a Hi-Lo warble is used as an alert tone.

## To add a hi-lo marker tone button, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the **None** button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select Marker Tone.
  - The Marker Tone Setup tab appears.
- 5. Click the **Marker Tone** tab.
  - The Marker Tone Setup page appears.
- 6. From the Tone Type group box, select the **Hi-Lo** radio button.
- 7. In the Low Frequency field, enter the **frequency** (in Hz).
- 8. In the Low/On Duration field, enter a duration (in ms).
- 9. In the Hi Frequency field, enter a frequency (in Hz).
- 10. In the Hi/Off Duration field, enter the duration (in ms).
- 11. In the Tone Level field, enter the **tone level** (in dB).
- 12. In the Key-up Duration field, enter the **duration** (in ms).

- 13. In the Time Between Tones field, enter a **time** (in seconds).
- 14. Click **OK**.

The Marker Tone button is created.

## Low Frequency field

The Low Frequency field identifies the frequency, in Hz, of the low tone sent when the button is pressed.

The range for this field is 0 to 3000Hz.

## Low/On Duration field

The Low/On Duration field identifies the duration, in ms, the low frequency is played.

The range for this field is 0 to 5000ms.



#### Notice!

If Tone is selected, this field is ignored because the tone is continuous. If Pulsed Tone is selected, this field indicates the length of each tone off period. If Hi-Lo is selected, this field indicates how long the high tone is played.

## Hi Frequency field

The Hi Frequency field identifies the frequency of the Hi tone sent when the button is pressed.

The range for this field is 0 to 3000Hz.

## Hi/Off Duration field

The **Hi/Off Duration** field identifies the duration the Hi frequency is turned off.

The range for this field is 0 to 5000ms.

## Tone Level field

The **Tone Level** field identifies the relative change for allowable tone level.

The range for this field is -40 to 10dB.



#### Notice!

If Tone is selected, this field is ignored because the tone is continuous. If Pulsed Tone is selected, this field indicates the length of each tone off period. If Hi-Lo is selected, this field indicates how long the high tone is played.

# **Key-up Duration field**

The **Key-up Duration** field identifies the duration of the tone.

The range for this field is 0 to 10,000ms.

#### **Time Between Tones field**

The **Time Between Tones** field identifies the duration between key-ups.

The range for this field is 0 to 32 seconds.

# 31.45 MDC-1200

The MDC-1200 function, creates a button to open the MDC-1200 Dispatching window.

In C-Soft Runtime, when the window is open the user can view the system list, call and status history, status IDs, voice and data messages and select groups and individuals to place calls.

# MDC-1200 Setup page

When the MDC-1200 window function is selected from the UI Element drop down menu, the **MDC-1200 Setup** page appears.




Figure 31.33: MDC-1200 Setup Page - UI Element Setup

#### **Console Requests group box**

# **Timeout sec field**

The **Timeout sec** field is used to configure the amount of time, in seconds, the console waits when sending status requests, radio checks, radio enable, and radio disable messages. If the radio is unable to respond, No Response, appears in the status bar of the dispatching window depending on the current state of the radio.

The range for this field is 1 to 10 seconds.

## **Password Protection group box**

## **Emergency check box**

The Emergency check box indicates the console operator is prompted for the supervisor password before they are allowed to send an emergency message.

#### Radio Enable/Disable check box

The Radio Enable/Disable check box indicates the console operator is prompted for the supervisor password before they are allowed to enable or disable the radio.

## **Radio Remote Monitor check box**

The Radio Remote Monitor check box indicates the console operator is prompted for the supervisor password before they are allowed to remotely monitor the radio.

## **Remote Monitor group box**

#### **Enable Global Multiplier check box**

The Enable Global Multiplier check box indicates the values entered in the RX Multiplier and TX Multiplier fields are multiplied by two.

# Remote Monitor Type drop down menu

The Remote Monitor Type drop down menu is used to select a mode for radio transmission indications.

Available selections for this field are:

- Non-Silent Radio indicates transmission is occurring by flashing TX LED on the radio display when using radio remote monitor.
- Silent No transmit indication appears during transmission.



Figure 31.34: Remote Monitor Type Drop Down Menu

# RX Multiplier drop down menu

The RX Multiplier drop down menu indicates the amount of time the radio receiving the remote monitor command is unable to receive calls after transmitting. The value is multiplied by the remote monitor time programmed in the radio to determine the total time.

Available selections for this field are: 0 to 3.




Figure 31.35: Rx Multiplier Drop Down Menu

## TX Multiplier drop down menu

The **TX Multiplier** drop down menu is used to indicate how long the radio receiving the remote monitor command is allowed to transmit. The value is multiplied by the remote monitor time programmed in the radio to determine total transmit time.

Available selections for this field are: 0 to 3.




Figure 31.36: Tx Multiplier Drop Down Menu

To add an MDC-1200 Window button, do the following:

- From the Insert menu, select Add UI Button.
   A None button appears on the console window.
- Right-click the **None** button.A shortcut menu appears.

- From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select MDC-1200 Window. The MDC-1200 Setup tab appears.
- Click the MDC-1200 Setup tab.
  - The MDC-1200 Setup page appears
- 6. From the Console Request group box, enter a **time** for the timeout.
- From the Password Protection group box, select the **password protection** radio button. NOTE: For more information, refer to "Password Protection Group Box".
- 8. From the Remote Monitor group box, configure a multiplier. NOTE: For more information, refer to "Remote Monitor Group Box".
- Click OK.

A button with MDC-1200 on it appears.

#### 31.45.1 MDC-1200 Dispatching window

The MDC-1200 Dispatching window, shown in the Figure below, is used by the console operator in C-Soft Runtime to send and receive MDC-1200 messages. The status bar provides feedback about MDC-1200.




Figure 31.37: Selected Items Page - MDC-1200 Dispatching Window

## System Type drop down menu

The **System Type** drop down menu is used to change from the currently selected system to another system in the console position. When a system is selected, the system list populates with filters and components contained in the system.

Up to 200 systems can be created.

The default systems included in the drop down menu depend on the currently selected line's configuration.

# **System List**

The **System List** populates with system components that belong to the system currently selected in the System drop down menu. The system name is the first item to appear in the list. Filter components are listed next in the hierarchy. When a filter component is expanded individual units and groups are visible.

Systems can be configured, by the console admin, to display filters only. In that case, only components affiliated with a filter appear in the System List. Otherwise, all components, including components with deny icons (permission to place calls denied), appear in the list. Refer to the Figure below.

Icon	Туре	Description
	Filter	The Filter icon indicates the component is used to group, sort, and label the components contained in the filter.
		To view or hide filters, do one of the following:  - Click   to expand the filter list.  - Click   to collapse the filter list.
8	Deny	The Deny icon indicates the tagged item does not allow the console operator to place a call or send messages to this component.
<b>Ø</b>	Allow	The Allow icon indicates the component is available for selection. The console operator can place calls to these components.

Figure 31.38: MDC-1200 System Displays Only Filters Example

# System List flyout menu

The **System List** flyout menu is used as a quick method of accessing the Select Type commands that are also available with the MDC Message buttons.


Available selections for this field are:

- Call Alert
- Radio Check
- Request Status
- Select Call
- Radio Status
- Remote Monitor
- Emergency

# To access the System List flyout menu, do the following:

 In the system list, right-click the system, individual, or group to send the call or message to.

The System List flyout menu appears.



#### Selected Items page

The **Selected Items** page is used to view the currently selected component's ID information. The selected item list is used to determine where a call or status message is sent to. The operator can select one component per system in the list. Up to 200 messages can be sent simultaneously as long as they are each sent to a different system. When a system component in the system list is selected it is added to the selected items page.

Grayed out icons with deny tags are not available for selection.

## To add a component's ID to the Selected Items page, do the following:

In the System List field, select the component.

The component is highlighted, and appears in the Selected Items list.

Refer to "Manual Select Group Box" to learn how to manually enter an ID.

## To remove an ID from the Selected Items page, do the following:

- Right-click the unwanted component.
   A flyout menu appears.
- 2. Click Remove Item.

The item disappears from the list.

## Manual Select group box

The Manual Select group box is used to communicate with system users not in the system list.

#### **User ID field**

The **User ID** field is used to enter an MDC ID (in hexadecimal format) for selection to add to the list.

# Add to Selected button

The **Add to Selected** button is used to add the MDC ID entered in the User ID field to the selected items list.

## To manually place an individual radio ID in the selected items list, do the following:

- In the User ID field, enter an **ID** from 001-DFFF.

The ID appears in the Selected Items list.

## To manually place a group ID in the selected items list, do the following:

- In the User ID field, enter an **ID** from 000-FFF.

The ID appears in the Selected Items list.

## To manually place a system ID in the selected items list, do the following:

- In the User ID field, enter **FFFF**.

The ID appears in the Selected Items list.



#### Notice!

The character F behaves like a wildcard.

The **MDC Message** buttons, located at the bottom of the MDC-1200 Dispatching window, are used to send calls, alerts, statuses, and messages. When a button is clicked, the status bar confirms activity.

MDC offers ANI capabilities on PTT. When transmitting on a line, C-Soft sends the console's ID to the radio. A PTT call displays in the history pages as a Voice message type. The ID alias or ID appear on the line's Select button.

#### **Call Alert button**

The **Call Alert** button is used to send an alert message.

## To send a call alert, do the following:

From the system list, select the unit ID to send the alert message to.

OR

From the system list, select the **group** to send the alert message to The highlighted item is added to the selected items list.

Click Call Alert.

An alert is sent to the selected user(s) MDC-1200 radio.

#### **Radio Check button**

The Radio Check button indicates a message is sent to check for radio activity.

## To send a radio check message to an MDC-1200 radio, do the following:

- In the system list, select a unit ID to send the radio check message to.
   The highlighted item is added to the selected items list.
- 2. Click Radio Check.

If the selected radio is able to respond, Acknowledge appears on the line's select button, History window, and in the item list on the History page.

If the radio is unable to respond within the configured time allowed, No Response appears on the select button, the Per Line Call History window, and the list on the History page.

## **Status Request button**

The **Status Request** button is used to request status from a unit in the system.

#### To request a status from a unit, do the following:

In the system list, select a unit ID to send the alert message to.
 The highlight item is added to the selected items list.

#### 2. Click Status Request.

If the selected radio is able to respond, the (status message) appears on the line's select button, the Per Line Call History window, and in the item list on the History page. If the radio is unable to respond within the configured time allowed, No Response appears on the select button, the Per Line Call History window, and the list on the History page.

#### **Select Call button**

The **Select Call** button is used to place a select call.

## To place an MDC-1200 select call, do the following:

1. In the system list, select a **unit ID** to place the select call to.

The highlighted item is added to the selected items list.

OR

In the system list, select a **group** to place the select call to.

The highlighted item is added to the selected items list.

Click Select Call.

The select call message is sent and the receiving radio performs select call actions.

#### Radio Disable button

The **Radio Disable** button is used to disable a radio in the field from use by unauthorized persons.

## To disable a radio, do the following:

- In the system list, select a unit you want to disable from use.
   The highlighted item is added to the selected items list.
- 2. Click Radio Disable.

The disable radio message is sent and the radio no longer functions.

If the selected radio is able to respond, Acknowledge appears on the line's select button, History window, and in the item list on the History page.

If the radio is unable to respond within the configured time allowed, No Response appears on the select button, the Per Line Call History window, and the list on the History page.

# **Radio Enable button**

The Radio Enable button is used to enable a radio that has been disabled.

## To **enable a radio**, do the following:

- 1. In the system list, select a **unit** you want to enable for use.

  The highlighted item is added to the selected items list.
- 2. Click Radio Enable.

The microphone on the selected unit is open for monitoring.

If the selected radio is able to respond, Acknowledge appears on the line's select button, History window, and in the item list on the History page.

If the radio is unable to respond within the configured time allowed, No Response appears on the select button, the Per Line Call History window, and the list on the History page.

#### **Remote Monitor button**

The **Remote Monitor** button is used to remotely keyup a microphone for monitoring purposes.

To monitor a unit, do the following:

- In the system list, select a **unit ID** you want to monitor remotely. The highlighted item is added to the selected items list.
- Click Remote Monitor.

The microphone on the selected unit is open for monitoring.

# **Emergency button**

The **Emergency** button is used to send an emergency alert.

# To send an emergency call, do the following:

In the system list, select the **unit ID** to which the emergency alert is sent.

The highlighted item is added to the selected items list.

OR

In the system list, select the **group** to which the emergency alert is sent.

The highlighted item is added to the selected items list.

2. Click Emergency.

The emergency alert is sent and the receiving unit performs emergency actions.

#### 31.45.2 History page

The **History** page is used to view a log of received messages. Calls received from parallel consoles are included in the log. The history page is also used to place calls. Status, group and call color coding is supported. Click and drag column headings to rearrange column order. Messages can be sent to an ID in the history list. Items in the history list can not be removed. When C-Soft Runtime is closed all call history is cleared.

For more information, refer to "Per Line Call History Window Lines Window Field" on "Per Line Call History Window Lines Field".

## Note:

- Received messages also appear on the line's select button while receiving a call and in the Per Line Call History window, refer to "Per Line Call History Window" on page 314.
- MDC-1200 call history can also be found on the Per Line Call History window.




Figure 31.39: History Page - MDC Dispatching Window

## To place a select call from the History page, do the following:

- 1. From the history log, select a **unit ID** entry in the history log.
- 2. Click Select Call.

The call is sent.

For more calling options, refer to "Selected Items Page" on *MDC-1200 Dispatching window, page 294*.

## **Date column**

The **Date** column displays the date the message was received.

## Time column

The **Time** column displays the time the message was received.

## **Channel column**

The **Channel** column displays the frequency the message was sent on.

# Call Type column

The **Call Type** column displays the type of message received.

There are seven call type possibilities:

Call Alert Type

Call Alert indicates an alert message was received from an MDC-1200 radio. When a call alert message is received, all alerts and the caller's alias or ID appears on the receiving line's button. If annunciations are configured, they are played when an alert is received. Refer to "Annunciation of Call Alert Group Box" on page 341.

## **Emergency Type**

Emergency indicates an emergency message was received from an MDC-1200 radio.

## Group Call Type

Group Call indicates a group call was received from an MDC-1200 radio. When a group call is received, the group call initiator's ANI or ID appear on the receiving line's select button. If annunciations are configured, they are heard when a group call is received. Refer to "Annunciation of Select Call Group Box" on page 339.

## Select Call Type

Select Call indicates a select call was received from an MDC-1200 radio. When an individual call is received, the caller's ANI or ID appears on the receiving line's select button. If annunciations are configured, they are heard when a select call is received. Refer to "Annunciation of Select Call Group Box" on page 339.

#### Status Type

Status indicates a status message was received from an MDC-1200 radio. When a status message is selected, the alias or ID appears in the Calling ID field and a status message appears in the Status message field.

## Txt msg Type

Txt msg (Text Message) indicates a text message was received from an MDC-1200 radio. When a text message is selected, the alias or ID appear in the Calling ID field and the text message appears in the Test Message field.

## Voice Type

Voice indicates a voice message was received from an MDC-1200 radio. If available, the ANI displays on the receiving line's select button, otherwise the ID appears.

#### Call Details group box

The Call Details group box gives information about a selected item in the history list.

## Calling ID

The Calling ID is the alias or ID number of the MDC-1200 radio that sent the selected message.

## Status Message field

The Status Message field is used to display the status message received by the selected message.

If a text message appears in the field, the label changes to Text Message.

## Text Message field

The **Text Message** field is used to display the text message received by the selected message.

If a status message appears in the field, the label changes to Status Message.

## **Call History View group box**

#### All Lines radio button

The All Lines radio button indicates the history list displays all messages received on all lines.

#### Selected Line radio button

The Selected Line radio button indicates the history list displays messages received on selected lines in the system.

## Refer to

MDC-1200 Dispatching window, page 294

#### 31.46 Monitor

The **Monitor** function allows the console operator to send a packet burst, similar to a frequency change, to a remote radio, instructing the radio to open squelch or ignore CTCSS tones.

## To add a monitor button, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the None button.
  - A shortcut menu appears.
- From the shortcut menu, select Properties.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select Monitor.
- Click OK.

The button changes color and MON appears on the button.

#### 31.47 **MOTOTRBO Radio Setup page**

When the MOTOTRBO function is selected from the UI Element drop down menu, the MOTOTRBO Radio Setup window appears.



#### Notice!

Each line controlling either a MTRBi or MOTOTRBO requires its own window.

The MOTOTRBO Radio Setup page, shown in the Figure below, is used for setting Dispatch Window features and entering time intervals to check for the Master Console.




Figure 31.40: MOTOTRBO Radio Setup Page Example

#### **MOTOTRBO Dispatch Window Setup group box**

## **Enable MOTOTRBO Dispatch Window check box**

The **Enable MOTOTRBO Dispatch Window** check box, if selected, allows the user to open the Dispatch Window in Runtime. If not selected, the user is not able to open the Dispatch Window in Runtime.

## **Dispatch Window Config button**

The **Dispatch Window Config** button is used to open the Dispatch Window settings. The button text and color of the Dispatch Window can be updated in this view.

For more information on Dispatch Window Config button, refer to the Figure below.

## **MOTOTRBO Radio List Font Size field**

The MOTOTRBO Radio List Font Size field is used to enter the font size of the ID List.

#### Text Message RX Button Blink Color drop down palette

The **Text Message TX Button Blink Color** drop down palette is used to select the color that the MOTOTRBO Dispatch Window button blinks when a text message is received. The button will not blink if the MOTOTRBO Dispatch Window's Text Message tab is already open.

## **MOTOTRBO Timing group box**

# **Master Heartbeat Send Time field**

The **Master Heartbeat Send Time** field is used to enter an interval for the master console to send its heartbeat out to all other consoles on the control line (i.e., 1).

The range for this field is 1 to 999 seconds.

The default is 1.

#### MTRBi Check Send Time field

The **MTRBi Check Send Time** field is used to enter an interval for C-Soft to verify the MTRBi on a certain line is alive (i.e., 4).

#### Note:

- Allow one second for the check function to complete.
- This function is only available when MTRBi is selected on the MOTOTRBO Setup tab.

EXAMPLE: If this field is set to four seconds, the console sends an MTRBi check command then waits for four minus one second, or three seconds for a response.

The range for this field is 2 to 999 seconds.

The default is 4.

#### Slave Check Time field

The **Slave Check Time** field is used to enter an interval for the console to wait to receive a heartbeat from the master before it changes into the master. (i.e., 4)

EXAMPLE: At startup, the console waits four seconds for a heartbeat, if nothing is received, the console changes to the master console. If a heartbeat is detected, the console remains a slave and resets to four seconds.

The range for this field is 3 to 999 seconds.

The default is 4.

## **Master Resend Command Time field**

The **Master Resend Command Time** field is used to enter an interval for C-Soft to resend a MOTOTRBO command (i.e., 1).

EXAMPLE: If C-Soft sends a MOTOTRBO command and does not get a response in one second, it sends the command again, waits one second, if nothing sends again, waits one second. If no response is received after three tries the command is cleared and goes to the next command to send to the buffer. The maximum tries is three.

The range for this field is 1 to 999 seconds.

The default is 1.

# **PTT Hangtime field**

The **PTT Hangtime** field is used to enter the amount of time C-Soft waits before sending the end of call command to the MTRBi. This delay allows the IP-224 to finish processing the outgoing audio before the mobile stops transmitting.

The value entered in this field is multiplied by 20ms to calculate the total delay. This value should match the Packet Delay Before Playback field in the Ethernet Setup section of the IP-223 technical manual and the IP-224 technical manual.

The range for this field is 0 to 99 x 20ms.

EXAMPLE: A value of 10 delays sending the end of call command by 200ms.

This feature is only enabled when MTRBi is selected from the MOTOTRBO Setup tab in Signaling Setup.

## **Password Protection group box**

The **Password Protection** group box enables the user to set up functions that require a user password before allowing the user access.

If not selected, no password is required.

#### Radio Monitor check box

The **Radio Monitor** check box indicates the user must enter a password to use these functions.

## Radio Inhibit/Uninhibit check box

The **Radio Inhibit/Uninhibit** check box indicates the user must enter a password to use the function.

#### Call Alert check box

The Call Alert check box indicates the user must enter a password to use the function.

#### **MOTOTRBO Misc group box**

#### Talk Permit Tones check box

The **Talk Permit Tones** check box, if selected, enables the user to hear go ahead Tones when PTT is pressed in Runtime.

### Channel Alias Read check box

The **Channel Alias Read** check box indicates the channel's aliases are read automatically from the mobile radio.

This feature is only enabled when MOTOTRBO is selected from the MOTOTRBO Setup tab in the Signaling Setup Window.

# 31.47.1 Dispatch Window

The **Dispatch Window**, shown in the Figure below, is used to select the color, font and font size of the Dispatch Window settings.




Figure 31.41: Dispatch Window Example

# Dispatch Window Color drop down menu

The **Dispatch Window Color** drop down menu is used to select the color of the Dispatch Window.

## To select the color of the Dispatch Window, do the following:

 From the Dispatch Window Color drop down menu, select the desired color for the dispatch window.

## **Set Font button**

The **Set Font** button opens the Font window.




Figure 31.42: Dispatch Window Font Drop Down Menu

To set the font of the Dispatch Window, do the following:

From the Font window, select the desired font for your text.

#### **Main Control Page**

The Main Control page, shown in the Figure "Dispatch Window Example" on Dispatch Window, page 306, is used to change the color, font type, and font size for the following buttons:

- InPTT
- Private Call
- Group Call
- Mute
- Select
- Numerical Pad
- Delete




Figure 31.43: Select Color and Text

# Button Color Up drop down menu

The Button Color Up drop down menu is used to select the color of the button as it is released.

## **Button Color Down drop down denu**

The Button Color Down drop down menu is used to select the color of the button as it is pressed.

# **Button Text Color drop down menu**

The Button Text Color drop down menu is used to select a color for the button text.

## **Enable Button check box**

The Enable Button check box is used to enable the button in C-Soft Runtime. If disabled, the button's operation is not available.

#### **Button Text field**

The **Button Text** field is used to add text to the button.

## **OK** button

The **OK** button is used to accept the changes to the button.

#### **Cancel button**

The **Cancel** button is used to discard any changes to the button.

## To select color and text of the desired button, do the following:

- 1. From the Main Control menu, press the **desired button**. Select Color and Text appears.
- 2. From the Button Color Up drop down menu, select the **desired color**.
- 3. From the Button Color Down drop down menu, select the **desired color**.
- 4. From the Button Text Color drop down menu, select the **desired color**.
- 5. Select the **Enable Button** check box to enable the button's functionality in C-Soft Runtime.
- 6. In the Button Text field, enter the **desired text** for the button.
- 7. Click **OK**.

The entries are saved.

## **Unit Control Page**

The **Unit Control** page, shown in Figure below is used to change the color, font type, and font size for the following buttons:




Figure 31.44: Unit Control Page Example

## **Radio Check button**

The **Radio Check** button is used to select the color of the button and text of the Radio Check button.

## **Remote Monitor button**

The **Remote Monitor** button is used to select the color of the button and text of the Remote Monitor button.

 Bosch Security Systems, LLC
 Technical Manual
 2021-06 | 14 | F.01U.218.561

#### Call Alert button

The Call Alert button is used to select the color of the button and text of the Call Alert button.

#### Radio Disable button

The Radio Disable button is used to select the color of the button and text of the Radio Disable button.

#### Radio Enable button

The Radio Enable button is used to select the color of the button and text of the Radio Enable button.

## **GPS Trigger On button**

The GPS Trigger On button is used to select the color of the button and text of the GPS Trigger On button.

## **GPS Read button**

The GPS Read button is used to select the color of the button and text of the GPS Read button.

## **GPS Trigger Off button**

The GPS Trigger Off button is used to select the color of the button and text of the GPS Trigger Off button.

# **Keypad**

The **Keypad** buttons are used to select the color of the buttons and text of the Keypad buttons.

## To select color and text of the desired button, do the following:

- 1. From the Unit Control window, select the **desired button**. Select Color and Text appears.
- 2. From the Button Color Up drop down menu, select the **desired color**.
- 3. From the Button Color Down drop down menu, select the **desired color**.
- From the Button Text Color drop down menu, select the **desired color**.
- Select the **Enable Button** check box to enable the selected color and text of the button.
- 6. In the Button Text field, enter the **desired text** for the button.
- 7. Click OK.

The entries are saved.

### **Text Message page**

The **Text Message** page, shown in the Figure below, is used to select the color of the button and text of the text message.




Figure 31.45: Text Message Page Example

## **Clear History button**

The **Clear History** button is used to select the color of the button and text of the Clear History button.

#### **Send Unit Text button**

The **Send Unit Text** button is used to select the color of the button and text of the Send Unit Text button.

# **Send Group Text button**

The **Send Group Text** button is used to select color of the button and text of the Send Group Text button.

To select color and text of the desired button, do the following:

- From the Text Message menu, press the **desired button**.
   Select Color and Text appears.
- 2. From the Button Color Up drop down menu, select the **desired color**.
- 3. From the Button Color Down drop down menu, select the **desired color**.
- 4. From the Button Text Color drop down menu, select the **desired color**.
- 5. Select the **Enable Button** check box to enable the selected color and text of the button.
- 6. In the Button Text field, enter the **desired text** for the button.
- 7. Click OK.

The entries are saved.

## **History page**

The **History Message** page, shown in the Figure below, is used to change the color, font type, and font size for the following buttons:

Figure 31.46: History Message Page Example

#### **Private Call button**

The **Private Call** button is used to select the color of the button and text of the Private Call button.

To select color and text of the desired button, do the following:

- From the History menu press the **desired button**.
   Select Color and Text appears.
- 2. From the Button Color Up drop down menu, select the **desired color**.
- 3. From the Button Color Down drop down menu, select the **desired color**.
- 4. From the Button Text Color drop down menu, select the **desired color**.
- 5. In the Private text field, enter the desired text to be displayed when a call from an individual is selected.
- 6. In the Group Text field, enter the **desired text** to be displayed when a call from a group is selected.
- 7. Click **OK**.

The entries are saved.



#### Notice!

The Private Call Button uses the Enable Button setting from the DFSI Window's Main Control tab's Private Call and Group Call buttons.

# 31.47.2 MOTOTRBO Dispatching window

The **MOTOTRBO Dispatching** window, shown in the Figure below, is used by the console operator in C-Soft Runtime to manage a MOTOTRBO line's call history, channel changes, send text messages and alerts, read GPS coordinates and read remote radio positions. Volume adjustments, radio checks, and radio enable/disable are also conducted from this window.

During operation, all parallel consoles on the same network synchronize to each other. Consoles on the same network display the same channel and zone, received ID, alias, history and notifications.

Each line controlling a MTRBi (MOTOTRBO) or MOTOTRBO Interface requires its own window.

# To add a MOTOTRBO button, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the **None** button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select **MOTOTRBO**.
  - The MOTOTRBO Radio Setup page appears.
- 5. In the Master Heartbeat Sent time field, enter a **time interval** to send a heartbeat.
- 6. In the MTRBi Check Send Time field, enter a time interval to check MTRBi status.
- 7. In the Slave Check Time field, enter the **amount of time** C-Soft waits before changing to the master console.
- 8. In the Master Resend Command Time field, enter the **amount of time** C-Soft waits before resending a command.
- 9. From the MOTOTRBO drop down menu, select a background color for the window.
- 10. Click **OK**.

The MOTOTRBO button is added to the console.

# **Main Control page**

The MOTOTRBO window displays the most frequently used MOTOTRBO fields.

The drop down menu selections are set up in C-Soft Designer and the MOTOTRBO radio programming software.




Figure 31.47: MOTOTRBO Dispatching Window

#### Channel drop down menu

The **Channel** drop down menu is used to change the channel of the selected line. If a parallel console or the radio changes the channel, this field updates with the current channel information.

Available selections for this field are configured in the radio.

# Zone drop down menu

The **Zone** drop down menu is used to change the zone of the selected line. If a parallel console or the radio changes the zone, this field updates with the current zone information.

Available selections for this field are configured in the radio.

## **Volume Slider**

The **Volume Slider** is used to increase or decrease the volume to the speaker or handset currently connected. The volume indicator gives a graphical representation of the total volume.



#### Notice!

MOTOTRBO is compatible with the ADHB-4 which can also be used to adjust volume.

## **Trbo Ptt button**

The **Trbo Ptt** button is used the same as a normal key up of a mobile radio.

#### **Private Call button**

The **Private Call** button is used to select what is entered in the ID field for a private call.

## **Group Call button**

The Group Call button is used to select what is entered in the ID field for a group call.

#### **Mute button**

The **Mute** button is used to mute or amplify the selected line's volume. If the console speaker is muted, the universal no symbol appears on the speaker icon.

#### Select button

The **Select** button is used to select or deselect the MOTOTRBO Line.

## **Status Information field**

The **Status Information** field displays all incoming and outgoing MOTOTRBO radio status information.

#### **MOTOTRBO Connection Indicator**

The **MOTOTRBO Connection Indicator** indicates the status of the connection to the MOTOTRBO currently displayed in the MOTOTRBO window. If green, the unit is online and functional. If red, the unit is offline or disconnected.

## **Unit Control page**

When the Unit Control tab is clicked from the MOTOTRBO window, the Control Buttons page appears. The **Unit Control** page is used to access MOTOTRBO functions. When a radio is selected in the ID field, a button can be clicked to perform an action.

Figure 31.48: MOTOTRBO Window - Unit Control

# **Radio Check button**

The Radio Check button is used to verify if the target radio is currently online and functional.

## Radio Disable button

The **Radio Disable** button is used to disable a target radio from use. This feature can be used in the case of a lost or stolen radio.

#### Radio Enable button

The **Radio Enable** button is used to enable the target radio for use. This feature is used to enable a radio if it has been disabled with the Radio Disable button.

## **Remote Monitor button**

The **Remote Monitor** button is used to monitor the target remote radio.

#### **Call Alert button**

The **Call Alert** button is used to send an alert to the target remote radio.

#### **GPS Read button**

The **GPS Read** button is used to request a read of the selected radio's current location and navigate to the radio's location on Google Earth.

# **GPS Trigger On button**

The **GPS Trigger On** button is used to enable the GPS to send status at a regular interval to the console. The interval is determined by the value entered in the GPS Trigger On field.

## **GPS Trigger Off button**

The **GPS Trigger Off** button is used to disable the radio from periodic GPS coordinate updates status to the console.

## **GPS Trigger On field**

The **GPS Trigger On** field is used to configure the interval with which the selected radio sends a GPS location to the console.

Available options for this field are: 30 sec, 1 min, 4 min, 8 min, 10 min, 20 min, and 30 min.

## **Text Message page**

When the **Text Message** tab is clicked the Text Message page appears. Refer to the Figure on 441.

The Text Message page is used to send text messages to the selected individual or a group of radios and to view text messages sent and received during the current C-Soft Runtime session.

## **Radio Name column**

The **Radio Name** column displays the name assigned to the radio the text message was sent or received.

#### Time column

The **Time** column displays the time the text message was sent or received.

#### **Text Message column**

The **Text Message** column displays the text message sent to or received from the radio.

## Quick Text drop down menu

The **Quick Text** drop down menu is used to select a text ID number assigned to a preprogrammed text message. When a text ID is selected, its message appears in the Text field.

#### **Text field**

The **Text** field displays a preview of the text message to be sent when Send Text is clicked. A text message can be entered using the Quick Text drop down menu or it can be entered manually.

This field can contain up to 100 characters.

## **Send Unit Text button**

The **Send Unit Text** button is used to send the message in the Text field to the selected radio. When clicked, the message is sent to the radio.

To **send a text message**, do the following:

1. In the Text field, enter a **text message** to send.

OR

From the Quick Text drop down menu, select a **Text ID**.

2. From the ID drop down menu, select an individual to send the text message to.

ΟR

From the ID drop down menu, select a group to send the text message to.

3. Click Send Unit Text.

The text message is sent to the selected user.

OR

Click Send Group Text.

The text message is sent to the selected group.

#### **Clear History button**

The Clear History button is used to clear all text messages in the list.

# To clear text message history, do the following:

Click Clear History.

The text message history list is deleted.

## History page

The **History** page appears when MOTOTRBO window is maximized. The History page is global for all MOTOTRBO lines. All MOTOTRBO active and previous calls appear in the list. Each call's radio name, radio ID, date, time, call type, and the call's current state appear.



#### Notice!

When C-Soft Runtime is closed, this list is cleared.

#### Date column

The **Date** column displays the date the call was received.

#### Time column

The **Time** column displays the time the call was received.

# Freq column

The **Freq** column displays the frequency the call came from.

## Status column

The Status column displays the current status of the call.

Available options for this field are Mobile PTT, In Progress, Call RX., GPS Position, On, Off, Passed and Failed.

#### **User ID column**

The User ID column displays the caller's user ID.

# **Call Type column**

The **Call Type** column displays the type of call.

Available options for this field are Private, Group, Alert, Enable, Disable, Check, Scan, Monitor and GPS Read.

#### **Private Call button**

The **Private Call** button is used to initiate a private call to the User ID displayed in the selected entry's User ID column.

# 31.48 Mute Group

The **Mute Group** function allows the console operator to mute the audio on a pre-defined group of lines.

## **Line Group page**

When the **Mute Group** function is selected from the UI Element drop down menu, the Line Group page appears. Refer to the Figure below.



#### Notice!

The Line Group page is used to select the lines that belong to a specific Mute Group.




Figure 31.49: Line Group Page - UI Element Setup

## **Select Lines for Group field**

The **Select Lines for Group** field contains a list of all the lines configured on the "*Per Line Parameters window, page 61*". Selecting a line from this list, assigns the line to the group.

Click the Group Programmed button in the C-Soft Runtime program to place the lines defined on the Line Group page into a select condition.

To add a Mute Group button, do the following:

- From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the None button.
  - A shortcut menu appears.
- From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select **Mute Group**.
  - The Line Group tab appears.
- 5. Click the **Line Group** tab.
  - The Line Group page appears.
- 6. From the Select Line for Group field, select the **line**(s) you want to add to the group.

The selected lines are assigned to the group. The button color changes and Mute Group appears on the button.



#### Notice!

Deselect the highlighted line, to remove a line from the Mute Group List.

#### Refer to

Per Line Parameters window, page 61

#### 31.49 **Mute Main**

The Mute Main function allows the console operator to mute all lines not currently selected.



## Notice!

Selected lines can also be muted when the Allow Muting Selected Lines option is selected on the Global Parameters page. Refer to "Global Parameter Setup window, page 114".

## To add a Mute Main button, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the None button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select Mute Main.
- 5. Click OK.

The button changes color and Mute appears on the button.

# Refer to

Global Parameter Setup window, page 114

# 31.50 Mute-Per Line

The **Mute-Per Line** function allows the console operator to mute a particular line. It is a toggle button that is active when clicked and inactive when released.

## **Mute Icon**

A **Mute Icon**, shown in the Figure below, appears on a line's Select button, a group select button, a phone onhook/offhook button, a SIP button or a NENA indication anytime the line is muted, RX blocked, or group muted.

This icon can be customized by selecting an image for the Mute icon in the *Button Images* window, page 141.




Figure 31.50: Mute Icon - Select Button

# 31.50.1 Per Line Mute Button Setup page

When the Mute - Per Line function is selected from the UI Element drop down menu, as shown in the Figure below, the **Per Line Mute Button Setup** page appears.

The Per Line Mute Button setup tab is used to set the Mute Time and Minimum Mute Level.




Figure 31.51: Per Line Mute Button Setup Page - UI Element Setup

#### **Mute Time field**

The **Mute Time** field identifies the duration audio is muted before the audio is automatically restored. A value of zero disables this feature.

The range for this field is 0 to 180 seconds.

# Min Mute Level field

The **Min Mute Level** field identifies the level the unselected audio level is reduced at the speaker. Enter a value from -20 to -1dB to reduce the level on the muted line accordingly without completely muting the line. This ensures the console operator is unable to completely turn off audio being monitored. A value of zero completely mutes the line.

The range for this field is -20 to -1dB.



#### Notice!

Selected lines can also be muted when the Allow Muting Selected Lines option is selected on the Global Parameters page. Refer to "Global Parameter Setup window, page 114".

## To add a Mute-Per Line button, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- Right-click the None button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select **Mute Per Line**.
  - The Line to Associate Function With drop down menu becomes active. The Per Line Mute Button Setup tab appears.
- 5. From the Line to Associate Function With drop down menu, select the line you want to associate with the Mute - Per Line function.
- 6. Click the Per Line Mute Button Setup tab.
  - The Per Line Mute Button Setup page appears.
- 7. In the Mute Time field, enter the **amount of time** the line is muted before audio is automatically restored.
- In the Min Mute Level field, enter the audio level for the unselected line.
- Click OK. 9.

The button changes color and Mute appears on the button.

#### 31.51 P25-DFSI window

The P25-DFSI window allows the console operator to open the P25-DFSI Dispatching window.

# P25-DFSI Misc page

When the P25-DFSI function is selected from the UI Element drop down menu, the P25-DFSI Misc page appears. Refer to the Figure below.




Figure 31.52: P25-DFSI Misc - UI Element Setup

## Misc group box

## **Enable P25-DFSI Dispatch Window check box**

The **Enable P25-DFSI Dispatch Window** check box gives the user to open the Dispatch Window in Runtime. If not selected, the user is not able to open the Dispatch Window in Runtime.

## **Receive All Talk Groups check box**

The **Receive All Talk Groups** check box indicates all incoming Talk Groups can be heard. If not selected, only incoming calls with Talk Groups matching the current Talk Group will be heard, all others are muted.

# Receive All Private Calls check box

The **Receive All Private Calls** check box indicates all incoming Private Calls can be heard. If not selected, only incoming Private Calls sent directly to the console will be heard, all others are muted.

## P25-DFSI Radio List Font Size field

The **P25-DFSI Radio List Font Size** field is used to select a font size for the P25-DFSI Radio List.

The range for this field is 0 to 99. The default is 12.

## **Dispatch Window Config button**

The **Dispatch Window Config** button is used to open the Dispatch Window settings. The button text and color of the Dispatch Window can be updated in this view. For more information, refer to "Appendix E - P25-DFSI (Digital Fixed Station Interface), page 479".

## **Password Protection group box**

The **Password Protection** group box enables the user to set up functions that require a user password before allowing the user access.

If not selected, no password is required.

#### Radio Monitor check box

The **Radio Monitor** check box, if enabled, indicates the Radio Monitor function is password protected.

For more information, refer to "Global Parameter Setup window, page 114".

## Radio Inhibit/Uninhibit check box

The **Radio Inhibit/Uninhibit** check box, if enabled, indicates the Radio Inhibit/Uninhibit function is password protected.

For more information, refer to "Global Parameter Setup window, page 114".

## Call Alert check box

The Call Alert check box, if enabled, indicates the Call Alert function is password protected.

For more information, refer to "Global Parameter Setup window, page 114".

## Vote Select/Disable check box

The **Vote Select/Disable** check box, if enabled, indicates the Vote Select/Disable function is password protected.

For more information, refer to "Global Parameter Setup window, page 114".

#### **OK** button

The **OK** button saves the entries and closes the window.

# 31.52 Page

The **Page** function allows the console operator to send a single page to a specific line on a specific frequency.

## Page Setup page

When the Page function is selected from the UI Element drop down menu, the **Page Setup** page appears. Refer to the Figure below.




Figure 31.53: Page Setup Page - UI Element Setup

## Page Setup group box

### Format drop down menu

The **Format** drop down menu is used to select the desired pager. This field contains all the pagers defined for the line in the "*Paging Settings window, page 149*".

## Frequency drop down menu

The **Frequency** drop down menu is used to select the frequency for the page. This field contains all of the frequencies defined for "Freqs Button".

## **Talk Time field**

The **Talk Time** field is used to enter the amount of time, in ms, allowed for the console operator to add a voice message to a page after the page has been sent.

The range for this field is 0 to 32000ms.

## **Page String field**

The **Page String** field is used to enter the page string specific to the pager selected in the format field.

This field can contain up to 35 characters.

### **Use Manual Cap Code Entry check box**

The **Use Manual Cap Code Entry** check box indicates a page string is manually entered by the user in Runtime, instead of using the predefined page string entered in the Page String field.

 Bosch Security Systems, LLC
 Technical Manual
 2021-06 | 14 | F.01U.218.561



### Notice!

Selecting this option disables the Page String field.

In C-Soft Runtime, when the page button is clicked, the Manual Paging Entry window appears. The user enters the number to page and clicks Send Page.




Figure 31.54: Manual Page Entry Window

### Send on Selected (not steered) check box

The **Send on Selected (not steered)** check box indicates the page is sent to the selected line or the unselected line. Otherwise, the page is sent to the line configured for the page button.

### Relay Setup group box

## **Active Relay With Page check box**

The **Active Relay With Page** check box indicates a configured relay activates when a page is sent.

## **Relay Destination group box**

The **Relay Destination** radio buttons identify the relay to be controlled. When a selection is made, the fields necessary to enter the setup information for the relay are enabled.

## ADHB-4 Settings group box

The **ADHB-4 Settings** radio buttons identify which ADHB-4 relay is activated when the page is sent.

## None radio button

The **None** radio button indicates none of the ADHB-4 relays is activated.

### Relay 1 radio button

The **Relay1** radio button indicates the first relay in the ADHB-4 is being controlled.

### Relay 2 radio button

The **Relay 2** radio button indicates the second relay in the ADHB-4 is being controlled.

### **NEO Settings group box**

The **NEO Settings** field identifies the IP Address and the relay, if any, for the NEO-10.

#### IP field

### Relay drop down menu

The **Relay** drop down menu is used to select the desired relay.

Available selections for this field are None, Port 1, Port 2, Port 3, Port 4, Port 5, Port 6, Port 7, Port 8, Port 9 and Port 10.

### **Active Duration field**

The **Active Duration** field is used to enter the length of time, in ms, the relay remains active from the start of the Annunciation.

The range for this field is 300-3000ms.

### To add a Page button, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the **None** button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select Page.
  - The Line to Associate Function With drop down menu becomes active. The Page Setup tab appears.
- 5. From the Line to Associate Function With drop down menu, select the **line** you want to associate with the Page function.
- 6. Click the Page Setup tab.
  - The Page Setup page appears.
- 7. From the Format drop down menu, select the **type of pager** being used.
- 8. From the Frequency drop down menu, select the **frequency** for the pager.
- 9. In the Talk Time field, enter the **amount of time** allowed for the console operator to add a voice message to the page.
- 10. In the Page String field, enter the page string or code specific to the pager.
- 11. Select the Send on Selected (not steered) check box, if desired.
- 12. Click **OK**.

The button changes color and Page appears on the button.

## 31.53 Page Cancel

The **Page Cancel** function is used to cancel the transmission of one or more pages while the pages are being sent.

If the Manually Confirm When Pages Are Done Sending check box is selected ("Paging Settings window, page 149"), the Page Cancel button clears the Paging Done icons from all paging buttons.



Figure 31.55: Paging Button

### Note:

- These icons can be customized by using the *Button Images window, page 141*.
- If you do not want to use one of the icons, you must make a 1 pixel bmp file and call it out properly (see above). If you delete the .bmp file, the C-Soft Runtime uses the default icons.

### Refer to

- Paging Settings window, page 149

## 31.54 Page Manual Entry

The **Page Manual Entry** function allows the incorporation of up to five single tones in sequence for a specific line.

## 31.54.1 Manual Page Setup

When the Page Manual Entry function is selected from the UI Element drop down menu, the **Manual Page Setup** page appears. Refer to the Figure below.




Figure 31.56: Manual Page Setup Page - UI Element Setup

## Initial Lead-In Delay field

The Initial Lead-in Delay field identifies the amount of time to use for the lead-in delay.

The range for this field is 0 to 20000ms.

## Frequency drop down menu

The **Frequency** drop down menu identifies the frequency to send the page on. This field contains all of the frequencies defined for the line in "Freqs Button".

### **Tone Level field**

The **Tone Level** field identifies the audio level of the tone.

The range for this field is -60 to 10dB.

## Tone (1-5) fields

The **Tone (1-5)** fields identify the frequency for the tone.

The range for this field is 0 to 3000Hz.

## Tone (1-5) Level fields

The **Tone (1-5)** Level fields identify the length for the tone.

The range for this field is 0 to 65000ms.

## Talk Time field

The **Talk Time** field identifies the maximum amount of time, allowed for talk time.

The range for this field is 0 to 65000ms.

## Send on Selected (not steered) check box

The **Send on Selected (not steered)** check box indicates the page is sent to the selected line. Otherwise, the page is sent to the line configured for the page button.

## **Relay Setup group box**

## **Active Relay With Annunciation check box**

The **Active Relay With Annunciation** check box indicates a configured relay activates when an Page is sent.

## **Relay Destination group box**

The **Relay Destination** radio buttons identify the relay to be controlled. When a selection is made, the fields necessary to enter the setup information for the relay are enabled.

## ADHB-4 Settings group box

The **ADHB-4 Settings** radio buttons identify which ADHB-4 relay to activate when the page is sent.

### None radio button

The **None** radio button indicates none of the ADHB-4 relays is activated when sending a page.

### Relay 1 radio button

The **Relay1** radio button indicates the first relay in the ADHB-4 is being controlled.

## Relay 2 radio button

The **Relay 2** radio button indicates the second relay in the ADHB-4 is being controlled.

## **NEO Settings group box**

The **NEO Settings** field identifies the IP Address and the relay, if any, for the NEO-10.

## IP field

The IP field identifies the IP Address of the NEO-10.

## Relay drop down menu

The **Relay** drop down menu is used to select the desired relay.

Available selections for this field are None, Port 1, Port 2, Port 3, Port 4, Port 5, Port 6, Port 7, Port 8, Port 9 and Port 10.

### **Active Duration field**

The **Active Duration** field is used to enter the length of time, in ms, the relay remains active from the start of the Annunciation.

The range for this field is 300-3000ms.

## **Page Generation options**

### **Page Tone Iteration Count field**

The **Page Tone Iteration Count** field is used to determine the number of times the button's tone sequence is sent during the page and allows for tone sequences to be repeated a specified number of times.

The range for this field is 1 - 100.

The default value for this field is 1.

### To add a Manual Page button, do the following:

- 1. From the Insert menu, select **Add UI Button**.
  - A None button appears on the console window.
- 2. Right-click the **None** button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select Page-Manual Entry.
  - The Line to Associate Function With drop down menu becomes active. The Manual Page Setup tab appears.
- 5. From the Line to Associate Function With drop down menu, select the **line** you want to associate with the Manual Page function.
- 6. Click the Manual Page Setup tab.
  - The Manual Page Setup page appears.
- 7. In the Initial Lead in Delay field, enter the **lead-in delay** for the pager.
- 8. From the Frequency drop down menu, select the **type of frequency** for the pager.
- 9. In the Tone 1 through Tone 5 fields, enter the **level** and **amount of time** for each tone.
- 10. In the Talk Time field, enter the **amount of time** allowed for the console operator to add a voice message to the page.
- 11. Select the **Send on Selected (not steered)** check box, if desired.
- 12. Click **OK**.

The button changes color and Page appears on the button.

## 31.55 Page Send

The **Page Send** function allows a console operator to send a group of pages selected using the Page Stack button. This option also works when the Always Stack Page Buttons check box is selected, refer to "Always Stack Page Buttons Check Box" on "Always Stack Page Buttons Check Box".

In C-Soft Runtime, the console operator is notified when the last stacked page is sent. A voice message can be sent to page recipients.

## To add a Page Send button, do the following:

- From the Insert menu, select Add UI Button.
   A None button appears on the console window.
- 2. Right-click the None button.
  - A shortcut menu appears.
- From the shortcut menu, select **Properties**.
   The UI Element Setup window appears.

- 4. From the UI Element drop down menu, select **Page Send**.
- 5 Click OK

The button changes color and Page Send appears on the button.

## 31.56 Page Stack

The **Page Stack** function allows the console operator to select the number of pages to be sent in succession.

In C-Soft Runtime, after pressing the Page Stack button, the console operator can select multiple Page buttons. Normally, a page is sent the moment the Page button is pressed, but when the Page button is pressed after the Page Stack button, all selected pages are stacked first and sent when the Page Send button is clicked.



#### Notice!

When the Page Send button is clicked, pages assigned to the same line number are sent in the order they were selected, but pages assigned to different line numbers are sent in order of ascending line number.

For example, when the Page Send button is pressed, pages that were selected in this order: XYZ (line 5), XYY (line 5), XXY (line 4), ZZY (line 3) are sent in this order: ZZY (line 3), XXY (line 4), XYZ (line 5), XYY (line 5).

## 31.56.1 Page Stack Setup

When the Page Stack function is selected from the UI Element drop down menu, a **Page Stack Setup** page appears. Refer to the Figure below.




Figure 31.57: Options Page - UI Element Setup

### Unlatch stack button after page check box

The **Unlatch stack button after page** check box indicates the Page Stack button automatically unlatches (toggle off) after pages are sent.

To add a Page Stack button, do the following:

- From the Insert menu, select Add UI Button.
   A None button appears on the console window.
- Right-click the **None** button.A shortcut menu appears.

- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select **Page Stack**.
  - The Option tab appears.
- 5. Click the **Options** tab.
  - The Options page appears.
- 6. Select the **Unlatch stack button after page** check box to automatically unlatch after the pages are sent, if desired.
- 7. Click OK.

The button changes color and Stack Pages appears on the button.

## 31.57 Page Stack Programmed

The **Page Stack Programmed** function creates a button used to select a pre-defined group of pages. While in C-Soft Runtime, clicking the Page Stacked Programmed button causes the predefined pages to be stacked.



### Notice!

When the Page Send button is clicked, pages assigned to the same line number are sent in the order they were selected, but pages assigned to different line numbers are sent in order of ascending line number.

For example, when the Page Send button is pressed, pages that were selected in this order: XYZ (line 5), XYY (line 5), XXY (line 4), ZZY (line 3) are sent in this order: ZZY (line 3), XXY (line 4), XYZ (line 5), XYY (line 5).

### To **send stacked pages**, do the following:

- From C-Soft Runtime, click the Page Stacked Programmed button.
   The pages are stacked in the order defined in the Selected Pages list.
- 2. Click the Page Send button.

The Pages are sent.

## 31.57.1 Programmed Stack Setup page

When Pages Stack Programmed is selected from the drop down menu, the **Programmed Stack Setup** page appears. Refer to the Figure below.

A maximum of 50 pages can be configured for a single Page Stack Programmed button.

Figure 31.58: Programmed Stack Setup - UI Element Setup

## **All Pages field**

The **All Pages** field displays all pages in the system. This list is used to select a page to add to the Selected pages field.

## **Selected Pages field**

The **Selected Pages** field displays pages selected for the stack. When the console operator clicks the Page Stack Programmed button, a page is sent to members in this field.

## **Move Right button**

The **Arrow Right** button is used to move pages from the All Pages field to the Selected Pages field.

### Move Left button

The **Arrow Left** button is used to move pages from the Selected Pages field to the All Pages field.

## **Move Up Button**

The **Move Up** button is used to move the selected page up in the Selected Pages list.

### **Move Down Button**

The **Move Down** button is used to move the selected page down in the Selected Pages list.

### To add a Page Stack Programmed button, do the following:

1. From the Insert menu, select Add UI Button.

A None button appears on the console window.

2. Right-click the **None** button.

A shortcut menu appears.

3. From the shortcut menu, select **Properties**.

The UI Element Setup window appears.

4. From the UI Element drop down menu, select Page Stack Programmed.

The Programmed Stack Setup tab appears.

5. Click the **Programmed Stack Setup tab**.

The Programmed Stack Setup page appears.

- 6. Select **pages** from the All Pages panel.
- 7. Click >>> to move them to the Selected Pages pane.
- 8. Click OK.

The button changes color and Page Send appears on the button.

## 31.58 Per Line Call History

The **Per Line Call History** function creates a button used to open a list of past calls received on the associated line.

In C-Soft Runtime, the Per Line Call History window is used to view incoming calls, make outgoing calls, and playback call audio based upon programming setup.


## To add a Per Line Call History button, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the **None** button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select **Per Line Call History**.
- 5. From the Line to Associate Function With drop down menu, select the **line** to display call history.
- 6. Click OK.

The color of the button changes and Per Line Call History appears on the button.

## Per Line Call History Setup page

The **Per Line Call History Setup** window allows users to determine which columns are visible in the Per Line Call History window. The respective columns display in the Per Line Call History window if selected and hidden if not checked.



## **Column Setup group box**

### **Call Duration check box**

The **Call Duration** check box is used to add a Call Duration column to the Per Line Call History window.

## Caller ID check box

The Caller ID check box is used to add a Caller ID column to the Per Line Call History window.

### **Comments check box**

The **Comments** check box is used to add a Comments column to the Per Line Call History window.

### Date check box

The **Date** check box is used to add a Date column to the Per Line Call History window.

## **Direction check box**

The **Direction** check box is used to add a Direction column to the Per Line Call History window.

## Frequency check box

The **Frequency** check box is used to add a Frequency column to the Per Line Call History window.

## Line Name check box

The **Line Name** check box is used to add a Line Name column to the Per Line Call History window.

### Status check box

The Status check box is used to add a Status column to the Per Line Call History window.

## Talkgroup check box

The **Talkgroup** check box is used to add a Talkgroup column to the Per Line Call History window.



### Notice!

This field is only available when the associated line is configured for a P25-DFSI line.

### Time check box

The **Time** check box is used to add a Time column to the Per Line Call History window.

### User ID check box

The User ID check box is used to add a User ID column to the Per Line Call History window.

## 31.58.1 Per Line Call History window

The **Per Line Call History** window is used to view the associated line's call history. Each entry in the call history contains details regarding an individual call. Icons in the left column display the current status of the call entry. The console operator can also send messages, statuses, and alerts to the ID listed in the window by clicking a Call button at the bottom of the window.



Figure 31.59: Per Line Call History Window - C-Soft Runtime

### Icon Status column

The Icon Status column displays an icon representative of the call entry state.

The call entry is pinned. A pinned call entry is always located at the top of the call list control and cannot be deleted until the call is unpinned.



The call entry contains audio that can be played.



The call entry contains audio that can be played and the call entry is pinned.

The call entry contains audio, but the line was muted when the call was received. The un-muted audio can still be played.

The call entry contains audio, but the line was muted when the call was received and the call entry was pinned. The un-muted audio can still be played.



The audio for a call entry is currently being played.



The audio for a pinned call entry is currently being played.

### Date column

The **Date** column displays the date of the call or operation.

### Time column

The **Time** column displays the time of the call or operation.

## Freq column

The **Freq** column displays the frequency of the call or operation.

### Status column

The **Status** column displays additional call or operation information. For example, if a status message is received, the Status column contains a Status Alias. If the entry represents an outgoing Select Call, the Status column contains "Sent Select Call".

### User ID column

The User ID column displays the source User Alias/ID or Group Alias/ID of the call or operation.

## **Calling ID Column**

The Calling ID column displays the destination User Alias/ID or Group Alias/ID of the call or operation.

### **Direction column**

The Direction column displays the call or operation's direction. Incoming calls or operations display Rx and outgoing calls or operations display Tx.

### **Duration column**

The **Duration** column displays the duration of the recorded call audio.

### **Comments column**

The **Comments** column displays comments from the user.

## 31.58.2 Per Line Call History window - 5/6 Tone line

The Status List window displays the status of a call. If the configured line is set to 5/6 Tone DTMF ANI signaling, and one or more call formats have been configured in the Call Setup tab, the Per Line Call History window displays the user defined call buttons as shown in the Figure below.




Figure 31.60: Per Line Call History Window: 5/6 Tone Line

### **Set Status button**

The **Set Status** button is used to open the Status List window and select a status to send. Refer to the Figure on "*Status List window, page 236*".

To send a status ID from the Per Line Call History window in C-Soft Runtime, do the following:

1. While in C-Soft Runtime, select the **line** you want to place the call from.

2. Select a **Per Line Call History** button.

The Per Line Call History window appears.

3. From the ID Type drop down menu, select an **alias** or an **ID number**.

The selected User ID in the User List is highlighted.

4. Select Set Status.

The Status List window appears.

5. From the ID type drop down menu, select an **alias** or **ID number** to sort the list. The list is sorted depending on the selected type.

6. From the Status drop down menu, select a **status ID** to send.

The selected status ID is highlighted.

OR

From the status ID list, select a **status ID** to send.

The selected status ID is highlighted.

Click Done.

If a password is required to send the status ID, the Password Entry window appears.

8. Using the keypad, enter the **password**.

For each character you enter, asterisks fill the empty field at the top of the window.

9. Click Enter.

The Password Entry window closes and the selected status's alias appears in the Status Message field or, if the password is incorrectly entered, an error message appears.

10. Click a Call button to place the call.

The message is sent and a confirmation or error message appears in the Dispatching status bar.

11. Click Done.

The window closes.

## To open the Status List window, do the following:

- 1. Open a **Per Line Call History window** associated with a 5/6 Tone line.
- 2. Click the **Set Status** button.

The Status List window appears.





### Notice!

The Status field is used only for 5/6 Tone/DTMF ANI Signaling.

### Call (1-10) Buttons

The **Call (1-10)** buttons are used to place user-defined calls configured in the "5-6 Tone/DTMF ANI system type, page 75". For the call buttons panel to be enabled, the line must be configured for 5/6 Tone DTMF Signaling, and at least one Call Format must be set up. The labels used only for 5/6 Tone/DTMF ANI Setup page appear on these buttons in the Call List window.

### To place a call from the Per Line Call History window, do the following:

- Select an ID in the list.
   Available call buttons on the bottom of the window become active.
- 2. Select a call button.

The call is placed.

### Refer to

- Status List window, page 236
- 5-6 Tone/DTMF ANI system type, page 75

## 31.58.3 IRR Playback Control window



## Notice!

For the IRR Playback control to appear, the line must be configured for IRR Recording. If IRR Recording is enabled on the line, the Per Line Call History Window will display the Audio Playback Control.




Figure 31.61: Per Line Call History Window

### Save to File button

The Save to File button is used to save the currently selected items to a .csv file.

To save a .csv file of the items in the list, do the following:

- 1. From the Per Line Call History list, select the **items** you want to save.
- Click Save to File.

The Save window appears.

- 3. In the File name field, enter a **name** for your .csv file.
- Click Save.

### **Done button**

The **Done** button is used to close the Per Line Call History window.

### Note:

When an ADHB-4 is installed in the system:

- Master Select audio will also affect the IRR playback audio level if Output Speaker 1 is selected in the Recording Settings.
- Master Unselect audio will also affect the IRR playback audio level if Output Speaker 2 to
   6 is selected in the Recording Settings.

## 31.58.4 Comments window

The **Comments** window, shown in the Figure below appears when the user right clicks on a call entry in either the Per Line window or the Global Call History window and selects the Edit Comment menu item. The Comments window is used to either create a new comment or modify an existing comment for a menu item.

Up to 100 characters can be entered in a single comment.



Figure 31.62: Comments window



## Notice!

Phone functions listed below are specific to PSTN lines attached to a C-6200 or IP-223 with TDI or PIB adapters. These should not be confused with SIP Phone operation.

## 31.59 Phone-Flashhook

The **Phone-Flashhook** function allows the console operator to perform a flashhook operation on the phone line. This button is generally included as part of a DTMF keypad.

## To add a Flash button, do the following:

- 1. From the Insert menu, select **Add UI Button**.
  - A None button appears on the console window.
- 2. Right-click the None button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select Phone Flashhook.
- 5. Click OK.

The button changes color and Flash appears on the button.

## 31.60 Phone-Hold

The **Phone-Hold** function allows the console operator to place a particular line on hold. While a line is in hold status, no TX audio is sent to the line and RX audio is sent to the unselect speaker.

### To add a Hold button, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the **None** button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select **Phone Hold**.
  - The Line to Associate Function With drop down menu becomes active.
- 5. From the Line to Associate Function With drop down menu, select the **line** to associate the Hold function.
- 6. Click OK.

The button changes color and Hold appears on the button.

## 31.61 Phone-On/Offhook

The **Phone-On/Offhook** function is available to add a line set up as a phone line.

A phone, like a radio circuit, can be used as a network device. A C-6200 console with a phone card offers phone lines for use by anyone on the network. A phone line can be used for direct phone communications by a console operator, or to add a crosspatch to telephone capability for radio users.

When the console operator presses the Phone-On/Offhook button, the line goes offhook and a dial tone is audible. All radio traffic is moved to the unselect speaker. Full-duplex audio is present from the microphone while the line is offhook and not on hold. Placing the line on hold mutes the transmit audio and places the receive audio on the unselect speaker.

When a hard-wired phone card receives an incoming call, a ring signal is sent out. The C-Soft program generates a ringing sound and places a RING icon on the on/offhook button. When the line is taken offhook, the first console to answer the call takes control of the line and all others are denied.



### Notice!

A Mute-Per Line button can be associated with a Phone line to mute the phone line's mic. The mute icon appears when the Phone line is muted, RX blocked, or when a Mute Main button is selected. Refer to "*Mute-Per Line, page 321*".

## To add a Phone On/Offhook button, do the following:

- 1. From the Insert menu, select **Add UI Button**.
  - A None button appears on the console window.
- 2. Right-click the **None** button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select **Phone On/Offhook**.
  - The Line to Associate Function With drop down menu becomes active and the Remote Phone Select tab appears.
- 5. From the Line to Associate Function With drop down menu, select the **line** to associate the On/Offhook function.
- 6. Click the Remote Phone Select tab.
  - The Remote Phone Select page appears.
- 7. From the Remote Phone Number drop down menu, select the **physical line** of the device the PSTN line is attached to.
- When specifying a specific line using an IP-223, valid options are 1 or 2.
- When specifying a specific line for a **C-6200** choices can be **1-18**.
- To use **any line** on the device, select **Pool**.
- 8. Click OK.

The button changes color and Phone Onhook appears on the button.

## Refer to

- Mute-Per Line, page 321

## 31.61.1 Remote Phone Line Select page

When the Phone On/Offhook function is selected from the UI Element drop down menu, the **Remote Phone Line Select** page appears. Refer to the Figure below.




Figure 31.63: Remote Phone Line Select Page - UI Element Setup

### Remote Phone Number drop down menu

The **Remote Phone Number** drop down menu identifies the line to force the use of a particular phone line on the console.

### To **use any line**, do the following:

- From the Remote Phone Number drop down menu, select **Pool**.

C-Soft creates a ring only if the selected line is ringing.

## 31.62 PTT-Group Call

The **PTT-Group Call** button is used to call a specific group/talk group.

Refer to the Table "Radio Operations Supported by System Type," on page 394 for radio operations supported by Group PTT.

## To send a group call, do the following:

1. If the Keypad is present, select the **group** from the Contacts tab or manually enter a group ID.

OR

From the Group-PTT drop down menu, select the **group** you want to call.

- 2. Press and hold the **Group PTT** button and begin speaking.
- 3. Release the **Group PTT** button to stop transmitting.

The PTT-Group Call function allows the console operator to transmit audio to a group of radios.

From the Insert menu, select Add UI Button.
 A None button appears on the console window.

- 2. Right-click the None button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select PTT-Group Call.
- 5 Click OK

The button changes color and PTT appears on the button.

## 31.63 PTT-Main

The **PTT-Main** function allows the console operator to transmit audio to all selected channels. This button is generally included on all console designs. In C-Soft Runtime, if the console operator presses the PTT-Main button, audio is sent to all selected channels.

## To add a PTT-Main button, do the following:

- From the Insert menu, select Add UI Button.
   A None button appears on the console window.
- 2. Right-click the None button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**. The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select PTT-Main.
- 5. Click OK.

The button changes color and PTT appears on the button.

## 31.64 PTT-Per Line

The **PTT-Per Line** function, or instant PTT function, allows the console operator to immediately key up a specific line on the current frequency.

When the PTT-Per Line function is selected, a line must be selected from the Line to Associate Function With drop down menu on the Type page.

## 31.64.1 Per Line PTT Setup page

When the PTT-Per Line function is selected from the UI Element drop down menu, the **Per Line PTT Setup** page appears. Refer to the Figure below.




Figure 31.64: Per Line PTT Setup Page - UI Element Setup

### Select PTT Frequency drop down menu

The **Select PTT Frequency** drop down menu identifies the desired frequency to use per selected line.

## To add a PTT-Per Line button, do the following:

- From the UI Element drop down menu, select PTT-Per Line.
   The Line to Associate Function With drop down menu becomes active.
- 2. From the Line to Associate Function With drop down menu, select the **line** to associate with PTT Per Line.
- Click the Per Line PTT Setup tab.
   The Per Line PTT Setup page appears.
- 4. From the Select PTT Frequency drop down menu, select the **frequency**.
- 5 Click OK

The color of the button changes and Freq X (where X is the frequency) appears on the button.

## 31.65 PTT-Private Call

The PTT-Private Call button is used to call an individual radio user.

Refer to the table "Radio Operations Supported by System Type," on "*Keypad, page 433*" to see radio operations supported by PTT-Private Call.

## To add a PTT-Private Call button, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the **None** button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select PTT-Private Call.
- 5. Click **OK**.

The button changes color and PTT-Private Call appears on the button.

### To send a private call, do the following:

1. If the Keypad is present, select the **User** from the Contacts tab or manually enter a **User ID**.

OR

From the PTT-Private Call drop down menu, select the user you want to call.

- 2. Press hold the **PTT-Private Call** button and begin speaking.
- 3. Release the PTT-Private Call button to stop transmitting.

## 31.66 PTT-Talk Back

The **PTT-Talk Back** function allows the console operator to transmit back to the last line from which audio was received.

## To add a PTT-Talk Back button, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the None button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select PTT-Talk Back.
- 5. Click OK.

The button changes color and PTT-Talk Back appears on the button.

## 31.67 Radio Call Alert

The Radio Call Alert button is used to send an alert message to a target radio.

Refer to the table "Radio Operations Supported by System Type," on *Keypad, page 433* to see radio operations supported by Radio Call Alert.

### To add a Radio Call Alert button, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the **None** button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select Radio Call Alert.
- Click OK

The button changes color and Call Alert appears on the button.

## To **send a radio call alert message**, do the following:

 If the Keypad is present, select the **User** from the Contacts tab or manually enter a **User** ID.

OR

Select the **User ID** to send the call alert.

2. Click Radio Call Alert.

The command is sent.

## 31.68 Radio Call Type

The **Radio Call Type** button is used to switch between Conference Call and Broadcast Call. This feature is only available for the NEXEDGE IP interface.

## To add a Radio Call Type button, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the None button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. Click OK.

The button changes color and Call Type appears on the button.

## 31.69 Radio Check

The Radio Check function is used to send a message to check for radio activity.

Refer to the table "Radio Operations Supported by System Type," on "*Keypad, page 433*" to see radio operations supported by Radio Check.

## To add a Radio Check button, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the None button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select Radio Check.
- 5. Click **OK**.

The button changes color and Radio Check appears on the button.

## To send a radio check message, do the following:

- 1. If the Keypad is present, select the **User** from the Contacts tab or manually enter a **User ID**.
  - OR
  - Select the **User ID** to send the radio check message to.
- 2. Click the **command button** on the Radio Check button.

## 31.70 Radio Disable

The **Radio Disable** button is used to disable a radio in the field from use by unauthorized persons.

Refer to the table "Radio Operations Supported by System Type," on "Keypad, page 433" for radio operations supported by Radio Disable.

### To add a Radio Disable button, do the following:

- From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the None button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select Radio Disable.
- Click OK.

The button changes color and Radio Disable appears on the button.

### To disable a radio, do the following:

If the Keypad is present, select the **User** from the Contacts tab or manually enter a **User** ID.

OR

Select the **Unit ID** to disable.

2. Click Radio Disable.

The command is sent.

#### 31.71 Radio Enable

The **Radio Enable** button is used to enable a radio that has been disabled.

Refer to the table "Radio Operations Supported by System Type," on "Keypad, page 433" for radio operations supported by Radio Enable.

## To add a Radio Enable button, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the None button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- From the UI Element drop down menu, select Radio Enable.
- Click OK.

The button changes color and Radio Enable appears on the button.

## To **enable a radio**, do the following:

If the Keypad is present, select the **User** from the Contacts tab or manually enter a **User** ID.

OR

Select the Unit ID to enable.

Click Radio Enable.

The command is sent.

#### 31.72 Radio Regroup

The Radio Regroup button allows the dispatcher to temporarily reassign a radio to a different talkgroup.

## To add a Radio Regroup button, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the **None** button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select Radio Regroup.
- 5. Click OK.

The button changes color and Radio Regroup appears on the button.

## 31.73 Radio Ungroup

The **Radio Ungroup** button allows the dispatcher to reset a radio to their original talkgroup after using the Radio Regroup button.

### To add a Radio Ungroup button, do the following:

- From the Insert menu, select Add UI Button.
   A None button appears on the console window.
- 2. Right-click the **None** button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**. The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select Radio Ungroup.
- 5 Click OK

The button changes color and Radio Ungroup appears on the button.



### Notice!

The Radio Regroup and Radio Ungroup buttons are only available for the NEXEDGE IP interface.

## 31.74 Radio Remote Monitor

The **Radio Remote Monitor** button allows the dispatcher to open the mic of a targeted radio and hear any audio in the vicinity of that radio.

Refer to the table "Radio Operations Supported by System Type," on "*Keypad, page 433*" for radio operations supported by Radio Remote Monitor.

### To add a Remote Monitor button, do the following:

- From the Insert menu, select Add UI Button.
   A None button appears on the console window.
- 2. Right-click the None button.
  - A shortcut menu appears.
- From the shortcut menu, select **Properties**.
   The UI Element Setup window appears.

- 4. From the UI Element drop down menu, select **Remote Monitor**.
- 5 Click **OK**

The button changes color and Remote Monitor appears on the button.

### To monitor a unit, do the following:

If a Keypad is present, select a **User** from the Contacts tab.

From the Remote Monitor drop down menu, select the unit to monitor.

Click Remote Monitor.

The command is sent.

#### 31.75 **Radio Status**

The Radio Status function is used to send a status message to a unit.

Refer to the table "Radio Operations Supported by System Type," on "Keypad, page 433" for radio operations supported by radio status. The list of statuses which can be sent from the button configured in the Radio Status Setup window.

### To send a radio status, do the following:

From the Contacts tab of the Keypad, select a **user**.

OR

Manually enter a **User ID**.

- 2. From the Radio Status drop down menu, select the **status** to be sent.
- Click the Radio Status button.

The status message is sent to the user selected in the Keypad or manually entered.

#### 31.76 Radio Status Request

The Radio Status Request button is used to send message to request status from a unit in the system.

Refer to the table "Radio Operations Supported by System Type," on "Keypad, page 433" for radio operations supported by Radio Status Request.

## To add a Radio Status Request button, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the **None** button.

A shortcut menu appears.

- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select Radio Status Request.
- 5. Click OK.

The button changes color and Status Request appears on the button.

To **request a status from a unit**, do the following:

1. If the Keypad is present, select the **User** from the Contacts tab or manually enter a **User ID**.

OR

From the Radio Status Request drop down menu, select the **User** to send the radio status message to.

2. Click Radio Status Request.

The command is sent.

## 31.77 Radio Select Call

The Radio Select Call function is used to send a Select Call to a unit in the system.

Refer to the table "Radio Operations Supported by System Type," on "Keypad, page 433" for radio operations supported by Radio Select Call.

## To add a Radio Select Call button, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the None button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select Radio Select Call.
- 5. Click OK.

The button changes color and Radio Select Call appears on the button.

## To send a select call, do the following:

If the Keypad is present, select the **User** from the Contacts tab or manually enter a **User** ID.

OR

Select the **Unit ID** to enable.

2. Click Radio Select Call.

The command is sent.

# 31.78 Radio-On/Offhook

The **Radio-On/Offhook** function allows the console operator to control a radio using a standard PSTN (Public Switched Telephone Network) phone line. Radio - On/Offhook is similar to "*Phone-On/Offhook*, page 343", except radio-on/offhook has a Keep-Alive tone generated to keep the phone line from dropping. A keep-alive tone goes between the radio and console so the system knows to stay active until after the connection is broken.



## Notice!

Requires an IP-223 with TDI's at both ends.

To add a Radio On/OffHook button, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the None button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select Radio On/Offhook.
  - The Line to Associate Function With drop down menu becomes active and the Remote Phone Select tab appears.
- 5. From the Line to Associate Function With drop down menu, select the **line** to associate the On/Offhook function.
- 6. Click the Remote Phone Line Select tab.
  - The Remote Phone Line Select page appears.
- 7. From the Remote Phone Number drop down menu, select the **line** to force the use of a particular phone line on the console.
- 8. Click OK.

The button changes color and Radio OnHook appears on the button

### Refer to

- Phone-On/Offhook, page 343

## 31.79 Relay Control Button

The **Relay Control Button** function allows the console operator to control the relays on an attached ADHB-4 or a network-connected NEO-10.

## 31.79.1 Relay Control Setup page

When Relay Control Button is selected from the UI Element drop down menu, the **Relay Control Setup** page appears.




Figure 31.65: Relay Control Setup Page - C-Soft

## To open the Relay Control Setup page, do the following:

- 1. Select Insert | Add IU Button.
  - A None button is added to the console.
- 2. Right-click the **None** button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element Function drop down menu, select **Relay Control**.

The Relay Control Setup tab appears.

### **Relay Destination group box**

The **Relay Destination** radio buttons identify the relay to be controlled. When a selection is made, the fields necessary to enter the setup information for the relay are enabled.

### ADHB-4 radio button

The **ADHB-4** radio button indicates an ADHB-4 is controlled by the Relay Control button.

## **NEO** radio button

The **NEO** radio button indicates a NEO-10 is controlled by the Relay Control button.

### **ADHB-4 Settings group box**

The **ADHB-4 Settings** radio buttons identify which ADHB-4 relay is activated when the button is pressed, or when the configured input conditions are met.

### None radio button

The **None** radio button indicates none of the ADHB-4 relays is activated when the button is pressed.

### Relay 1 radio button

The **Relay1** radio button indicates the first relay in the ADHB-4 is being controlled.

### Relay 2 radio button

The **Relay 2** radio button indicates the second relay in the ADHB-4 is being controlled.

### **NEO Settings group box**

The **NEO Settings** field identifies the IP Address and the relay, if any, for the NEO-10.

#### IP field

The **IP** field identifies the IP Address of the NEO-10.

### Relay drop down menu

The **Relay** drop down menu is used to select the desired relay.

Available selections for this field are None, Port 1, Port 2, Port 3, Port 4, Port 5, Port 6, Port 7, Port 8, Port 9 and Port 10.

## To configure and add an ADHB-4 Relay Control button, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- Right-click the None button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select Relay Control Button.
  - The Relay Control Setup tab appears.
- Click the Relay Control Setup tab.
  - The Relay Control Setup page appears.
- 6. From the Relay Destination group box, select the **ADHB-4** radio button.
  - The ADHB-4 Settings group box becomes active.
- 7. From the ADHB-4 Settings group box, select the **None** radio button.
  - OR

From the ADHB-4 Settings group box, select the **Relay1** radio button.

OR

From the ADHB-4 Settings group box, select the **Relay2** radio button.

8. Click **OK**.

The button changes color and Relay Off appears on the button.

## To configure and add a NEO Relay Control button, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- Right-click the None button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select **Relay Control Button**. The Relay Control Setup tab appears.

- 5. Click the Relay Control Setup tab.
  - The Relay Control Setup page appears.
- 6. From the Relay Destination group box, select **NEO**.
  - The NEO Settings group box becomes active.
- From the Relay Behavior group box, select the **desired mode** radio button for the relay control
- 8. In the IP field, enter the **IP Address** of the NEO-10.
- 9. From the Relay drop down menu, select the **desired relay**.
- 10. Click **OK**.

The button changes color and Relay Off appears on the button.

### **Relay Behavior group box**

The **Relay Behavior** radio buttons identify the mode for the relay control.

## Latch Relay On/Off radio button

The **Latch Relay** radio button indicates the relay's latch is controlled by the operator. When the Relay Control button is clicked the device is active. When the Relay Control button is pressed again the device is inactive.

### **Momentary Relay radio button**

The **Momentary Relay** radio button indicates the relay is active when the button is pressed. When the button is released, the relay is inactive.

### **Timed Relay radio button**

The **Timed Relay** radio button indicates that when an Relay Control button is clicked, it remains active for the amount of time configured in the Timed field. When the radio button is selected, you must configure a time in the Timed field.

### **Timed Relay field**

The **Time Relay** field is used to set the time, in ms, when the Timed Relay radio button is selected.

The range for this field is 0 to 30000ms.

### **Emergency Relay Trigger group box**

The **Emergency Relay Trigger** group box is used to configure how the relay behaves when an emergency call is received.

### **Activate Relay on Emergency Call check box**

The **Activate Relay on Emergency Call** check box indicates an emergency call activates the configured relay. If the check box is selected, a radio emergency deactivation radio button can be selected.

### **Relay Control Button Only radio button**

The **Relay Control Button Only** radio button is used to configure the relay to deactivate when the relay control button is released.

### **Emergency Clear and Acknowledge radio button**

The **Emergency Clear and Acknowledge** radio button indicates the relay is deactivated when the emergency is acknowledged, cleared, or when the relay control button is released.

## **Emergency Acknowledge radio button**

The **Emergency Acknowledge** radio button indicates the relay is deactivated when the emergency is acknowledged or when the relay control button is released.

### Phone Relay Trigger group box

The **Phone Relay Trigger** group box is used to configure how the relay behaves when a phone call is received.

## Activate Relay in Call check box

The **Activate Relay in Call** check box indicates the relay is activated while C-Soft is in a phone call. This setting includes both a phone line going offhook as well as C-Soft participating in a SIP call.

## Activate Relay on Phone Ring check box

The **Activate Relay on Phone Ring** check box indicates a phone ring activates the configured relay. When the check box is selected, the phone ring behavior can be configured. This setting includes both a ringing phone line as well as an incoming SIP call.

### **Cadence radio button**

The **Cadence** radio button indicates the relay is activated when an individual phone ring starts and deactivated when the phone ring ends.

EXAMPLE: A phone ringing three times, produces an on/off/on/off /on/off pattern.

### Steady radio button

The **Steady** radio button indicates the relay is activated when the first phone ring is received and deactivates when the call is answered or the caller terminates the call.

EXAMPLE: A phone ringing three times, produces a on/off pattern.

### PTT Relay Trigger group box

## **Activate Relay on PTT check box**

The **Activate Relay on PTT** check box indicates the configured relay is active when any console-generated transmit event, with the exception of intercom and intercom per line, occurs.

## 31.79.1.1 Relay Destination group box

## 31.79.1.2 ADHB-4 Settings group box

## 31.79.1.3 NEO Settings group box

## 31.79.1.4 Relay Behavior group box

## 31.79.1.5 Emergency Relay Trigger group box

## 31.79.1.6 Phone Relay Trigger group box

## 31.79.1.7 PTT Relay Trigger group box

## 31.79.2 Text Message Control page

To open the **Text Message Control** page, do the following:

- From the Insert menu, select Add UI Button.
   A None button appears on the console window.
- Right-click the **None** button.A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**. The UI Element Setup window appears.
- 4. From the UI Element Function drop down menu, select **Relay Control Button**. The Relay Control Setup, Text Message Control, and Status Control tabs appear.
- 5. Click the **Text Message Control** tab.

The Text Message Control page appears.




Figure 31.66: Text Message Control Page

### **Custom Text Message field**

The Custom Text Message field is used to enter a text message that is not in the Text Message ID List.

### **Text Message List field**

The Text Message List field is used select a status that was pre-created in the Text Message ID List.

### Add button

The **Add** button is used to add the custom or selected text message to the Relay On field.

### Remove button

The **Remove** button is used to add the custom or selected text message to the Relay On field.

## Relay On field

The Relay On field is used to list the different text messages that are sent when the relay is turned on.

### Add button

The **Add** button is used to add the custom or selected text message to the Relay Off field.

### Remove button

The Remove button is used to add the custom or selected text message to the Relay Off field.

### Relay Off field

The **Relay Off** field is used to list the different text messages that are sent when the relay is turned off.

## **OK** button

The **OK** button saves the modifications and closes the window.

## To create a text message relay control button, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the None button.
  - A shortcut menu appears.
- From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element Function drop down menu, select Relay Control Button.
  - The Relay Control Setup, Text Message Control, and Status Control tabs appear.
- 5. Click the **Text Message Control** tab.
  - The Text Message Control page appears.
- 6. In the Custom Text Message field, enter a custom text message that is not listed in the Text Message ID List.

OR

From the Text Message List Group Box, select the **status desired** to trigger relays on and off.

The list of text messages is pulled from the Text Message ID List.

7. Click the **Add button** to add the status to either the Relay On group box or the Relay Off group box.

The Text Message moves from the Custom Text Message field or the Text Message List. **IMPORTANT**: A status cannot be used for both a trigger on and a trigger off. If the relay control type is timed, the Relay Off group box is disabled since the relay automatically latches off when the designated time has elapsed.

8. Click OK.

The modifications are made and the window closes.

#### To remove status from the relay on or relay off lists, do the following:

- From the UI Element Function drop down menu, select Relay Control Button.
   The Relay Control Setup, Text Message Control, and Status Control tabs appear.
- 2. Click the **Text Message Control** tab.

The Text Message Control page appears.

3. From the Relay On list, select the **text message** to remove from the list.

From the Relay Off list, select the **text message** to remove from the list.

 Click the **Remove button** to remove the status from either the Relay On group box or the Relay Off group box.

The Text Message is removed from the Relay On or the Relay Off list.

5. Click OK.

The modifications are made and the window closes.

### 31.79.3 Status Control page

To open the Status Control page, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the **None** button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.

The UI Element Setup window appears.

- 4. From the UI Element Function drop down menu, select **Relay Control Button**.
  - The Relay Control Setup, Text Message Control, and Status Control tabs appear.
- 5. Click the Status Control tab.

The Status Control page appears.

Figure 31.67: Status Control Page

#### Status List field

The Status List field is used to select the status to add to the Relay On field or Relay Off field.

#### Add button

The **Add** button is used to add the custom or selected status to the Relay On field.

#### **Remove button**

The **Remove** button is used to add the custom or selected status to the Relay On field.

## **Relay On field**

The **Relay On** field is used to list the different statuses that are sent when the relay is turned on.

#### Add button

The Add button is used to add the custom or selected status to the Relay Off field.

### Remove button

The **Remove** button is used to add the custom or selected status to the Relay Off field.

### **Relay Off field**

The **Relay Off** field is used to list the different statuses that are sent when the relay is turned off.

#### **OK** button

The **OK** button saves the modifications and closes the window.

To create a status control button, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the **None** button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element Function drop down menu, select **Relay Control Button**.
  - The Relay Control Setup, Text Message Control, and Status Control tabs appear.
- 5. Click the **Status Control** tab.
  - The Status Control page appears.
- 6. From the Status List group box, select the **status desired** to trigger relays on and off. The list of statuses is pulled from the Status Message ID List.
- Click the **Add button** to add the status to either the Relay On group box or the Relay Off group box.
  - The Status moves from the Status List to the Relay On or Relay Off group box.
  - **IMPORTANT**: A status cannot be used for both a trigger on and a trigger off. If the relay control type is timed, the Relay Off group box is disabled since the relay automatically latches off when the designated time has elapsed.
- 8. Click OK.

The modifications are made and the window closes.

### To remove status from the relay on or relay off lists, do the following:

- From the UI Element Function drop down menu, select Relay Control Button.
   The Relay Control Setup, Text Message Control, and Status Control tabs appear.
- 2. Click the Status Control tab.
  - The Status Control page appears.
- 3. From the Relay On list, select the **status** to remove from the list.
  - OR
  - From the Relay Off list, select the **status** to remove from the list.
- Click the **Remove button** to remove the status from either the Relay On group box or the Relay Off group box.
  - The status is removed from the Relay On or the Relay Off list.
- 5. Click **OK**.

The modifications are made and the window closes.

## 31.80 RX AII

The RX All function allows the console operator to remove mute on selected lines if Allow Muting Selected Lines is selected.

In C-Soft Runtime, if the console operator presses the RX All button it does not change the select status of any line.

#### To add an RX All button, do the following:

- 1. From the Insert menu, select **Add UI Button**.
  - A None button appears on the console window.
- 2. Right-click the **None** button.
  - A shortcut menu appears.

- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select **RX AII**.
- 5. Click OK.

The button color changes and RX All appears on the button.

## 31.81 Scan

The **Scan** function allows the console operator to scan a selected line.

#### To add a Scan button, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the None button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select **Scan**.
  - The Line to Associate Function With drop down menu becomes active.
- 5. From the Line to Associate Function With drop down menu, select the **line** to associate with Scan.
- 6. Click OK.

The button color changes and Scan Off appears on the button.

### To activate or deactivate a radio's scan mode in Runtime, do the following:

- 1. Press the Scan button.
  - The radio's scan mode is activated.
- 2. Press the **Scan button** again.

The radio's scan mode is deactivated.

## 31.82 Select

The **Select** function allows the console operator to toggle transmission channels when a master or accessory PTT button is selected. DTMF and Alert tones are also transmitted to all selected lines. Select buttons also indicate the type of activity on a line, such as: audio receive, audio transmit, mute, crossmute, intercom, link fail, and supervisor status.

The Supervisor icon cannot be customized.

 A Mute-Per Line button can be associated with the line assigned to the Select button to mute the RX (incoming) audio. The mute icon appears when the Select line is muted, RX blocked, or when a Mute-Main button is selected. Refer to "Mute-Per Line, page 321".

For more information, refer to Button Images window, page 141.

#### Select Button Setup page

When Select is chosen from the UI Element drop down menu, the **Select Button Setup** page appears.

To open the Select Button Setup page, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the **None** button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select **Select**.
  - The Select Button Setup tab appears.
- 5. Click the **Select Button Setup** tab.
  - The Select Button Setup page appears.




Figure 31.68: Select Button Setup - UI Element Setup

### **Annunciation of Select Call group box**

## **Blink Select Button check box**

The **Blink Select Button** check box is used to indicate the button blinks light blue when the console receives a select call.

## No Beep radio button

The No Beep radio button indicates no tones are heard when a select call is received.

### Beep for radio button

The **Beep for** radio button is used to indicate a select call alert tone is heard when a select call is received.

#### Beep for seconds field

The **Beep for seconds** field indicates the amount of time the select call alert tone plays.

The range for this field is 1-10 seconds.

### Beep Until PTT radio button

The **Beep Until PTT** radio button indicates the select call alert tone is heard until a PTT operation is performed on the line that received the select call.

#### To **configure a blinking button indication**, do the following:

- From the Select Button Setup page, select the **Blink Select Button** check box.

### To configure the desired notification, select one of the following:

- No Beep radio button no beep sound is played when a select call is received.
- Beep For radio button a beep sounds for the specified the number of second.
- Beep Until PTT radio button a beep sounds until a PTT when a select call is received.

#### **Action On Select Call group box**

#### No Action radio button

The No Action radio button indicates an active mute button is not opened during a select call.

#### Open Mute for radio button

The **Open Mute** for radio button indicates a muted line is opened upon receiving a select call.

The Open Mute for seconds field must also be configured.

### Open Mute for seconds field

The **Open Mute for seconds** field indicates the amount of time a muted line is unmuted upon receiving a select call.

The range for this field is 1 to 20 seconds.

#### To configure the desired action, select one of the following:

- No Action radio button no action occurs.
- Open Mute for radio button specifies the duration, in seconds, muted line remains open (unmuted).

### To add a Select button, do the following

- 1. From the Insert menu, select **Add UI Button**.
  - A None button appears on the console window.
- 2. Right-click the **None** button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select **Select**.
  - The Line to Associate Function With drop down menu becomes active and the Select Button Setup tab appears.
- From the Line to Associate Function With drop down menu, select the line to associate with Select.

- 6. Click the Select Button Setup tab.
  - The Select Button Setup page appears.
- 7. In the DTMF Digits for Select Call field, enter the **digits required** to activate the select call feature.
- 8. From the Annunciation of Select Call group box, select the **type of notification** to be used
- 9. From the Action on Select Call group box, select the mute action during a select call.
- 10. Click **OK**.

The button changes color and Select appears on the button.

#### **Annunciation of Call Alert group box**

#### **Blink Select Button check box**

The **Blink Select Button** check box indicates the button blinks orange when the console receives a call alert.

### No Beep radio button

The **No Beep** radio button indicates no tones are heard when a call alert is received.

#### Beep for check box

The **Beep for** check box indicates a call alert tone is heard when a call alert is received.

The Beep for seconds field indicates the amount of time the alert tone plays.

### Blink Border on Receive group box

#### No Blinking radio button

The No Blinking radio button indicates the Select button does not blink when receiving a call.

### Blink for radio button

The **Blink for** radio button indicates upon receiving a call the Select button's border blinks for the amount of time set in the seconds field. When the line is transmitting the blinking stops.

When selected, the Blink for Radio button field is active.

#### Blink for field

The **Blink for** field indicates the amount of time, in seconds, the Select button blinks upon receiving a call.

### Blink Until PTT radio button

The **Blink Until PTT** radio button indicates upon receiving a call, the Select button's border blinks until a PTT is generated on the line.

#### Blink Color drop down palette

The Blink Color drop down palette indicates the color of the button border when it blinks.

### **DTMF Digits for Select Call fields**

The **DTMF Digits for Select Call** fields identifies the digits required to activate the select call feature. C-Soft can respond up to five different DTMF strings.

This field can contain up to 10 characters.

#### Beep for seconds field

The **Beep for** seconds field indicates the amount of time the call alert tone plays.

The Beep for radio button must be selected for this field to be active.

The range for this field is 1 to 10 seconds.

### Beep Until PTT radio button

The Beep Until PTT radio button indicates the alert tone is heard until a PTT operation is performed on the line that received the call alert.

#### To **configure a blinking button indication**, do the following:

From the Select Button Setup page, select the Blink Select Button check box.

### To configure the desired notification, select one of the following:

- No Beep radio button no beep sound is played when a select call is received.
- Beep For radio button a beep sounds for the specified number of second (0-10 seconds) when a Select Call is received.
- Beep Until PTT radio button a beep sounds until a PTT when a select call is received.

#### **DTMF Digits for Select Call group box**

The DTMF Digits for Select Call group box contains five fields to specify DTMF digit strings to trigger a select call in C-Soft. When the console receives any of the DTMF strings configured in the select call setup, the button notifies the operator by either blinking or beeping depending on the console configuration.

### **Trigger Emergency check box**

The Trigger Emergency check box indicates an emergency is triggered when the string entered in the field is received.

#### Refer to

Mute-Per Line, page 321

#### 31.83 SIP Call Control

The SIP Call Control function creates a button to open the SIP Calls window shown in SIP Calls window, page 375.




Figure 31.69: SIP Window - SIP Call Control

### Refer to

- SIP Calls window, page 375

## 31.83.1 SIP Window page

### **Incoming Call Answer Behavior group box**

The **Incoming Call Answer Behavior** group box is used to determine how C-Soft responds to incoming calls.

### **Automatic button**

The Automatic button indicates incoming calls are answered automatically by C-Soft.

#### **Manual button**

The **Manual** button indicates incoming calls are answered by clicking the Answer button in the SIP Call Control window.

## Answer Call on SIP Call Control Click check box

The **Answer Call on SIP Call Control Click** check box indicates incoming calls are answered using the SIP Call Control button. This option also allows calls to be answered in a single button press.

### Allow Do Not Disturb check box

The **Allow Do Not Disturb** check box indicates the Do Not Disturb feature is available. If unchecked, the Do Not Disturb button is disabled.

## SIP Call Options group box




Figure 31.70: Normal Window Size




Figure 31.71: Large Window Size

## **Display Missed Call Notifications check box**

The **Display Missed Call Notifications** check box indicates if any missed call notifications should be displayed to the user. When selected, missed calls generate notifications on the SIP Call Control button and in the SIP Call Control window.

In configurations where the extension is configured for one or more Ring Groups, it may be useful to not display missed call notifications.

### Display Extension on Incoming Call check box

The **Display Extension on Incoming Call** check box indicates the incoming extension number is displayed in addition to any alias information in the SIP Call Display window.

When not selected, the incoming SIP extension number is only displayed if there is no caller ID information included in the incoming call.

### **SIP Window options**

#### Window Size radio buttons

The **Window Size** radio buttons are used to specify the size of the SIP window.

Available options are Normal and Large.



#### Notice!

The Large window size is recommended for touch-screen operation.

### Display Backspace Button check box

The **Display Backspace Button** check box is used to display an on-screen backspace button in the top right corner of the SIP Call Control window. The on-screen backspace button is useful for touchscreen operations when using C-Soft without a keyboard.

### Background drop down palette

The **Background** drop down palette is used to change the background color of the SIP Call Display window.

A light color is recommended.

### Text drop down palette

The **Text** drop down palette is used to change the color of the SIP Call Display window.

A dark color is recommended.

### Filter + Contact Text button

The **Filter + Contact Text** button is used to select a font for the SIP Call Control's Contact and Filter list.

## 31.83.2 SIP Speed Dial page

The **SIP Speed Dial** page allows entry of 12 numbers. These provide an easy and convenient way to access commonly-called extensions. Additionally, each entry contains a Presence check box. If an entry's Presence check box is selected, C-Soft attempts to subscribe to presence notifications for the extension.

Figure 31.72: Speed Dial Page

Refer to "Speed Dial Pane" for additional information on the Presence feature.

In C-Soft Runtime, when the window is open, the user can receive, place, and transfer phone calls, control the call volume, view history or view a list of missed calls. Monitor the Status Bar at the top of the console window for success or failure messages.

#### To **initiate a connection to the SIP server**, do the following:

Open C-Soft Runtime.

C-Soft attempts to connect to the server.

- If the SIP server connection is successful, the message appears on the console status bar.
- If the SIP server connection fails, the message appears on the console status bar.
- If the SIP server connection becomes disconnected during use, the failure message appears in the status bar.




During SIP calls, some status messages and icons appear directly on the SIP Call control button during SIP call activity. These same indications as well as status messages, appear in the SIP Calls window. Refer to the Figure below.

### Note:

 Bosch Security Systems, LLC
 Technical Manual
 2021-06 | 14 | F.01U.218.561

- A Mute Per Line button can be associated with a SIP Call Control button to mute the SIP line's RX (incoming) audio. The mute icon, refer to the Figure below, appears when the SIP line is muted per line, RX blocked, or when a Mute-Main button is selected.
- If the line is muted, and a call is initiated from the SIP Calls window, the line is automatically unmuted.



Tab. 31.7: SIP Call Buttons with Status Indications

## SIP Incoming Call popup menu

The SIP Incoming Call popup menu, shown in the Figure below, can be used to quickly access the incoming SIP call. During an incoming call, the status indicator changes to RING. Rightclick the incoming SIP call button to access the popup menu.

Available selections for this menu are:

- Open SIP Window Opens the SIP Calls window. For more information, refer to "SIP Calls window, page 375".
- Answer Answers the incoming call. For more information, refer to "Call/Answer Button" on Call page, page 375.
- Ignore Ignores the incoming call. For more information, refer to "Hang Up/Hang Up >/ Ignore Button" on Call page, page 375.

Figure 31.73: SIP Incoming Call popup Menu

#### Refer to

- SIP Calls window, page 375
- Call page, page 375

### 31.83.3 SIP Calls window

The SIP Calls window is used to manage SIP Calls, view call history and view missed calls.

## 31.83.4 Call page

When a SIP Call Control button is clicked in C-Soft Runtime, the SIP Calls window opens to the **Call** page. Refer to the Figure below.

The Call page is used to place incoming and outgoing SIP phone calls, place holds, initiate 3-way calling, mute the microphone, transfer calls, and activate do not disturb.




Figure 31.74: SIP Calls Window - Call Page

#### SIP Call display

The **SIP Call** display is used to enter a phone number to call. It also provides status messages and icons to indicate the state of the associated SIP line.

To enter a phone number to call, do the following:

- 1. Ensure the SIP Calls window is open.
- Using the Keypad pane or the keyboard keypad, enter the **phone number** to call.
   The digits appear in the SIP display.
- Click Call.

OR

While the SIP display has focus, press **Enter**.

When the call is connected, the Connected icon appears in the display.

#### Call/Answer button

The Call/Answer button is used to place or answer a call.

This button is disabled until a number is entered or an incoming call is received.

- If a contact is selected from the Contacts pane, or a phone number is entered in the SIP Call display, the Call button is enabled.
- If a call is being received on a line while the SIP Calls window is open, a ring icon appears
  on the SIP Call display, the Call/Answer button changes to Answer, and the Call/Answer
  and Ignore buttons are enabled.




Figure 31.75: SIP Calls - Incoming Call

To answer a call, do the following:

Click Answer.

The incoming call is connected.

If the line is already engaged in a call, the existing call is placed on hold and the Cancel button label changes to Switch.

To return to a caller on hold while on another call, do the following:

#### Click Switch.

The current caller is placed on hold and the other call is taken off hold.

### To answer and merge a waiting call with the current call, do the following.

- While already engaged in a call, click **Answer**. The current call is placed on hold and the incoming call is answered.
- Click 3-way Call. 2.

The on-hold call is taken off hold, and joined with the other call. The two callers and console operator are connected in one conversation. The 3-Way Call button label changes to Leave Call.



Figure 31.76: SIP Calls - Outgoing Call

### To place an outgoing call, do the following:

- 1. Using the Keypad pane or keyboard, enter the **phone number**. The number appears in the SIP Calls display.
- 2. Click Call.

OR

Press Enter.

The call is placed to the phone number entered in step 1.

To disconnect from the call, click Hang Up.

## Hang Up/Hang Up >/Ignore Button

The Hang Up/Hang Up >/Ignore button is used to disconnect the current SIP call or ignore an incoming call.

- During a call, the Hang Up button is enabled.
- If multiple parties are connected via consultant transfer, 3-way calling, or call waiting the Hang Up > button appears. Click the Hang Up > button to open a popup menu containing all currently connected calls.
- While an incoming call is ringing, the Hang Up button's text changes to Ignore.




Figure 31.77: Hang Up > Button with popup Menu

### To disengage a 2-way call, do the following:

Click the Hang Up button.

The call is disconnected and the connected icon disappears.

### To disengage a call with multiple participants, do the following:

Click Hang Up >.

A popup menu appears. Refer to the Figure above.

2. Select an individual call to disconnect from.

OR

Select Both to disconnect both calls.

### To **ignore an incoming call**, do the following:

Click Ignore.

The call is ignored and the caller information is added to the list on the Missed page.

### **Hold button**

The Hold button places the current call on hold. During hold, C-Soft does not send or receive audio.

- If multiple parties are connected at one time, the hold button places all calls on hold or takes all calls off hold.
- If the console operator is talking to the consulting party during a consultant transfer or speaking to one party during a call waiting event, clicking the Hold button places the active participant on hold.

#### Note:

- Hold options can be configured on the SIP server.
- The SIP hold button stops both incoming and outgoing audio, whereas the console hold button only stops the outgoing audio.




Figure 31.78: Call Page - On Hold

### To place a call on hold, do the following:

- While in a SIP call, click **Hold**.

The call is placed on hold and the On Hold icon appears in the SIP Call display.

### To take a call off hold, do the following:

Click the **Hold** button.

The call is taken off hold.

## **Mute Mic/Unmute Mic button**

The Mute Mic button is used to stop microphone audio from reaching any connected party.




Figure 31.79: Call Page - Mute Mic

### To mute the microphone, do the following:

While engaged in a SIP call, click Mute Mic.

The button changes to Unmute Mic, the Mute Mic icon appears in the SIP Call display, and microphone audio is not sent.

### To unmute the microphone, do the following:

Click Unmute Mic.

The button label changes to Mute Mic, the icon disappears from the display, and the microphone is open.

#### **DND/Disable DND button**

The DND (Do Not Disturb) / Disable DND button is used to activate do not disturb mode. While active, callers automatically receive a message stating the number is unavailable. While DND is active, DND icons appear on the Call page and the associated SIP button.



Figure 31.80: Call Page - DND

### To activate DND, do the following:

Click DND.

The button label changes to Disable DND and the DND icon appears in the SIP Call display.

Calls received while in do not disturb mode are logged on the Missed page.

### To **disable DND**, do the following:

Click Disable DND.

The specific do not disturb message is configured on the SIP server.

### Consultant Xfr/Blind Xfr button

The **Consultant Xfr/Blind Xfr** button is used to blind transfer a call or transfer with consultation.

- A blind transfer is a call transferred to a second party without announcing the call to the receiver.
- A consultant transfer allows the console operator to announce the transferred call to the receiver.
- The button label is changed by right-clicking the button and selecting the function from the popup menu.




Figure 31.81: Consultant Xfr popup Menu

To abort the transfer function at any time, click Cancel. The incoming call remains connected.

### To make a consultant transfer, do the following:

From the Call page for the line, if the button label is Consultant Xfr, go to step 3. OR

Right-click Blind Xfr.

A popup menu appears.

Select Consultant Xfr.

The button label and function changes to Consultant Xfr.

Click Consultant Xfr.

Enter transfer destination appears and the SIP Call display is ready to accept a transfer destination.

- 4. Using the Keypad pane, keyboard, or the Contacts list, enter the new destination number in the SIP Calls window.
- Click Consultant Xfr.

The current call is placed on hold and a call is placed to the destination number. When the call is answered, the Hang Up button changes to Hang Up >.

- 6. Announce the caller to the **second party**.
- 7. Click Consultant Xfr.

The first and second call are now connected, and disconnected from C-Soft.

Click **Hang Up** to disconnect from the call.

Both callers are disconnected from the console.

## To make a blind transfer, do the following:

From the Call page for the line, if the button label is Blind Xfr, go to **step 3**.

OR

Right-click Consultant Xfr.

A popup menu appears.

#### 2. Select Blind Xfr.

The button changes to Blind Xfr.

#### 3. Click Blind Xfr.

Enter Transfer destination appears in the display and the SIP Call display is ready to accept a number.

- 4. Using the Keypad pane, keyboard, or Contacts list enter the **destination number**. The phone number appears at the bottom of the display.
- 5. Click Blind Xfr.

The original call is transferred to the destination number and immediately disconnected from the console.

#### **Line Conf button**

The **Line Conf** button is used to join two SIP phone calls already in progress into a line conference. A line already involved in a 3-way call can be included in the line conference. During a line conference, the SIP Calls window border changes to black. An example is shown in the Figure below.

Due to processing demands, a maximum of six remote parties (plus the console) can be mixed together at one time.



Figure 31.82: SIP Calls Page - Line Conference

To place two lines into a line conference, do the following:

- 1. Engage **two SIP** calls on two separate lines.
- From the first line's call window, click Line Conf.
   The window's border turns black.
- 3. From the second line's call window, click **Line Conf**.

The second line's SIP Call window turns black. Both lines are now in communication with each other.

#### 3-Way Call button

The 3-Way Call button is used to establish a call in which three participants are engaged.

#### To abort the 3-way call function at any time, click Cancel.

The original call remains connected to the console.

### To establish a 3-way call, do the following:

- While already engaged in a call, click 3-Way Call. Enter New Destination appears in the display.
- Using the Keypad pane, keyboard, or Contacts list enter the **new destination number**. The number appears at the bottom of the display.
- Click 3-Way Call.

The current call is placed on hold and a call is placed to the new destination number. The Hang Up button changes to Hang Up >.

4. Click 3-Way Call.

The first call is taken off hold and joined in the current call. Both parties and the console operator are connected. The 3-Way Call button's label changes to Leave Call.

### Cancel/Switch button

The Cancel/Switch button is used to cancel an operation or switch to another call.

- If the button is active and Cancel appears on it, it can be used to cancel a blind transfer, consultant transfer, 3-way call or restore a call to its previous state.
- If the button is active and Switch appears on it, it can be used to switch from the current call to a call-waiting call.

#### To cancel a transfer or 3-way call operation before it is completed, do the following:

Click Cancel.

The operation is canceled, the current caller remains on the line, and the Cancel button is disabled.

#### To switch to a waiting call while already in a call, do the following:

Click Switch.

The current call is placed on hold, the waiting call becomes active.

Click Switch to switch back to the other call.

#### Mute icon

The Mute icon is used to instantly mute audio on the SIP line.




Figure 31.83: Call Page - Mute Icon

### To mute audio on the SIP line, do the following:

Click Mute.

The Volume slider moves to the bottom of the volume bar. The speaker icon changes to a red mute icon and audio is turned off.

Clicking Mute restores the Volume slider to its previous value.

### **Volume Slider**

The **Volume** slider is used to adjust the speaker volume for the associated line.

### To decrease the volume, do the following:


Slide the volume slider down.

### To **increase the volume**, do the following:

Slide the volume slider up.

## **Expand Button**

The **Expand** button is used to expand the SIP Calls window, refer to the Figure in 480. When the Expand button is clicked, a Misc tab, Forward tab, and additional features appear on the Call, History, and Missed pages.





## **Collapse button**

The **Collapse** button is used to collapse the SIP Calls window, refer to the Figure above.

- Collapse button.



#### Contacts pane

The Contact pane is used to view, edit, or delete the list of contacts within the SIP system. This list is managed using a popup menu. The contact list can be divided into subdirectories making it easier to group and maintain contacts. Additionally, the Contact Search bar can be used to filter the contact list to contain only contacts that match the entered text.

The Contact List supports 5000 SIP contacts.

The Contacts pane appears on the Call page when the expand button is clicked.




Figure 31.84: Call Page - Contacts Pane



#### Notice!

The Pop-up Menu is not accessible with a mouse on the IP-30xx devices.



#### Notice!

Subdirectory Group names can be modified from their default names (Subdirectory 1, Subdirectory 2, etc.) by editing the Contact Directory CSV file. The CSV file is located at C: \ProgamData\Telex Communications\design folder\ and is named sip directory <veg>.cvs (where <veg> is the name of the C-Soft Design file. You can edit this file directly using a text editor or import the file into any common spreadsheet application, such as Excel). The Directory file is only created after adding the first contact to an operational position.

To place a call to a contact in the list, do the following:

From the Contacts pane, select a **contact**. The contact's number appears in the SIP call display.

#### 2. Click Call.

A call is placed to the selected contact.

OR

Double-click the contact.

The default action (the bold item in the popup menu i.e Call) is performed and the call is placed.

OR

Right-click the contact and select Call.

A call is placed to the selected contact.


#### To add a new contact to the list, do the following:

1. Right-click the contact list.

A popup menu appears.

2. Click Add New.

The Edit Contact window appears.



- 3. From the Subdirectory drop down menu, select a **subdirectory to associate to a Contact**, if desired.
- 4. In the First Name field, enter the **first name** of the contact.
- 5. In the Last Name field, enter the **last name** of the contact.
- 6. In the Display Name field, enter a **user-recognizable name** for the contact.
- 7. In the Number field, enter the **phone number** for the contact.
- 8. In the Notes field, enter **appropriate comments** for the contact.
- 9. Click OK.

The contact is added to the contacts list.

### To edit a contact in the list, do the following:

1. Right-click the contact list.

A popup menu appears.

2. Click Edit.

The Edit Contact window appears.

- 3. Make **changes** to the appropriate fields.
- 4. Click **OK**.

The changes to the contact information are saved.

To delete an entry from the contacts list, do the following:

Right-click a **contact** to delete.

The contact list popup menu appears.

2. Click **Delete**.

The contact is removed from the list.

#### To import a contact list from a .csv file, do the following:

1. Right-click the contact list.

A popup menu appears.

2. Click Import.

The Import window appears.

- 3. Select a .csv file to import.
- 4. Click **OK**.

All contacts contained in the .csv file are added to the list.

### To export a contact to a .csv file, do the following:

1. Right-click the contact list.

A popup menu appears.

Click Export.

The Export window appears.

From the Name drop down menu, select a **name**.

In the Name field, enter a **name** for the .csv file.

4. Click **OK**.

All contacts are exported to the selected .csv file.

### Keypad pane

The **Keypad** pane is used to enter DTMF digits and access voice mail messages.

The Keypad appears when the Keypad tab is clicked while in the maximized Call page. The Call page is maximized using the Expand button.

### Note:

- These digits can also be entered using the keyboard.
- While in a call, the keypad generates DTMF tones. When not in a call, the keypad inserts the digits in the SIP call display.




Figure 31.85: Call Page - Keypad Pane

#### To access the keypad pane, do the following:

- From the Calls page, click the **expand** button. The contacts page appears.
- Click the **Keypad** tab.

The Keypad pane appears.

#### **CLR** button

The CLR (Clear) button is used to clear the information from the SIP Call display.

The SIP Call display entry field must be enabled.

#### <-- button

The <-- button is used to delete the last entered character from the SIP Call display.

The SIP Call display entry field must be enabled.

#### Flash button

The **Flash** button is used to send a hook flash signal.

This feature is only available during a SIP call.

## Voice mail button

The Voice mail button is used to access a specific voice mail number. The SIP server must support this feature.

### To configure a specific voice mail number for the button, do the following:

- Right-click Voice mail and select Configure from the popup menu. The Edit Contact window appears.
- 2. In the Number field, enter the **phone number** for the button.

#### Click OK.

The voice mail number is stored.

#### To call the stored voice mail number, do the following:

Click the Voice mail button.

A call is placed to the specified phone number.

#### Voice mail notification icon

When the Voice mail notification icon, shown in the Figure above, appears in the SIP Calls display, voice mails are waiting. The number indicated to the right of the New text, (e.g. 4), is the quantity of voice mail messages in queue.

### **Speed Dial pane**

If at least one speed dial extension is configured, the SIP window in C-Soft Runtime displays an additional Speed Dial pane.




Figure 31.86: Call Page - Speed Dial Pane

In C-Soft Runtime, the current call state of the speed dial number is color coded (for example, green means the number is available to call):

- If not currently in a call, pressing the button calls the specified number.
- If already in a call with the specified number, pressing the button hangs up the call.

- If already in a call, but not with the specified number, pressing the button forwards the current call to the specified extension.

If the Presence setting is enabled, C-Soft attempts to monitor the Presence State of each of the configured button extensions. Each Speed Dial button color changes based on the corresponding extension's presence. Additionally, any Autodial buttons in the main console window configured to the same extension also change color with the extension's presence information.

The Presence states and colors are:

Presence state	Color
Available (not in a call)	Green
Unavailable (in a call)	Red
Incoming Ring	Yellow
Outgoing Ring	Blue
No Presence Information	Grey

# 31.83.5 History page

When the History tab is clicked from the SIP Calls window, the History page appears. Refer to the Figure below. The **History** page is used to view past SIP Calls received on the selected line.




Figure 31.87: History Page - Maximized

### **Description column**

The **Description** column displays the call's number and url or the alias.

#### Date and Time column

The Date and Time column displays the date and time the call occurred

#### **Phone Number column**

The **Phone Number** column displays the phone number that called.

### **History legend**

The **History** legend displays the color format used for incoming and outgoing calls.

### **Call button**

The Call button is used to place a call to the selected phone number. If no call is selected from the list, the Call button is disabled.

The Call button appears on the History page when the Expand button is clicked.

To call a contact in the History list, do the following:

- Select the **phone number** to call.
- 2. Click the Call button.

OR

Select Call from the entry's popup menu.

Double-click the entry.

The call is placed and the SIP Calls window switches to the Call page.

#### 31.83.6 Missed page

When the Missed tab is clicked from the SIP Calls window, the Missed page appears. Refer to the Figure below. The Missed page is used to view calls received, but not answered on the selected SIP line.




Figure 31.88: Missed Page

#### **Description column**

The **Description** column displays the call's number and url or the alias.

#### **Date and Time column**

The Date and Time column displays the date and time the call occurred

#### **Phone Number column**

The **Phone Number** column displays the phone number that called.

This column is visible when the Expand button is clicked to maximize the window.

### Missed Calls legend

The **Missed Calls** legend display the color format used for unanswered, ignored, do not disturb, and forwarded calls.

#### Call button

The **Call** button is used to place a call to the selected phone number. If no call is selected from the list, the Call button is disabled.

The Call button appears when the Missed page is maximized. Click the Expand button to maximize the window.

#### **Call button**

The **Call** button is used to place a call to a phone number selected from the list. This button is visible when the Expand button is clicked to maximize the window.

## To place a call from the missed call list, do the following:

- Select a call from the list.
- 2. Click Return Call.

OR

Double-click an entry.

OR

Right-click an entry and select Call from the popup menu.

The call is placed to the selected phone number.

#### **Clear List button**

The **Clear List** button is used to clear all calls from the list. This button is visible when the window is maximized.

### To clear all calls from the list, do the following:

Click Clear List.

The list is cleared.

## **31.83.7** Misc page

The **Misc** page is used to view the following system information:

- Domain Displays the registered domain of the SIP line.
- Protocol Displays the SIP protocol for the line.

- SIP Registration - Displays the registration information for the SIP line.

The Misc page, refer to the Figure below, becomes available in the SIP Calls window when the expand button is clicked.



Figure 31.89: Misc Page

## 31.83.8 Forward page

The **Forward** page is used to configure forwarding options.

The Forward page, shown in the Figure below, becomes available in the SIP Calls window when the expand button is clicked.




Figure 31.90: Forward Page

#### Forward All Calls check box

The **Forward All Calls** check box indicates all calls received on the line are forwarded to the phone number entered in the Destination field for this check box.



#### Notice!

This selection cannot be combined with any other forwarding option.

#### **Destination field**

The **Destination** field is used to enter the phone number to forward all incoming calls to.

#### **Address Book**

The Address Book button is used to locate a phone number to enter in the Destination field.



### Forward calls while busy check box

The **Forward call while busy** check box indicates calls received while the line is busy are forwarded to the phone number in the Destination field for this check box



### Notice!

This check box can be used in combination with the Forward unanswered calls option. Some SIP servers (i.e. 3CX) have their own settings for forwarding a call when an extension is busy. When using these servers the call forwarding logic in the server takes precedence over the call forwarding settings in C-Soft.

## **Destination field**

The **Destination** field is used to enter the phone number to forward incoming calls to when the line is busy.

#### **Address Book**

The Address Book button is used to locate a phone number to enter in the Destination field.

### Forward unanswered calls after check box

The **Forward unanswered calls after** check box indicates calls left unanswered are forwarded to the phone number entered in the Destination after the amount of time configured in the Forward unanswered all after seconds field.



### Notice!

This check box can be used in combination with the Forward calls while busy option.

 Bosch Security Systems, LLC
 Technical Manual
 2021-06 | 14 | F.01U.218.561

## Forward unanswered calls after seconds field

The **Forward unanswered calls after seconds** field is used to enter the amount of time, in seconds, the call is left unanswered before it is forwarded to the phone number in the Destination field.

#### **Destination field**

The **Destination** field is used to enter the phone number to forward unanswered calls after [X] seconds.

#### **Address Book**

The Address Book button is used to locate a phone number to enter in the Destination field.

### **Apply button**

The **Apply** button is used to save changes made to the Forward page.

#### To set up call forwarding, do the following:

1. From the Forward page, select the **Forward all calls** check box.

OR

Select the Forward calls while busy check box.

OR

Select the Forward unanswered calls check box.

- 2. In the Forward unanswered calls after seconds field, enter the **amount of time** in seconds.
- 3. In the Destination field for the selected check box, enter the **phone number** the call is to be forwarded to.

OR

Click the Address Book button.

The address book appears.

4. Select a **phone number** to forward calls to.

The phone number appears in the Destination field.

5. Click Select.

The window closes and the phone number appears in the selected field.

OR

Click Cancel

The changes are not accepted and the window closes.

6. Click **Apply** to accept changes.

The changes are applied.

### **Close button**

The Close button is used to close the SIP Calls window.

# 31.84 Status Stack Programmed

The **Status Stack Programmed** window, shown in the Figure below, is used to pre-configure a stack status which defines the user or group a particular status is sent. Programmed stack statuses are used to execute an existing stack status in C-Soft Runtime.

### Stack Setup page

When Status Stack Programmed is chosen from the UI Element drop down menu, the **Stack Setup** page appears.



#### Notice!

This feature is only supported in FleetSync and NEXEDGE Direct IP.

## To open the Stack Setup page, do the following:

- From the Insert menu, select Add UI Button.
   A None button appears on the console window.
- 2. Right-click the **None** button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**. The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select **Status Stack Programmed**. The Stack Setup tab appears.
- 5. Click the **Stack Setup tab**.

The Stack Setup window appears.




Figure 31.91: Status Stack Programmed - Stack Setup Page

## Add Status group box

# Status drop down menu

The **Status** drop down menu is used to select an existing status you want to configure for the stack setup.

To create statuses, refer to "Status Message ID List window, page 187".

#### Unit ID drop down menu

The Unit ID drop down menu is used to select an existing Unit ID to send the status.

#### Group ID drop down menu

The Group ID drop down menu is used to select an existing Group ID to send the status.

#### Add button

The **Add** button is used to add the selected status and either the selected Unit ID or Group ID to the Status/Destination display pane.

### Status/Destination display pane

The **Status/Destination** display pane displays the preprogrammed status messages and the destination each is sent to when the configured button is clicked.

#### Remove button

The **Remove** button is used to remove the selected preprogrammed status from the Status/ Destination display pane.

#### To remove a status from the Status/Destination display pane, do the following:

- 1. From the Status/Destination display pane, select the **Status** you want to remove.
- 2. Click the Remove button.

The Status is removed from the Status/Destination display pane.

## 31.85 Status Stack window

The Status Stack window, shown in the Figure below, is used to configure the window appearance and functionality of the status stack, including the number of visible entries and the actions to take when a failed attempt occurs. The Status stack window allow users to select multiple statuses and send them.

#### Stack Setup page

When Status Stack Window is chosen from the UI Element drop down menu, the **Stack Setup** page appears.

## To open the Stack Setup page, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- Right-click the None button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- From the UI Element drop down menu, select Status Stack Window.
   The Stack Setup tab appears.
- 5. Click the Stack Setup tab.

The Stack Setup window appears.




Figure 31.92: Stack Status Window - Stack Setup Page

# 31.85.1 Window Appearance group box

## **Maximum Number of Visible Entries field**

The **Maximum Number of Visible Entries** field is used to set the maximum number of visible entries inside a Stack window at one time.

The range for this field is 0-9.

#### **Set Font button**

The **Set Font** button is used to open the Font window. From this window you can set the font you want to display in the Stack Status window.

# 31.85.2 Failed Attempts group box

### **Number of Retries field**

The **Number of Retries** field is used to set the number of times the system retries the status.

The range for this field is 0-9999.

## **Retry Wait field**

The **Retry Wait** field is used to set the amount of time to wait between status tries.

The range for this field is 0-9.

#### Resend Immediately radio button

The **Resend Immediately** radio button is used to set the system to resend the failed status immediately, regardless of the status of the status stack.

#### **Resend After Stack Completion radio button**

The **Resend After Stack Completion** radio button is used to set the system to resend the failed status after the status stack has completely finished.

## 31.85.3 Status Stack window

The **Status Stack** window is used to display the status of stacks being sent such as the date, time, channel, etc. This window is also used to administer status stacks - sent and failed sends.



#### Notice!

This feature is only supported in FleetSync and NEXEDGE Direct IP.




Figure 31.93: Stacked Status Window

## Status Stack display pane

The **Status Stack** display pane displays columns of different information:

- Date Column The date the status stack was sent.
- Time Column The time the status stack was sent.
- Channel Column The channel the status is sent from.
- Status Alias Column The name of the status sent.
- Unit ID Column The User ID of the recipient of the status.

- Group ID Column The Group ID of the group receiving the status.
- Status Column The Status of the stack sent. Available Statuses are:

#### Status drop down menu

The **Status** drop down menu is used to select the status alias. Doing this, refines the list of statuses shown in the display pane, making it easier to find the particular status you are searching. The selections listed in this menu are directly related to the statuses you created in the Status Message ID List window. For more information, refer to "Status Message ID List window, page 187".

## Groups display pane

The **Groups** display pane displays the groups, if any, associated with the selected status.

#### Users display pane

The **Users** display pane displays the users, if any, associated with the selected status.

#### **Resend button**

The **Resend** button resends a failed status. You can select more than one status to resend by pressing the Ctrl key and selecting with the mouse which statuses you want to resend.

#### Clear button

The Clear button clears the Stacked Status window of all statuses.

#### Done button

The Done button closes the Stacked Status window.

#### Add button

The Add button adds more statuses to send

#### Send button

The **Send** button sends the selected statuses to the appropriate users or groups.

#### Refer to

- Status Message ID List window, page 187

# 31.86 Supervisor

The **Supervisor** function allows a single dispatch location to seize control of a line or group of lines.

In C-Soft Runtime, after clicking the Supervisor button, the console operator enters the 4-digit PIN number. When the PIN is entered, a supervisor packet burst is sent to all selected lines. When a console receives a packet burst, those lines are removed from local control. The console operator of those lines is no longer able to hear receive traffic or create transmit traffic.

Supervisor password and timeout are configured on the "Control Settings page, page 124".

#### To add a Supervisor button, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the None button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select **Supervisor**.
- 5. Click OK.

The button changes color and Supervisor appears on the button.

#### Refer to

Control Settings page, page 124

# 31.87 Talk Around button

The **Talk Around** button is used, on a per line basis, to toggle the radio talk around feature. Talk around bypasses a radio repeater system, permitting direct radio-to-radio communication.

In C-Soft Runtime, after clicking the talk around button, the button changes colors and talk around is enabled (the button position is down). After clicking the button again, talk around is disabled (the button position is up).

## To add a Talk Around button, do the following:

- 1. From the Insert menu, select Add UI Button.
  - A None button appears on the console window.
- 2. Right-click the None button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select **Talk Around**.
- 5. Click **OK**.

The button changes color and Talk Around appears on the button.

## 31.88 Text button

The **Text** button displays text or can serve as a colored space filler.



### Notice!

There is no action associated with this UI Button.

## To add a text button, do the following:

1. From the Insert menu, select **Add UI Button**.

A None button appears on the console window.

- 2. Right-click the None button.
  - A shortcut menu appears.

- 3. From the shortcut menu, select **Properties**. The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select **Text Button**.
- 5. Click the Colors tab.

The Colors page appears.

From the Colors page you can enter the text and change the color you want on the button. Also, you can leave the text field blank and change the color of the button to serve as a colored space filler. For more information, refer to "Colors page, page 407".

#### Refer to

Colors page, page 407

## 31.89 TX All

The **TX All** function allows the console operator to place all lines into a selected mode. A subsequent PTT is then transmitted on all lines.

## To add a TX All button, do the following:

- From the Insert menu, select Add UI Button.
   A None button appears on the console window.
- Right-click the **None** button.A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**. The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select **TX All**.
- 5. Click **OK**.

The button color changes and TX All appears on the button.

# 32 UI Element Setup window - Add button

The **UI Element Setup** window is used to configure the button to perform the assigned command when clicked in C-Soft Runtime.

To open the UI Element Setup window for a UI Button, do the following:

- Right-click the **UI Element button**.
   The properties menu appears.
- 2. Click Properties.
  - The UI Element window appears.
- Double-click the UI Element button.

The UI Element window appears.



#### Notice!

The first field on the UI Element Setup window identifies the type of button you are configuring and cannot be changed. In this case, it is UI Element: Button. The type is determined by the button you right-click.

# 32.1 Type page

The **Type** page, shown in the Figure below, is used to configure the type of function for the UI Element button. Some UI Elements require further configuration and when selected from the function drop down menu, additional configuration pages appear.




Figure 32.1: Type Page - UI Element Setup

#### Filter drop down menu

The **Filter** drop down menu is used to select a filter that shows only elements associated with the type of filter chosen.

Available selections for this field are:

- All - All UI Elements are available

- FleetSync UI Elements which can be used with FleetSync are available
- MDC-1200 UI Elements which can be used with MDC-1200 are available
- MOTOTRBO UI Elements which can be used with MOTOTRBO are available
- P25-DFSI UI Elements which can be used with P25-DFSI are available
- Phone UI Elements which can be used with Phone are available
- SIP UI Elements which can be used with SIP are available
- ADHB-4 Only Only UI Elements associated with the ADHB-4 are available
- Crosspatch Only Only UI Elements associated with Crosspatch are available
- FleetSync Only Only UI Elements associated with FleetSync are available
- MDC-1200 Only Only UI Elements associated with MDC-1200 are available
- P25-DFSI Only Only UI Elements associated with P25-DFSI are available
- Paging Only Only UI Elements associated with Paging are available
- Phone Only Only UI Elements associated with Phone are available
- PTT Only Only UI Elements associated with PTT are available
- SIP Only Only UI Elements associated with SIP are available

### **UI Element Function drop down menu**

The **UI Element Function** drop down menu is used to select an operation for the button. For more information on individual function configurations, refer to "*UI Element Functions configuration*, page 213".




Figure 32.2: UI Element Function Drop Down Menu

### Line to Associate Function With drop down menu

The **Line to Associate Function With** drop down menu is used to select a line to associate the function with. Not all functions are associated per line. This field is grayed out if the UI element function is a global function.

## **OK** button

The **OK** button saves the entries and closes the window.




Figure 32.3: Alert Setup Page - UI Element Setup



#### Notice!

If the console contains a UI Element button with no assigned function, ERROR! Button with no a/ssigned UI element function appears in the Design Errors window when the C-Soft Designer is saved. Refer to the Figure below.




Figure 32.4: Design Errors Window

# 32.2 Colors page

When Add UI Button or Add popup Button is selected from the Insert Menu the **Colors** page appears. This page also provides a visual display of the button in the up position with the selected attributes, and can be pressed to display the button in its down state. Refer to the Figure below.




Figure 32.5: Colors Page - UI Element Setup

### **Button Up and Button Down group box**

#### Button drop down menu

The **Button** drop down menu displays the color of the button when it is available for selection (Button Up) or when it is selected (Button Down). Default button colors are defined for each UI element function. The button colors can be changed by selecting the drop down menu to open a color palette.

#### Text drop down menu

The **Text** drop down menu displays the color of the text on the button when it is available for selection (Button Up) or when it is selected (Button Down). Default text colors are defined for each UI element function. The text colors can be changed by selecting the drop down menu to open a color palette.

#### **Button Images group box**

The **Button Images** group box is used to add a graphic to a button. The Button Images group box supports image types of .bmp, .png, .jpg, and .gif.

### Note:

- For a transparent button when using a 24-bit color bitmap, use RGB color 192, 192, 192.
- Suggested maximum image size is 1680 x 1050 pixels.
- Suggested maximum resolution is 72dpi.
- Only 24-bit and 32-bit .png files are supported.

## **Up Position and Down Position Image fields**

The **Up Position and Down Position image** fields identify the image to use on the button. Use the browse button located next to the field to select the image.

To use the same image on the Up and Down button position, do the following:

Using the browse button located next to the Down Position Image field, select the image.

#### To use a different image for the Up and Down button position, do the following:

- Using the browse button located next to the **image** field, select the image for each field.

#### To clear an entry from the Up and Down button position Image fields, do the following:

- Click the **X** button located next to the image field.

#### **Button Up Text field**

The **Button Up Text** field identifies the text displayed on the button when the button is available for selection.

This field can contain up to 49 characters.

## **Button Down Text field**

The **Button Down Text** field identifies the text displayed on the button when the button is selected.

This field can contain up to 49 characters.

#### Border Color drop down menu

The **Border Color** drop down menu displays the color of the border around the button. The border color can be changed by opening the palette with the drop down menu to select the desired color. The button border is half of the grid size on the console window. This allows UI Elements with the same color border to be grouped together, or to help create a visual separation between groups of buttons.

## Set Font button

The **Set Font** button displays a Font window used to select the text attributes for the button text.

## **OK** button

The **OK** button saves the entries and closes the window.

# 32.3 Radio Command buttons

The **Radio Command** buttons, shown in the Figure below, allow the user to send a radio command to specific user or group. If a keypad is present in the design file, Radio Command buttons contain a single button and use the keypad's destination as the command's target. However, if no keypad is present the button comprised of two individual buttons; the command button and a drop down button.




Figure 32.6: Radio Command Button

### Radio Command drop down button

The **Radio Command** drop down button is used to display all the users or groups associated with the radio command.

If no keypad is present, the following button function types display users in the drop down list:

- GPS Read
- GPS Trigger On
- GPS Trigger Off
- Private Call
- Radio Call Alert
- Radio Call Type
- Radio Check
- Radio Disable
- Radio Enable
- Radio Select Call
- Radio Status Request
- Radio Regroup
- Radio Ungroup
- Remote Monitor

The following statuses display statuses in the drop down list:

Radio Status

The following button function types display groups in the drop down list:

- Group Call

The following button function types display call priorities in the drop down list:

Call Priority

To select a user from the drop down list, do the following:

1. Click the Radio Command button.

The drop down list opens displaying users/groups configured in the line's signaling system.



2. From the Radio Command drop down list, select an entry.

The Command Button displays the selected user name. When the command button is pressed, the button's configured command is sent to the selected.



# 33 UI Element Setup window - Add Clock

The **Add Clock** option inserts a clock on the console. C-Soft can support multiple clocks on a design file for radio resources covering different time zones. The time and button format are controlled with the Clock Control page.

While in C-Soft Runtime, the clock displays as configured. An example is shown in the Figure below.




Figure 33.1: Console Clock Example

To insert a clock button, do the following:

From the menu bar, select Insert | Add Clock.

A clock button appears on the console.

# 33.1 Clock Control page

The Clock Control page, shown in the Figure below, appears when the clock is right-clicked.




Figure 33.2: Clock Control Page

#### **Time Format group box**

#### 12 Hour radio button

The 12 Hour radio button indicates the time displays in civilian time format.

#### 24 Hour Radio Button

The 24 hour radio button indicates the time displays in military time format.

## Appearance group box

# **Background Color drop down palette**

The Background Color drop down palette is used to set the clock background color.

## **Border Color drop down palette**

The **Border Color** drop down palette is used to set the clock border color.

### Test Color drop down palette

The **Text Color** drop down palette is used to set the clock text color.

#### **Border Thickness field**

The **Border Thickness** field is used to set the clock border thickness.

The range for this field is 0 to 20.

#### **Set Font button**

The **Set Font** button is used to open the font window.

#### Font window

The **Font** window, shown in the Figure below, indicates the font used to display the time on the clock display. The font window includes standard options for Font, Font Style, and Size. When you change the format, a preview of the text appears in the Sample field.




Figure 33.3: Font Window - Clock Control

### **Time Source group box**

# **Use Local Computer Time check box**

The **Use Local Computer Time** check box indicates the time that displays on the clock is derived from the PC running C-Soft. Otherwise, an offset time must be selected from the Time Offset drop down menu.

# Time Offset drop down menu

The **Time Offset** drop down menu is used to select an offset time for the clock. The Use Local Computer Time check box must be cleared for this field to be active.

Available selections for this field are:

GMT-12:00	GMT-11:00	GMT-10:00	GMT-09:00	GMT-08:00	GMT-07:00
GMT-06:00	GMT-05:00	GMT-04:00	GMT-03:30	GMT-03:00	GMT-02:00
GMT-01:00	GMT	GMT+01:00	GMT+02:00	GMT+03:00	GMT+03:30
GMT+04:00	GMT+04:30	GMT+05:00	GMT+05:30	GMT+05:45	GMT+06:00
GMT+06:30	GMT+07:00	GMT+08:00	GMT+09:00	GMT+09:30	GMT+10:00
GMT+11:00	GMT+12:00	GMT+13:00			

# Date Format drop down menu

The **Date Format** drop down menu is used to select the display format for the clock. The clock control displays in the selected format.

Available selections for this field are:

Selection	Console clock display format		
None	Date is not displayed. The clock only displays the time.		
Wednesday, March 17, 2010	Day of the Week, Month Day, Year (4-digit)		
Wednesday March 17	Day of the Week Month Day		
Wed March 17	Day of the Week Abbreviated Month Day		
Wednesday Mar 17	Day of the Week Month Abbreviated Day		
March 17, 2010	Month Day, Year (4-digit)		
Mar 17, 2010	Month Abbreviated Day, Year (4-digit)		
17-Mar-2010	Day-Month Abbreviated-Year (4-digit)		
17-Mar-10	Day-Month Abbreviated-Year (2-digit)		
March 17	Month Day		
03/17/10	dd/mm/yy		
03/17/2010	mm/dd/yyyy		
17/03/2010	dd/mm/yyyy		
17.03.2010	dd.mm.yyyy		
2010-03-17	yyyy-mm-dd		
17 March 2010	Day Month Year (4-digit)		
17 Mar 2010	Day, Month Abbreviated, Year (4-digit)		
2010 March 17	Year (4-digit) Month Day		
2010 Mar 17	Year (4-digit), Month Abbreviated Day		

# 34 UI Element Setup window - Add Frame

The **Add Frame** option inserts a Frame on the console. The button format and color are controlled with the Frame Setup page.

To **insert a Frame**, do the following:

From the menu bar, select Insert | Add Frame.

A Frame appears on the console.




Figure 34.1: Insert/Add Frame from Insert Drop Down Menu

## Frame Setup page

The **Frame Setup** page, shown in the Figure below, appears when the Frame button is right-clicked on the edge of the frame.




Figure 34.2: Frame Setup Page

### **Border Width field**

The **Border Width** field is used to enter the border width of the frame.

The range for this field is 0 to 999.

### **Border Color field**

The **Border Color** field is used to select the border color of the frame.

## Use Image check box

The **Use Image** check box indicates the frame displays the selected image file.

# To **select an image file**, do the following:

Click the Browse button.

The Frame supports image types of .bmp, .png, .jpg, and .gif.




Figure 34.3: Use Image Check Box

# 35 UI Element Setup window - Add Frequency Control

## The Frequency Control

The **Frequency Control** is used to change the frequency on a line. When a frequency is changed, a burst of packets is sent onto the Ethernet network requesting the remote radio to change to the new frequency of the selected line. Additionally, all other consoles on the network must change to display the new frequency of the radio on that particular line.

A Frequency Control is composed of two buttons, (frequency up and frequency down) and the current frequency display area.




Figure 35.1: Frequency Control

The Frequency Control automatically contains all frequencies configured for the line, except for frequencies configured for Pair Mode and are non-transmittable.

For more information, refer to "Freqs Button".

### Frequency Down button

The Frequency Down button is used to select the previous configured frequency.

## Frequency Up button

The **Frequency Up** button is used to advance to the next configured frequency.

## **Current Frequency display**

The **Current Frequency** display displays the active frequency on the line associated to the frequency control. The selected frequency can be changed by either; clicking the Frequency Down or Frequency Up buttons, or by clicking on the Current Frequency Display area and selecting a frequency from a drop down list.

### To scroll through the available frequencies, do the following:

Press and hold the Frequency Down or Up buttons.

The Frequency Control begins cycling through the available frequencies on the configured line.

## To select a frequency while scrolling, do the following:

Release the Frequency Up or Down button when the desired frequency is visible.

### To select a frequency from the drop down list, do the following:

1. Click the Current Frequency Display area.

A drop down menu containing all available frequencies are displayed. Frequencies are displayed in ascending numeric order starting at Frequency 1.

2. From the drop down menu, select the desired **frequency**.



Figure 35.2: Frequency Control Drop Down

When Scannable is selected for the line, right-click the frequency control to display a shortcut menu that provides the console operator the ability to add or remove the currently selected frequency from the scan list.

When a frequency is in the scan list, the scan list, the consoler icon appears next to the frequency in the frequency Display area and in the Frequency drop down list. Parallel consolers are also alerted to update their display if a frequency is added or removed from the scan list.

For more information refer to "Scannable Check Box" on "Scannable Check Box".

#### **Add Frequency Control**

The **Add Frequency Control** function inserts a Frequency Control on the console. The button format and color are controlled with the Frequency Control page.

To insert a frequency control button, do the following:

From the menu bar, select Insert | Add Frequency Control.

A Frequency Control appears on the console.

# 35.1 Colors page

The **Colors** page, shown in the Figure below, is used to select the settings for the Orientation, Arrow Button Settings, and Text settings.




Figure 35.3: Colors Page - UI Element Setup

#### **Orientation group box**

The **Orientation** group box specifies whether the Frequency Up and Down buttons are placed to the left and right of the control or the top and bottom of the control.

#### Horizontal radio button

The **Horizontal** radio button indicates the Frequency Up and Down buttons are drawn to the right and left of the frequency display area.



Figure 35.4: Frequency Control in the Horizontal Orientation

## **Vertical radio button**

The **Vertical** radio button indicates the Frequency Up and Down buttons are drawn to the top and bottom of the frequency display area.



Figure 35.5: Frequency Control in the Vertical Orientation

# **Border Color group box**

#### Border Color drop down menu

The **Border Color** drop down menu displays the color of the border around the frequency control. The border color can be changed by opening the palette with the drop down menu to select the desired color. The frequency control border is half of the grid size on the console window. The frequency control border being half the size of the grid size allows UI Elements with the same color border to be grouped together, or to help create a visual separation between groups of UI Elements.

## **Arrow Button Settings group box**

The **Arrow Button Settings** group box contains settings which control the appearance of the Frequency Up and Down buttons.

#### **Button Size field**

The **Button Size** field sets the height (if the orientation is set to vertical) or width (if the orientation is set to horizontal) of the Frequency Up and Down buttons The button size field allows for a larger drop down button to accommodate users of touch screen monitors.

The range for this field is 0 to 200.

The default value for this field is 17.

### Up Color drop down menu

The **Up Color** drop down menu displays the color of the button when it is available for selection (Button Up). The button colors can be changed by selecting the drop down menu to open a color palette.

## Down Color drop down menu

The **Down Color** drop down menu displays the color of the button when it is selected (Button Down). The button colors can be changed by selecting the drop down menu to open a color palette.

#### Arrow Color drop down menu

The **Arrow Color** drop down menu displays the color of the arrow in the drop down button. The arrow color can be changed by opening the palette with the drop down menu to select the desired color.

### **Text Settings group box**

The **Text Settings** group box properties control the appearance of the Frequency Display area and the Frequency drop down list.

## **Background Color drop down menu**

The **Background Color** drop down menu displays the background color of the Frequency Display area and Frequency drop down list. The background color can be changed by selecting the drop down menu to open a color palette.

## Text Color drop down menu

The **Text Color** drop down menu displays the color of the text in the Frequency Display area and Frequency drop down list. The text colors can be changed by selecting the drop down menu to open a color palette.

#### **Set Font button**

The **Set Font** button displays a Font window used to select the text attributes for the Frequency Display area and Frequency drop down list.

#### **OK** button

The **OK** button saves the entries and closes the window.

# 35.2 Frequency Control page

The **Frequency Control** page, shown in the Figure below, is used to select the Frequency List Settings and the Scrolling Settings.




Figure 35.6: Frequency Control Page - UI Element Setup

### Frequency List Settings group box

The **Frequency List** group box properties control the appearance and the display location of the Frequency drop down list. The Frequency List appears when the user clicks the Frequency Display area and disappears when either a frequency has been selected or the user has clicked on another control.

# **Drop Down Direction radio buttons**

The **Drop Down Direction** group box is used to select the direction the drop down list containing the list of available frequencies is displayed relative to the frequency control.

#### Above radio button

The **Above** radio button indicates the drop down list is displayed above the frequency control.

#### Below radio button

The **Below** radio button indicates the drop down list is displayed below the frequency control.

#### Left radio button

The **Left** radio button indicates the drop down list is displayed to the left of the frequency control.

#### Right radio button

The **Right** radio button indicates the drop down list is displayed to the right of the frequency control.

### **Entry Spacing field**

The **Entry Spacing** field is used to enter the amount of space in pixels between individual entries in the drop down list. The valued entered for Entry Spacing and the font type determine the height of the individual entries in the drop down list. When using a touch screen monitor the entry spacing value can be increased to allow individual entries to be selected from a touch screen.

The range for this field is 0 to 99.

The default value for this field is 8.

#### Visible Entries field

The **Visible Entries** field is used to enter the number of frequencies visible in the drop down list without scrolling.

The default value for this field is 10.

## **Scrolling Settings group box**

#### Scrollbar Width field

The **Scrollbar Width** field is used to set the width in pixels of the scrollbar in the drop down list.

The default value for this field is 17.

#### Minimum Slider Size field

The **Minimum Slider Size** field is used to set the minimum height of the scrollbar's thumbtack slider in the drop down list. The thumbtack slider is sized proportionally to the total number of entries in the list and the number of entries which are displayed. The minimum slider size ensures the scrollbar will always be as large as the entered value.

The default value for this field is 17.

#### **Initial Delay field**

The **Initial Delay** field is used to set the number of milliseconds a Frequency Up or Down button must be held down before the frequency control begins scrolling through the available frequencies. The larger the value, the longer the Frequency Up or Down buttons must held before scrolling begins.

The range for this field is 10 to 9999.

The default value for this field is 500.

## Repeat Delay field

The **Repeat Delay** field is used to set the number of milliseconds between frequency changes once the Frequency Control begins scrolling. The larger the value, the slower the Frequency Control will cycle though the available Frequency List.

The range for this field is 10 to 9999.

The default value for this field is 100.

# 36


# **UI Element Setup window - Add Keypad**

Use the Keypad UI Element Properties to configure the colors associated with each Mode; Common, Contact, Manual, and History. The Keypad GUI Element Settings window contains five pages: Type, Common, Contact Tab, Manual Tab, and History Tab.

### To customize the Keypad Graphical User Interface, do the following:

- From the Insert menu, select Add Keypad.
   The keypad module is created on the Designer desktop.
- 2. Right-click on the **keypad**. A popup menu appears.
- 3. From the popup menu, select **Properties**.

The UI Element Setup window appears.



4. Click each tab to **configure colors** for the associated buttons and fields.

# 36.1 Common page

The **Common** page is used to set the appearance settings for common keypad window elements shared between multiple pages.




Figure 36.1: Keypad GUI Element - Common Page

#### **Line Contact display settings**

## Line Background Color drop down palette

The **Line Background Color** drop down palette is used to set the background color of the selected contact area.

#### Line Text Color drop down palette

The **Line Text Color** drop down palette is used to set the text color of the selected contact area.

#### **Line Font button**

The **Line Font** button opens the Font window. From this window, you can set the font of the selected contact area.

#### User/Alias Background Color drop down palette

The **User/Alias Background Color** drop down palette is used to set the background color of the User/Alias display area.

#### User/Alias Text Color drop down palette

The **User/Alias Text Color** drop down palette is used to set the text color of the User/Alias display area.

### **ANI/Alias Font button**

The **ANI/Alias Font** button opens the font window. From this window, you can set the font of the User/Alias display area.

#### Search/UserID Background Color drop down palette

The **Search/UserID Background Color** drop down palette is used to set the background color of the Search/UserID area.

## Search/UserID Text Color drop down palette

The **Search/UserID Color** drop down palette is used to set the text color of the Search/UserID entry area.

#### Search/UserID Font button

The **Search/User ID Font** button opens the Font window. From this window, you can set the font of the Search/UserID Entry area.

### Separator/Background group box

## Separator/Background Color drop down palette

The **Separator/Background Color** drop down palette is used to set the color of other non-defined background areas.

## **Mode Button Settings group box**

### Color Up Color drop down palette

The **Color Up Color** drop down palette is used to set the color of the mode buttons in the unpressed state.

## Color Down Color drop down palette

The **Color Down Color** drop down palette is used to set the color of the mode buttons in the depressed state.

### **Text Color Up Color drop down palette**

The **Text Color Up Color** drop down palette is used to set the text color of the mode buttons in the unpressed state.

#### **Text Color Down Color drop down palette**

The **Text Color Down Color** drop down palette is used to set the text color of the mode buttons in the depressed state.

#### **Mode Font button**

The **Mode Font** button opens the Font window. From this window, you can set the of the Mode buttons.

## **Contact Button Label field**

The Contact Button Label field is used to enter the text shown on the Contacts button.

#### Manual Button Label field

The **Manual Button Label** field is used to enter the text shown on the Manual button.

## **History Button Label field**

The History Button Label field is used to enter the text shown on the History button.

### **Border Settings group box**

## **Border Width field**

The Border Width field is used to set the border width for the entire keypad control.

### **Border Color drop down palette**

The **Border Color** drop down palette is used to set the border color for the entire keypad control.

## **Status Settings group box**

## **Background Color drop down palette**

The **Background Color** drop down palette is used to set the background color of the status display area.

## Status Text Color drop down palette

The **Status Text Color** drop down palette is used to set the text color of the status display area.

#### Status Font button

The **Status Font** button opens the Font window. From this window, you can set the font of the status display area.

#### **Default button**

The **Default** button is used to return all the Common Tab settings back to the factory default settings.

### **Apply button**

The **Apply** button is used to apply the modifications made to the Common Tab settings.

# 36.2 Contact Tab page

The **Contact Tab** page is used to set the appearance settings for the Contact window.




Figure 36.2: Keypad GUI Element - Contact Tab Page

## **Contact Filter Settings group box**

## **Background Color drop down palette**

The **Background Color** drop down palette is used to set the background color of the filter area.

#### **Text Color drop down palette**

The **Text Color** drop down palette is used to set the text color of the filter area.

#### **Button Color drop down palette**

The Button Color drop down palette is used to set the color of the button in the filter area.

# **Button Text Color drop down palette**

The **Button Text** color drop down palette is used to set the color of the arrow on the button in the filter area.

#### **Entry Spacing field**

The **Entry Spacing** field is used to enter the spacing between entries in the filter entry list.

#### **Button/Scrollbar Width field**

The **Button/Scrollbar Width** field is used to enter the width of the filter selection button and filter entry list scrollbar.

#### **Scroll Slider Height field**

The **Scroll Slider Height** field is used to enter the height of the filter entry list scrollbar's slider.

#### **Visible Entries field**

The **Visible Entries** field is used to enter the number of entries displayed at once in the filter entry list.

## **Contact List Settings group box**

#### **Background Color drop down palette**

The **Background Color** drop down palette is used to set the background color of every odd row of the Contact List area.

#### Alternate Color drop down palette

The **Alternate Color** drop down palette is used to set the background color of every even row of the Contact List area.

#### **Text Color drop down palette**

The **Text Color** drop down palette is used to set the text color of the Contact List area.

### Row Height field

The Row Height field is used to enter the height of each row in the Contact List.

#### Scrollbar Width field

The Scrollbar Width field is used to enter the width of the Contact List scrollbar.

### Minimum Slider Height field

The **Minimum Slider Height** field is used to set the minimum slider height of the Contact List area.

#### Display drop down menu

The **Display** drop down menu is used to set how the Contacts information is displayed in the Contact List.

Available options are:

- Alias + ID
- Alias

#### **Shared Settings group box**

#### Filter + Contact Font button

The **Filter + Contact Font** button opens the Font window. From this winder you can set the font of both the filter entry list and the contact list.

#### **Apply button**

The **Apply** button is used to apply the modifications made to the Contact Tab settings.

# 36.3 Manual Tab page

The **Manual Tab** page is used to set the appearance settings for the Manual window.




Figure 36.3: Keypad GUI Element - Manual Tab Page

## **Delete Button Settings group box**

## **Button Up drop down palette**

The **Button Up** drop down palette is used to set the color of the Delete button in the unpressed state.

#### **Button Down drop down palette**

The **Button Down** drop down palette is used to set the color of the Delete button in the depressed state.

## Arrow Color drop down palette

The **Arrow Color** drop down palette is used to set the color of the arrow on the Delete button.

# **Keypad Button Settings group box**

#### **Button Up drop down palette**

The **Bottom Up** drop down palette is used to set the color of the manual entry button in the unpressed state.

## **Button Down drop down palette**

The **Button Down** drop down palette is used to set the color of the manual entry button in the depressed state.

# **Button Text Up drop down palette**

The **Button Text Up** drop down palette is used to set the text color of the manual entry button in the unpressed state.

### **Button Text Down drop down palette**

The **Button Text Down** drop down palette is used to set the text color of the manual entry button in the depressed state.

#### **Button Font button**

The **Button Font** button opens the Font window. From this window, you can set the font for the manual entry buttons.

# **Apply button**

The **Apply** button is used to apply the modifications made to the Manual Tab settings.

# 36.4 History Tab page

The **History Tab** page is used to set the appearance settings for the History window.




Figure 36.4: Keypad GUI Element - History Tab Page

## **History List Settings group box**

## **Background Color drop down palette**

The **Background Color** drop down palette is used to set the background color of every odd row of the History List area.

## Alternate Color drop down palette

The **Alternate Color** drop down palette is used to set the background color of every even row of the History List area.

#### **Text Color drop down palette**

The **Text Color** drop down palette is used to set the text color of the History List area.

#### **Row Height field**

The **Row Height** field is used to enter the height of each row in the History List.

#### **History List Font button**

The **History List Font** button opens the Font window. From this window you can set the font for the History List window.

## 36.5 Keypad

The Add Keypad option is used to add the keypad module, shown in the Figure below, to your C-Soft Console. The keypad module is used to specify a destination address for radio operations. Use the following Table to see the different radio operations for the different system types.

	FleetSyn c	Telex- Serial	MDC- 1200	MOTOTRBO	P25- DFSI	Sprint Direct Connect	AIS	NEXEDGE Control Station	NEXEDG E IP Interface	Telex- Enhanced- ANI
Radio Check			х	х	х		x			
Radio Enable/ Disable	х	х	х	х	х	х	x	x	x	х
Call Alert			х	x	х	x	х	x	x	
Select Call	x	х	х					х	x	х
Remote Monitor		х	х	х	х		х	х	х	x
Status Request	х	х	х		х		х	х	х	x
Status Message	х	х				х	х	х	х	x
GPS Operation s				х			x	x	x	
Private PTT	х	х		х	х	х	х	х	х	x
Group PTT	x	х		x	х	х		х	x	х
Radio Regroup								x	х	

Radio				х	х	
Ungroup						

Table 36.8: Radio Operations Supported by System Type

NAVIGATION: Select Insert | Add Keypad from the menu bar.



Figure 36.5: Keypad Module - C-Soft

The keypad module has three modes of operation:

- Contacts Mode Used to search for contact/user IDs.
- Manual Mode Displays a numeric keypad on the screen while allowing for keyboard input.
- History Mode Displays a list of recently used contact/user IDs and can be used to specify destination for new operations.




Figure 36.6: Keypad Module - Common Controls

#### **Selected Line Display**

The Selected Line display shows the currently selected line. For example, Line 1.

#### **Selected Contact display**

The Selected Contact display shows the currently selected contact. The selected contact is the destination of any radio command messages sent from the corresponding radio command buttons.

#### **User Entry field**

The **User Entry** field is used to enter information necessary for keypad operation. Depending on the current mode selected, this field behaves differently.

- In Contact mode, the user entry field is used to search contacts. When text is entered, the contact list updates to only show contacts whose User IDs or Aliases match (or partially match) the entered text. This search is not case sensitive. If no users match the entered text, the entered text becomes the selected contact (for example, manually entering an ID).
- In Manual mode, the user entry field is used to display the entered digits.
- In History mode, the user entry field is used to display the entered digits.

#### **Contacts Mode button**

The Contacts Mode, shown in the Figure below, is used to search for contacts. The use of filters further narrows the search parameters when looking for contacts.




Figure 36.7: Keypad Module - Contacts Pane

#### Filter drop down menu

The Filter drop down menu is used to select a filter to use when looking for contacts. When a filter is selected from the list, only contacts contained within the specified filter are shown.

Filters are created using the Filter List Setup window, refer to "Filter List Setup window, page 177". Once filters are created, user IDs are associated with filters in the User ID List Setup window, refer to "User ID List window, page 179". Group IDs are associated with filters in the Group ID List Setup window, refer to "Group ID List window, page 183".

#### **Contact List pane**

The Contact List pane displays all contacts associated with the selected line. When a contact entry is selected, the selected Contact Display is updated with the selected contact information. Any radio operations use the selected contact's as the destination.

If the contact uses a System List, only contacts within the system list are shown.

Signaling/System Types Requiring a System List			Signaling/System Types Not Requiring a System List					
_	FleetSync	_	Generic					
-	Telex-Serial	_	5/6 Tone					
-	MDC-1200	_	iDen					
-	MOTOTRBO	_	Sprint Direct Connect					
-	P25-DFSI	_	AIS					
_	NEXEDGE							

#### Manual Mode

The **Manual Mode**, shown in the Figure below, is used to manually enter the desired ID. The numeric keypad can be used with a mouse, but is used largely for touch-screen users or users without a keyboard.

If the manually entered ID matches a known User ID or Group ID, the selected contact display area display the matching contact information.

# (i)

#### Notice!

The ABC button displays the DTMF buttons A - F.




Figure 36.8: Keypad Module - Manual Panel

#### **History Mode**

The **History Mode**, shown in the Figure below, is used to view any operations initiated that use the keypad's destination as a target. When a history event is selected, the contact associated with the selected history event appears in the Selected Contact area. Each entry includes:

- Operation Destination (the Contact ID or Alias, if known)
- Operation Type
- Line name on which the operation was sent
- Timestamp of when the operation occurred.



Figure 36.9: Keypad Module - History Pane

#### **Status Bar**

The **Status Bar** displays relevant operation information. This includes notifications of specifying an invalid User ID, operation sent notifications, and operation results notification.




Figure 36.10: Keypad Module - Status Bar

#### **UI Element Setup window - Add Popup Button** 37

Select Add UI Popup Button from the Insert menu to place a popup button in the upper left hand corner of the console window. Popup buttons can also be added to a popup window. The popup button displays an activity icon when a line inside the popup window has incoming audio traffic. The activity icon can be customized by creating a graphic file named activity.bmp. This file must be located in the same directory as the csoftruntime.exe file.


#### To add a popup button to the C-Soft Console window, do the following:

From the Insert menu, select Add popup Button.

A popup button appears on the C-Soft console window.

#### To open a popup window in C-Soft Designer, do the following:

- 1. Right-click a **UI element popup button**. A shortcut menu appears.
- 2. From the shortcut menu, select **Open popup**. A popup window appears.



#### To close a popup window, do the following

Click the **X** in the upper-right corner of the popup window.

The popup window closes.

#### To resize the popup window in C-Soft Designer, do the following:

- 1. Right-click the popup button.
- From the Shortcut menu, select **Open popup**.
- Click **resize buttons**  $\stackrel{+}{\longleftrightarrow} \stackrel{-}{\longleftrightarrow} \stackrel{+}{\longleftrightarrow} \stackrel{+}{\downarrow} \stackrel{-}{\downarrow}$  to increase/reduce width/height. 3. OR

Press the **Ctrl key** while pressing the arrow keys on your keyboard.

#### Note:

- If, as a result of resizing, the window extends past the window view, move the popup button to a new position.
- The popup window cannot be resized in C-Soft Runtime.

#### To insert items into the popup window, do the following:

Right-click the **Popup button**. A flyout menu appears.

- From the flyout menu, select **Open Popup**.
   The Popup window opens.
- Right-click anywhere **inside** the Popup window.
   A flyout menu appears.
- 4. From the flyout, select the **desired element**.
- 5. **Repeat** as necessary.



#### Notice!

The popup button must be selected in order to insert items into a popup window.

To edit items in the popup window, do the following:

- 1. Open a **popup window** as described above.
- Select the **item**(s) in the popup window.
   Red targets appear on the items.
- 3. Perform the desired **action** on the selected item(s).



#### Notice!

The parameters for the item(s) can be changed, and the item(s) can be cut, copied, or moved in the same way as an item(s) is when it is placed directly on the console window.

## 37.1 Popup Window Setup page

The Popup Window Control function creates a popup window to which additional controls and button can be added. The popup window is one of the most versatile user interface options. Popup windows can be used to group together similar line functions, pages, alerts, or any combination of button and slider controls. Popup buttons can even be included within a popup window allowing for nested controls. When popup Window Control is selected from the UI Element Function drop down menu, the **Popup Window Setup** page appears.




Figure 37.1: Popup Window Setup Page

#### 37.1.1 Window Options group box

#### Allow window to be moved check box

The **Allow window to be moved** check box indicates the popup window can be moved in C-Soft Runtime.

#### Automatically close children popup windows check box

The **Automatically close children popup windows** check box indicates when a popup window is closed, any associated children popup windows automatically close. When cleared, the children popup windows remain open after the parent window has closed.

#### Open Window on Activity check box

The **Open Window on Activity** check box indicates the popup window automatically opens when activity is occurring within the popup window.

#### **Background Color drop down palette**

The Window **Background Color** drop down palette is used to set a background color for the popup window.

### 37.1.2 Button Options group box

#### Highlight button on focus check box

The **Highlight button on focus** check box is used to indicate to the user when the button's child window is in focus.

#### Focus Color drop down palette

The **Focus Color** drop down palette is used to select the color the button changes to when the button window it opens is under focus.

#### 37.1.3 Logo group box

#### Image Filename field

The **Image Filename** field identifies the file path of a image to be displayed in the background of the Console window.

This field can contain up to 255 characters.

C-Soft supports 1-bit, 4-bit, 8-bit and 24-bit bitmaps, .png, .jpg, and .gif file formats.

#### **Browse button**

The Browse button opens the Open window, which is used to navigate to the logo image file.

To change the image file, do the following:

- Click Browse.
  - The Open window appears.
- 2. Select the **file** you want to use for the image.
- Click Open.

The path to the image file appears in the field.

#### Position drop down menu

The **Position** drop down menu is used to select the location of the image logo on the console window.

Available selections for this field are: Upper-Left, Upper-Right, Lower-Left, Lower-Right, Center and Stretch.

## 37.2 Popup Webpage

The **Popup Webpage** function provides the ability to embed a webpage in the popup window. When the popup Webpage button is pressed, the specified webpage is displayed in the popup window.

A maximum of three webpages are allowed on any console design.

#### 37.2.1 Popup Webpage Setup page

When the popup Webpage function is selected, the **Popup Webpage Setup** page appears. Refer to the Figure below.




Figure 37.2: Popup Webpage Setup Page - UI Element Setup

#### Webpage URL field

The Webpage URL field identifies the URL of the webpage to display in the popup window.

This field can contain up to 98 characters.

#### Refresh Interval field

The **Refresh Interval** field identifies the amount of time that passes before the webpage displayed in the popup window is automatically refreshed. For example, if a radar weather map is displayed on the console operator's window, an entry of 300 in this field automatically refreshes the radar image every five minutes. A value of zero indicates the webpage refreshes on C-Soft application startup.

The range for this field is 0 to 999.

#### Refresh when a popup button is pressed check box

The **Refresh when popup button is pressed** check box indicates the webpage display is refreshed when the popup Webpage button is pressed.

## 37.3 Type page

The **Type** page is used to configure the type of function for the UI Element Popup (Control) button. Some UI Elements require further configuration and when selected from the function drop down menu additional configuration pages appear. Refer to the Figure below.

 Bosch Security Systems, LLC
 Technical Manual
 2021-06 | 14 | F.01U.218.561




Figure 37.3: Type Page - UI Element Setup Popup Control

#### **UI Element Function drop down menu**

The **UI Element Function** drop down menu is used to select an operation for the popup button. Each function configuration is described in the following section.

Available selections for this field are:

- Popup Call History
- Popup Webpage
- Popup Window Control

#### Refer to

- Instant Recall, page 278

## 37.4 Popup Global Call History

The **Popup Global Call History** function creates a button used to open the Global Call History window.

In C-Soft Runtime, the Global Call History is used to view per line calls received and stored in the history log. The Global Call History window also logs the state changes of input indication and relays from an ADHB-4 or NEO-10. In addition to displaying the global call history, the log can be used to play back received audio. Transmitted audio is only recorded on Phone or SIP Phone lines.

Global Call History stores up to 10 minutes of audio across all lines not enabled for Per Line Recording. For lines enabled for Per Line Recording, Global Call History window displays an additional 60 minutes of audio for each enabled line. Silence between calls is not stored.

#### Note:

 C-Soft supports one Global Call History window per console. If a Global Call History window button already exists, the Popup Call History function is not available for selection.

- Recording calls is also accomplished by adding an Instant Recall Recording button to the console, refer to "Instant Recall, page 278" for details.
- While the call history audio is playing, the recorder continues to record incoming calls.

#### 37.4.1 Call List Options page

When the popup Call History function is selected, the **Call List Options** page appears. Refer to the Figure below.




Figure 37.4: Call List Options Page - UI Element Setup

#### **Logging Options group box**

#### Include Muted Calls in List check box

The **Include Muted Calls in List** check box indicates muted calls are included in the call history log.

#### **Include NEO Changes in List check box**

The **Include NEO Changes in List** check box indicates the NEO-10 event changes are included in the call history log.

#### List appearance

#### **Call Window Lines field**

The Call Window Lines field identifies the number of lines of text saved in the call history log.

The range for this field is 1 to 500 lines.

#### **Call Window Font Size field**

The Call Window Font Size field identifies the font size of the text in the call history log.

The range for this field is 0 to 72.

The default is 8 point.

#### **Column Setup group box**

The **Column Setup** group box allows the user to determine which columns are visible in the Global Call History window. The respective columns display in the Global Call History window if selected and hidden if not selected.

#### **Call Duration check box**

The **Call Duration** check box is used to add a Call Duration column to the Global Call History window.

#### Caller ID check box

The Caller ID check box is used to add a Caller ID column to the Global Call History window.

#### **Comments check box**

The **Comments** check box is used to add a Comments column to the Global Call History window.

#### Date check box

The Date check box is used to add a Date column to the Global Call History window.

#### Direction check box

The Direction check box is used to add a Direction column to the Global Call History window.

#### Frequency check box

The **Frequency** check box is used to add a Frequency column to the Global Call History window.

#### Line Name check box

The **Line Name** check box is used to add a Line Name column to the Global Call History window.

#### Status check box

The **Status** check box is used to add a Status column to the Global Call History window.

#### Talkgroup check box

The **Talkgroup** check box is used to add a Talkgroup column to the Global Call History window.



#### Notice!

Only lines configured for P25-DFSI use the Talkgroup column.

#### Time check box

The **Time** check box is used to add a Time column to the Global Call History window.

#### User ID check box

The User ID check box is used to add a User ID column to the Global Call History window.

## 37.5 Global Call History window

The **Global Call History** window provides a log of past calls received by the console. The operator uses the log to view previously received calls. In addition, the calls can be selected for playback.

This log can contain up to 500 calls.




Figure 37.5: Global Call History Window

#### Save to File button

The Save to File button is used to save the currently selected items to a .csv file.



#### Notice!

IP-30XX devices do not have the Save to File button.

### To save a .csv file of the items in the list, do the following:

- 1. From the Per Line Call History list, select the **items** you want to save.
- 2. Click Save to File.
  - The Save window appears.
- 3. In the File name field, enter a **name** for your .csv file.
- 4. Click Save.

#### **Done button**

The **Done** button is used to close the window.

## 38 UI Element Setup window - Add Text

The **Add Text** option opens the Font window, shown in the Figure below.

NAVIGATION: Select Insert | Add Text from the menu bar.

#### **Font window**

The **Font** window is used to add descriptive text to the console window or to a popup window. The Font window includes standard options for Font, Font Style, Size, and Color formatting. When you change the format, a preview of the text appears in the sample field.

For more information, refer to "User interface element configuration, page 53".




Figure 38.1: Font Window

#### Horizontal check box

The **Horizontal** check box indicates the text is displayed on the console window in a horizontal orientation. If not selected, the text is displayed vertically.

#### **Enter Text field**

The **Enter Text** field identifies the text to place on the console window.

This field can contain up to 50 characters.

#### **OK** button

The **OK** button saves the entries and closes the window.

#### **Cancel button**

The Cancel button discards any changes made and closes the window.

 Bosch Security Systems, LLC
 Technical Manual
 2021-06 | 14 | F.01U.218.561

## 39 UI Element Setup window - Add Text Message Control

The Add Text Message Control window is used to send and receive text messages.




Figure 39.1: UI Element Setup window - Text Message

#### **Text Message page**

When the Text Message Control function is selected from the UI Element drop down menu, **Text Message** page appears. Refer to the Figure above.

#### **Common Settings group box**

#### **Border Width field**

The **Border Width** field is used to set the outside border width of the control.

The range for this field is 0 to 20.

#### **Border Color drop down menu**

The Border Color drop down menu is used to set the outside border color.

#### **Background Color drop down menu**

The Background Color drop down menu is used to set the color of non-control areas.

#### Title group box

#### Background Color drop down menu

The Background Color drop down menu is used to set the background color of the title area.

#### **Text Color drop down menu**

The **Text Color** drop down menu is used to set the text color of the title area text.

#### **Title Font button**

The **Title Font** button is used to sets the font of the title area text.

#### History group box

#### **Incoming Text Color drop down menu**

The **Incoming Text Color** drop down menu is used to set the text color of incoming text messages.

#### Incoming Bk Color drop down menu

The **Incoming Bk Color** drop down menu is used to sets the background color of incoming text messages.

#### Outgoing Text Color drop down menu

The **Outgoing Text Color** drop down menu is used to set the text color of outgoing text messages.

#### Outgoing Bk Color drop down menu

The **Outgoing Bk Color** drop down menu is used to set the background color of outgoing text messages.

#### Scrollbar Width field

The **Scrollbar Width** field is used to set the scrollbar width.

The range of this field is 10 to 100.

#### Minimum Slider Height field

The **Minimum Slider Height** field is used to set the slider height.

The range of this field is 10 to 100.

#### **History Font button**

The **History Font** button is used to set the font for all incoming and outgoing text messages.

#### **Text Entry group box**

#### Text Color drop down menu

The **Text Color** drop down menu is used to set the text color for the text entry area.

#### **Text Entry Font button**

The **Text Entry Font** button is used to set the text font for the text entry area.

#### Status group box

#### **Text Color drop down menu**

The **Text Color** drop down menu is used to set the color for the status area text.

#### Bk Color drop down menu

The **Bk Color** drop down menu is used to set the background color of the status area.

#### **Status Font button**

The **Status Font** button is used to set the font of the status area text.

#### **Default button**


The **Default** button is used to reset all parameter settings to their default values.

#### **Apply button**

The **Apply** button is used to save changes made to the Text Message page.

To use the Text Message Control, do the following:

- 1. Select the **line** on which to send the text message.
- Using the keypad, select the **destination** for the text message.
   The selected destination appears in the Destination Display of the Text Message Control.



3. Enter text into the entry field.

OR

Click the **QuickText button** to select a pre-defined text message.

4. When finished, press the **Send** button.

The text message is sent, and displays as an outgoing message in the Text Message History List. In addition, the Status Notification Area displays a notification that the text was sent.

## 40 UI Element Setup window - Add Volume Control

The **Add Volume Control** option is used to place a volume control slider, shown in the Figure below, in the upper left-hand corner of the console window. This section provides information on the functionality of the different volume controls selected from the UI Element Function drop down menu.



Figure 40.1: Volume Control Slider




Figure 40.2: Type Page - UI Element Setup Volume Control

To access the UI Element Setup window for Volume Control, do the following:

- From the Insert menu, select Add Volume Control.
   A Volume Control slider appears on the C-Soft console window.
- 2. Right-click the **Volume Control** slider.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**. The UI Element Setup window appears.

## 40.1 Type page

When Add Volume Control is selected from the menu bar, the UI Element window opens to the **Type** page. Refer to the Figure above.

#### **UI Element Function drop down menu**

The **UI Element Function** drop down menu is used to select the desired functionality for the volume control.

Available selections for this field are:

- Volume-Master Select Allows a single volume control that manipulates the volume of all selected audio.
- Volume-Master Unselect Allows the console operator to change the unselect volume for all lines.
- Volume-ADHB-4 NENA Allows the console operator to change the volume of NENA audio when operating with ADHB-4.
- Volume-Auxiliary Track Left Allows the console operator to change the left channel volume of the Auxiliary audio when operating with an ADHGB-4 Gen 2.
- Volume-Auxiliary Track Right Allows the console operator to change the right channel volume of the Auxiliary audio when operating with an ADHGB-4 Gen 2.
- Volume-Per Line Allows the console operator to control the relative level of the selected line with respect to other lines.

#### Line to Associate Function With drop down menu

The **Line to Associate Function With** drop down menu is used to select the line to associate the button or volume control with. This field is only enabled when the selected entry in the UI Element Function field requires a line association.

#### **OK** button

The **OK** button saves the entries and closes the window.



#### Notice!

If the associated line is muted, the volume control for the line is disabled.

## 40.2 Vol. Control page

When the Vol Control tab is selected from the UI Element Setup window, the **Vol. Control** page appears. Refer to the Figure below.




Figure 40.3: Vol. Control Page - UI Element Setup Volume Control

#### **Orientation group box**

The **Orientation** group box contains buttons to orient the volume control.

#### Horizontal radio button

The **Horizontal** radio button is used to position the volume control horizontally.

#### **Vertical radio button**

The Vertical radio button is used to position the volume control vertically.

#### Minimum Volume field

The Minimum Volume field identifies the minimum volume level for the control.

The range for this field is -20 to -1dB.

Zero (0) mutes the audio.

#### Maximum Gain drop down menu

The Maximum Gain drop down menu identifies the maximum volume level for the control.

Available selections for this field are: 0, 3, 6, 9, and 12.

The default for this field is 0. It is advisable to add some gain to every volume control.

#### Slider Background Color drop down menu

The **Slider Background Color** drop down menu displays the color of the volume control slider. Use the drop down color palette to select the desired color.

#### To add a volume control, do the following:

- From the Insert menu, select Add Volume Control.
   A Volume Control slider appears on the C-Soft console window.
- Right-click the Volume Control slider.
   A shortcut menu appears.

- 3. From the shortcut menu, select **Properties**.
  - The UI Element Setup window appears.
- 4. From the UI Element Function drop down menu, select a **volume function**.
  - The Vol. Control tab appears.
  - Click the **Vol. Control** tab.

    The Vol. Control page appears.
- 6. In the Orientation field, select the desired **orientation** radio button of the volume control
- 7. In the Minimum Volume field, enter a **minimum volume**.
- 8. From the Maximum Gain drop down menu, select the maximum gain.
- 9. From the Slider Background Color drop down menu, select the **background color** for the slider control.
- 10. Click **OK**.

slider.

A volume control appears on the console.

## 41 UI Element Setup window - Add VU Meter

The **Add VU Meter** option inserts a VU Meter on the console. The control format and color are controlled with the VU Meter Control page.

To insert a VU Meter control, do the following:

- From the menu bar, select **Insert | Add VU** Meter.

A VU Meter control appears on the console.

## 41.1 VU Meter Control page

The **VU Meter Control** page, shown in the Figure below, is where the control format and color are configured.




Figure 41.1: VU Meter Control Page

To access the VU Meter Control page, do the following:

- 1. Right-click the **VU Meter control**.
  - A shortcut menu appears.
- From the shortcut menu, select **Properties**.
   The UI Element Setup window appears.

#### **Orientation group box**

#### Horizontal radio button

The **Horizontal** radio button indicates the VU Meter Control is in the horizontal position on the console.

#### **Vertical radio button**

The **Vertical** radio button indicates the VU Meter Control is in the vertical position on the console.

#### VU Meter Background Color drop down menu

The **VU Meter Background Color** drop down menu is used to select the VU Meter Control background color.

**458** en | View menu C-Soft 7.700

## 42 View menu

The View menu contains commands used to change the window view.

#### Toolbar toggle

The **Toolbar** toggle indicates whether the toolbar is visible or not.

- If the toolbar is toggled on (selected), the toolbar is visible on the console window.
- If the toolbar is toggled off (not selected), the toolbar is not visible on the console window.

#### **Status Bar toggle**

The **Status Bar** toggle indicates whether the Status bar is visible or not.

- If the Status Bar is toggled on (selected), the status bar is visible on the console window.
- If the Status Bar is toggled off (not selected), the status bar is not visible on the console window.

C-Soft 7.700 Configure menu | en 459

## 43 Configure menu

The **Configure Menu** contains configuration settings for target devices and external key mapping.

Bosch Security Systems, LLC Technical Manual 2021-06 | 14 | F.01U.218.561

460 en | Device Setup C-Soft 7.700

## 44 Device Setup

The **Device Setup** window contains settings to configure the design file for operation on a specific hardware platform along with other peripheral settings.




Figure 44.1: Device Setup

#### **Design Target**

Sets the target hardware platform for the design. Options are: Desktop, IP-300X, and IP-3018. Setting the Design Target to IP-300X sets the Design's window size to dimensions matching the IP-300X device, making it easier to create a Design compatible with the IP-300X's screen dimensions.

#### **Keypad Module check box**

Specifies that the Design is intended to use Side Car Button Module. If checked, additional hardware key mapping options are available in the Key Mappings Setup window (see *Global Key Mapping, page 461*). Global Key Mapping is only enabled when IP-300x or IP-3018 is the design target.

#### **Hide Mouse Cursor check box**

Specifies that C-Soft hides the mouse cursor, which is desirable when running C-Soft on a touchscreen.

C-Soft 7.700 Global Key Mapping | en 461

## 45 Global Key Mapping

The Global Key Mapping window is used to map physical hardware buttons of the IP-30XX to buttons in the C-Soft Design.

When opened, the Global Key Mapping window displays a tab representing the Main Console window, as well as dynamically creating tabs for each Popup button that exists in the Design. While a specific Popup is opened, pressing the specified hardware key entry activates the configured button for that specific popup button / tab. If a button mapping is not configured for a specific popup, the button's behavior is defined by the configured button in the Main Console tab.

Each tab contains a list of all available Keys, as defined by settings in the *Device Setup, page 460* page.

Each KeyMap\_ButtonX entry represents the physical hardware buttons on the front of the IP-30XX device, numbered from left to right. For example, the IP-300X's leftmost button is button 1, and the rightmost is button 6.

Each Sidecar\_ButtonX represents physical hardware buttons if using a Sidecar Button Module, numbered top to bottom, left to right. For example, the topmost row are buttons 1-4, the second row are buttons 5-8, and so on.




Figure 45.1: Global Key Mapping window

To configure an IP-30XX hardware key to a button, do the following:

- 1. Configure the Design Target to the **correct hardware** (see *Device Setup, page 460*).
- Select Configure | Global Key Mapping.
   The Global Key Mapping window appears

Bosch Security Systems, LLC Technical Manual 2021-06 | 14 | F.01U.218.561

3. In the Main Console tab, on the row corresponding to the desired button, click the empty **Line** column

Upon selecting the column entry, the dropdown displays a list of available lines, as well as a Global option.

- 4. Select the desired **line** or **Global** if the button is to operate globally.
- In the same row, click the empty column Button Name: Type column.
   Upon selecting the column entry, the dropdown displays a list of buttons on the main console window, filtered by the selected line.
- 6. When finished, press the OK button to close the window.

C-Soft 7.700 Run menu | en 463

#### 46 Run menu

The **Run** menu, shown in the Figure below, is used to either launch the current C-Soft Design or open a .veg file you desire.



Figure 46.1: Run Menu - C-Soft


To open the current C-Soft design in C-Soft Runtime, do the following:

- From the Run menu, select **Run C-Soft**.

The currently open C-Soft Design file is launched in C-Soft Runtime.

To select a C-Soft Runtime executable to run, do the following:

1. From the Run menu, select **Select C-Soft Location**.



- 2. Navigate to and select the C-Soft Runtime executable you want to run.
- 3. Click the Open button.
- 4. From the Run menu, select **Run C-Soft**.

The current C-Soft design file is launched in the specified C-Soft Runtime executable.

## 47 About C-Soft Designer

The **About C-Soft Designer** window is used to view C-Soft version information, Bosch's mailing address and website URL.

NAVIGATION: Select Help | About C-Soft Designer.

## 48 C-Soft Runtime program

Once the design is created and saved, the C-Soft Designer program generates a file read by the **C-Soft Runtime** program. The C-Soft Runtime software does the actual IP communications with the other radio elements available on the network. The C-Soft Console appears when the C-Soft Runtime program is opened.

Upon starting C-Soft Runtime, C-Soft will automatically attempt to acquire all necessary Telex software-based licenses based on the line types and enabled features configured in the Design file. C-Soft checks for licenses on the local computer, as well as any Telex License Servers specified in the License Server settings set in the Design file. Refer to "*Peripherals page, page 131*" for instructions on how to specify a License Server.

#### **Dealer Mode**

**Dealer Mode** is a feature license specifically designed for Telex Radio Dispatch certified dealers to demonstrate C-Soft's capabilities for a limited amount of time. It allows C-Soft to operate as if the following licenses are available:

- 50 lines
- 12 SIP lines
- 24 P25-DFSI lines
- 24 NEXEDGE lines
- 100 lines of per-line call playback
- 24 AIS lines
- 24 P25 CSSI Lines
- P25 Encryption
- API license

Upon startup, if C-Soft Runtime detects a Dealer Mode license, it will display the Dealer Mode License window to indicate that C-Soft is operating in Dealer Mode, and that the license is not for resale. Every 15 minutes, the Dealer Mode License window reappears. After 60 minutes, the license expires, and C-Soft will cease to function and need to be restarted.




Figure 48.1: Dealer Mode License Window

Finally, the Status bar will display Dealer License: Not for Resale whenever it would otherwise be clear.



Figure 48.2: Dealer License Status Bar

#### **Demo Mode**

If no software licenses are detected, C-Soft will display the License Error dialog, blocking access to its user interface. It is still possible to open and test the user interface by entering **Demo Mode**. While in Demo Mode, C-Soft is unable to transmit or receive audio.

#### To run C-Soft Runtime in Demo mode, do the following:

1. Double-click the **C-Soft Runtime desktop shortcut**.



2. Click the **Demo button** to enter Demo Mode.

#### Refer to

- Peripherals page, page 131

#### 48.1 C-Soft Console

The C-**Soft Console** opens to the configuration stored in the default file. If no default file is specified by the user, the Set Default.Veg File window appears.

Alternatively, any .veg file can be double-clicked to open the C-Soft Console. In this case, the Set Default Veg File window does not appear.

#### Set Default Veg File window


The **Set Default Veg File** window is used to locate and set the default .veg file that opens when C-Soft Runtime is opened. This window appears the first time C-Soft Runtime is opened or when the default .veg file is reset to none. For more information, refer to "Reset Default .Veg File" below.

#### To set the default .veg file, do the following:

- Double-click the C-Soft Runtime shortcut installed on your desktop during C-Soft installation.
  - The Set Default .Veg File window appears.
- 2. Browse to the .veg file created in C-Soft Designer.
- Select the .veg file.

#### 4. Click Open.

The default file is set to the selected configuration and C-Soft Runtime opens.



#### **Example Console**

When the C-Soft Runtime program is started, the C-Soft Console displays the console design. A six line console design, along with several other user interface elements, is shown in the Figure below.

The Title Bar contains the C-Soft Console label and is used to access a shortcut menu. For more information, refer to "C-Soft Console Title Bar Shortcut Menu" below.

The status bar, located directly below the title bar, is divided into seven panes providing different status information. From left to right, these panes display: text messages, the IR playback position, the NENA on an ADHB-4, the connected ADHB-4, the PTT status, the VU meter, and the current time, as set on the computer clock.

The recording icon is used to indicate if the console is configured and able to record per line audio to the hard drive. The icon appears in the menu bar if a line is enabled for IRR Line Recording and the audio recording directory is valid. For more information, refer to "IRR Recording page, page 127".




Figure 48.3: C-Soft Console Window

#### C-Soft Console Title Bar shortcut menu

The **C-Soft Console Title Bar** shortcut menu is used to set the window size, find the current C-Soft version, view license information, and set the default .veg file.

#### To open the title bar shortcut menu, do the following:

- Right-click the **Title Bar** to open the shortcut menu.

The menu shown in the Figure below appears.




Figure 48.4: C-Soft Console Title Bar Shortcut menu - Minimize

#### Restore

**Restore** is used to restore the window to the last-set window size.

To shrink the window to the size last set by the console operator, do the following:

1. Right-click the title bar.

The Title Bar shortcut menu appears.

2. Click Restore.

The window is restored.

#### Move

**Move** is used to the move window. This option is not available (grayed out) if the window is maximized.



#### Notice!

The window can also be sized when the move cursor is active.

To **move the window**, do the following:

1. Right-click the title bar.

The Title Bar shortcut menu appears.

2. Click Move.

The Move cursor appears.

- 3. Click and hold the title bar.
- 4. Drag the **window** into place.

# Size

**Size** is used to change the height and/or width of the window. This option is not available (grayed out) if the window is maximized.



# Notice!

The window can also be moved when the size cursor is active.

To size the window, do the following:

1. Right-click the **title bar**.

The Title Bar shortcut menu appears.

2. Click Size.

The Size cursor appears.

3. Click and hold the cursor on the edge of the window.

The cursor changes.

4. Drag the **window** to the desired size.

#### **Minimize**

Minimize is used to shrink the window to a minimized icon on the task bar.



#### Notice!

If the current view is already minimized, this selection is grayed out.

# Maximize

Maximize is used to change the window to full screen view.



#### Notice!

If the current view is already maximized, this selection is grayed out.

#### Close

Close is used to close the C-Soft Runtime program.

#### **About C-Soft Runtime**

About C-Soft Runtime is used to open the about C- Soft Runtime window.

This window contains the following information:

- Version
- Telex's address
- Sales Support Phone Number
- Website Address

#### **License Information**

The License Information window displays all Telex License Keys detected by C-Soft.

Each row in the License List represents a detected software license. The Source column displays the license's source, and Option column contains the detected license. Licenses that have been successfully checked out and are currently in use by the instance of C-Soft are displayed in blue.

# Reset Default .Veg File

Reset Default .Veg File is used to change the default file to none. When reset, and C-Soft Runtime is opened, the Set Default Veg File window appears.

To reset the default file to none, do the following:

- Right-click the title bar.
  - The Title Bar shortcut menu appears.
- 2. Select Reset Default Veg File.

The default file is set to none.



#### Set Default .Veg File

Set **Default .Veg File** is used to set the current configuration as the default file. When a .veg file is double-clicked C-Soft Runtime opens to the selected configuration. This configuration can be set as the default file.

To set the current C-Soft Console configuration as the default .veg file, do the following:

- Right-click the **title bar**.
   The Title Bar shortcut menu appears.
- 2. Select Set Default Veg File.



# **Window Sizing**

By default, the C-Soft Runtime program window fills the entire monitor window. However, this may not be acceptable for a single monitor system, when only a small monitor is available, or if the console operator views the software on a multi-monitor computer. In these cases, the size of the console window can be changed to match the size of the console operator's monitor window.

When the C-Soft Runtime program starts it looks for the file cposi[.veg file name].txt. This file is created each time the C-Soft Runtime program is closed. The cposi[.veg file name].txt (for example, cposi\_Default.txt) file records the size and position of the C-Soft Runtime program window. In addition to storing the position information, the cposi[.veg file name].txt file also stores the console state at shutdown. This includes information such as the selected channels, mute states, volumes, channel frequencies, and the entries in the call log (without the IRR audio). Since the cposi.txt file does not exist the first time the C-Soft Runtime program is started, the C-Soft Runtime window fills the entire screen.



#### Notical

If one console design is closed and a different console design is started, the states do not match.

To change the size of the program window, do the following:

- 1. Ensure the following **fields are selected**, refer to "Window Controls Check Boxes" on page 121 for details.
  - Allow Minimize
  - Allow Maximize
  - Allow Resize
  - Allow Close

For more information, refer to "Save Runtime Status on Close Check Box" on page 120.

**TIP**: If this is an existing design, verify these controls are enabled for the design. If they are not, select the Windows controls listed above, and then proceed to the next step.

- 2. Save the designer file (.veg).
- 3. Open the .veg file you just saved.
- 4. Resize and position the **console window**, as desired.

The elements on the window do not rescale to fit the window size and some may be hidden from view when the window is resized. This step is only to create the size and position of the window. The next time the console window is opened, all of the elements on the console window are automatically scaled to fit the console window by the C-Soft Runtime program.

- 5. Close the **C-Soft Runtime program** when the console window is set to the desired size and position.
  - The cposi.[veg file name].txt file is created by the program is when it is closed
- 6. Open the .veg file.
  - The window opens using the last location and size with the buttons, sliders, VU Meter, and clock in the correct locations.
- 7. If the console display needs further adjustment, repeat the **above steps** until the console window is the desired size.

#### Refer to

- IRR Recording page, page 127

# 49 Appendix A - Telex Tone Group Numbers and Paging Plans

# 49.1 Telex Tone Group Numbers

Telex Group No.	1	2	3	4	5	6	7
Tone Group	Mot 1	Mot 2	Mot 3	Mot 4	Mot 5	Mot 6	Mot A
0	330.5	569.31	1092.4	321.7	553.9	1122.5	358.9
1	349.0	600.9	288.5	339.6	584.8	1153.4	398.1
2	368.5	634.5	296.5	358.6	617.4	1185.2	441.6
3	389.0	669.9	304.7	378.6	651.9	1217.8	489.8
4	410.8	707.3	313.0	399.8	688.3	1251.4	543.3
5	433.7	746.8	953.7	422.1	726.8	1285.8	602.6
6	457.9	788.5	979.9	445.7	767.4	1321.2	668.3
7	483.5	832.5	1006.9	470.5	810.2	1357.6	741.3
8	510.5	879.0	1034.7	496.8	855.5	1395.0	822.2
9	539.0	928.1	1063.2	524.6	903.2	1433.4	912.0
Diagonal	569.1	979.9	569.1	569.1	979.9	979.9	979.9

Tab. 49.9: Telex Tone Group Numbers (1-7)

Telex Group No.	8	9	10	11	12	13	14	15
Tone Group	Mot B	Mot Z	GE A'	GE B'	GE C'	Mot 10	Mot 11	Custom
0	371.5	346.7	682.5	652.5	667.5	1472.9	1930.2	1034.9
1	412.1	384.6	592.5	607.5	712.5	1513.5	1989.0	953.9
2	457.1	426.6	757.5	787.5	772.5	1555.2	2043.8	0
3	507.0	473.2	802.5	832.5	817.5	1598.0	2094.5	0
4	562.3	524.8	847.5	877.5	862.5	1642.0	2155.6	0
5	623.7	582.1	892.5	922.5	907.5	1687.2	2212.2	0
6	691.8	645.7	937.5	967.5	952.5	1733.7	2271.7	0
7	767.4	716.1	547.5	517.5	532.5	1781.5	2334.6	0
8	851.1	794.3	727.5	562.5	577.5	1830.5	2401.0	0
9	944.1	881.0	637.5	697.5	622.5	1881.0	2468.2	0

Diagonal   979.9   979.9   742.5   742.5   742.5   None   None	Diagonal	979.9	979.9	742.5	742.5	742.5	None	None	None
---	----------	-------	-------	-------	-------	-------	------	------	------

Tab. 49.10: Telex Tone Group Numbers (8-15)

# 49.2 Tone and Gap Durations for Standard Paging Plans

Tone #1 (ms)	Gap (ms)	Tone #2 (ms)	Group Call (ms)	Туре
1000	-	3000	8000	GE std, Mot std Tone and Voice
400	0	800	8000	Mot Tone Only
1000	0	3000	6000	NEC-B
1000	300	3000	6000	NEC-A
1000	0	1000	4000	NEC-C
400	0	800	4000	NEC-M
500	0	500	3000	NEC-L
400	0	400	3000	NEC-D

Tab. 49.11: Tone and Gap Durations for Standard Paging Plans

# **Appendix B - 2 Tone 1000 Plan Numbers**

Telex Code Plan #	1	2	3	4	5	6	7	8	9
Pager Capcodes	Mot A	Mot C	Mot D	Mot E	Mot F	Mot G	Mot H	Mot J	Mot K
0xx	2+4	N/A							
1xx	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1
2xx	2+2	2+2	2+2	2+2	1+3	1+3	1+3	1+4	1+4
Зхх	3+3	1+2	1+2	1+2	3+3	3+3	3+3	4+1	4+1
4xx	1+2	4+4	1+5	2+1	4+4	3+1	3+1	4+4	4+4
5xx	1+3	1+4	5+5	1+6	3+1	5+5	1+6	5+5	1+6
6xx	2+1	2+1	2+1	6+6	1+4	1+5	6+6	1+5	6+6
7xx	3+1	4+1	5+1	6+1	4+1	5+1	6+1	4+5	6+1
8xx	2+3	2+4	2+5	2+6	3+4	3+5	3+6	5+4	4+6
9xx	3+2	4+2	5+2	6+2	4+3	5+3	6+3	5+1	6+4

Tab. 50.12: 2 Tone 1000 Plan Numbers (1-9)

Telex Code Plan #	10	11	12	13	14	15	16	17
Pager Capcodes	Mot L	Mot M	Mot N	Mot P	Mot Q	Mot R	Mot S	Mot T
0xx	N/A	4+2	4+2	4+2	4+2	4+2	4+2	4+2
1xx	1+1	2+3	2+3	2+3	2+4	2+4	2+5	3+4
2xx	1+5	2+2	2+2	2+2	2+2	2+2	2+2	4+3
Зхх	5+1	3+3	3+3	3+3	4+2	4+2	5+2	3+3
4xx	1+6	4+4	3+2	3+2	4+4	4+4	2+6	4+4
5xx	5+5	3+2	5+5	2+6	5+5	2+6	5+5	5+5
6xx	6+6	2+4	2+5	6+6	2+5	6+6	6+6	3+5
7xx	6+1	4+2	5+2	6+2	4+5	6+2	6+2	4+5
8xx	5+6	3+4	3+5	3+6	5+4	4+6	5+6	5+4
9xx	6+5	4+3	5+3	6+3	5+2	6+4	6+5	5+3

Tab. 50.13: 2 Tone 1000 Plan Numbers (10-17)


Telex Code Plan #	18	19	20	21	22	23	24	25
Pager Capcodes	Mot U	Mot V	Mot W	Mot Y	Mot MT	GE X	GE Y	GE Z
0xx	4+2	4+2	4+2	N/A	4+2	10+10	11+11	10+10
1xx	3+4	3+5	4+6	7+7	1+1	11+10	12+11	12+10
2xx	4+3	5+3	6+4	8+8	2+2	11+11	12+12	12+12
Зхх	3+3	3+3	5+6	9+9	1+2	10+11	11+12	10+12
4xx	4+4	3+6	4+4	7+8	4+4	12+12	N/A	N/A
5xx	3+6	5+5	5+5	7+9	5+5	12+10	N/A	N/A
6xx	6+6	6+6	6+6	8+7	2+1	12+11	N/A	N/A
7xx	6+3	6+3	4+5	9+7	4+5	10+12	N/A	N/A
8xx	4+6	5+6	5+4	8+9	5+4	11+12	N/A	N/A
9xx	6+4	6+5	6+5	9+8	2+4	N/A	N/A	N/A

Tab. 50.14: 2 Tone 1000 Plan Numbers (18-25)

# 51 Appendix C - Supported Tone Frequencies

Tone	Со				E	uropea	n Tone l	Freque	ncies i	n Hz				Mot	orola
Numb er	de Dig it	ZVEI1	ZVEI 2	KEN	PZV E I	DZV EI	PDZV EI	CCIR 1	CCIR 2	PCCI R	EEA	EURO SIGNAL	NATE L	EIA	MOD AT
TONE 0	0	2400	2400	815	2400	2200	2200	1981	1981	1981	1981	979.8	1633	600	637.5
TONE 1	1	1060	1060	882	1060	970	970	1124	1124	1124	1124	903.1	631	741	787.5
TONE 2	2	1160	1160	954	1160	1060	1060	1197	1197	1197	1197	832.5	697	882	937.5
TONE 3	3	1270	1270	1032	1270	1160	1160	1275	1275	1275	1275	767.4	770	1023	1087. 5
TONE 4	4	1400	1400	1117	1400	1270	1270	1358	1358	1358	1358	707.4	852	1164	1237. 5
TONE 5	5	1530	1530	1209	1530	1400	1400	1446	1446	1446	1446	652.0	941	1305	1387. 5
TONE 6	6	1670	1670	1308	1670	1530	1530	1540	1540	1540	1540	601.0	1040	1446	1537. 5
TONE 7	7	1830	1830	1415	1830	1670	1670	1640	1640	1640	1640	554.0	1209	1587	1687. 5
TONE 8	8	2000	2000	1531	2000	1830	1830	1747	1747	1747	1747	510.7	1336	1728	1837. 5
TONE 9	9	2200	2200	1657	2200	2000	2000	1860	1860	1860	1860	470.8	1477	1869	1987. 5
GROU P TONE	А	2800	885	1939	970	825/ 885	825	2400		1050	1055			2151	
	В	810	810	2270	810	740	886	930		930	930			2292	
RESE T TONE	С	970	970	2098	2800	2600	2600	2247		2400	2247			2010	
	D	885	680	2457	885	885	856	991	2110	991	991			2292	
REPE AT TONE	Е	2600	970	1792	2600	2400	2400	2110	2400	2110	2110	1062.9	1805	459	487.5
	F	680	2600		680	680		1055	2400	1995	1091		1995	1091	

# 52 Appendix D - Echo Packets Diagram



2021-06 | 14 | F.01U.218.561

# 53 Appendix E - P25-DFSI (Digital Fixed Station Interface) 53.1 P25-DFSI C-Soft Architecture

A C-Soft console can be configured for two different types of system architectures; a Stand Alone console, or a Client/Server console.

A **Stand Alone console** is defined as a single console connection to n (where n is the number of repeaters or Fixed Stations).

A **Client/Server console** is defined as multiple consoles connected to a server console which is connected to n (where n is the number of repeaters or Fixed Stations).



#### Notice!

The maximum total number of consoles connected to one P25 DFSI is 25.

A Stand Alone Console is a simple configuration, requiring the least amount of setup time. Refer to the Figure below.




Figure 53.1: Stand Alone Console Configuration

If more than one console operator is controlling the fixed stations, a Client/Server configuration should be used. Refer to the Figure below. One console is set up as a server, two consoles are set up as clients and one console is set up as a client console providing back up to the main server console.




Figure 53.2: Server/Client Console Configuration



#### Notice!

There is no special software needed between consoles. Any C-Soft console can be configured as a Stand Alone, Server, Client or Backup console via user setting in C-Soft designer.

# 53.2 P25 DFSI Global Setup window

The **P25 DFSI Global Setup** window, shown in the Figure below, is used to determine what type of console is required for the system.

For example, if you require a stand alone system, then you have only one console, and an equal number of lines to base stations in your system. Only one .veg file needs to be created with the global console type set to stand alone.

If you require a client/server system, you must create one. veg file with a global console type set to server and a second .veg file with the console type set to client or client and backup server console.



#### Notice!

Each Client console has a unique Console ID, therefore, it is required to have a different veg file for each console position in the system.



#### Notice!

The parameters on this page affect all line types set to P25-DFSI.

A Console ID must first be added. Refer to the Figure below. This ID is used by the individual radios to make Private Calls with the console. This ID shows up as the radio ID when implementing a PTT from the console.




Figure 53.3: P25 DFSI Global Setup Window

To set up P25 DFSI Global Values, do the following:

From the Edit menu, select **Setup P25-DFSI**.
 P25 DFSI Global Setup window appears.

# 53.2.1 Console Type group box

The **Console Type** group box is used to make a selection between Stand Alone Console, Server Console, Client Console and Client and Backup Server Console.

#### Stand Alone radio button

The **Stand Alone** radio button indicates one console is used.

#### Server Console radio button

The **Server Console** radio button indicates multiple consoles are used.



#### Notice!

Only one server per system.

#### Client Console radio button

The **Client Console** radio button indicates the C-Soft Console is connected with a Server Console.

# Client & Backup Server Console radio button

The **Client & Backup Server Console** radio button indicates a Server is already setup and a backup Server is needed, in case the server computer goes down.



#### Notice!

Only one Backup Server per system.

# Console ID field

The **Console ID** field is used to enter the ID of the console. This ID is used by the individual radios to make Private Calls with the console, and appears as the radio ID when implementing a PTT from the console.

# 53.2.2 Backup Server Ping Address group box

The **Backup Server Ping Address** group box is used for communication between all C-Soft Consoles to determine if the Server is operational or if the Server is down.

#### IP field

The **IP** field is a multicast address. It is used for communication between all the C-Soft Consoles to determine if the primary server is operational or is down. IP field number is the same among all of the consoles in the system.

#### **Port Field**

The **Port** field is a multicast port. It used for communication between all the C-Soft Consoles to determine if the primary server is operational or is down. The Port field number is the same among all of the consoles in the system.

# 53.2.3 Heartbeats group box

The **Heartbeats** group box is used to configure a Fixed Station Heartbeat Time, a Host Heartbeat Time, and the Number of Missed Heartbeats Allowed.

#### **Fixed Station Heartbeat Time field**

The **Fixed Station Heartbeat Time** field indicates the time, in seconds, the fixed station sends heartbeats to the C-Soft Console. This field is only enabled if the console type is set to Server Console or Client & Backup Server Console mode.

The range for this field is 5 to 255.

The default is 30.

#### **Host Heartbeat Time field**

The **Host Heartbeat Time** field indicates the time, in seconds, the C-Soft Console sends heartbeats to the fixed station. This field is only enabled if the console type is set to Server Console or Client & Backup Server Console mode.

The range for this field is 5 to 255.

The default is 30.

#### Number of Missed Heartbeats Allowed field

The **Number of Missed Heartbeats Allowed** field indicates the number of missed heartbeats from the Fixed Station before C-Soft terminates communication with the fixed station and tries to connect again.

The range for this field is 0 to 5.

The default is 2.

# 53.2.4 Radio/Repeater Control Signals group box

The **Radio/Repeater Control Signals** group box is used to configure the number of control retries and the wait time between retries from the server to establish contact with the radio.

#### **Number of Control Retries field**

The **Number of Control Retries** field indicates the number of times a control command is sent if no acknowledgment is received.

The range for this field is 0 to 5.

The default is 3.

#### **Control Retry Time**

The **Control Retry Time** field indicates the time, in ms, C-Soft waits before sending the same control command.

The range for this field is 500 to 1000.

The default is 600.

# 53.2.5 Packet Controls group box

The Packet Controls group box is used to set the packet delay for the C-Soft Console.

# **Control Packet Delay field**

The **Control Packet Delay** field is used to enter a value that is multiplied by 20ms to set the delay between P25 DFSI Control Packets sent from C-Soft. This field is only enabled if the console type is set to Server Console or Client & Backup Server Console mode.

The range for this field is 0 to 99.

The default is 0.

# Setting up a P25-DFSI Line

To set up a P25-DFSI Line, do the following:

- From the Edit Window, select Setup Per Line Parameters.
   The Per Line Parameters window appears.
- 2. From the Line Type drop down menu, select **P25-DFSI**.
- 3. Click the Signal Setup button.

The P25-DFSI Setup window appears.



Figure 53.4: P25-DFSI Line Type



# Notice!

Below are four examples of how a console can be configured, depending the Console Type selected in P25 DFSI Global Setup window (i.e. Stand Alone, Server or Client). Refer to the Figure on *P25 DFSI Global Setup window, page 480*.

#### Refer to

- P25 DFSI Global Setup window, page 480

# 53.3 Console Type Setup

The **Console Type Setup** is used to configure the console depending on the Console Type selected in P25 DFSI Global Setup window.

# 53.3.1 Stand Alone Console

#### **Stand Alone Console type**

The **Stand Alone Console** is the easiest console type to set up and should be the starting point for building a Client/Server system.

The three parameters to be set up are:

- The Per Line IP connections which consist of the control Unicast Address of FS and the Voice Address of the FS
- The channel numbers to a single base station
- P25 Manufacturer



#### Notice!

The Control Port of FS must match the DFSI control port of the Base Station. The Voice Port of FS can be the same as, or different than the DFSI Voice Port of the base station.

The Signaling Parameters window, shown in the Figure below, is used to set up the per line IP connections and channel numbers to a single base station.




Figure 53.5: P25-DFSI Setup-Stand Alone Console

# **Fixed Station (FS) Connections group box**

The **Fixed Station (FS) Connections** group box contains the Control Address of Fixed Station group box and the Voice Address of Fixed Station group box.

# **Control Address of Fixed Station group box**

#### **Control Unicast Address of FS field**

The **Control Unicast Address of FS** field is used to enter an IP Address of the P25 base station.

# **Control Port of FS field**

The **Control Port of FS** field is used to enter the port number of the P25 base station.

The range for this field is 1054 to 65536.



#### Notice!

The Control Port of FS field must match the DFSI Control Port of the P25 base station.

# **Voice Address of Fixed Station group box**

#### Voice IP Address of FS field

The Voice IP Address of FS field is used to enter the voice IP address of the P25 base station.

#### Voice Port of FS field

The **Voice Port of FS** field is used to enter the unique port number of the P25 base station.

The range for this field is 1054 to 65536.

## **Backup Enabled check box**

The **Backup Enabled** check box enables the backup FS setup button. It is used when the system needs to have a secondary P25 base station for backup in the event the primary base station is down.


# 53.4 Backup FS Setup window

The **Backup FS Setup** button opens the Backup Fixed Station Setup window.

To open the Backup Fixed Station Setup window, do the following:

- 1. Select the **Backup Enabled** check box.
- Click Backup FS Setup.

The Backup Fixed Station Setup window appears.



3. Configure your backup station.

NOTE: If connection is lost to a Fixed Station, C-Soft automatically switches to the Backup Fixed Station if Backup Enabled is selected.

4. Restart **C-Soft** to return to the original Fixed Station.

#### **Control Address of Fixed Station group box**

#### **Control Unicast Address of FS field**

The **Control Unicast Address of FS** field is used to enter an IP Address of the P25 base station.

#### **Control Port of FS field**

The Control Port of FS field is used to enter the port number of the P25 base station.

The range for this field is 1054 to 65536.



#### Notice!

The Control Port of FS field must match the DFSI Control Port of the P25 base station.

# **Voice Address of Fixed Station group box**

## Voice IP Address of FS field

The Voice IP Address of FS field is used to enter the IP Address of the P25 base station.

#### Voice Port of FS field

The Voice Port of FS field is used to enter the unique port number of the P25 base station.

The range for this field is 1054 to 65536.

# P25 Manufacture drop down menu

The **P25 Manufacture** drop down menu is used to select the manufacturer of the repeater.

Available selections for this field are:

- Daniels
- Tait



# Notice!

Since there may be small differences between radio designs, this field is important to insure C-Soft works correctly with the repeater.

#### **Channel Setup button**

The **Channel Setup** button is used to open the DFSI Channel Table window. For more information, refer to "*Channel Table window, page 497*".

# **Edit Global DFSI Parameters button**

The **Edit Global DFSI Parameters** button is used to open the P25 DFSI Global Setup window, shown in Figure on *P25 DFSI Global Setup window*, page 480.

# 53.5 Server Console

The Signaling Parameters window, shown in the Figure below, is used to set up the **Server Console** Configuration. The FS (Fixed Station) Connection portion of the window is the same as that for a Stand Alone Console. As in the case of the "Stand Alone Console", one line of the Server Console connects to one base station. The difference between the Stand Alone and Server is the client(s) now connects and talks to the server on a per line basis in order to control and communicate with the base station connected to this line.




Figure 53.6: P25-DFSI- Server Console

To change settings to a Server Console, do the following:

- 1. From the menu bar, select **Edit | Setup P25 | DFSI**. The P25 DFSI Global Setup window appears.
- In the Console Type group box, click the Server Console radio button. Server Console is the console for the system.
- 3. From the menu bar, select **Edit | Setup Per Line Parameters**. The Per Line Parameters window appears.
- 4. With P25-DFSI selected in the Line Type drop down menu, click **Signal Setup**.

The P25-DFSI Setup - Console configuration: Server Console window appears.

# Fixed Station (FS) Connections group box

The **Fixed Station (FS) Connections** group box contains the Control Address of Fixed Station group box and the Voice Address of Fixed Station group box.

#### **Control Address of Fixed Station group box**

#### **Control Unicast Address of FS field**

The **Control Unicast Address of FS** field is used to enter an IP Address of the P25 base station.

#### **Control Port of FS field**

The Control Port of FS field is used to enter the port number of the P25 base station.

The range for this field is 1054 to 65536.



#### Notice!

The Control Port of FS field must match the DFSI Control Port of the P25 base station.

# Voice Address of Fixed Station group box

## Voice IP Address of FS field

The Voice IP Address of FS field is used to enter the IP Address of the P25 base station.

#### Voice Port of FS field

The **Voice Port of FS** field is used to enter the voice port number of the P25 base station. The Voice Port of FS field must match the voice port number configured in Daniels P25 base station and unique for Tait P25 base station.

The range for this field is 1054 to 65536.

#### **Backup Enabled check box**

The **Backup Enabled** check box enables the backup FS setup button. It is used when the system needs to have a secondary P25 base station for backup in the event the primary base station is down.

# 53.6 Backup FS Setup window


The Backup FS Setup button opens the Backup Fixed Station Setup window.

To open the Backup Fixed Station Setup window, do the following:

1. Select the **Backup Enabled** check box.

# 2. Click Backup FS Setup.

The Backup Fixed Station Setup window appears.



# 3. Configure your backup station.

NOTE: If connection is lost to a Fixed Station, C-Soft automatically switches to the Backup Fixed Station if Backup Enabled is selected.

4. Restart **C-Soft** to return to the original Fixed Station.

# **Control Address of Fixed Station group box**

#### **Control Unicast Address of FS field**

The **Control Unicast Address of FS** field is used to enter an IP Address of the P25 base station.

#### **Control Port of FS field**

The Control Port of FS field is used to enter the port number of the P25 base station.

The range for this field is 1054 to 65536.



# Notice!

The Control Port of FS field must match the DFSI Control Port of the P25 base station.

# **Voice Address of Fixed Station group box**

#### Voice IP Address of FS field

The Voice IP Address of FS field is used to enter the IP Address of the P25 base station.

# Voice Port of FS field

The **Voice Port of FS** field is used to enter the voice port number of the P25 base station.

The range for this field is 1054 to 65536.



#### Notice!

The Voice Port of FS field must match the voice port number configured in Daniels P25 base station and unique for Tait P25 base station.

# **Server Connections group box**

#### **IP Address of this Computer field**

The **IP Address of this Computer** field cannot be modified. When a client is configured, it must connect to the IP Address of the PC the server console resides on.

#### **Server Control Port field**

The **Server Control Port** field is used to enter the port number the client connects to the server and to control the base station/radio functionality.

The range for this field is 1054 to 65536.

# Server's Voice Address group box

The **Server's Voice Address** group box is used to configure the (MCA) Multicast Address and ports the server uses to communicate with the client and client consoles.

#### Rx MCA field

The Rx MCA field is used to enter the receive Multicast Address used to receive P25 audio.

#### Port field

The **Port** field is used to enter the port number used to receive P25 audio.

The range for this field is 1054 to 65536.

#### Tx MCA field

The Tx MCA field is used to enter the transmit Multicast Address used to transmit P25 audio.

#### Port field

The **Port** field is used to enter the port number used to transmit P25 audio.

The range for this field is 1054 to 65536.

# P25 Manufacture drop down menu

The **P25 Manufacture** drop down menu is used to select the manufacturer of the repeater.

Available selections for this field are:

- Codan
- Tait



# Notice!

Since there may be small differences between radio designs, this field is important to insure C-Soft works correctly with the repeater.

#### **Channel Setup button**

The **Channel Setup** button is used to open the DFSI Channel Table window. For more information, refer to "*Channel Table window, page 497*".

The Channel Table window displays all of the channels open for a selected line.

#### **Edit Global DFSI Parameters button**

The **Edit Global DFSI Parameters** button is used to open the P25 DFSI Global Setup window. For more information, refer to "*P25 DFSI Global Setup window, page 480*".

The P25 DFSI Global Setup window is used to select the type of console required for the system.

# 53.7 Client Console

The Signaling Parameters window, shown in the Figure below, is used to set up the **Client Console** Configuration. Each client requires a different .veg file because of the console ID.



# Notice!

The server console must have the number of lines equal to the number of base stations; clients cannot directly access the base station without going through the server.




Figure 53.7: P25-DFSI Client Console

To change settings to a Server Console, do the following:

- 1. From the menu bar, select **Edit | Setup P25 | DFSI**.
  - The P25 DFSI Global Setup window appears.
- 2. Select the **Client Console** radio button to make the console type a Client Console.
- 3. From the menu bar, select **Edit | Setup Per Line Parameters**. The Per Line Parameters window appears.
- 4. From the Line Type drop down menu, select **P25-DFSI**.
- 5. With P25-DFSI selected in the Line Type drop down menu, click **Signal Setup**.

The P25-DFSI Setup - Console configuration Client Console window appears.

#### **Client Connections**

The Client Connections group box is used to configure per-line signaling setup address fields.

### **Control Address of Server group box**

#### **Control Unicast Address of Server field**

The Control Unicast Address of Server field is used to enter the IP Address of the server PC.

#### **Control Port of Server field**

The **Control Port of Server** field is used to enter the port address of the server control port for this line.



#### Notice!

The Port Address must match the value setting of the Server Control Port on the Server Console setup.

#### **Voice Address of Server group box**

#### Rx MCA field

The Rx MCA field is used to enter the receive Multicast Address used to receive P25 audio.

# Tx MCA field

The Tx MCA field is used to enter the transmit Multicast Address used to transmit P25 audio.

#### P25 Manufacture drop down menu

The **P25 Manufacture** drop down menu is used to select the manufacturer of the repeater.

Available selections for this field are:

- Daniels
- Tait



# Notice!

Since there may be small differences between radio designs, this field is important to insure C-Soft works correctly with the repeater.

# **Channel Setup button**

The **Channel Setup** button is used to open the DFSI Channel Table window. For more information, refer to "*Channel Table window, page 497*".

The Channel Table window displays all of the channels open for a selected line.

#### **Edit Global DFSI Parameters button**

The **Edit Global DFSI Parameters** button is used to open the P25 DFSI Global Setup window. For more information, refer to "*P25 DFSI Global Setup window, page 480*".

The P25 DFSI Global Setup window is used to select the type of console required for the system.

# 53.8 Client Console with Server Backup

The Signaling Parameters window, shown in the Figure below, is used to set up the Server Console Configuration. The backup client console or .veg file must have the same number of lines the server console or .veg file does.

The top half of the page, shown in the Figure below, is exactly the same as the setting for a Stand Alone Console or for a Server Console. The bottom half of the page is exactly the same as the setting for a client console.




Figure 53.8: P25-DFSI Client Console with Server Backup

To change settings to a Server Console, do the following:

1. From the menu bar, select **Edit | Setup P25 | DFSI**. The P25 DFSI Global Setup window appears.

- 2. Click the **Client & Backup Server Console** radio button to make the console type Client and Backup Server.
  - Client & Backup Server Console is now the console for the system.
- 3. From the menu bar, select **Edit | Setup Per Line Parameters**. The Per Line Parameters window appears.
- 4. From the Line Type drop down menu, select **P25-DFSI**.

# Fixed Station (FS) Connections (For Backup Server) group box

The **Fixed Station (FS) Connections (For Backup Server)** group box is used to connect with the backup FSI if the Server Console fails to receive heartbeats from the Primary FSI.

# Address of Fixed Station (For Backup Server) group box

#### **Control Unicast Address of FS field**

The **Control Unicast Address of FS** field is used to enter an IP Address of the P25 base station.

#### Control Port of FS field

The Control Port of FS field is used to enter the port number of the P25 base station.

The range for this field is 1054 to 65536.



#### Notice!

The Control Port of FS field must match the DFSI Control Port of the P25 base station.

# Voice Address of Fixed Station (For Backup Server) group box

## **Voice IP Address of FS field**

The **Voice IP Address of FS** field is used to enter the voice IP address of the P25 base station.

#### **Voice Port of FS field**

The **Voice Port of FS** field is used to enter the voice port number of the P25 base station. The Voice Port of FS field must match the voice port number configured in Daniels P25 base station and unique for Tait P25 base station.

The range for this field is 1054 to 65536.

#### **Backup Enabled check box**

The **Backup Enabled** check box enables the backup FS setup button.

# 53.9 Backup FS Setup window


The Backup FS Setup button opens the Backup Fixed Station Setup window.

# To open the Backup Fixed Station Setup window, do the following:

1. Select the **Backup Enabled** check box.

# 2. Click Backup FS Setup.

The Backup Fixed Station Setup window appears.



# 3. Configure your backup station.

NOTE: If connection is lost to a Fixed Station, C-Soft automatically switches to the Backup Fixed Station if Backup Enabled is selected.

4. Restart **C-Soft** to return to the original Fixed Station.

# 53.9.1 Client Connections group box

The Client Connections group box is used to configure per-line signaling setup address fields.

# 53.9.2 Control Address of Server group box

# **Control Unicast Address of Server field**

The Control Unicast Address of Server field is used to enter the IP Address of the server PC.

# **Control Port of Server field**

The **Control Port of Server** field is used to enter the port address of the server control port for this line.



## Notice!

The Port Address must match the value setting of the Server Control Port on the Server Console setup.

# 53.9.3 Voice Address of Server group box

# **Rx MCA field**

The **Rx MCA** field displays the RX Multicast Address and Port that the server and clients use to receive P25 voice (a different value for each line). The MCA and ports must match the MCA and ports you entered in the server console.

# Tx MCA field

The **Tx MCA** field displays the TX Multicast Address and Port that the server and clients use to transmit P25 voice (a different value for each line). The MCA and ports must match the MCA and ports you entered in the server console.

# P25 Manufacture drop down menu

The **P25 Manufacture** drop down menu is used to select the manufacturer of the repeater.

Available selections for this field are:

- Daniels
- Tait



#### Notice!

Since there may be small differences between radio designs, this field is important to insure C-Soft works correctly with the repeater.

# **Channel Setup button**

The **Channel Setup** button is used to open the DFSI Channel Table window. For more information, refer to "*Channel Table window, page 497*".

The Channel Table window displays all of the channels open for a selected line.

#### Refer to

- Server Console, page 488

# 53.10 Channel Table window

The Channel Table window, shown in the Figure below, is used to view channel information.

To open the Channel Table window, do the following:

In the Per Line Parameters window with P25 DFSI line type selected, click the Freqs button.

The Channel Table appears.




Figure 53.9: DFSI Channel Table

#### **Channel Number column**

The **Channel Number** column displays the physical channel number assigned to the radio.



# Notice!

The Channel Number must match the Channel Number set up in the Fixed Station.

#### **Channel Label column**

The **Channel Label** column displays the name of the channel.

# RX-NAC (Hex) column

The **RX-NAC (Hex)** column displays the receive NAC (Network Access Code). This code must match the incoming NAC from a radio so the audio can be heard on C-Soft.



# Notice!

The RX-NAC must match the RX-NAC set up in the Fixed Station.

#### TX-NAC (Hex) column

The TX-NAC (Hex) column displays the TX-NAC (Transmit Network Access Code).



#### Notice!

The TX-NAC must match the TX-NAC, set up in the Fixed Station.

# TGID NAC (Hex) column

The **TGID** (**Talk Group ID**) (**Hex**) column displays the Talk Group ID for the channel and is an additional filter, used in both TX and RX directions.

# Analog/Digital column

The **Analog/Digital** column displays the type of voice encoding/decoding by the console for the selected channel. (A setting of P25 Digital causes the channel to transmit and receive in P25 digital audio).

Analog uses G711 encoding/decoding for both transmit and receive. Mixed mode receives in either analog or digital and transmit audio is selectable (analog or digital) via a user defined button.

Available options are:

- P25 Digital The channel transmits and receives in P25 digital audio
- Analog The channel transmits and receives using G711 encoding/decoding.
- Mixed Mode Receives audio in either analog or digital. Transmit audio is selectable (analog or digital) through the use of a user-defined button.

#### **RX Block Lines panel**

The **RX Block Lines** panel is used to select lines that have their receive audio blocked when having their configurations modified. This allows the console operator to transmit on a radio that has overlapping coverage with other radios, without getting feedback from the radios receiving the transmitted signal. This function also operates when a parallel console is transmitting on the line.

#### To **mute a line during transmission**, do the following:

- From the RX Block Lines panel, select the **lines** you want to block.
   The line is highlighted.
- 2. Click the **line**(s) a second time to clear the selection.

The line is no longer highlighted.

#### Load File button

The **Load File** button is used to load a saved Channel Table from a saved .csv (comma separated values) file.

#### Save File button

The Save File button is used to save the Channel Table to a .csv file.

#### **Add Channel button**

The Add Channel button is used to manually configure another line.

#### **Delete Channel button**

The **Delete Channel** button is used to delete a channel from the channel table.

To delete a channel, do the following:

- 1. From the Channel Table, highlight the **channel row** to be deleted.
- 2. Click the **Delete Channel** button.

The channel is deleted.

#### **Edit Global DFSI Parameters button**

The **Edit Global DFSI Parameters** button is used to open the P25 DFSI Global Setup window. For more information, refer to "*P25 DFSI Global Setup window, page 480*".

The P25 DFSI Global Setup window is where the type of console required for the system is selected.

#### Refer to

- P25 DFSI Global Setup window, page 480

# 53.11 Setting Up Additional P25-DFSI lines

When adding multiple lines, the procedure is repeated from above.



#### Notice!

When setting up multiple lines, each line must have unique Unicast Addresses, Ports, and Multicast Addresses. The only address that is constant among the lines is the IP Address of the Server P.C.

# Adding Buttons to the Design

Once you have created the lines to be used for the P25 system, buttons need to be created on the console. You can assign buttons to either individual lines or you can use the preconfigured P25-DFSI Window button.

The P25-DFSI Window button contains all P25 radio/base station functionality in a single popup window.



#### Notice!

Each DFSI line requires one P25\_DFSI button; however, only one window is shown, depending on the line/button selected.




Figure 53.10: DFSI Design Options

For a P25 DFSI button without a Select Button, an "S" appears on the button for selected. A "U" appears on the button if unselected.



Figure 53.11: P25 DFSI - Select and Unselect

# P25-DFSI Misc Page setup

The P25-DFSI Misc window is used to change the colors of the buttons.




Figure 53.12: P25-DFSI Misc

# To add a P25-DFSI button to the console, do the following:

- From the Insert menu, select Add UI Button.
   A None button appears on the console window.
- 2. Right-click the **None** button.
  - A shortcut menu appears.
- 3. From the shortcut menu, select **Properties**. The UI Element Setup window appears.
- 4. From the UI Element drop down menu, select **P25-DFSI Window**.
- 5. Click the P25-DFSI Misc tab.

The P25-DFSI Misc Page appears.

#### Misc group box

# Enable P25-DFSI Dispatch Window check box

The **Enable P25-DFSI Dispatch Window** check box is used to enable the P25-DFSI Dispatch Window. If unselected, the user cannot open the DFSI Window in Runtime.

The default is selected.

# Receive All Talk Groups check box

The **Receive All Talk Groups** check box, if enabled, allows the console operator to be able to hear all incoming Talk Groups on that line. When the check box is not enabled, the line mutes all audio not matching the current Talk Group of that line.

The default is selected.

# Receive All Private Calls check box

The **Receive All Private Calls** check box, if enabled, allows the console operator be able to hear all Private Calls on that line. When the check box is not enabled, the line mutes private calls not directed to the console.

The default is selected.

#### P25-DFSI Radio List Font Size field

The P25-DFSI Radio List Font Size field indicates the size of the P25-DFSI Radio List Font Size.

The default is 12.

# **Password Protection group box**

#### Radio Monitor check box

The Radio Monitor check box, if enabled, indicates the Radio Monitor function is password protected.

For more information, refer to "Global Parameter Setup window, page 114".

# Radio Inhibit/Uninhibit check box

The Radio Inhibit/Uninhibit check box, if enabled, indicates the Radio Inhibit/Uninhibit function is password protected.

For more information, refer to "Global Parameter Setup window, page 114".

#### **Call Alert check box**

The Call Alert check box, if enabled, indicates the Call Alert function is password protected.

For more information, refer to "Global Parameter Setup window, page 114".

# Vote Select/Disable check box

The Vote Select/Disable check box, if enabled, indicates the Vote Select/Disable function is password protected.

For more information, refer to "Global Parameter Setup window, page 114".

# **Dispatch Window Config button**

The Dispatch Window Config button is used to change the color of the buttons and background of the Dispatch Window. Refer to the Figure below.




Figure 53.13: Dispatch Window

# 53.12 P25-DFSI window and C-Soft Runtime

The **P25-DFSI** window is the general control of a DFSI line. Clicking on the P25-DFSI button in the Figure "DFSI Design Options" in "Setting Up Additional P25-DFSI lines, page 500", during runtime, opens the window shown in the Figure below.

# Refer to

- Setting Up Additional P25-DFSI lines, page 500

# 53.12.1 Main Control page

The **Main Control** page is used to change the settings of the main control.




Figure 53.14: DFSI 1: Channel 1 - Main Control

### Channel drop down menu

The Channel drop down menu is used to select the channel.

### **Volume Slider**

The Volume slider is used to increase or decrease the volume of the P25 audio.

### **Group Call button**

The **Group Call** button is used to make a group call to the group ID in the ID box.

### Talk Group field and drop down menu

The **Talk Group** drop down menu is used to place group calls to the group selected from the list. The text above the drop down menu displays the selected value.

### **Private Call button**

The Private Call button is used to initiate a Private Call to the radio ID in the ID box.

### Private Call drop down menu

The **Private Call** drop down menu is used to place private calls to the radio selected form the list.

### **Mute button**

The Mute button is a latching button (press it, it stays muted, press again, it unmutes).

### Selected button

The Selected button changes the current line from Selected Audio to Unselected audio.

### **Digital button**

The **Digital** button is used to toggle the channel between Analog and Digital.



### Notice!

The channel must be configured for mixed mode. For more information, refer to "Analog/Digital Column" on *Channel Table window, page 497.* 

### Repeat On/Off button

The Repeat On/Off button is used to turn the base stations Repeater functionality On or Off.

### **Monitor On/Off button**

The Monitor On/Off button is used to enable or disable monitor mode directly over the DFSI




Figure 53.15: DFSI 1: Channel 1- Main Control Keypad

### **Keypad flyout**

The **Keypad** flyout is used to manually select unit IDs for a private call.

### Refer to

- Channel Table window, page 497

# 53.12.2 Unit Control page

The Unit Control page us used to send unit specific commands.

Figure 53.16: DFSI 1: Channel 1 - Unit Control

### **ID List flyout**

The **ID** List flyout contains all the Unit IDs and Group IDs setup for P25-DFSI. The ID List flyout is used to access the preprogrammed Unit ID and Group ID list.

### **Date column**

The **Date** column is used to show the historical date commands were sent.

### Time column

The **Time** column is used to show the historical time commands were sent.

### Freq column

The **Freq** column is used to show the frequency that was sent.

### Status column

The **Status** column is used to show any status information about the sent command.

### **TG-NAC** column

The TG-NAC column is used to show the talk group and identifier number for the radio call.

### Source ID column

The **Source ID** column is used to identify the number of the calling subscriber unit.

### **Target ID column**

The **Target ID** column is used to identify the number the source ID is calling.

### **Radio Check button**

The Radio Check button is used to verify if the target radio is currently online and functional.

### **Status Request button**

The **Status Request** button is used to read the Status of a Radio.

## **Radio Inhibit button**

The **Radio Inhibit** button is used to disable a radio from use. This feature can be used in the case of a lost or stolen radio.

### **Call Alert button**

The **Call Alert** button is used to send an alert to the target remote radio.

### **Radio Monitor button**

The Radio Monitor button is used to monitor the selected remote radio.

### Radio Uninhibit button

The **Radio Uninhibit** button is used to enable the radio for use. This feature is used to enable a radio if it has been disabled with the Radio Inhibit button.

### **Text Message button**

The **Text Message** button is used to send the selected Text Message from the drop down menu to the selected radio.




Figure 53.17: DFSI 1: Channel 1 - Unit Control - ID List

### 53.12.3 Voting page

The **Voting** page is used to provide a visual representation of voter status.




Figure 53.18: DFSI 1: Channel 1 - Voting

### Receiver column

The **Receiver** column is used to display the various voting receivers that are being used.

### **Vote State column**

The **Vote State** column display the status of the various voting receivers.

### Report button

The **Report** button is used to view the current Vote State of the receiver selected in the ID box.

### **Normal button**

The Normal button is used to set the receiver into normal state.

### Select button

The **Select** button is used to select the receiver to use.

### Disable button

The **Disable** button is used to disable the receiver input at voter.

### 53.12.4 Repeater page

The Repeater page shows the current state of all P25-DFSI lines setup in C-Soft.




Figure 53.19: DFSI 1: Channel 1 - Repeater

When a line is selected, if the call is a Group Call, the PTT Button turns into a Group Call button. If the call selected is a Private Call, the PTT Button becomes a Private Call button.

# 53.12.5 History page

The **History** page is used to show the historical information for traffic on the line.




Figure 53.20: DFSI: Channel 1 - History

### **Alert Cancel button**

The **Alert Cancel** button is used to ignore a Call Alert on the P25-DFSI line.

### System features and requirement for DFSI Interface 53.13

### **Supported DFSI Repeaters**

For the most up to date information on repeater support, go to www.telex.com.

- BK/Relm M/8150 with DFSI
- Codan
- EF Johnson Atlas
- **ICOM**
- RIC-M
- Tait

### Supported DFSI repeater functions

For the most up to date information on supported DFSI repeater functions, go to www.telex.com.

- Channel Change
- Repeat mode
- Monitor
- Voting

### Supported DFSI radio functions

For the most up to date information on supported DFSI radio functions, go to www.telexradiodispatch.com.

- Digital\Analog\Mixed Mode
- Radio Check
- Radio Inhibit
- Radio Uninhibit
- Status request
- Call Alert
- Radio Monitor
- Private Call
- Group Call

### **Required for C-Soft Setup**

- C-Soft 6.5000 or higher
- Software-based license key for P25-DFSI lines
- Supported Repeater (refer to Supported DFSI Repeaters, above)
- IP Addresses and Ports of Repeater

### 53.14 **Frequently Asked Questions**

- P25-DFSI Line of Server Console won't connect to Fixed Station: Check the Control Unicast Address of FS and Control Port of FS in the P25-DFSI Setup.
- P25-DFSI Line of Client Console won't connect to Fixed Station: Check the Control Unicast Address of Server and Control Port of Server in the P25-DFSI Setup.
- The wrong channel selected is shown: Check the P25 Manufacture in the P25-DFSI Setup.

# 54 Appendix F - P25 Encryption

Due to C-Soft's Designer/Runtime separation, C-Soft first requires keys are registered and organized in the design file. C-Soft uses a specialized architecture to allow for clarity and flexibility in the task of key management. C-Soft utilizes several constructs and definitions to simplify the management of encryption keys:

- Registered Key: A registered key's information consists of a key name and a CKR (Common Key Reference).
- Encryption Option: Specifies the cryptographic method used to transmit. Available encryption options are a Registered Key or Clear.
- Encryption Profile: An ordered group of encryption options which represent a list of all encryption options available on a given P25-DFSI talkgroup.


Each C-Soft design maintains a list of registered encryption keys, which are organized into encryption profiles. Each P25-DFSI line contains a list of channels that are each linked to an encryption profile, allowing the dispatcher to select and use any of the encryption options available in the encryption profile.

Once these organization steps are completed, encryption keys must be loaded into C-Soft Runtime. Once loaded, C-Soft Runtime uses the key organization as defined in the design file, but uses key data directly loaded into Runtime. This allows for C-Soft to easily manage key updates, changeovers, and other cryptographic maintenance tasks.



### Notice!

The P25-DFSI Encryption functionality is a value added option to your C-Soft license; please contact your regional Bosch Sales person for details on how to purchase.






Figure 54.1: Encryption Configuration Constructs

In the example shown in the Figure below, there are three channels on both Line 1 and Line 2.

- P25 DFSI Line 1's Channel 1 is linked to the encryption profile Clear that contains only one encryption option, Clear. While using P25 DFSI Line 1's Channel 1, the dispatcher can only transmit unencrypted.
- P25 DFSI Line 1's Channel 2 is linked to Encryption Profile A that contains three encryption options. While using P25 DFSI Line 1's Channel 2, the dispatcher can choose whether to transmit unencrypted, with Key 1 or with Key 2.
- P25 DFSI Line 1's Channel 3 is linked to the encryption profile B that contains only one encryption option. While on Channel 3, the dispatcher can only transmit using Key 3.
- P25-DFSI Line 2 contains three channels that are linked to encryption profile B. While on all of these channels, the dispatcher can only transmit using Key 3.





Figure 54.2: Organization Configuration Example

# **Encryption configuration**

In order to utilize the P25-DFSI Encryption features, the following configuration steps need to be completed:



"Registering keys, page 519".

- 2. "Group encryption options into encryption profiles, page 522".
- 3. "Link P25-DFSI Channels to an encryption profile, page 523".
- 4. "Activate Key Fill Device serial port, page 524".
- 5. "Add an Encryption Option Select button, page 524".


The majority of encryption configuration is contained in the Encryption Setup window, shown in "Encryption Setup window, page 516".

NAVIGATION: From the Edit menu, select Setup P25 | Encryption.

### Refer to

- Registering keys, page 519
- Group encryption options into encryption profiles, page 522
- Link P25-DFSI Channels to an encryption profile, page 523
- Activate Key Fill Device serial port, page 524
- Add an Encryption Option Select button, page 524
- Encryption Setup window, page 516

# 54.2 Encryption Setup window



### **Encryption Keys group box**

### Name column field

The **Name** column field is used to enter the name of the key being registered. A maximum of 100 keys can be registered.

Up to 24 alphanumeric characters can be entered into this field.

### **CKR** column field

The **CKR** column field is used to enter the common key reference number. A common key reference number is used to link a key name to an encryption key in a key fill device, commonly used for key name display purposes. This additional reference value allows changing a key's name without having to know its key ID.

The range for this field is 0 through 65535.

### **Key Fill Device group box**

The **Key Fill Device** group box is used to import encryption key data (Name and CKR) from a key fill device to C-Soft.

### Serial Port drop down menu

The **Serial Port** drop down menu is used to specify the serial port that C-Soft Designer opens in order to communicate with an attached key fill device for key registration purposes.



### Notice!

This value is also used in C-Soft Runtime to specify the serial port used to communicate with an attached key fill device for key loading.

### Start button

The **Start** button is used to immediately open the serial port listed in the Serial Port drop down menu, allowing communication with the key fill device in C-Soft Designer.

The button toggles between a start and stop function.



### Notice!

It is not recommended to use the DES demo key in any capacity where robust encryption is required. It is used mainly for demonstration and debugging.

### **Encryption Profiles group box**

The **Encryption Profiles** group box is used to create encryption profiles with different encryption keys. For more information, refer to "*Group encryption options into encryption profiles*, page 522". Up to 50 encryption profiles can be created. Each profile can have up to 25 encryption options associated with it.



### Notice!

The Encryption Profile list always contains an encryption profile labeled Clear, which contains the Clear encryption option only. By default, any P25-DFSI Line's channels are linked to the clear encryption profile.

### Name column field

The Name column is used to enter a profile name, such as All Keys or Clear Only.

### Summary column field

The **Summary** column field summarizes the key options included in the Key Profile (i.e., Clear +2keys). This column is automatically generated.

### **Edit button**

The **Edit** button is used to open the Encryption Profile window of the currently selected encryption profile. Use this window to add and remove different encryption options to the profile as well as set the default encryption option.

### **Delete button**

The **Delete** button is used to delete an encryption profile.

- 1. Select the **profile** intended for deletion.
- 2. Click the **Delete** button.
  - A warning message appears verifying the intention to delete the profile.
- 3. Click OK.

The profile is deleted from the Encryption Profiles list.

# 54.3 Encryption Profile Edit window

The **Encryption Profile Edit** window is used to create encryption profiles using the user created encryption options and Clear.

For more information, refer to "Group encryption options into encryption profiles, page 522".




Figure 54.3: Encryption Profile Edit Window

### **Profile Name field**

The **Profile Name** field is used to enter a name for the encryption profile.

### **All Options list**

The **All Options** list displays a list of all available encryption options for use in the profile.

### Add button

The Add button is used to move options from the All Options list to the Selected Options list.

### Remove button

The **Remove** button is used to move options from the Selected Options list to the All Options list.

### **Selected Options list**

The **Select Options** list displays a list of the encryption options selected for the profile being created. The Selected Options list is an ordered list.



### Notice!

The first option listed is always the default option. For example, in Figure 228, Clear is the default encryption option. The default option is the first option listed on the Encryption Button Popup List in C-Soft Runtime.

Use the up and down buttons to move the selected encryption options up or down in the list.

### **OK** button

The **OK** button is used to accept the modifications made and closes the Encryption Profile window.

### **Cancel button**

The **Cancel** button is used to close the Encryption Profile window. No modifications made are saved.

### Refer to

- Group encryption options into encryption profiles, page 522

# 54.4 Registering keys

Registering keys requires two pieces of information:

- The Key's Name
- The Keys CKR (Common Key Reference) value

To transmit encrypted audio using a specific encryption key, the key must be registered into the system design.

There are two methods to register keys; manually or automatically.

### **Register manually**

To **register manually**, do the following:

- From the Edit menu, select P25 | Encryption.
   The Encryption Setup screen appears.
- 2. In the Name column, enter a unique name for the key.
- 3. In the CKR column field, enter the **CKR number** for the key.

### Register automatically

When using a key fill device to import keys to C-Soft, some radios do not use key names, refer to "Key Fill Device Group Box".

### To register automatically, do the following:

- 1. From the Edit menu, select **P25 | Encryption**. The Encryption Setup screen appears.
- 2. From the Serial Port drop down menu, select the **COM port** to be used to communicate with a key fill device.
- 3. Click the Start button.

The specified serial port for communication with an attached key fill device opens. NOTE: C-Soft Designer may be unable to acquire the serial port if C-Soft Runtime has reserved the port.


4. Using the Key Fill Device, load the keys into C-Soft.

The updated Key Names and CKRs appear in the Encryption Keys table.



### Notice!

When using the automatic register feature, only Key Names and CKRs are loaded.



# 54.5 Connecting a key fill device



Depending on the radio you are using, a few differences must be noted.

- If using a Tait Recon KVL, connect the bottom DB-9 serial port to the C-Soft Console PC using a null serial cable.
- If using either the Motorola KVL-3000+ or KVL-4000, the Tait 9000 Series to KVL adapter is also necessary. On the Motorola KVL, connect the 10-pin connector to the Tait 9000 Series to KVL Adapter. And then connect the DB-9 serial port to the C-Soft Console PC using a null serial cable.

### **Key Fill Device Features and Limitations**

While all tested key fill devices follow the same base P25-defined Key Fill Device Interface Protocol, there may exist several operational differences and behavior.

### **Key Names**

The Motorola KVL-3000+ and Motorola KVL-4000 do not include **Key Names** when importing encryption key data. This results in the following behavior:


- In C-Soft Designer, when using Automatic key registration, only keys' CKR values are added to the Key List. Their names must be manually set.
- In C-Soft Runtime, when receiving an audio call encrypted with a key with a non-registered but loaded key, C-Soft will display "Unregistered Key (#)", where # is the CKR of the key. This can be amended by manually registering the key in the Design, which makes the key name appear properly.
- The Tait Recon KVL key load process includes key names, and in each of these cases, the Key Name is properly displayed.

# 54.6 Group encryption options into encryption profiles

Encryption Profiles are ordered groups of encryption options such as registered keys and Clear.

To group encryption options into encryption profiles, do the following:


From the Edit menu, select P25 | Encryption.
 The Encryption Setup screen appears.



- 2. In the Encryption Profile group box, click in the **Click to create profile field**. The name column field becomes active.
- 3. Enter a **profile name** in the active field. The profile name appears in the field.

### 4. Click the Edit button.

The Encryption Profile window appears.



- From the All Options list, select the **options** to add to the profile.
   Multiple options can be selected at one time.
- 6. Click the **Add button** to move the encryption options to the Selected Options list.
- 7. Use the **up and down buttons** to reorder the Selected Options list, if applicable. NOTE: Reordering the Selected Options list is useful when wanting to the default encryption option in which the topmost entry becomes the default.
- 8. Click OK.

The Edit Encryption Profile window closes.


# 54.7 Link P25-DFSI Channels to an encryption profile

Each P25-DFSI Channel needs to be configured to select which Encryption Profile to use. When the specific P25-DFSI Channel is selected, only encryption options in the associated encryption profile are available to use for transmit.

To link the P25-DFSI channels to the encryption profile, do the following:

- From the Edit Window, select Setup Per Line Parameters.
   The Per Line Parameters window appears.
- 2. Press the **Freqs button** of the desired P25-DFSI line. The Channel Table appears.

From the Encryption Profile column drop down menu, select an encryption profile for each channel.



### 4. Click OK.

The Channel Table modifications are saved, and the Channel Table window closes.

# 54.7.1 Activate Key Fill Device serial port

To permit communication between C-Soft and a key fill device, the desired serial port must be configured.

### To configure C-Soft Runtime's serial port, do the following:

- From the Edit menu, select P25 | Encryption.
   The Encryption Setup screen appears.
- 2. From the Serial Port drop down menu, select the **COM port** to be used to communicate with a key fill device.
- Click the **OK button**.
   The Encryption Setup window closes.
- 4. Save the design.



### Notice!

When C-Soft Runtime is launched with the Design, C-Soft opens the selected serial port for communication with an attached key fill device.

# 54.8 Add an Encryption Option Select button

Encryption Profiles containing more than one encryption option need a UI element to control the encryption option to be used while transmitting. Secondarily, the Encryption Option Select button also displays encryption key information when receiving encrypted audio.

### To add an Encryption Option Select button, do the following

1. From the Insert menu, select **Add Button**.

OR

Right-click in an empty spot in the Design workplace.

A popup menu appears.

2. Select the Add button.

A button appears in the design workspace.

Right-click on the button.

A popup menu appears.

4. From the popup menu, select **Properties**.

The UI Properties window appears.

# Type Colors Options UI Element: Button Filter: All UI Element Function: Encryption Key Select Line to Associate Function With: Line 1

- 5. From the UI Element Function drop down menu, select **Encryption Key Select**.
- 6. From the Line to Associate Function With, select the **P25-DFSI Line configured for P25 Encryption**.

 $\cap R$ 

Select the **Global** checkbox to have the Encryption key Select button display information based on the currently selected line.

7. Click **OK**.

The window closes and the button displays Key Select.

# 54.9 Loading keys to C-Soft Runtime

At this point, C-Soft Runtime does not have any actual key data. This key data must be loaded from a key fill device. C-Soft Runtime communicates to a key fill device through the PC's serial port.

To load keys into C-Soft Runtime, do the following:

- 1. Launch C-Soft Runtime.
- Attach a Key Fill Device to the C-Soft Dispatch Console PC via the serial port.
   Upon successful connection, C-Soft's Status Bar displays a "Key Fill Device Attached" message.
  - NOTE: C-Soft Runtime may be unable to acquire the serial port if C-Soft Designer is using it to register keys.
- 3. Using the key fill device, **load one or more keys into C-Soft** in the same fashion as a

Once finished, C-Soft's Status Bar displays a "# Key(s) Updated" message, where "#" specifies the number of keys that were loaded or updated. The keys are now successfully loaded into C-Soft.

Refer to "Connecting a key fill device, page 521" for more information on using a key fill device.

### Refer to

- Connecting a key fill device, page 521

# 54.10 Receiving encrypted calls

When receiving a call with encrypted audio, C-Soft attempts to find a loaded key in which the incoming Key ID matches the received Key ID. If a matching key is found, the call is decoded and played. If C-Soft does not possess a key with a matching Key ID, the incoming call's audio is muted.

While receiving a call encrypted with an AES key, the line's Select button displays FIPS to indicate the call is being decrypted using a FIPS-validated cryptographic library.

In addition, the Encryption Key Select button momentarily displays the incoming call's key name, or the Key's CKR if the name is not known. Since there are potentially two locations in which a key name is specified, C-Soft uses the following priority list for displaying Key Information:

- 1. Registered Key Name from Design's Encryption Key List
- 2. Key Name obtained from the key fill device.
- 3. "Unregistered Key < CKR>"

The incoming call flow is summarized as follows:




Figure 54.4: Receiving Call Flow

# 54.11 Transmitting encrypted calls

The Encryption Key Select button is the essential UI element for encryption operation. The button is either configured as global meaning the content is changed based on the currently selected line, or statically configured to a specific line.

The Encryption Key Select button is also linked to the currently selected channel/talkgroups, and changes its content when the active channel/talkgroups is changed. The Encryption Key Select button's selected option is preserved between switching selected lines and switching channel/talkgroups.




Figure 54.5: Encryption Key Select Button (with Option List)

The Encryption Key Select button's drop down menu contains a list of all encryption options contained in the encryption profile linked by the currently selected frequency of the associated line. In addition, it contains information relevant to encryption key validity.

### The icon/states include:

Icon	Meaning	Description
	Blank	Used for "Clear", indicates transmissions are not encrypted.
7	Key	Key data is loaded and available.
*	No Data	Key name/CKR are registered in the Design file, but C-Soft Runtime does not possess data for the key. Any attempt to transmit using a registered but not loaded key is blocked. After using a key fill device to load the key's data into C-Soft Runtime, the no data icon changes to key.

Once an encryption option is selected, pressing a PTT button (e.g. Main PTT, Per-Line PTT, Private PTT, or Group PTT) button will transmit using the selected key. While receiving a call encrypted with an AES key, the line's Select button displays FIPS to indicate the call is being decrypted using a FIPS-validated cryptographic library. The transmit call flow is as follows:




Figure 54.6: Transmit Call Flow

# 55 Appendix G - CSSI Interface

The P25 CSSI interface is designed to connect directly to P25 Trunking System via an IP Interface without using a radio gateway or additional hardware. The C-Soft CSSI interface provides flexibility in deployment and offers advanced radio control features. CSSI interface is an option feature on C-Soft and available in 2, 6, 12, and 24 talk paths.

### Notice!



Included with this option is the ability to define a line as either P25 CSSI or P25 DFSI. The total number of lines available is constrained by the number of lines in the P25 CSSI option license. In other words, a six line P25 CSSI license could have all six lines set up for P25 CSSI, or all six lines set up for P25 DFSI, or a combination of 4 lines set up for P25 CSSI and two lines set up for P25 DFSI.

# 55.1 Supported features



### Notice!

While C-Soft supports these features, each radio manufacturers supported CSSI feature set varies, consult technical support for a list of known features per manufacturer.

The CSSI Trunking Interface supports the following features:

- Console Registration
- Group Call
- Private Call
- Call Alert
- Announcement Call
- System Call
- Short Message Decode
- Status Query/Update
- Radio Unit Monitor
- Radio Check
- Radio Enable
- Radio Disable
- Emergency Alarm
- Emergency Acknowledgement
- Audio Encryption and Keys Loading
- P25 Phase 1
- P25 Phase 2
- P25 DFSI (refer to "Appendix E P25-DFSI (Digital Fixed Station Interface), page 479")

### Refer to

Appendix E - P25-DFSI (Digital Fixed Station Interface), page 479

# 55.2 Theory of operation

### Console

In a P25 CSSI interface, the C-Soft console acts as an RFSS System. When the console starts, it needs to register its talk groups with the P25 trunking infrastructure via IP connection to gain access to the system.



### Notice!

The registration process fails on certain talk groups if those talk groups are not preprogrammed in the CSSI system.

### Call Line

Each CSSI line within a console design can be set up as either Talk Group or Unit Call lines. **Talk Group** lines use either a Group PTT or InPTT button for call activation. Using a GroupPTT button allows the talk group ID to be varied on the line. Using an InPTT button creates a dedicated line with only one talk group ID. All talk groups needing to receive and transmit on must be registered with the CSSI system. The console registers all talk groups contained in the consoles System List when the console first starts. Talk group validation can be viewed in the console's Global Call History window (refer to "Global Call History window, page 447").

A **Unit Call** line is used to send private calls to an individual radio subscriber. Unit lines use either a Private PTT button or an InPTT button for call activation. Using a Private PTT button allows the unit ID to be varied on the line. Using an InPTT button creates a dedicated line to call only one unit ID. Radio buttons such as Call Alert, Remote Monitor, etc. are typical buttons assigned to this type of line. Console designers can add a Keypad module to the console design to provide easy access to the Talk Group or Private Call user list during call operations when using the Private PTT button.



### Notice!

It is strongly recommended to assign Radio Control Buttons such as Radio Call Alert, Radio Check, Radio Disable, Radio Enable, and Radio Remote Monitor to a unit call line. This ensures seamless operation on the console.

Assigning the Radio Control Buttons on group lines that may be restricted can produce unpredictable results.

The console registers all talk groups contained in the consoles System List when the console first starts up. The System List can be edited using the System List Window (refer to "Status List window, page 236"). Talk group validation can be viewed in the console's Global Call History window (refer to "Global Call History window, page 447").

### Refer to

- Global Call History window, page 447
- Status List window, page 236

### 55.2.1 Distribution of receive audio to the lines

### **Talk Groups**

The CSSI protocol is based on SIP (Session Initiation Protocol); therefore the console implementation also uses this protocol to structure the operation of the console. The console first scans all lines for a Group PTT button that is set to the incoming talk group ID. If the receive ID matches the line's talk group ID, the line receives the audio.

If no Group PTT button is set to the incoming ID, the console then scans all lines with an Instant PTT button (a dedicated line) for a group ID assigned to the line (the talk group ID assigned in C-Soft Designer). If the receive ID matches the lines talk group ID, that line receives the audio.

If no line matches the ID, the receive audio goes to the first available (non-busy) line with a Group PTT. If all lines are busy, the call is missed.

### Notice!



If a console system cannot tolerate any missed talk group calls, the console administrator must have as many Talk Group lines as voice channels available on the CSSI system and all lines must have Group PTT buttons.

If a dispatcher needs to monitor and talk to a specific talk group, an InPTT button is used to create a dedicated line.

Unit lines operate exactly the same as group lines, with one exception, if all unit call lines are busy the console sends back a busy signal to the calling unit.

### **Operational Notes**

- The talk group or unit ID shown on the Group PTT, InPTT, and Private PTT is the line's current transmit and receive ID.
- If the keypad module is used on the C-Soft console to change talk group and unit IDs, console operators must select the desired line by clicking on the Select button first and changing the ID in the keypad. The ID changes on the selected line's PTT button and any radio buttons assigned to it. If a console operator selects another, the previous selected line retains its ID. This operation holds true for all non-dedicated lines. Dedicated lines are preset to the default designer value; the keypad has not effect on these lines.
- Up to 24 CSSI lines can be created with any combination of Talk Group or Unit lines.

### **Group Call line**

A **Group Call** is used to talk to multiple radios within a talk group.

Group lines use Group PTT or an InPTT button for call activation. Using a Group PTT button allows the Group ID to be varied on the line. Using an InPTT button creates a dedicated line with only one Group ID. In addition, a Radio Status button can be assigned to a group line to send status messages to a group.

### Notice!



All talk groups must be registered with the CSSI system. Upon initial start up, the console registers all CSSI groups listed in the Group ID List. Talk group validation can be viewed in the console's Global Call History window. The registration process fails on groups not preprogrammed on the CSSI system. To configure the console's system list, refer to "File menu - Edit System List, page 193".

### Refer to

- File menu - Edit System List, page 193

### 55.2.2 Individual Call line

An **Individual Call** line is used to send private calls to individual units. Individual Call lines use a Private PTT or an InPTT button for call activation. Using a Private PTT button allows the unit ID to be varied on the line. Using an InPTT button creates a dedicated line with only one unit ID.

Radio buttons (Call Alert, Remote Monitor, Regroup, Ungroup, etc.) are typically assigned to this type of line. Console operators can add a Keypad to the console design, providing easy access to the user list during call operation. All Unit Calls are received by the console when the Individual Call line is in Scanning Mode. In Dedicated Mode, the Individual Call line becomes a point-to-point call with one preprogrammed unit.

# 55.3 CSSI Call types

Each CSSI line within a console design can be set up as either Group or Individual Call lines.

### 55.3.1 Group Call

**Talk Group** lines use either a Group PTT or InPTT button for call activation. Using a GroupPTT button allows the talk group ID to be varied on the line. Using an InPTT button creates a dedicated line with only one talk group ID.

### To create a Group Call, do the following:


- 1. From the Edit Window, select **Setup Per Line Parameters**. The Per Line Parameters window appears.
  - Click the **Signal Setup button** of the P25 CSSI line to create a group call.
    - The Signaling Parameters screen appears.
- 3. Click the CSSI tab.
  - The CSSI page appears.
- 4. From the Call Type drop down menu, select **Group Call**.
- 5. From the Encryption Profile drop down menu, select the **encryption profile** to use, if applicable.
- 6. In the Call Number field, enter the **Talk Group Number of the line** if using an InPTT button on the line.





### Notice!

If the console designer assigns an InPTT button to the line, this line would only transmit to and receive from the default ID. This is called a Static Group Line. If the console designer assigns a Group PTT button to the line, the default ID is overridden at run time by the current Group ID assigned by the selectable Group PTT button. This is called Manual Group line.






Figure 55.1: Static Group Line and Manual Line Set Up

### 55.3.2 Individual Call

An **Individual Call** line is used to send private calls to individual users. Individual lines use either a Private PTT button or an InPTT button for call activation. Using a Private PTT button allows the unit ID to be varied on the line. Using an InPTT button creates a dedicated line with only one unit ID. Radio buttons such as Call Alert, Remote Monitor, etc. are typical buttons assigned to this type of line. Console operators can add a Keypad to the console design to provide easy access to the user list during call operation.

### To create an Individual Call, do the following:

- From the Edit Window, select Setup Per Line Parameters.
   The Per Line Parameters window appears.
- 2. Click the **Signal Setup button** of the P25 CSSI line to create an individual call. The Signaling Parameters screen appears.
- Click the CSSI tab.
   The CSSI page appears.
- 4. From the Call Type drop down menu, select **Individual Call**.
- 5. From the Encryption Profile drop down menu, select the **encryption profile** to use, if applicable.
- 6. In the Call Number field, enter the **Individual Call Number of the line** if using an InPTT button on the line.



### Notice!

If the console designer assigns an InPTT button to the line, this line would only transmit to and receive from the default unit ID.

If the console designer assigns a Private PTT button to the line, the Private PTT overrides the default number and allows different units to be selected.





Figure 55.2: Private Call Configuration

# 55.4 C-Soft Setup parameters

To program a P25 unit radio or parallel console ID for CSSI operation, do the following:

1. From the edit menu, select **Edit User ID List**.

The User ID List window appears.



- 2. In the Name column, enter the alias for each line.
- 3. In the User ID column, enter the User ID for each line (the User ID is in decimal format).
- 4. From the Type drop down menu, select **P25-CSSI**.
- 5. Click OK.




### Notice!

To program an All Call ID that can transmit to all CSSI subscribers on the system, enter 65535 in the User ID column, and select CSSI from the Type drop down menu. All numbers are in decimal format.

### To program a P25 Trunking talkgroup for CSSI operation, do the following:

1. From the Edit menu, select Edit Group ID List.

The Group ID List window appears.



- 2. In the Group column, enter the **Group alias** for each line.
- 3. In the Group ID column, enter the **Group ID** for each line (the Group ID is in decimal format).
- 4. From the Type drop down menu, select **CSSI** for each line.
- 5. Click OK.



### Notice!

During start up, C-Soft registers all of the pre-programmed CSSI Talk Groups. C-Soft can only communicate to Talk Groups registered to the system.

# 55.5 Signaling Parameters




Figure 55.3: Signaling Parameters - CSSI Page

# **Console Call Parameters group box**

The **Console Call Parameters** group box is used to configure a line's voice call. Configuration options include the type of call, the encryption profile to use, and the call number.

The **Call Type** drop down menu is used to select the type of call designated to the line.

Available options are Group Call or Individual Call.

# **Encryption Profile drop down menu**

The **Encryption Profile** drop down menu is used to select the encryption profile to use for the line, if any. For more on Encryption profiles, refer to "Appendix F - P25 Encryption, page 513".

### **Call Number field**

The **Call Number** field is used to enter the Talk Group ID or the Individual ID, depending on what is selected in the Call Type drop down menu. This field is uniquely identified by a number.

The range for this field is 1 to 65535 in decimal.

### **RFSS Location Parameters group box**

The **RFSS Location Parameters** group box is used to configure the P25 repeater RFSS (Radio Frequency Sub-System) that connects to the line. The following field values are obtained from the systems RFSS.

### **RFSS ID Dec/Hex fields**

The **RFSS ID Dec/Hex** fields are used to enter the ID of the Home RFSS in the connected P25 Trunking system. The unique identifier can be entered in either decimal or hex format.

The range for this field is 1 to 65535 in decimal.

### System ID Dec/Hex fields

The **System ID Dec/Hex** fields is used to enter the ID for the LMR system within a WACN (Wide Area Communication Network). The unique identifier can be entered in either decimal or hex format.

The range for this field is 1 to 4095 in decimal format.

### WACN ID Dec/Hex fields

The **WACN ID Dec/Hex** fields are used to enter the WACN ID, which is a collection of one or more LMR systems. The unique identifier for each LMR system can be entered in either decimal or hex format.

The range for this field is 1 to 1048575.

### **RFSS IP Address field**

The **RFSS IP Address** field is used to enter the IP Address of the RFSS system. Individual RF sites use this address to connect with.

### **RFSS Location ID field**

The **RFSS Location ID** field displays the an ID that is made up of the RFSS ID, System ID, and the WACN ID. This field cannot be modified. This field is most commonly used for comparison purposes when setting up a CSSI system.

### Global CSSI Setup button


The **Global CSSI Setup** button opens the Global P25 CSSI Parameters setup window. For more information, refer to "*Global P25 CSSI Parameters, page 540*".

# 55.6 CSSI System setup

To set up a CSSI Line, do the following:

1. From the Edit menu, select Setup Per Line Parameters.

The Per Line Parameters window appears.




2. From the Line Type drop down menu, select **CSSI**.

NOTE: The Multicast address and port number information is used for cross console communications supporting the following features: Call Queue, Emergency and Crosspatch updates. These fields should match on each console in a shared system.

3. Click the Signal Setup button.


The Signaling Parameters window appears.



4. From the System Type drop down menu, select **P25 CSSI**.

### 5. Click the CSSI tab.

The CSSI window appears.



- 6. From the Call Type drop down menu, select the Call Type.
- 7. In the Talk Group Number field, enter the **Talk Group Number**.

# 55.7 Global P25 CSSI Parameters

The **Global CSSI Parameters** apply to all CSSI console lines and only need to be set once per console. The Global CSSI Parameters window is assessable from any line, but the values are constant between lines, and can be found at Edit | Setup CSSI.




Figure 55.4: Global CSSI Trunking Parameters Window

### **Console Location group box**

The **Console Location** group box is used to define the console location identifiers.

### Console ID Dec/Hex fields

The **Console ID Dec/Hex** fields are used to enter the ID that is assigned to the console.

The range for this field is 1 to 16777215 in decimal format.

#### Console RFSS ID Dec/Hex fields

The **Console RFSS ID Dec/Hex** fields are used to enter the ID of the RFSS. This ID must match the external CSSI RFSS ID which was set up on the LMR system.

The range for this field is 1 to 65535 in decimal format.

### Console System ID Dec/Hex fields

The **Console System ID Dec/Hex** fields are used to enter Control System ID. This ID must match the CSSI System ID which is set up on the LMR system.

The range for this field is 1 to 4095 in decimal format.

#### Console WACN ID Dec/Hex fields

The **Console WACN ID Dec/Hex** fields are used to enter the WACN ID. The WACN is a collection of one or more uniquely identified LMR Systems.

The range for this field is 1 to 101048575 in decimal format.

#### **Console Location ID field**

The **Console Location ID** field displays the location ID of the console. This ID is made up of the Console RFSS ID, Console System ID and the Console WACN ID. This field is used for comparison purposes when setting up a CSSI system. This field cannot be edited.

#### Console SUID field

The **Console SUID** field displays the SUID (subscriber unit ID). This ID is made up of the Console WACN ID, Console System ID, and Console ID. This field is used for comparison purposes when setting up a CSSI system. This field cannot be edited.

#### **Enable Heartbeats check box**

The **Enable Heartbeats** check box determines whether or not heartbeats are sent from the console to the LMR RFSS.

#### **Heartbeat Rate field**

The **Heartbeat Rate** field is used to enter rate at which heartbeats are sent from the console to the LMR RFSS.

The range for this field is 10 to 120 seconds.

#### Missed Heartbeats field

The **Missed Heartbeats** field is used to enter the number of missed heartbeats allowed before an error is generated.

The range for this field is 1 to 10.

### Receive FNE Supplementary data by SUs registered with group check box

The Receive FNE Supplementary data by SUs registered with group check box determines whether or not a group registration with both the LMR RFSS and LMR FNE (Fixed Network Equipment) is allowed. This allows supplementary operations such as Status, Call Alert, Radio Check, etc. to be handled by FNE. For example, an SU sends a Status update to the FNE. All the consoles registered to the FNE for that group receives the status update. The SU does not need to send status updates to each individual console.

#### **Console Tx Priority field**

The **Console Tx Priority** field is used to enter the transmit priority level. Consoles with a higher priority level transmits over a console that has a lower priority level.

The range for this field is 1 to 255.



### Notice!

A console always transmits over an SU.

### **Local Console button**

The Local Console button opens the "Local Consoles page, page 129".

# 56 Appendix H - Kenwood NEXEDGE Direct IP interface

The NEXEDGE Direct IP interface is designed to connect directly to NEXEDGE Trunking and NEXEDGE Conventional Systems via an IP Interface without using a radio gateway or additional hardware. The C-Soft NEXEDGE IP interface provides flexibility in deployment and offers advanced radio control features. NEXEDGE IP interface is an option feature on C-Soft and available in 2, 6, 12, and 24 talk paths.

## **56.1** Supported features

The NEXEDGE Trunking and Conventional IP Interfaces support the following features:

- Direct IP Interface (no extra hardware or radio gateway needed)
- Supports both Narrow band (12.5Khz) and Very Narrow band (6.25Khz) Channel Spacing
- Group Call/Conference Call
- Unit/Private Call
- Alert Call
- Selectable Talk Group
- Emergency Call Decode with Acknowledgement Capabilities
- Radio Status Request
- Radio Status Decode
- Radio Status Encode
- Radio Remote Grouping
- Over-The-Air-Aliasing
- Supports up to 24 Talk Paths per Console
- Call Queuing Using Incoming Status
- Radio Remote Monitor with Supervisor Password
- Radio Stun
- Radio Revive
- Support the following Conventional interface types:
  - No Signaling with RAN
  - Signaling without RAN
  - Signaling and RAN
- Radio Remote Grouping (Trunking Only)
- GPS Decode with IP Interface
- Text Messaging (Trunking Only)
- Broadcast Call (Trunking Only)

## 56.2 Theory of operation

#### Console

In a NEXEDGE system, the console acts as a radio SU (Subscriber). When the console starts, it needs to register its unit ID with the NEXEDGE infrastructure via IP connection to gain access to the system. Once it is registered, it then registers all the NEXEDGE talk groups programmed in the Group ID List.

#### **Private Call**

Individual units, or SUs, are calls the console wants to talk to that are not registered by the console. All unit calls are received by the console if the consoles Unit line is in SCAN mode. Scanning mode allows a line to overflow to another line, if busy. If the Unit line is in dedicated mode, the line becomes a point to point call with only one unit. Dedicated mode does not allow an overflow. If a line is busy, the call is missed.



#### Notice!

The consoles registered Unit ID is set from the Global Parameter Setup window, Console Unit ID Number (refer to "Global Parameter Setup window, page 114").

### **Group Call**

All talk groups the console is required to listen and talk on must be registered with the NEXEDGE system. The console registers all talk groups contained in the consoles System List when the console first starts up. Talk group validation can be viewed in the console's Global Call History window (refer to "Global Call History window, page 447").



#### Notice!

The registration process fails on certain talk groups if those talk groups are not preprogrammed in the NEXEDGE system.

#### Call Line

Each NEXEDGE line within a console design can be set up as either Talk Group or Unit Call lines. Talk Group lines use either a Group PTT or InPTT button for call activation. Using a GroupPTT button allows the talk group ID to be varied on the line. Using an InPTT button creates a dedicated line with only one talk group ID.

A Unit Call line is used to send private calls to individual units or SUs. Unit lines use either a Private PTT button or an InPTT button for call activation. Using a Private PTT button allows the unit ID to be varied on the line. Using an InPTT button creates a dedicated line to call only one unit ID. Radio buttons such as Call Alert, Remote Monitor, etc. are typical buttons assigned to this type of line. Console designers can add a Keypad to the console design to provide easy access to the Talk Group or Private Call user list during call operations when using the Private PTT button.



### Notice!

It is strongly recommended to assign Radio Control Buttons such as Radio Call Alert, Radio Check, Radio Disable, Radio Enable, and Radio Remote Monitor to a unit call line. This ensures seamless operation on the console.

Assigning the Radio Control Buttons on group lines that may be restricted can produce unpredictable results.



In the Conventional interface, when not using talk groups, the RAN (Radio Access Node) configured is used for the Call Line.

#### Refer to

- Global Parameter Setup window, page 114
- Global Call History window, page 447

### 56.2.1 Distribution of receive audio to the lines

#### **Talk Groups**

The NEXEDGE protocol is based on SIP (Session Initiation Protocol); therefore the console implementation also uses this protocol to structure the operation of the console. The console first scans all lines for a Group PTT button that is set to the incoming talk group ID. If the receive ID matches the line's talk group ID, the line receives the audio.

If no Group PTT button are set to the incoming ID, the console then scans all lines with an Instant PTT button (a dedicated line) for a group ID assigned to the line (the talk group ID assigned in C-Soft Designer). If the receive ID matches the lines talk group ID, that line receives the audio.

If no line matches the ID, the receive audio goes to the first available (non-busy) line with a Group PTT. If all lines are busy, the call is missed.

### **RANs (Conventional Only)**

When using talk groups, the console scans all the lines to match the talk group, once it has found a match it then attempts to match the RAN, as well. If you are not using a talk group the console scans to find a line matching the RAN. If a match is not found the call is missed.



#### Notice!

If a console system cannot tolerate any missed talk group calls, the console administrator must have as many Talk Group lines as voice channels available on the CSSI system and all lines must have Group PTT buttons.

If a dispatcher needs to monitor and talk to a specific talk group, an InPTT button is used to create a dedicated line.

Unit lines operate exactly the same as group lines, with one exception, if all unit call lines are busy the console sends back a busy signal to the calling unit.

#### **Operational Notes**

- The talk group or unit ID shown on the Group PTT, InPTT, and Private PTT is the line's current transmit and receive ID.
- If the keypad module is used on the C-Soft console to change talk group and unit IDs, console operators must select the desired line by clicking on the Select button first and changing the ID in the keypad. The ID changes on the selected line's PTT button and any

radio buttons assigned to it. If a console operator selects another, the previous selected line retains its ID. This operation holds true for all non-dedicated lines. Dedicated lines are preset to the default designer value; the keypad has not effect on these lines.

- Up to 24 CSSI lines can be created with any combination of Talk Group or Unit lines.

### 56.2.2 Group Call line

A Group Call line can be set as a Conference Call:

Conference Call: A Conference Call is used to talk to multiple radios within a talk group.

Group lines use Group PTT or an InPTT button for call activation. Using a Group PTT button allows the Group ID to be varied on the line. Using an InPTT button creates a dedicated line with only one Group ID. In addition, a Radio Status button can be assigned to a group line to send status messages to a group.

#### Notice!



All talk groups must be registered with the CSSI system. Upon initial start up, the console registers all CSSI groups listed in the Group ID List. Talk group validation can be viewed in the console's Global Call History window. The registration process fails on groups not preprogrammed on the CSSI system. To configure the console's system list, refer to "File menu - Edit System List, page 193".

UNIT CALL LINE

A **Unit Call** line is used to send private calls to individual units. Unit Call lines use a Private PTT or an InPTT button for call activation. Using a Private PTT button allows the unit ID to be varied on the line. Using an InPTT button creates a dedicated line with only one unit ID.

Radio buttons (Call Alert, Remote Monitor, Regroup, Ungroup, etc.) are typically assigned to this type of line. Console operators can add a Keypad to the console design, providing easy access to the user list during call operation. All Unit Calls are received by the console when the Unit Call line is in Scanning Mode. In Dedicated Mode, the Unit Call line becomes a point-to-point call with one pre-programmed unit.

## 56.3 NEXEDGE Call types

Each NEXEDGE line within a console design can be set up as either Conference (Talk Group) or Unit Call lines.

### 56.3.1 Conference call


Talk Group lines use either a Group PTT or InPTT button for call activation. Using a GroupPTT button allows the talk group ID to be varied on the line. Using an InPTT button creates a dedicated line with only one talk group ID.

To create a conference call or talk group, do the following:

- 1. From the Call Type drop down menu, select Conference Call.
- 2. In the Talk Group Number field, enter the Talk Group Number of the line.



If the console designer assigns an InPTT button to the line, this line would only transmit to and receive from the default ID. This is called a Static Group Line. If the console designer assigns a Group PTT button to the line, the default ID is overridden at run time by the current Group ID assigned by the selectable Group PTT button. This is called Manual Group line.






Figure 56.1: Group and Manual Line Set Up

### 56.3.2 Unit call

A **Unit Call** line is used to send private calls to individual users. Unit line use either a Private PTT button or an InPTT button for call activation. Using a Private PTT button allows the unit ID to be varied on the line. Using an InPTT button creates a dedicated line with only one unit ID. Radio buttons such as Call Alert, Remote Monitor, etc. are typical buttons assigned to this type of line. Console operators can add a Keypad to the console design to provide easy access to the user list during call operation.

To **create a unit call**, do the following:

- 1. From the Call Type drop down menu, select Unit Call.
- 2. In the Unit ID Number field, enter the **Unit Call Number of the line**.



#### Notice!

If the console designer assigns an InPTT button to the line, this line would only transmit to and receive from the default unit ID.

If the console designer assigns a Private PTT button to the line, the Private PTT overrides the default number and allows different units to be selected.




Figure 56.2: Private Call Configuration

## 56.4 C-Soft Setup parameters

To program a NEXEDGE radio in C-Soft, do the following:

1. From the edit menu, select Edit User ID List.

The User ID List window appears.



2. In the Name column, enter the alias for each line.

- 3. In the User ID column, enter the **User ID** for each line (the User ID is in decimal format).
- 4. From the Type drop down menu, select **NEXEDGE-CONV** or **NEXEDGE-TRUNK**.
- 5. Click OK.




To program an All Call ID that can transmit to all NEXEDGE subscribers on the system, enter 65535 in the User ID column, and select NEXEDGE from the Type drop down menu.

### To program a Group ID for NEXEDGE in C-Soft, do the following:

From the Edit menu, select Edit Group ID List.

Group ID List Group: Sort By Name

The Group ID List window appears.




- In the Group column, enter the **Group alias** for each line.
- In the Group ID column, enter the Group ID for each line (the Group ID is in decimal format).
- 4. From the Type drop down menu, select **NEXEDGE** for each line.
- In the Group ID column, enter the Group ID for each line (the Group ID is in decimal format).
- Click OK. 6.

During start up, C-Soft will register all of the pre-programmed NEXEDGE Talk Groups. C-Soft can only communicate to Talk Groups registered to the system.

#### 56.5 **NEXEDGE Trunking System setup**


To set up a NEXEDGE Line, do the following:

1. From the Edit menu, select **Setup Per Line Parameters**. The Per Line Parameters window appears.



- From the Line Type drop down menu, select NEXEDGE.
   NOTE: The Multicast address and port number information is used for cross console communications supporting the following features: Call Queue, Emergency and Crosspatch updates. These fields should match on each console in a shared system.
- 3. Click the Signal Setup button.


The Signaling Parameters window appears.



4. From the System Type drop down menu, select **NEXEDGE Trunking**.

#### Click the **NEXEDGE Trunking Parameters tab**.

The NEXEDGE Trunking Parameters window appears.



- From the Call Type drop down menu, select the call type (refer to "NEXEDGE Trunking Parameters page, page 553").
- 7. In the Talk Group Number field, enter the Talk Group Number for the Trunking

### Refer to

NEXEDGE Trunking Parameters page, page 553

#### 56.5.1 **NEXEDGE Trunking Parameters page**

### **Console Call Parameters group box**

The **Console Call Parameters** group box is used to configure Call Type and Default ID.

The **Call Type** drop down menu is used to select the type of call designated to the line.

Available selections for this field are:

- Broadcast Call: A Broadcast Call is a group call. It temporarily disables a remote radio's ability to respond to the dispatcher in a set amount of time pre-configured in the NEXEDGE system. Broadcast calls can be used in a special event or in an emergency situation for announcement.
- Conference Call: A Conference Call allows a Talk Group.
- Unit Call Lines: A Unit Call allows the dispatcher to talk to a specific radio unit.

#### **Talk Group Number field**

The **Talk Group Number** field is used to enter the default talk group ID for the line. The Talk Group Number is a unique Talk Group ID defined by the system administrator and programmed in the NEXEDGE system.



#### Notice!

If an InPTT button is assigned to the line, the line only transmits to, and receives from, the default Talk Group ID. This is known as a Static Group line. However, if a Group PTT button is assigned to the line, the default talk group ID is overridden by the current Group ID. This is known as a Manual Group line.

#### **Unit Call Number field**

The **Unit Call Number** field is used to enter the default Unit Call number. The Unit Call Number is a unique NEXEDGE subscriber ID defined by the system administrator and programmed in the NEXEDGE system.



#### Notice!

An InPTT button on this line allows calls to and from the Default Unit ID. A Private PTT button overrides the default unit number and allows different units to be selected.

## 56.6 Console Global Setup

The Global NEXEDGE Trunking parameters apply to all NEXEDGE console lines and only need to be set once for any line. The Global NEXEDGE Trunking Parameters window is assessable from any line, but the values are constant between lines, and can be found at Edit | Setup NEXEDGE.




Figure 56.3: Global NEXEDGE Trunking Parameters Window

### **Console Unit ID Number field**

The **Console Unit ID** field is used to enter the console's unique ID registered to the NEXEDGE system. This number must be programmed in the NEXEDGE system as a console ID.



### Notice!

The console's registered Unit ID is set in the global parameters window (Console Unit ID Number).

#### Console SIP Rx Port field

The **Console SIP Rx Port** field displays the console's receive port number for the SIP connection. This field cannot be edited.

#### Console SIP Tx Port field

The **Console SIP Tx Port** field displays the console's transmit port number for the SIP connection. This field cannot be edited.

#### **System Code field**

The **System Code** field is used to enter the number assigned to the NEXEDGE system. The console System Code must match the NEXEDGE site system code.

The range for this field is 1-131070.

### Network Category drop down menu

The **Network Category** drop down menu is used to select the coverage size. The console Network Category must match the NEXEDGE site network category.

Available options are:

- Local
- Regional

### **Channel Spacing drop down menu**

The **Channel Spacing** drop down menu is used to set the frequency separation between two adjacent channels. The console Channel Spacing must match the NEXEDGE site channel spacing.

Available options are:

- Narrow Band (12.5kHz)
- Very Narrow Band (6.25kHz)

### **Enable Over the Air Aliasing check box**

The **Enable Over the Air Aliasing** check box is used to enable over the air aliasing. Over the Air Alias allows the console to display the unique name of the calling transceiver without using User ID list in C-Soft for aliasing.



#### Notice!

The Over-the-Air Alias option must be enabled and Unit ID Name must be programmed in the transceiver for the console to receive the name.

### 56.6.1 Local Consoles button

The Local Consoles button allows users to setup a parallel console for the dispatch system.

#### **Enable Heartbeat check box**

The **Enable Heartbeat** check box indicates the system is monitoring the site verifying it is still online. When enabled, the Heartbeat Rate field and Missed Heartbeats Allowed fields become active.

#### **Heartbeat Rate field**

The **Heartbeat Rate** field is used to enter how often the heartbeat occurs, in seconds.

### **Missed Heartbeats Allowed field**

The **Missed Heartbeats Allowed** field is used to enter the number of missed heartbeats allowed before disabling the corresponding site. Disabling the site grays out all lines associated with the site.

#### **Transmit Delay check box**

The **Transmit Delay** check box enables transmit delay when delay is necessary for Radio Command functions.

### **Initial Transmit Delay Time field**

The **Initial Transmit Delay Time** field is used to ensure receipt of a radio command request when the called subscriber unit uses scan or battery saver. The Repeater sends an idle signaling command to the called subscriber at the designated time before sending the Radio Command (Radio Status, Radio Monitor, etc.). This insures the subscriber is available to receive the request from the repeater.

Initial Transmit Delay Time can range from 0 to 25000msec.

### **Transmit Delay Time field**

The **Transmit Delay Time** field is used to send a delay time along with the Radio Command request. Initial Transmit Delay Time and Transmit Delay Time are summed in value to determine for the overall delay time.

Transmit Delay Time ranges from 0 to 6000msec.

#### **RAN Encode button**

The **RAN Encode** button opens the NEXEDGE Conventional RANs window. For more information, refer to "NEXEDGE Conventional RANs window, page 563".

#### Refer to

- NEXEDGE Conventional RANs window, page 563

# 56.7 NEXEDGE Conventional IP system configuration



#### Notice!

Samples of a NEXEDGE .veg file and NEXEDGE System List.xml are available for reference design at www.telex.com/us/dispatch/line.

 Bosch Security Systems, LLC
 Technical Manual
 2021-06 | 14 | F.01U.218.561




Figure 56.4: Signaling Parameters Window - Conventional System Type

When NEXEDGE is selected as the Line Type and the Signal Setup button is clicked, the NEXEDGE Conventional Parameters Tab appears, refer to the Figure in "NEXEDGE Conventional Parameters window, page 558".

#### Refer to

- NEXEDGE Conventional Parameters window, page 558

### 56.8 NEXEDGE Conventional Parameters window

The **NEXEDGE Conventional Parameters** window is used to configure the IP Address of the NEXEDGE conventional system.




Figure 56.5: NEXEDGE Conventional Parameters Window



When using a Group PTT or Private PTT button, the talk group number and Unit Call number are pulled from the system list. In addition, Talk Group Number, Unit Talk Group Number and RAN Encode fields cannot be modified. To edit the RAN, see the Global NEXEDGE Conventional Setup window.

### **Parameters That Apply to This Line group box**

The **Parameters That Apply to This Line** group box is used to set up the Console Call Parameters, such as Call Type, RAN number, etc., and the System Site Parameters, such as the Site Number and Site IP Address.

#### **Console Call Parameters group box**

The **Console Call Parameters** group box is used to select the call type and the default ID for the selected call type.

The **Call Type** drop down menu is used to select the type of call to assign the configured parameters. Select Conference Call to set up a group talk line or select Unit Call to set up a Private Call Line.

Available selections for this field are:

- Conference Call: A Conference Call allows a Talk Group.
- Unit Call Lines: A Unit Call allows the dispatcher to talk to a specific radio unit.

#### **Encryption Key Field**

The **Encryption Key** field is used to enter the default encryption key for the Line.

#### **Talk Group Number field**

The **Talk Group Number** field is used to enter the Group ID assigned to the group.

### **RAN Encode Display field**

The RAN Encode field displays the RAN (Remote Access Node) for the call type. This field cannot be modified. Modifications to the RAN are done on the Global NEXEDGE Conv.

### **System Site Parameters group box**

The **System Site Parameters** group box is used to match the IP Address of the NEXEDGE Conventional system.

#### Site Number field

The Site Number field is used to enter the site number of the NEXEDGE conventional system.

#### Site IP Address field

The **Site IP Address** field is use to enter the site IP Address the NEXEDGE conventional system is located.

### Parameters That Apply to All Lines group box

### Global NEXEDGE Convn. Setup button

The **Global NEXEDGE Convn. Setup** button, when clicked, opens the Global NEXEDGE Conventional Setup Window.

### **Global Encryption Key Data button**

The Global Encryption Key Data button opens the NEXEDGE Encryption window.

### **OK** button

The **OK** button saves any changes made and closes the window.

### **Cancel button**

The **Cancel** button discards any changes made and closes the window.

## 56.9 Global NEXEDGE Conventional Parameters window




Figure 56.6: Global NEXEDGE Conventional Parameters Window

### Parameters Apply to All Lines group box

#### **Console Unit ID Number field**

The **Console Unit ID** field is used to enter the console's unique ID registered to the NEXEDGE system. This number must be programmed in the NEXEDGE system as a console ID.

#### **Console SIP Rx Port field**

The **Console SIP Rx Port** field displays the console's receive port number for the SIP connection. This field cannot be edited.

The number must match the NEXEDGE site's Tx SIP port number.

The default port number is 5060.

#### **Console SIP Tx Port field**

The **Console SIP Tx Port** field displays the console's transmit port number for the SIP connection. This field cannot be edited.

The number must match the NEXEDGE site's Rx SIP port number The default port number is 5060.

### **Enable Over the Air Aliasing check box**

The **Enable Over the Air Aliasing** check box allows the console to display the unique name of the calling transceiver without using the User ID list in C-Soft for aliasing.



#### Notice!

The Over-the-Air Alias option must be enabled and Unit ID Name must be programmed in the transceiver for the console to receive the name.

#### **System Code field**

This field is not used for the Conventional Interface.

### **Network Category field**

This field is not used for the Conventional Interface.

### **Channel Spacing drop down menu**

The **Channel Spacing** drop down menu is used to set the frequency separation between two adjacent channels. The console Channel Spacing must match the NEXEDGE site channel spacing.

Available options are:

- Narrow Band (12.5kHz)
- Very Narrow Band (6.25kHz)

### **Local Console button**

The Local Console button opens the "Local Consoles page, page 129".

#### **Enable Heartbeat check box**

The **Enable Heartbeat** check box indicates the system is monitoring the site verifying it is still online. When enabled, the Heartbeat Rate field and Missed Heartbeats Allowed fields become active.

#### **Heartbeat Rate field**

The **Heartbeat Rate** field is used to enter how often the heartbeat occurs, in seconds.

#### Missed Heartbeats Allowed field

The **Missed Heartbeats Allowed** field is used to enter the number of missed heartbeats allowed before disabling the corresponding site. Disabling the site grays out all lines associated with the site.

### **Transmit Delay check box**

The **Transmit Delay** check box enables transmit delay when delay is necessary for Radio Command functions.

#### **Initial Transmit Delay Time field**

The **Initial Transmit Delay Time** field is used to ensure receipt of a radio command request when the called subscriber unit uses scan or battery saver. The Repeater sends an idle signaling command to the called subscriber at the designated time before sending the Radio Command (Radio Status, Radio Monitor, etc.). This insures the subscriber is available to receive the request from the repeater.

Initial Transmit Delay Time can range from 0 to 25000msec.

#### **Transmit Delay Time field**

The **Transmit Delay Time** field is used to send a delay time along with the Radio Command request. Initial Transmit Delay Time and Transmit Delay Time are summed in value to determine for the overall delay time.

Transmit Delay Time ranges from 0 to 6000msec.

#### **RAN Encode button**

The **RAN Encode** button opens the NEXEDGE Conventional RANs window. For more information, refer to "NEXEDGE Conventional RANs window, page 563".

#### **OK button**

The **OK** button saves any changes made and closes the window.

#### **Cancel button**

The Cancel button discards any changes made and closes the window.

### 56.10 NEXEDGE Conventional RANs window

The **NEXEDGE Conventional RANs** window allows you to configure all talk groups and units to their respective RAN (Remote Access Node). The repeater must have the matching talk group/unit programmed for this to work. By populating the RANs list, the user has the ability to change the RAN number for each talk/unit. This can also be changed on the Signaling Parameters Setup and are reflected in this list.



### Notice!

The name and ID fields cannot be modified from this window. These changes must be made in the System List window (refer to "Edit System List window, page 192").

 Bosch Security Systems, LLC
 Technical Manual
 2021-06 | 14 | F.01U.218.561




Figure 56.7: NEXEDGE Conventional RANs Window

### **Group/Unit Name field**

The **Group/Unit Name** field displays the name of the group or unit you want to assign the RAN to.

### **Group/Unit ID field**

The **Group/Unit ID** field displays the ID of the selected group or unit you want to assign the RAN to.

### **RAN Encode field**

The RAN Encode field is used to assign a RAN code used by the associated group or unit.

### Type drop down menu

The **Type** drop down menu is used to select the type of RAN you want to assign, either Groups or Units.



When Group is selected from the drop down menu, Group Name and Group ID are displayed as the columns; when Unit is selected from the drop down menu, Unit Name and Unit ID are displayed.

#### **OK** button

The **OK** button saves any changes made and closes the window.

### **Cancel button**

The Cancel button discards any changes made and closes the window.

#### Refer to

- Edit System List window, page 192

## 56.11 NEXEDGE Conventional IP set up

To set up a NEXEDGE Line, do the following:

1. From the Edit menu, select **Setup Per Line Parameters**.




2. From the Line Type drop down menu, select **NEXEDGE**.

Bosch Security Systems, LLC

3. Click the Signal Setup button.


The Signaling Parameters window appears.



4. From the System Type drop down menu, select **NEXEDGE Conventional**. The NEXEDGE Conventional Parameters tab appears.

### 5. Click the **NEXEDGE Conventional Parameters tab**.

The NEXEDGE Conventional Parameters window appears.



6. From the Call Type drop down menu, select either Conference Call or Unit Call.

## 56.12 C-Soft NEXEDGE Conventional IP interface

### **IP Console ID List**

The KPG-109DN application and system key file are required before gaining access to configuration settings for the system. The values set in the Console Unit ID, RANs and Channel Spacing must match the programming parameters in Kenwood Conventional System. The Figure below displays a Kenwood KPG-109DN conventional repeater programmer.

The Console ID in C-Soft must match one of the IDs on the following list.




Figure 56.8: Conventional IP Network Window

#### **Channel Edit window**

The **Channel Edit** window is used to enter the channel spacing and RAN settings. Channels can have a single RAN or use multiple encode/decode tables.




Figure 56.9: Channel Edit Window

#### **NEXEDGE System configuration** 56.13

#### 56.13.1 **NEXEDGE System configuration type 1 - No signaling with RAN**

Kenwood offers a system configuration that does not use signaling. This means there is no group talk and the distinguishing element between sites is the RAN (refer to the Figure below).




Figure 56.10: Set Up without Signaling

### System configuration features (supported)

- Static Line PTT
- Conference Calls
- Radio Status Request
- Radio Status Decode
- Radio Fnable
- Radio Disable
- **Emergency Decode**
- **Emergency Acknowledgement**



### Notice!

In the NEXEDGE Conventional system, Emergency call can be sent out either on a Talk Group or a Unit ID. However, when the talk group isn't used in the NEXEDGE system, in order to receive an emergency call, the radio has to be configured to send out the emergency call to a Unit ID which is a Console ID.

### **System configuration**

As seen in the Figure above, there are four sites with four different frequencies and four different RANs. C-Soft must be configured properly in order to interact correctly with the system. The number of lines must match the number of RANs. Radios should be configured as shown in the Figure below and lines should be configured as shown in the afterwards Figure.

### Radio configuration




Figure 56.11: No Signaling Radio Configuration



When setting the NXDN Signal ID to none, the Talk Group Number must be set to zero within C-Soft.

### **C-Soft configuration**




Figure 56.12: No Signaling C-Soft Configuration

### **RAN** configuration



#### Notice!

Since there are multiple RANs for the Talk Group 0, these do not show up on the Global RANs page.

The No Signal System Type does not support Unit Calls. Send Status and Request Status are the only radio commands supported in this configuration option.




Figure 56.13: Repeater Configuration Multiple Encode/Decode Tables




Figure 56.14: Multiple Encode/Decode Table

## 56.13.2 NEXEDGE System configuration type 2 - Signaling without RAN

The second system configuration uses only talk groups and no RANs. This configuration uses talk groups as the distinguishing factor between the different lines (refer to the Figure below).




Figure 56.15: Signaling Set Up

### System configuration features (supported)

- Static Line PTT, Group PTT, Private Call PTT
- Conference Calls
- Private Call
- Alert Call
- Selectable Talk Group
- Emergency Call Decode with Acknowledgement Capabilities
- Radio Status Request
- Radio Status Decode
- Radio Status Encode
- Radio Remote Monitor with Supervisor Password
- Radio Stun
- Radio Revive

### **Radio configuration**

Radios in this system configuration are configured similar to the Figure below.




Figure 56.16: Radio Signaling Configuration

### **C-Soft configuration**

C-Soft in this configuration is configured similar to the Figure below.




Figure 56.17: C-Soft Signaling Configuration

The RAN is set to zero, which is the same as None on the repeater.

### 56.13.3 NEXEDGE System configuration type 3 - Signaling and RAN

This system configuration type allows use of talk groups and RANs. This configuration allows for both the talk group and the RAN to be distinguishing factors. The lines have to match from the Radio Configuration and C-Soft to receive the call (refer to the Figure below).




Figure 56.18: Signaling and RANs Setup

### System configuration features (supported)

- Static Line PTT, Group PTT, Private Call PTT
- Conference Calls
- Private Call
- Alert Call
- Selectable Talk Group
- Selectable Users
- Emergency Call Decode with Acknowledgement Capabilities
- Radio Status Request
- Radio Status Encode
- Radio Remote Monitor with Supervisor Password
- Radio Stun
- Radio Revive
- Enhanced interference mitigation

### **Radio configuration**

Using the Figure below, configure the Radios.




Figure 56.19: Signaling with RANs Radio Configuration

In this configuration, the global RANs list populates the talk groups. Talk groups can only have one RAN associated with them. This configuration requires the repeater to be configured correctly with each repeater having the corrected decode and encode tables.




Figure 56.20: Signaling with RANs Configuration

# **NEXEDGE System manager parameters**

For C-Soft to function properly the values set in the console must match the programming parameters in the Kenwood Trunking System.




### Notice!

The KPG-110SM application and system key file are required to access the configuration settings for the system. The values set in the console, such as Site Number, Unit ID Number, Network Category, System Code, Network Category, and Channel Spacing, must match the programming parameters in the Kenwood trunking system.

To configure the Kenwood KPG-110SM radio for use with C-Soft, do the following:

1. Open the KPG-110SM System Manager.

2. From the Edit menu, select **System Configuration**.




NOTE: For additional support, see KPG-110SM user manual.

## **Under System Information**

- 3. In the Control Number field, enter Control Number.
- 4. In Network Category field, enter Network Category.
- In the System Code field, enter System Code.
   IMPORTANT: The values set in the console must match the programming parameters in the Kenwood System Manager.

6. From the Edit Menu, select **Console Information**.


The Console Information window appears.



7. From the Site drop down menu, select a **Site** to be modified.

#### 8. Click the Edit button.

The Console Edit window appears.



- 9. In the UID field, enter Unit ID.
- 10. Select the Valid check box.
- 11. Under Talkpath, select the Talkpath check box.
- 12. Click Close.


# **56.15** Kenwood radio programming software

To configure Kenwood KPG-109DN software, do the following:

- 1. Open the Kenwood KPG-109DN radio programming software.
- 2. From the Edit menu, select **Channel Information**. The Channel Information window appears.

Select desired channel and click Edit.

The Channel Edit window appears.



From the Channel Spacing (NXDN) drop down menu, select **Spacing**.



#### Notice!

Channel spacing values must match C-Soft console settings.

The NEXEDGE system allows maximum of 10 console connections per site and 100 console connections per system.

For additional support, refer to the Kenwood KPG-109DN user manual.

#### 56.16 **NEXEDGE Encryption window**

The NEXEDGE Encryption window is used to store up to 16 individual encryption keys, as shown in the second Figure. Each Key Number contains Key Data, Key ID, and Key Name, all of which need to contain unique data.

To open the NEXEDGE Encryption window from the Edit menu, do the following:

From the Edit Menu, select Setup NEXEDGE | Global Encryption Key Data.



To open the NEXEDGE Encryption window from the Per Line Parameters window, do the following:

- 1. From the menu bar, select **Edit | Setup Per Line Parameters**. The Per Line Parameters window appears.
- 2. On a line with a NEXEDGE line type, click the **Signal Setup button**. The Signalling Parameters Window appears.
- Click the NEXEDGE Trunking Parameters tab.
   The NEXEDGE Trunking Parameters page appears.
- 4. Click the **Global Encryption Key Data button** in the bottom right of the page. The NEXEDGE Encryption window appears.




Figure 56.21: NEXEDGE Encryption Window

### **Key Number column**

The Key Number column is a numerical assignment of the Key Data, Key ID, and Key Name Columns.

# **Key Data column**

The Key Data column is used to enter a unique encryption number used in the encryption algorithm routine. This field must be entered first when filling out the NEXEDGE Encryption window.

The range for this field is 1 to 32767.

## **Key ID column**

The Key ID column is used to enter an unique numerical alias for the Key Data. the Key ID is the actual data passed between the console and subscriber units, not the Key Data

The range for this field is 0 to 63.

## **Key Name column**

The Key Name column is used to enter a local alias associated for the console operator to recognize in the C-Soft Runtime application.

This field can be any combination of letters, numbers, or special characters up to 14 characters.

## **Encryption Mute Type drop down menu**

The **Encryption Mute Type** drop down menu is used to select the way encrypted audio is received by C-Soft when the Scrambler/Encrypt Key Select is set to None.

Available options are:

- Type 1: The console tries to match the encrypted audio received by scanning and matching the Key ID with the Key IDs created in C-Soft. If no match is found, the scrambled audio is heard.
- Type 2: The console does not scan the list and mutes all encrypted receive audio.

# 56.17 Scrambler/Encrypt Key Select button

The **Scrambler/Encrypt Key Select** button, shown in the Figure below, is set up to work with a specific line or as a global button to work with the selected line. This button includes a drop down menu that the user to change the current encryption key being used on the line.

The drop down menu includes the Key Names assigned in the NEXEDGE Encryption window.



## Notice!

The Scrambler/Encrypt Key Select button only works for NEXEDGE type lines, otherwise, it is grayed out.



Figure 56.22: Scrambler/Encrypt Key Select Button

# 57 Appendix I - Telex License Activation tool

C-Soft Runtime requires one or more software-based licenses to operate. The software-based licenses reside on a Telex License Server. The Telex License Server hosts and manages Telex feature licenses. C-Soft connects to the Telex Licensing Server to validate licensing requirements. Upon successful connection, C-Soft checks out the necessary licenses. Once C-Soft closes, the licenses are released and available for use by other C-Soft instances.

## **Telex Licensing Server**

The **Telex Licensing Server** is software package running on a PC or dedicated server. The primary function of the software is to maintain licenses and respond to licensing requests from C-Soft. When a license is added, the Telex Licensing Server detects the newly added license and makes it available for C-Soft license checkout/check-in request.

Telex License Server is comprised of two software components:

- Telex License Manager: The Telex License Manager is a background service running on the hosting computer. The License Manager maintains and responds to licensing requests from C-Soft. The service automatically starts on boot, and requires no user interaction.
   The service uses TCP port 27000 to respond to licensing requests from C-Soft.
- Telex License Activation Tool: The Telex Activation Tool is used to manage hosted Telex licenses. The Activation Tool has five primary features:
  - Viewing current licensing information
  - Adding a fulfillment
  - Returning a fulfillment
  - Repair fulfillments
  - Processing a fulfillment response message

# 57.1 Telex Licensing Server setup

The **Telex Licensing Server** can be installed in one of two locations:

- On the same PC as each C-Soft position
- On a dedicated server PC, hosting licenses for multiple C-Soft positions

## Installed on the same PC as each C-Soft position

Advantages	<ul> <li>No single point of failure.</li> <li>No configuration necessary in C-Soft. C-Soft Runtime automatically detects and check out locally hosted licenses.</li> </ul>
Disadvantages	License activation process must be completed for each PC running C-Soft

## Installed on a dedicated server PC

Advantages	If a single C-Soft position fails, a     replacement C-Soft position can be     configured without an additional license
	installation.

	<ul> <li>License activation process only needs to completed once.</li> </ul>
Disadvantages	If server PC fails, all C-Soft positions lose licensing.

# 57.2 Installation activation




Figure 57.1: Installation Activation Flow Diagram

# To activate purchased licenses, do the following:

- 1. Upon purchase of a feature, an e-mail is sent containing an **Entitlement Certificate**. The **Entitlement Certificate** contains a list of purchased features and an **Activation ID**.
- 2. On the target PC, install **Telex License Server**. Refer to "*Telex License Server setup, page 31*".
- 3. Once installed, launch the **Telex License Activation Tool**. Refer to the figure on "*View current licensing information, page 587*".
- 4. From the Telex Activation Tool, click the **Add Fulfillment button**.
- 5. In the Add License window, input contact information, as well as one or more **Activation**IDs received from the Entitlement Certificate. Refer to "Appendix I Telex License Activation tool, page 585".
  - A Fulfillment Request Message (Request.xml) is created.

## If an Internet connection is available:

- Select the **Online tab**.
   The Online Page appears.
- 2. Enter your System Activation Website Username and Password.
- Press the Activate Licenses button.
   The features granted by the license are now available.

### If an Internet connection is not available:

The Offline page appears.

2. Press the **Create request** button.

A prompt appears to save the Fulfillment Request Message (with default name Request.xml).

- 3. Visit the System Activation Website and use the **Manage License** feature.
- 4. Click the Browse button.
- 5. Select the newly created **Fulfillment Request Message**.
- 6. Click Activate.

A prompt appears to save the Add Fulfillment Response Message (RequestResponse.xml).

- 7. From the Telex License Activation Tool, select the **Process Response Message** feature. Refer to "*Process Response Message*, page 591".
- Select the Add Fulfillment Response Message file.
   The features granted by the license are now available.

#### Refer to

- Telex License Server setup, page 31
- View current licensing information, page 587
- Appendix I Telex License Activation tool, page 585
- Process Response Message, page 591

# 57.2.1 View current licensing information

The Telex License Activation Tool displays the computer's current license information. The left panel contains a list of Fulfillment IDs added. The right panel contains a table listing all licensed features, including quantity, order number, activation date, and expiration date of each feature.

Figure 57.2: Telex Activation Tool

## 57.2.2 Add Fulfillment

**Add Fulfillment** is used by the customer or dealer to add a Fulfillment from an Activation ID, which is contained within an Entitlement Certificate.

The window displays customer information fields (Location name, Customer name, Address, City and Email) for the user to fill in when adding a Fulfillment. The window also displays a field to enter an Activation ID, and a list of entered Activation IDs, if the user wishes to enter multiple Activation IDs in the same transaction.




Figure 57.3: Telex Activation Tool - Add License Window.



# Notice!

The Location Name field must be different for each position install at any single location.

To add a fulfillment, do the following:

1. From the Telex License Activation window, select Add Fulfillment.

The Add license window appears.

#### Under Customer information



#### Notice!

The Location Name field must be different for each position install at any single location.

- 1. In the Location name field, enter the location of C-Soft deployment.
- 2. In the Customer name field, enter the name of the customer.
- 3. In the Address field, enter the customer's address.
- 4. In the City field, enter the **customer's city**.
- In the Country field, select the **customer's country**.

#### **Under Activation information**

#### If an Internet connection is available:

- Select the Online tab.
  - The Online Page appears.
- Enter a **User Name** and **Password** for the dealer site.
- Click the **Activate Licenses** button.

The Telex License Activation Tool attempts to connect to the System Activation Website and execute the entire License Activation process. When finished, the license is activated and ready for use.

## If an Internet connection is not available:

- Select the Offline tab. The Offline page appears.
- 2. Click the Create Request button.

An Activation Request file is generated. The Activation Request file must be processed using the Dealer Activation website. Refer to the Process Response section for instructions on how to complete the manual licensing operation.

#### **Return Fulfillment** 57.2.3

Return Fulfillment is used by the customer or dealer to remove a Fulfillment currently licensed to the PC and returns the license to the dealer's available license pool. A list of available licenses can be found at the Bosch Dealers Activation website.

#### To **return a fulfillment**, do the following:

From the Telex License Activation window, select the **fulfillment** you want to return. The Return Fulfillment button is enabled.

## If an Internet connection is available:

- 1. Select the Online tab. The Online Page appears.
- Enter a User Name and Password for the dealer site.
- Click the Return Fulfillments button.

The Telex License Activation Tool attempts to connect to the System Activation Website and execute the License Return process.



#### Notice!

Once the Return Fulfillment process has been initiated, all licenses associated with the selected fulfillment are no longer available for license checkout.

#### If an Internet connection is not available:

- Select the **Offline tab**.
   The Offline page appears.
- 2. Click the **Create Request** button.

A Return Request file is generated. The Return Request file must be processed using the Dealer Activation website. Refer to the Process Response section for instructions on how to complete the manual licensing operation.

## 57.2.4 Repair

**Repair** is used by the customer or dealer to re-establish the validity of fulfillments licensed to the server. The Repair License button only appears if the license has been corrupted or tampered with.

## To **return a fulfillment**, do the following:

1. From the Telex License Activation window, select the **fulfillment** you want to return. The Return Fulfillment button is enabled.

# If an Internet connection is available:

- Select the Online tab.
   The Online Page appears.
- 2. Enter your Credentials.
- 3. Click the Return Fulfillments button.

The Telex License Activation Tool attempts to connect to the System Activation Website and execute the License Repair process.

## If an Internet connection is not available:

- Select the **Offline tab**.
   The Offline page appears.
- 2. Click the Create Request button.

A Repair Request file is generated. The Repair Request file must be processed using the Dealer Activation website. Refer to the Process Response section for instructions on how to complete the manual licensing operation.

# 57.2.5 Process Response Message

The **Process Response Message** is used to complete an offline Add Fulfillment, Return Fulfillment, or Repair Fulfillment operation. Pressing the Process Response Message button opens the Process Response Message Window.

Figure 57.4: Offline Response Window

The Process Response Window contains a field used to select an Add Fulfillment Response Message (RequestResponse.xml), Return Fulfillment Response Message (ReturnResponse.xml), or Repair Response Message (RepairResponse.xml). After selecting one of these files, pressing the Process Response Message button completes the transaction.

- Add Fulfillment Response Message: If processing an Add Fulfillment Response Message, a
  fulfillment is added to the Fulfillment list, and the newly licensed features appear in the
  list of licenses. The newly added features are available for C-Soft license checkout
  requests.
- Return Fulfillment Response Message: If processing a Return Fulfillment Response
  Message, the specified fulfillment is removed from the Fulfillment list and all licenses
  associated with it are removed from the list. The removed features are no longer available
  for C-Soft license checkout requests.
- Repair Response Message: If processing a Repair Response Message, all fulfillments are validated and made available for C-Soft license checkout requests.

# 58 Appendix J - DMR-AIS

The AIS (Application Specification Interface) protocol was developed by DMR (Digital Mobile Radio) association to standardize the interface between a third party application such as dispatch console and DMR radio system. As a DMR member, Bosch implemented the AIS standard in C-Soft dispatch console application to fully comply with the DMR Tier II Conventional and DMR Tier III Trunking systems via wireline connection. This implementation provides the flexibility for users to install and operate DMR radio communication systems. Unlike other console manufactures, the C-Soft AIS implementation requires no dedicated server nor gateway. Each console on a DMR network will act like a digital radio subscriber. This advanced architecture provides system reliable and transparency, enhances operation, and reduces the system cost.

# 58.1 Supported features

The C-Soft DMR-AIS interface currently supports the following feature set:

- Displays ANI and/or Alias of incoming calls
- Send and Receive Group Calls
  - Group Call is sent by selecting corresponding Frequency button and then pressing either InPTT or Main PTT button.
  - The Group Call type (Broadcast Call or Conference Call) can be controlled by using the Radio Call Type button.



#### Notice!

For Hytera DMR AIS interface, system All Call can be sent by configuring a group with a group ID of 16777215 for Conventional systems.

- Send and Receive Individual Calls
  - Individual Call is sent by selecting the corresponding Frequency button and then pressing either InPTT or Main PTT button.
  - Individual calls can be made by selecting or entering a user in the Keypad and then pressing the Private PTT button.
- Receive Emergency Notifications
  - Supports receiving both Emergency Calls and Emergency Alerts.
- Send and Receive Call Alerts
  - Call Alert is sent by selecting a user from the Keypad control and then clicking the Radio Call Alert button.
  - Call Alerts can only be sent on lines configured for Individual operation.
- Send and Receive Text Messages
  - Text Message is sent by selecting a user from the Keypad control and then entering the desired text into the Text Message Control. The message is sent when the Send button in the Text Message Control is clicked.
  - Text Message can be sent to a group by selecting the line and group and then entering the desired text into the Text Message Control. The message is sent when the Send button in the Text Message Control is clicked.

- Send Radio Enable / Disable Commands
  - Radio Enable/Disable commands is sent by selecting a user from the Keypad control and then clicking either the Radio Enable or the Radio Disable button.
  - Radio Enable/Disable commands can only be sent on lines configured for individual operation.

### Send Radio Check Command

- Radio Check command is sent by selecting a user from the Keypad control and then clicking either the Radio Check button.
- Radio Check Command can only be sent on lines configured for Individual operation.

#### Send Remote Monitor Command

- Remote Monitor command is sent by selecting a user from the Keypad control and then clicking either the Radio Check button.
- Remote Monitor command can only be sent on lines configured for Individual operation.

### Console Priority

- The Call Priority button can be created to set transmit priority level for each outbound call.
- Vocoder Support
  - C-Soft supports DMR standard AMBE+2 vocoder.
- GPS Support
  - GPS currently is not a part of DMR AIS standard. However, Telex has worked with other repeater manufactures to support their specific GPS data format.
  - The following GPS features are available in C-Soft:
     GPS Read (Standard Location Immediate Request)
     GPS Trigger (Toggle On/Off for Location Reporting)
     Incoming GPS Data triggered from Emergency Alarm
     Incoming GPS Data triggered from Emergency Call
     GPS data during voice calls



#### Noticel

Specific GPS supported functions vary depending on DMR repeater.

- Supports connection to up to 20 AIS compatible repeaters
  - Each repeater connection is configured with a name, IP Address, System Type (e.g. Conventional or Trunking), Vendor, Connection Port, Authentication Password, and Registration interval.
- Supports up to 24 AIS Interface lines
  - Each AIS Interface line connects to a specific repeater. The line configured with a Connection, Type (Group or Individual), and a list of affiliated Group or Individuals. Lines connected to a conventional repeater also use a time slot configuration.


- Each line can be configured to accept audio from one to 100 talkgroups.
- Indication of parallel console transmissions
  - Parallel Consoles are configured in C-Soft Designer by going to Edit | Setup Global Parameters | Local Consoles and entering the Subscriber IDs of the parallel consoles in the Direct IP Console Subscriber IDs field.
  - Calls initiated from parallel dispatch consoles display the 'T' icon on the receiving line's Select button.
- Crossmuting of parallel consoles
  - Calls from parallel consoles can be automatically muted by enabling the Crossmute direct IP console subscriber IDs field in Edit | Setup Global Parameters | Local Consoles
  - When this option is enabled calls initiated from parallel dispatch consoles display the 'XT' icon on the receiving line's Select button.
- Send Annunciations
  - Send audio from the .wav file on an AIS line using the Annunciation button.
- Crosspatching
  - Crosspatch audio from an AIS line to another line type supported by C-Soft.



### Notice!

The supported features for DMR AIS interface might vary depending operation modes and DMR manufacturer's specifications. Please check the manufacturer's manual and additional application notes for more information.

# 58.2 AIS Global Setup window



### **Global Settings group box**

# **Console ID field**

The Console ID field is used to enter the identification number assigned to the console.

The range for this field is 1 to 16777215 in decimal format.

# **Call Inactivity Timeout field**

The **Call Inactivity Timeout** field is used to enter the amount of time in seconds allowed to elapse with no voice traffic before the console terminates the call. before the console terminates the call. This value should be set to approximates two seconds greater then the AIS repeater's call inactivity timeouts.

The range for this field is 1 to 100 seconds.

## **Connection List group box**

#### Name column field

The **Name** column field is used to enter a unique name for the connection.

This field can contain up to 32 characters.

#### **IP column Field**

The **IP** column field is used to enter the IP Address of the connection being used to communicate.

#### System column drop down menu

The **System** column drop down menu is used to select the type of system the connection is running. There are three service tiers - Tiers I, II, and III. Tiers I and II are considered Conventional systems, where Tier II is only applicable for commercial radio markets. Tier III is classified as a trunking system. A trunking system uses a control channel to direct radio traffic automatically whereas the radio user manually directs a conventional system. Available options are:

- Conventional
- Trunking

#### Vendor column drop down menu

The **Vendor** column drop down menu is used to select the vendor of the system the connection is running. This setting allows the console to perform any logic or functionality that is unique to a specific radio system vendor.

The options available for this list are dependent on the currently selected System type. Available option for a system type of Conventional:

- Generic

Available options for a system type of Trunking:

- Generic
- Leonardo

#### **Connection Port field**

The **Connection Port** field displays the port number used by C-Soft to connect to the AIS repeater. The connection port need to match the port number used by the DMR-AIS system. The default value for this field is 5060.

#### Password column field

The **Password** column field is used to enter the password configured as the Authentication Password. When the field is left empty, the system does not require a password to register.

This field can contain up to 32 alpha numeric characters.

## Heartbeat (sec) column field

The **Heartbeat (sec)** column field is used to enter the length of time, in seconds, a console can be registered to the server without reregistering. This field can be used to monitor the network connection between C-Soft and the repeater.


The range for this field is 10 to 65535 seconds.

# 58.3 C-Soft Designer setup

To configure C-Soft Designer, do the following:

1. Open C-Soft Designer v7.300 or later.

From the Edit menu, select **Setup AIS**.
 The AIS Global Setup window appears.



3. In the Console ID field, enter the console ID.

**IMPORTANT**: Each console must have a unique ID.

4. In the Call Inactivity Timeout field, enter **amount of time, in seconds, allowed to elapse** with no voice traffic before the console terminates the call.

**NOTE**: This value should be set to approximately two seconds greater than the AIS repeater's call inactivity timeouts.

5. In the Connection List:

In the Name field, enter a **unique name** that is easily identifiable.

In the IP field, enter the IP Address of repeater configured earlier.

From the System drop down menu, select Conventional or Trunking.

From the Vendor drop down menu, select Generic unless connecting to a Leonardo Trunking system.

From the Connection Port drop down menu, select the connection port to use. 5060 is the default setting; however individual systems may require different orts depending on their configuration.


In Password field, enter the **password configured as the Authentication Password**, if applicable.

In the Heartbeat field, enter the **length of time** a console can be registered to the server without re-registering.


- 6. Click OK.
- 7. From the Edit Window, select **Setup Per Line Parameters**.

The Per Line Parameters window appears.

8. From the Line Type drop down menu, select **AIS** for the desired line.



9. Click the **Signal Setup button** for that line.



- 10. From the Connection drop down menu, select the **desired repeater**.
- 11. If the connection is configured as a conventional system, select **Slot 1** or **Slot 2** from the Slot drop down menu.

**NOTE**: A DMR conventional repeater supports two independent time slots, which function as channels. This field is disabled if the connection is configured as a Trunking system.

12. From the Type drop down menu, select **Group** or **Individual**.

**IMPORTANT**: Group lines can be used to transmit to and receive calls from DMR Talkgroups as well as receive and send group text messages. Individual lines can be used to transmit and receive individual calls, and send individual radio command operations. Individual radio command operations cannot be sent on Group lines.

In the Talkgroup List group box, enter one or more group contacts.

OR


Enter one or more individual contacts.

The contacts in the list are mapped to frequency numbers which are selected by the Frequency controls in C-Soft.

14. Click **OK**.

The Per Line AIS Setup window closes.


15. From the Edit menu, select **Setup Global Parameters**. The Global Parameter Setup window appears.



- 16. Click the Local Consoles tab.
  - The Local Consoles page appears.
- 17. In the Local Console IP Addresses group box, enter the **subscriber IDs** of the parallel consoles in the Direct IP Console Subscriber IDs field.
- 18. Select the **Crossmute direct IP console subscriber IDs check box** if parallel console transmit audio should not be heard on the other parallel consoles.

19. From the Edit menu, select Edit User ID List.

The User ID List window appears.




- 20. In the Name field, enter the name of the individual radio in the DMR system.
- 21. In the User ID field, enter the user ID of the individual radio in the DMR system.
- 22. From the Type drop down menu, select AIS.
  The User ID List is used to alias IDs for incoming calls and to populate the Keypad control.
- 23. Repeat step 20 through step 22, as necessary.
- 24. Click **OK**.

The User ID List window closes.

25. From the Edit menu, select Edit Group ID List.

The Group ID List window appears.



- 26. In the Group field, enter the name of the talkgroup in the DMR system.
- 27. In the Group ID field, enter the group ID of the talkgroup in the DMR system.
- 28. From the Type drop down menu, select AIS.
  The Group ID List is used to alias IDs for incoming calls and to populate the Keypad control.
- 29. Click **OK**.

The Group ID List window closes.

30. Save the .veg file.



# Notice!

Verify the Console ID and Group IDs are entered correctly because C-Soft registers its Console ID and all Talk Groups when it starts up.

# 59 Appendix K - C-Soft API Installation notes

API functionality allows third party applications to connect securely to C-Soft. This API allows external applications to exchange data and provide limited control of C-Soft.



#### Notice!

The API functionality is a value added option to you C-Soft license, please contact your regional Bosch Sales person for details on how to purchase.

# 59.1 Supported features

- Secured connection with user authentication
- 256-bit AES data encryption
- Main PTT
- Line PTT
- Private Call
- Group Call
- Line Selection
- Multiple Line Selection
- Channel/Talkgroup Selection (Frequency Control Only)
- Paging Functions (Single, Stack Pages)
- Remote Monitor (Covert Call)
- Crosspatch
- GPS Integration
- Event Notifications
- Private Call Acknowledgement
- Incoming Private Call Notification
- Emergency
- Connection Monitor (Heartbeat)
- Select Call
- Radio Call Status
- Relay/Input support
- SIP support

# 59.2 Setup External Systems window

# **59.2.1** API Setup




Figure 59.1: API Setup Window

#### **Enable API checkbox**

The **Enable API** checkbox is used to enable the API functionality in C-Soft. If this checkbox is not selected, the functionality of the API is completely disabled.

### **IP Address field**

The **IP Address** field is used to enter the IP Address of the 3<sup>rd</sup> party system. This is the IP Address that communicates with C-Soft. When a 3<sup>rd</sup> party system connects to C-Soft, C-Soft confirms the address before connecting to the address.



## Notice!

This address must match exactly between C-Soft and the 3<sup>rd</sup> party system.

## **TCP Port field**

The **TCP Port** field is used to enter the port number that C-Soft attempts to connect and communicate to the 3<sup>rd</sup> party system. If this does not match the 3<sup>rd</sup> party system's settings, communication cannot occur.

#### **Username field**

The **Username** field is used to enter the username used by the 3<sup>rd</sup> party system to log into C-Soft. If the 3<sup>rd</sup> party system does not have the correct username, communication fails.

#### Password field

The **Password** field is used to enter the password used by the 3<sup>rd</sup> party to log into C-Soft. If the 3<sup>rd</sup> party system password does not match, communication fails.

# **Encryption Key Field**

The **Encryption Key** field is used to enter or generate a 256-bit encryption key that is used to encrypt communications between C-Soft and the 3<sup>rd</sup> party system. This key must match exactly in both C-Soft and the 3<sup>rd</sup> party system or decryption fails and encryption cannot be used.

#### **Generate Key button**

The **Generate Key** button is used to generate a random encryption key. This key must match exactly in both C-Soft and the 3<sup>rd</sup> party system or decryption fails.

#### **OK button**

The **OK** button is used to accept the modifications and close the API Setup window.

#### **Cancel button**

The **Cancel** button closes the API Setup window without saving the modifications.

#### 59.2.1.1 API Setup window

To set up an API connection, do the following

- From the Edit menu, select Setup External System.
   The Setup External Systems window appears.
- 2. Navigate to the API Setup page.
- 3. Select the Enable API check box.
- 4. In the IP Address field, enter the **IP Address of the 3rd party system** communicating with C-Soft.
- 5. In the TCP Port field, enter the **port number** C-Soft attempts to connect and communicate with the 3<sup>rd</sup> party system.
  - **NOTE**: If the port number entered in this field does not match the 3<sup>rd</sup> party system's settings, communication cannot occur.
- 6. In the User Name field, enter the **username** the 3<sup>rd</sup> party system uses to log on to C-Soft. If the 3rd party user name does not have the correct username, communication cannot occur.
- 7. In the Password field, enter the **password** the 3<sup>rd</sup> party system uses to log into C-Soft. **NOTE**: The password can be anything, but the 3rd party system must use the same exact password for logging in. If the password does not match communication will fail.
- In the Encryption Key field, enter the **encryption key** to be used.

Click the Generate Key button.

An encryption code appears in the Encryption Key field.



# Notice!

The encryption key is an AES 256-bit key. C-Soft can generate the key or a key can be manually entered. This key must match on the 3<sup>rd</sup> party system and must be a valid AES 256-bit key. If the encryption key is not valid, decryption fails and the functionality cannot be used.

# 60 Appendix L - End user license agreement



Bosch Security Systems, LCC.
Telex Radio Dispatch Products
End User Software License Agreement
8601 E. Cornhusker Highway
P.O. Box 5579
Lincoln, Nebraska 68507, USA
Tel. +1 402 467 5321
Fax +1 402 467 3279
www.telex.com

### Important information

PLEASE READ THIS END USER LICENSE AGREEMENT (THE "LICENSE") CAREFULLY BEFORE OPENING THE PACKAGE AND/OR USING THE CONTENTS THEREOF AND/OR BEFORE DOWNLOADING OR INSTALLING THE SOFTWARE PROGRAM. IF YOU DO NOT AGREE TO THIS LICENSE DO NOT OPEN THE PACKAGE AND/OR DOWNLOAD AND/OR INSTALL THE SOFTWARE AND PROMPTLY (AND IN ANY EVENT, WITHIN 7 DAYS FROM THE DATE YOU RECEIVED THIS PACKAGE) RETURN THE SOFTWARE WITH THE ORIGINAL PACKAGE TO BOSCH, ERASE THE SOFTWARE, AND ANY PART THEREOF, FROM YOUR COMPUTER AND DO NOT USE IT IN ANY MANNER WHATSOEVER.

Bosch Security Systems, LCC. ("Bosch") licenses the software comprised in the Telex Radio Dispatch Products (each, together with associated documentation, the "Software") for the nonexclusive use by the end user (the "Licensee"). Licensee has read this License, and Licensee understands, accepts and expressly agrees to abide by all the terms, provisions and conditions of this License.

#### License of software

Under the terms of this nonexclusive and nontransferable License:

1.

Licensee may use a machine-readable form of the Software on a single computer or a single server at a time and only for the operation of Bosch products. Licensee may not and shall not (A) use the Software except as expressly authorized in this License and in the User Documentation; (B) sell, sub-license, lease, rent, assign, pledge, or otherwise transfer, make available or share Licensee's rights under this License with any party or entity; (C) modify, translate disassemble, decompile, reverse engineer, revise or enhance the Software or attempt to discover the Software's source code or create derivative works thereof; or (D) install the Software onto a server so that it is accessible via a public network.

#### 2.

This License does not convey to Licensee an ownership interest in or title to the Software, in whole or in part, but only the right to use the Software in accordance with the terms of this License. Nothing in this License constitutes a waiver of Bosch's intellectual property rights under any law.

#### 3. Open Source Software

The Software contains certain software components that are licensed by Bosch from various open source distributors (individually and collectively, the "Open Source Software"), and redistributed by Bosch to Licensee in accordance with the provisions of the open source licenses governing the Open Source Software (each, the "Open Source License"). The Open Source Software and applicable Open Source Licenses are listed in Schedule A to this License. The source code is available for a period of 12 months after our last shipment of this product and can be requested by sending an email to: open <u>source</u>-

<u>request@telexradiodispatch.com</u>. Please add "C-Soft Open Source Code" in the memo line of your message. Only Mozilla Public License open source inquiries/requests will be responded to via this email address.

### A. No Support of Open Source Software

Licensee acknowledges and agrees that the Open Source Software is sublicensed by Bosch to Licensee without support from Bosch. Licensee additionally understands and acknowledges that the open source licenses governing the Open Source Software offer few, if any, warranties.

## B. Open Source Rights; Restrictions on Use of Software

Licensee may use, modify, link, distribute the Open Source Software to the full extent permitted under the applicable Open Source License; provided that Licensee will not incorporate, link, distribute or use any third party software or code in conjunction with the Software in any way that (i) creates any obligation with respect to the Software, including the obligation to disclose or distribute its source code; or (ii) grants to any third party any rights to the Software. Without limiting the generality of the foregoing, Licensee will not incorporate, link, distribute or use the Software with any code or software licensed under the GNU General Public License ("GPL"), Lesser General Public License ("LGPL"), Mozilla, or any other Open Source License, in any manner that could cause the Software (or any modifications thereto) to become subject to the terms of the GPL, LGPL, Mozilla or such other Open Source License. Licensee, and any other third party receiving the Software or any copies thereof, do not and will not receive any right to use the Software or copies thereof in a manner that will cause any patents, copyrights or other intellectual property rights that are owned or controlled by Bosch or any of its Affiliates to become subject to any encumbrance or terms and conditions of any third party or Open Source License. These restrictions, limitations, exclusions and conditions will apply even if Bosch becomes aware of or fails to act in a manner to address any violation or failure to comply therewith. Also, no act by Bosch will be construed as inconsistent with the intent not to cause any intellectual property rights that are owned or controlled by Bosch or any of its affiliate to become subject to any Open Source License. For clarity and the avoidance of doubt, the restrictions set forth in this Section 1.3(B) are not intended and shall not be construed to apply to the Open Source Software.

## 4.

This License will terminate automatically if Licensee fails at any time to comply with any of its terms or conditions.

#### 5.

Licensee may terminate this License at any time by returning the Software to Bosch and complying with the terms of Section 1.6 below.

#### 6.

Except as expressly stated in this License, Bosch has no obligation to provide support, maintenance, upgrades, modifications, or new releases of the Software.

#### 7.

Upon any termination of this License, Licensee shall immediately return the Software to Bosch, or destroy all items of the Software and delete same from Licensee's hardware. After termination of this License, Bosch will not provide any further support for the Software.

#### 8.

The Software, including the AMBE® voice coding technology (the "Technology") embedded therein, is protected by intellectual property rights including patent rights, copyrights, and trade secrets of Digital Voice Systems, LCC. The Technology is licensed solely for use within the Software without further modification. The user of the Software is expressly prohibited from attempting to decompile, reverse engineer, or disassemble the Object Code, or in any other ways convert the Object Code into human-readable form. U.S. Pat. Nos. #5,870,405, #5,826,222, #5,754,974, #5,701,390, #5,715,365, #5,649,050, #5,630,011, #5,581,656, #5,517,511, #5,491,772, #5,247,579, #5,226,084 and #5,195,166.]

### Ownership and propriety rights; No implied rights

The Software is owned and copyrighted by Bosch and/or its suppliers. Except for the rights expressly granted herein, no rights whatsoever are granted to or implied in favor of Licensee. Bosch and its suppliers retain all rights to the Software, including, without limitation, all right, title and interest in or to all copyright, patent, trade secret, and other intellectual and proprietary rights therein, and any copies thereof, in whole or in part, all of which are the valuable property of Bosch and/or its suppliers. Licensee may not remove, change, or delete the copyright notice from the Software. Licensee will instruct its employees and others having access to the Software in, and ensure their compliance with the terms of, this License. Licensee shall use its best efforts to prevent any unauthorized copying of the Software. Licensee shall be responsible for any breach of any provision of this License by Licensee's employees. Licensee shall not sell, transfer, publish, disclose, commercially exploit or otherwise make available, the whole or any part of the Software, or any copies thereof, to any third party or persons not permitted by the terms of, and pursuant to the terms contained in this License and each applicable Open Source License. Licensee shall not be not in violation of this License, including this section, when a third party views the functional output resulting from Licensee's use of the Software.

### Software key

Licensee understands, acknowledges and agrees that, in order to use the Software and receive the benefit of the Software's functionality, Licensee must utilize the applicable Software key made available by Bosch to purchasers of the Telex Radio Dispatch-IP Console (each, the "Software Key"). Licensee understands that a specific Software Key must be used for each of C-Soft and the Network Recorder Application.

# 1.

Licensee may not and shall not (A) use the Software Key except as expressly authorized in this License and User Documentation (B) sell, sub-license, lease, rent, assign, pledge, or otherwise transfer the Software Key; (C) modify, disassemble, decompile, reverse engineer, revise or enhance the Software Key or create derivative works thereof.

#### 2.

Licensee acknowledges and agrees that its rights to the Software Key are subject to the intellectual property rights of Bosch and/or third parties. This License does not convey to Licensee an ownership interest in or title to intellectual property rights associated with the Software Key Nothing in this License constitutes a waiver of intellectual property rights of Bosch or any third party with respect to the Software Key.

#### **Taxes**

The License Fees for the Software is exclusive of all applicable federal, state, provincial and local taxes including, without limitation, sales, use, property, value added, goods and services, excise, and similar taxes, and all such taxes shall be assumed and paid by Licensee, excluding taxes on Bosch's net income. In the event that Bosch determines that any such taxes are subject to withholding requirements, Bosch may bill Licensee for such taxes, and Licensee shall promptly pay the amount billed. If any such tax for which Licensee is responsible hereunder is paid by Bosch, Licensee agrees to promptly reimburse Bosch therefor.

#### Warranty, limitation of liability, remedies

#### 1.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND INCLUDING A WARRANTY THAT THE SOFTWARE IS ERROR FREE OR WILL RUN UNINTERRUPTED, OR THAT IT IS FREE FROM INFRINGEMENT CLAIMS, ANY WARRANTY IMPLIED BY LAW, INCLUDING WARRANTY OF MERCHANTABILITY OR WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE, IS EXPRESSLY DISCLAIMED HEREBY NEITHER BOSCH NOR ITS SUPPLIERS SHALL BE LIABLE FOR ANY LOSS OF PROFITS, LOSS OF USE, LOSS OF BUSINESS, GOODWILL OR ECONOMIC OPPORTUNITY, INTERRUPTION OF BUSINESS, LOSS OF DATA, LOSS OF PROGRAMMING AND/OR PRODUCTION MATERIALS, DAMAGE TO BUSINESS REPUTATION, OR FOR INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES OF ANY KIND, WHETHER UNDER THIS AGREEMENT OR OTHERWISE. OR FOR ANY CLAIM BY ANY OTHER PARTY. Bosch does not warrant the functions provided by the Software. However, Bosch warrants the diskette or other media on which the Software is furnished to be free from material defects in materials and workmanship, under normal use, for a period of 90 days from the date of original purchase. Bosch's entire liability to Licensee, and Licensee's exclusive remedy, shall be the replacement of the diskette or other media not meeting Bosch's warranty, provided that Licensee returns the defective diskette or other media to Bosch. The replacement will be warranted for the remainder of the term of the original warranty, or 30 days, whichever is longer. Licensee acknowledges that it is solely responsible for the selection of the Software to achieve Licensee's intended results, and for the installation, use, and results obtained from the Software.

#### 2. Limited Warranty of Software Key; Remedies

Bosch warrants, for Licensee's benefit alone, that (i) the Software Key, when and as delivered to Licensee, and for a period of three years after the date of delivery (ii) will perform in all material respects in accordance with the User Documentation, provided that it is used on the computer hardware and with the operating system specified in the User Documentation; and (iii) will be in all material respects free from significant defects in materials and workmanship under normal use thereof. Use of the Software Key other than normal, which shall render this warranty void, includes misuse, tampering, modification, neglect or failure to follow Bosch instructions. This warranty additionally does not cover defects not caused by Bosch (including accidents or malfeasance while the Software Key is in transit or in Licensee's possession,

custody or control, or any defects or errors arising from any modification of the Software, including any Open Source Software, that is not made or approved by Bosch). Repairs not covered by this warranty shall be available on a time and material basis. Licensee understands, acknowledges and expressly agrees that all repair(s) and replacement(s) of a Software Key shall require the return of the original Software Key, and that lost Software Keys will not be replaced. If, at any time during the applicable warranty period, Bosch, or Licensee discovers one or more defects or errors in the Software Key or if the Software Key fails to operate in accordance with applicable specifications or is otherwise defective, Bosch's sole obligation shall be to repair or replace the defective item. EXCEPT AS EXPRESSLY STATED IN THIS AGREEMENT, BOSCH DOES NOT WARRANT THAT THE SOFTWARE KEY WILL MEET LICENSEE'S REQUIREMENTS OR THAT THE OPERATION OF THE SOFTWARE KEY WILL BE UNINTERRUPTED OR ERROR-FREE. BOSCH EXPRESSLY DISCLAIMS ALL EXPRESS WARRANTIES NOT STATED HEREIN AND ALL IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. FURTHER, NOTHING IN THIS LICENSE IS INTENDED OR SHALL BE CONSTRUED AS A WARRANTY BY BOSCH OF ANY OPEN SOURCE SOFTWARE, OR AN AGREEMENT BY BOSCH TO PROVIDE ANY SUPPORT OR MAINTENANCE WITH RESPECT TO THE OPEN SOURCE SOFTWARE: ANY SUCH WARRANTY OR AGREEMENT BEING EXPRESSLY DISCLAIMED HEREBY.

# **U.S. Government restricted rights**

Licensee will not use the Software or Software Key in any manner prohibited by applicable law, including any restrictions imposed by the United States Government. The Software is provided with restricted rights. Use, duplication, or disclosure is subject to legal restrictions of the U.S. Government as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFAR 252.227-7013, Federal Acquisition Regulation clause 52.227-19 (c) (2) Commercial Computer Software Restricted Rights, NASA clause 52.227.86 (d) Commercial Computer Software Licensing, or their successor.

## **Export control laws**

1.

Bosch's responsibility for delivery is limited to the delivery of the Software to Licensee. Bosch will not be responsible for obtaining any export licenses or reexport licenses which may be required for any subsequent shipping of the Software to destinations determined by Licensee.

2.

In the event that Licensee, or any subsequent party handling the Software after delivery by Bosch to Licensee, does export the Software then, as between Bosch and Licensee:

3.

Licensee shall be solely responsible for compliance with all applicable laws and regulations relating to such export including, but not limited to (a) export licenses or license exceptions, (b) determining correct classification at the time of export; and (c) any other regulatory agency approval requirements; and

any diversion of the Software contrary to applicable law (including but not limited to U.S. law and the law of the jurisdiction in which Licensee is located) by Licensee or any such subsequent party is prohibited, and Licensee shall be solely responsible for any diversion which is contrary to applicable law.

#### DISCLAIMER OF CONSEQUENTIAL DAMAGES

NEITHER PARTY SHALL BE LIABLE (WHETHER UNDER CONTRACT, TORT (INCLUDING NEGLIGENCE) OR OTHERWISE) TO THE OTHER PARTY FOR ANY LOSS OR DAMAGE (INCLUDING INDIRECT, SPECIAL OR CONSEQUENTIAL DAMAGES), INCLUDING, WITHOUT LIMITATION, ANY LOSS OR DAMAGE TO BUSINESS EARNINGS, LOST PROFITS OR GOODWILL AND LOST OR DAMAGED DATA OR DOCUMENTATION, SUFFERED BY ANY PERSON, ARISING FROM AND/OR RELATED WITH AND/OR CONNECTED TO DELIVERY, INSTALLATION, USE OR PERFORMANCE OF THE PRODUCT AND/OR ANY COMPONENT OF THE PRODUCT, EVEN IF SUCH PARTY IS ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

#### **Governing law**

This License shall be construed according to the laws of the State of New York and the U.S. The provisions of the United Nations Convention on Contracts for the International Sale of Goods shall not apply. Any dispute will be subject to arbitration under the rules of the American Arbitration Association and shall take place in Lincoln, Nebraska, Metropolitan area of Rochester, New York, U.S.A.

# **Entire agreement**

This License any Bosch Standard Terms and Conditions as applicable from time to time, as well as all exhibits, schedules or appendices hereto, constitutes the complete and exclusive statement of the terms hereof and supersedes all prior oral and written statements of any kind made by the parties or their representatives with respect to the subject matter hereof. Any customer purchase order or similar document issued by Licensee or subsequent shall not be part of this License and shall not add to or modify any of the terms hereof. This License may not be changed or supplemented except by a written amendment signed by authorized representatives of the parties.

# Schedule A Bosch Security Systems, LCC. Telex Radio Dispatch Products End User Software License Agreement Open Source Software and Open Source Software Licenses

Component	Description	License
ADPCM Vocoder	Telex ADPCM 32k Encode/ Decode format	BSD-3-Clause "New" or "Revised" License
alsa-lib	Advanced Linux Sound Architecture (ALSA) is a software framework and part of the Linux kernel that provides an application programming interface (API) for sound card device drivers	GNU Lesser General Public License
alsa-utils	Advanced Linux Sound Architecture (ALSA) is a software framework and part	GNU Lesser General Public License

	of the Linux kernel that provides an application programming interface (API) for sound card device drivers	
busybox	BusyBox combines tiny versions of many common UNIX utilities into a single small executable	GNU General Public License
CBitmapSlider	Code Project - "CBitmapSlider"	Code Project Open License 1.02
CButtonST	Code Project - "CButtonST (MFC Flat Buttons)"	CButtonST
CColorEdit/CColorStatic	Code Project - "Using colors in CEdit and CStatic"	Code Project Open License 1.02
CComboBox in a Grid Control	Code Project - "Using combo boxes in the MFC Grid Control"	Code Project Open License 1.02
cgic	cgic is an ANSI C-language library for the creation of CGIbased World Wide Web applications	CGIC License Note: This library contains modifications authored by Bosch Security Systems, LCC. Refer to the 5.0 CGIC License for a description of these changes.
cherokee	Cherokee is an innovative, feature rich, lightning fast and easy to configure open source web server designed for the next generation of highly concurrent secured web applications	GNU General Public License
CMemDC	Code Project - "Flicker Free Drawing in MFC"	Code Project Open License 1.02
CommonServiceLocator	IoC containers and service locators library	Microsoft Public License (MS-PL)
CppEvent	Cod Project - "Generic Observer Pattern and Events in C++	Code Project Open License 1.02
CppSQLite3	Code Project - "CppSQLite3 - C++ Wrapper for SQLite"	Code Project Open License 1.02
CProgressBar	Code Project - "Showing progress bar in a status bar pane"	Code Project Open License 1.02

dbus	D-Bus is a message bus system, a simple way for applications to talk to one another	GNU General Public License
DirectFB	DirectFB is a thin library that provides hardware graphics acceleration, input device handling and abstraction, integrated windowing system with support for translucent windows and multiple display layers, not only on top of the Linux Framebuffer Device	GNU Lesser General Public License
expat	Expat is an XML parser library written in C	The MIT License (MIT)
Font Awesome	Icon library and toolkit	The MIT License (MIT)
freetype	It is written in C, designed to be small, efficient, highly customizable, and portable while capable of producing high-quality output (glyph images) of most vector and bitmap font formats	GNU General Public License
jpeg	Free library for JPEG image compression	Independent JPEG Group License
jQuery	jQuery is a fast, small, and feature rich JavaScript library. https://blog.jquery.com	The MIT License (MIT)
jQuery File Upload Plugin	File Upload widget with multiple file selection, drag & drop support, progress bars, validation and preview images, audio and video for jQuery. https://github.com/blueimp/jQuery-File-Upload	The MIT License (MIT)
jQuery UI	jQuery UI is a curated set of user interface interactions, effects, widgets, and themes built on top of the jQuery JavaScript Library. https://blog.jqueryui.com	The MIT License (MIT)
libpng	libpng is the official PNG reference library	The zlib/libpng License

Linux Kernel	TI DaVinci Linux development (Kernel)	GNU General Public License
Microsoft.PowerShell.5.Refer enceAssemblies	SDK reference assemblies for PowerShell version 5	The MIT License (MIT)
mtdutils	MTD subsystem (stands for Memory Technology Devices) provides an abstraction layer for raw flash devices	GNU General Public License
MvvmLight	MVVM Framework for applications in WPF	The MIT License (MIT)
MvvmLightLibs	MVVM Framework for applications in WPF	The MIT License (MIT)
ncurses	The Ncurses (new curses) library is a free software, and emulation of curses in System V Release 4.0, and more	The X11 License (MIT/X Consortium)
net-snmp	Simple Network Management Protocol (SNMP) is widely used protocol for monitoring the health and welfare of network equipment	BSD-3-Clause
Network and Socket files	Networking library	Microsoft Public License (MS-PL)
NLog	Logging platform for various .NET platforms.	BSD 3-Clause "New" or "Revised" License
Open Phone Abstraction Library (OPAL)	SIP/VOIP	Mozilla Public License v1.1
OpenSSL	Full-featured toolkit for the Transport Layer Security (TLS) and Secure Sockets Layer (SSL) protocols. It is also a general-purpose cryptography library	OpenSSL License and SSLeay license
popt	The popt library exists essentially for parsing command line options	The X11 License (MIT/X Consortium)
Portable Windows Library (PTLib)	SIP/VOIP library	Mozilla Public License v1.1
Qwave.lib	Quality of Service (QOS) library	Microsoft Public License (MS-PL)

scew	The aim of SCEW is to provide an easy interface around the XML Expat parser, for creating new XML documents	GNU Lesser General Public License
SharpZipLib	Zip library for .NET platform	The MIT License (MIT)
sysvinit	Init is the parent of all processes. Its primary role is to create processes from a script stored in the file /etc/inittab. This package also contains well known and used utilities like reboot, shutdown, killall, poweroff, tellinit, sulogin, wall, etc.	GNU General Public License
TI UBL	Texas Instruments Davinci Serial Boot and Flashing (Bootloader)	GNU General Public License, version 2
TinyXML	XML Library	The zib/libpng License
U-Boot	"Das U-Boot" Source Tree (Bootloader)	GNU General Public License
XML CTreeCtrl	Code Project - "How to serialize a CTreeCtrl in XML"	Code Project Open License 1.02
zlib	zlib is a software library used for data compression	The zlib/libpng License

# **OSS License applications**

License	Embedded	C-Soft
BSD-3-Clause	X	Х
CButtonST License		Х
CGIC License	X	
Code Project Open License 1.02		X
GNU General Public License	Х	
GNU Lesser General Public License	X	
Independent JPEG Group License	Х	
The MIT License (MIT)	X	X
Microsoft Public License (Ms-PL)		X
Mozilla Public License v1.1		X
OpenSSL License	X	X
SSLeay License	X	X
The X11 License (MIT/X Consortium)	X	
The zlib/libpng License	X	X

# **BSD-3-Clause**

The Telex Radio Dispatch software contains open source software licensed under the BSD-3-Clause, and the license terms below in this schedule apply to that open source software.

# net-snmp

http://www.net-snmp.org/about/license.html

# License

Various copyrights apply to this package, listed in various separate parts below. Please make sure you read all parts.

# Cambridge Broadband Ltd, copyright notice (BSD)

Portions of this code are copyright (c) 2001-2003, Cambridge Broadband Ltd. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistribution of source code must retain the above copyright notice, this list of conditions and the following disclaimer.

- 2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/ or other materials provided with the distribution.
- 3. The name of Cambridge Broadband Ltd. may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDER "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDER BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

# CMU/UCD copyright notice (BSD like)

Copyright 1989,1991,1992 by Carnegie Mellon University
Derivative Work - 1996, 1998-2000
Copyright 1996, 1998-2000 The Regents of the University of California
All rights reserved.

Permission to use, copy, modify and distribute this software and its documentation for any purpose and without fee is hereby granted, provided that the above copyright notice appears in all copies and that both that copyright notice and this permission notice appear in supporting documentation, and that the name of CMU and The Regents of the University of California not be used in advertising or publicity pertaining or distribution of the software without specific written permission.

CMU AND THE REGENTS OF THE UNIVERSITY OF CALIFORNIA DISCLAIM ALL WARRANTIES WITH REGARD TO THIS SOFTWARE, INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS. IN NO EVENT SHALL CMU OR THE REGENTS OF CALIFORNIA BE LIABLE FOR ANY SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES OR ANY DAMAGES WHATSOEVER RESULTING FROM THE LOSS OF USE, DATA OR PROFITS, WHETHER IN AN ACTION OF CONTRACT, NEGLIGENCE OR OTHER TORTIOUS ACTION, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THIS SOFTWARE.

#### Networks Associates Technology, LCC copyright notice (BSD)

Copyright (c) 2001-2003, Networks Associates Technology, LCC All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- 1. Redistribution of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- 2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/ or other materials provided with the distribution.

3. Neither the name of the Networks Associates Technology, LCC nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDERS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

#### NLog copyright notice (BSD)

https://github.com/NLog/NLog/blob/master/LICENSE.txt

Copyright (c) 2004-2021 Jaroslaw Kowalski <jaak@jkowalski.net>, Kim Christensen, Julian Verdurmen

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions

- \* Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- \* Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- \* Neither the name of Jaroslaw Kowalski nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

# Stichting Mathematisch Centrum copyright notice (BSD)

Copyright 1992 by Stichting Mathematisch Centrum, Amsterdam, The Netherlands. All Rights Reserved

Permission to use, copy, modify, and distribute this software and its documentation for any purpose and without fee is hereby granted, provided that the above copyright notice appear in all copies and that both that copyright notice and this permission notice appear in supporting

documentation, and that the names of Stichting Mathematisch Centrum or CWI not be used in advertising or publicity pertaining to distribution of the software without specific, written prior permission.

STICHTING MATHEMATISCH CENTRUM DISCLAIMS ALL WARRANTIES WITH REGARD TO THIS SOFTWARE, INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS, IN NO EVENT SHALL STICHTING MATHEMATISCH CENTRUM BE LIABLE FOR ANY SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES OR ANY DAMAGES WHATSOEVER RESULTING FROM LOSS OF USE, DATA OR PROFITS, WHETHER IN AN ACTION OF CONTRACT, NEGLIGENCE OR OTHER TORTIOUS ACTION, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THIS SOFTWARE.

# Sun Microsystems, LCC. copyright notice (BSD)

Copyright © 2003 Sun Microsystems, LCC., 4150 Network Circle, Santa Clara, California 95054, U.S.A.

All rights reserved.

User is subject to license terms below.

This distribution may include materials developed by third parties.

Sun, Sun Microsystems, the Sun logo and Solaris are trademarks or registered trademarks of Sun Microsystems, LCC. in the U.S. and other countries.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- 1. Redistribution of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- 2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/ or other materials provided with the distribution.
- 3. Neither the name of the Sun Microsystems, LCC. nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDERS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

#### Sparta, LCC copyright notice (BSD)

Copyright © 2003-2009 Sparta, LCC. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistribution of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/ or other materials provided with the distribution.
- Neither the name Sparta, LCC nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDERS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

# Cisco/BUPTNIC copyright notice (BSD)

Copyright © 2004, Cisco, LCC and Information Network Center of Beijing University of Posts and Telecommunications.

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistribution of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/ or other materials provided with the distribution.
- Neither the name of Cisco, LCC, Beijing University of Posts and Telecommunications, nor the names of their contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDERS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN

CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

## Fabasoft R&D Software GmbH & Co KG copyright notice (BSD)

Copyright © Fabasoft R&D Software GmbH & Co KG, 2003 oss.fabasoft.com Author: Bernhard Penz

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- 1. Redistribution of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- 2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/ or other materials provided with the distribution.
- 3. The name of Fabasoft R&D Software GmbH & Co KG or any of its subsidiaries, brand or product names may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDER "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDER BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

# Apple LCC. copyright notice (BSD)

Copyright © 2007 Apple LCC. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- 1. Redistribution of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- 2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/ or other materials provided with the distribution.
- 3. Neither the name of Apple, LCC. ("Apple") nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permissions.

THIS SOFTWARE IS PROVIDED BY APPLE AND ITS CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL APPLE OR ITS CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT,

INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USER, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

# ScienceLogic, LLC copyright notice (BSD)

Copyright © 2009, ScienceLogic, LLC All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistribution of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- 2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/ or other materials provided with the distribution.
- Neither the name of ScienceLogic, LLC nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDERS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

# **CButtonST License**

The Telex Radio Dispatch software contains open source software developed by Davide Calabro and the license terms below in this Schedule 1 apply to that open source software.

# Disclaimer

THIS SOFTWARE AND THE ACCOMPANYING FILES ARE DISTRIBUTED "AS IS" AND WITHOUT ANY WARRANTIES WHETHER EXPRESSED OR IMPLIED. NO RESPONSIBILITIES FOR THE POSSIBLE DAMAGES OR EVEN FUNCTIONALITY CAN BE TAKEN. THE USER MUST ASSUME THE ENTIRE RISK OF USING THIS SOFTWARE.

#### **CGIC License**

The Telex Radio Dispatch software contains open source software licensed under the CGIC License, and the license terms below in this schedule (copied from the following website: http://www.boutell.com/cgic/license.txt) apply to that open source software.



## Notice!

This library contains modifications authored by Bosch Security Systems, LCC.

Modification Date: Feb 15, 2017

**Reason**: The multi-part form data parsing code performed slowly on Bosch hardware. This code was replaced with a buffered parser for better performance.

#### **Basic License**

CGIC, copyright 1996-2011 by Thomas Boutell and Boutell.Com, LCC.

Permission is granted to use CGIC in any application, commercial or noncommercial, at no cost. HOWEVER, this copyright paragraph must appear on a "credits" page accessible in the public online and offline documentation of the program.

Modified versions of the CGIC library should not be distributed without the attachment of a clear statement regarding the author of the modifications, and this notice may in no case be removed. Modifications may also be submitted to the author for inclusion in the main CGIC distribution.

IF YOU WOULD PREFER NOT TO ATTACH THE ABOVE NOTICE to the public documentation of your application, consult the information which follows regarding the availability of a nonexclusive commercial license for CGIC.

Signed originals are available on request after purchase.

Commercial licensees are entitled to ongoing email support and update notifications.

# **Commercial License**

The price of a nonexclusive commercial license is \$200 U.S. To purchase the license, visit our online store here: https://www.boutell.com/

### **CGIC Nonexclusive Commercial License**

The party purchasing this license is granted the right to utilize CGIC, major version 1 or 2, any minor version thereof, in CGI applications without the need for a credit notice of any kind. CGI applications developed by the holder of this license may be distributed freely in source code or binary form without additional fees or royalties. This license does not grant the right to use CGIC to create a development tool which passes on substantially all of the capabilities of the CGIC library to the user of the tool, unless that tool is to be used internally by the license holder only in order to develop CGI applications. This license may not be resold, but applications developed in accordance with the terms of the license may be distributed freely subject to the limitations described above.

Future minor (2.x) versions of CGIC will be covered by this license free of charge. If significant defects of workmanship are discovered in version 2.x, minor releases to correct them will be made available before or at the same time that those defects are addressed in any future major version.

Future "major" (3.x) versions will be available to licensees at an upgrade price of \$50. If, for any reason, any portion of this license is found to be invalid, that portion of the license only is invalidated and the remainder of the agreement remains in effect.

If this license has not been signed by Thomas Boutell or M. L. Grant on behalf of Boutell. Com, LCC., it is invalid.

Licensee's name:

Signed for Licensee:

Complete mailing address:

Phone number:

Email address:

Signed for Boutell.Com, LCC.:

Date:

# Code Project Open License (CPOL) 1.02

The Telex Radio Dispatch software contains open source software licensed under the Code Project Open License (CPOL) 1.02, and the license terms below in this Schedule 2 (copied from the website: http://www.codeproject.com/info/cpol10.aspx) apply to that open source software.

#### **Preamble**

This License governs Your use of the Work. This License is intended to allow developers to use the Source Code and Executable Files provided as part of the Work in any application in any form. The main points subject to the terms of the License are:

- Source Code and Executable Files can be used in commercial applications;
- Source Code and Executable Files can be redistributed; and
- Source Code can be modified to create derivative works.
- No claim of suitability, guarantee, or any warranty whatsoever is provided. The software is provided "as- is".
- The Article accompanying the Work may not be distributed or republished without the Author's consent.

This License is entered between You, the individual or other entity reading or otherwise making use of the Work licensed pursuant to this License and the individual or other entity which offers the Work under the terms of this License ("Author").

#### License

THE WORK (AS DEFINED BELOW) IS PROVIDED UNDER THE TERMS OF THIS CODE PROJECT OPEN LICENSE ("LICENSE"). THE WORK IS PROTECTED BY COPYRIGHT AND/OR OTHER APPLICABLE LAW. ANY USE OF THE WORK OTHER THAN AS AUTHORIZED UNDER THIS LICENSE OR COPYRIGHT LAW IS PROHIBITED.

BY EXERCISING ANY RIGHTS TO THE WORK PROVIDED HEREIN, YOU ACCEPT AND AGREE TO BE BOUND BY THE TERMS OF THIS LICENSE. THE AUTHOR GRANTS YOU THE RIGHTS CONTAINED HEREIN IN CONSIDERATION OF YOUR ACCEPTANCE OF SUCH TERMS AND CONDITIONS. IF YOU DO NOT AGREE TO ACCEPT AND BE BOUND BY THE TERMS OF THIS LICENSE, YOU CANNOT MAKE ANY USE OF THE WORK.

#### **Definitions**

- 1. "Articles" means, collectively, all articles written by Author which describes how the Source Code and Executable Files for the Work may be used by a user.
- 2. "Author" means the individual or entity that offers the Work under the terms of this License
- 3. "Derivative Work" means a work based upon the Work or upon the Work and other preexisting works.
- 4. "Executable Files" refer to the executables, binary files, configuration and any required data files included in the Work.
- 5. "Publisher" means the provider of the website, magazine, CD-ROM, DVD or other medium from or by which the Work is obtained by You.
- 6. "Source Code" refers to the collection of source code and configuration files used to create the Executable Files.
- 7. "Standard Version" refers to such a Work if it has not been modified, or has been modified in accordance with the consent of the Author, such consent being in the full discretion of the Author.
- 8. "Work" refers to the collection of files distributed by the Publisher, including the Source Code, Executable Files, binaries, data files, documentation, white papers and the Articles.
- 9. "You" is you, an individual or entity wishing to use the Work and exercise your rights under this License.

# Fair Use/Fair Use Rights

Nothing in this License is intended to reduce, limit, or restrict any rights arising from fair use, fair dealing, first sale or other limitations on the exclusive rights of the copyright owner under copyright law or other applicable laws.

#### **License Grant**

Subject to the terms and conditions of this License, the Author hereby grants You a worldwide, royalty-free, non-exclusive, perpetual (for the duration of the applicable copyright) license to exercise the rights in the Work as stated below:

- 1. You may use the standard version of the Source Code or Executable Files in Your own applications.
- 2. You may apply bug fixes, portability fixes and other modifications obtained from the Public Domain or from the Author. A Work modified in such a way shall still be considered the standard version and will be subject to this License.
- 3. You may otherwise modify Your copy of this Work (excluding the Articles) in any way to create a Derivative Work, provided that You insert a prominent notice in each changed file stating how, when and where You changed that file.
- 4. You may distribute the standard version of the Executable Files and Source Code or Derivative Work in aggregate with other (possibly commercial) programs as part of a larger (possibly commercial) software distribution.
- 5. The Articles discussing the Work published in any form by the author may not be distributed or republished without the Author's consent. The author retains copyright to any such Articles. You may use the Executable Files and Source Code pursuant to this License but you may not repost or republish or otherwise distribute or make available the Articles, without the prior written consent of the Author.

Any subroutines or modules supplied by You and linked into the Source Code or Executable Files of this Work shall not be considered part of this Work and will not be subject to the terms of this License.

#### **Patent License**

Subject to the terms and conditions of this License, each Author hereby grants to You a perpetual, worldwide, non-exclusive, no-charge, royalty-free, irrevocable (except as stated in this section) patent license to make, have made, use, import, and otherwise transfer the Work.

#### Restrictions

The license granted in Section 3 above is expressly made subject to and limited by the following restrictions:

- 1. You agree not to remove any of the original copyright, patent, trademark, and attribution notices and associated disclaimers that may appear in the Source Code or Executable Files.
- 2. You agree not to advertise or in any way imply that this Work is a product of Your own.
- The name of the Author may not be used to endorse or promote products derived from the Work without the prior written consent of the Author.
- 4. You agree not to sell, lease, or rent any part of the Work. This does not restrict you from including the Work or any part of the Work inside a larger software distribution that itself is being sold. The Work by itself, though, cannot be sold, leased or rented.
- 5. You may distribute the Executable Files and Source Code only under the terms of this License, and You must include a copy of, or the Uniform Resource Identifier for, this License with every copy of the Executable Files or Source Code You distribute and ensure that anyone receiving such Executable Files and Source Code agrees that the terms of this License apply to such Executable Files and/or Source Code. You may not offer or impose any terms on the Work that alter or restrict the terms of this License or the recipients' exercise of the rights granted hereunder. You may not sublicense the Work. You must keep intact all notices that refer to this License and to the disclaimer of warranties. You may not distribute the Executable Files or Source Code with any technological measures that control access or use of the Work in a manner inconsistent with the terms of this License.
- 6. You agree not to use the Work for illegal, immoral or improper purposes, or on pages containing illegal, immoral or improper material. The Work is subject to applicable export laws. You agree to comply with all such laws and regulations that may apply to the Work after Your receipt of the Work.

# Representations, Warranties and Disclaimer

THIS WORK IS PROVIDED "AS IS," "WHERE IS" AND "AS AVAILABLE", WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES OR CONDITIONS OR GUARANTEES. YOU, THE USER, ASSUME ALL RISK IN ITS USE, INCLUDING COPYRIGHT INFRINGEMENT, PATENT INFRINGEMENT, SUITABILITY, ETC. AUTHOR EXPRESSLY DISCLAIMS ALL EXPRESS, IMPLIED OR STATUTORY WARRANTIES OR CONDITIONS, INCLUDING WITHOUT LIMITATION, WARRANTIES OR CONDITIONS OF MERCHANTABILITY, MERCHANTABLE QUALITY OR FITNESS FOR A PARTICULAR PURPOSE, OR ANY WARRANTY OF TITLE OR NON-INFRINGEMENT, OR THAT THE WORK (OR ANY PORTION THEREOF) IS CORRECT, USEFUL, BUG-FREE OR FREE OF VIRUSES. YOU MUST PASS THIS DISCLAIMER ON WHENEVER YOU DISTRIBUTE THE WORK OR DERIVATIVE WORKS.

**Technical Manual** 

#### Indemnity

You agree to defend, indemnify and hold harmless the Author and the Publisher from and against any claims, suits, losses, damages, liabilities, costs, and expenses (including reasonable legal or attorneys' fees) resulting from or relating to any use of the Work by You.

#### **Limitation on Liability**

EXCEPT TO THE EXTENT REQUIRED BY APPLICABLE LAW, IN NO EVENT WILL THE AUTHOR OR THE PUBLISHER BE LIABLE TO YOU ON ANY LEGAL THEORY FOR ANY SPECIAL, INCIDENTAL, CONSEQUENTIAL, PUNITIVE OR EXEMPLARY DAMAGES ARISING OUT OF THIS LICENSE OR THE USE OF THE WORK OR OTHERWISE, EVEN IF THE AUTHOR OR THE PUBLISHER HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

#### **Termination**

- This License and the rights granted hereunder will terminate automatically upon any breach by You of any term of this License. Individuals or entities who have received Derivative Works from You under this License, however, will not have their licenses terminated provided such individuals or entities remain in full compliance with those licenses. Sections 1, 2, 6, 7, 8, 9, 10 and 11 will survive any termination of this License.
- 2. If You bring a copyright, trademark, patent or any other infringement claim against any contributor over infringements You claim are made by the Work, your License from such contributor to the Work ends automatically.
- Subject to the above terms and conditions, this License is perpetual (for the duration of the applicable copyright in the Work). Notwithstanding the above, the Author reserves the right to release the Work under different license terms or to stop distributing the Work at any time; provided, however that any such election will not serve to withdraw this License (or any other license that has been, or is required to be, granted under the terms of this License), and this License will continue in full force and effect unless terminated as stated above.

#### **Publisher**

The parties hereby confirm that the Publisher shall not, under any circumstances, be responsible for and shall not have any liability in respect of the subject matter of this License. The Publisher makes no warranty whatsoever in connection with the Work and shall not be liable to You or any party on any legal theory for any damages whatsoever, including without limitation any general, special, incidental or consequential damages arising in connection to this license. The Publisher reserves the right to cease making the Work available to You at any time without notice

#### Miscellaneous

- This License shall be governed by the laws of the location of the head office of the Author or if the Author is an individual, the laws of location of the principal place of residence of the Author.
- If any provision of this License is invalid or unenforceable under applicable law, it shall not affect the validity or enforceability of the remainder of the terms of this License, and without further action by the parties to this License, such provision shall be reformed to the minimum extent necessary to make such provision valid and enforceable.
- No term or provision of this License shall be deemed waived and no breach consented to unless such waiver or consent shall be in writing and signed by the party to be charged with such waiver or consent.

This License constitutes the entire agreement between the parties with respect to the Work licensed herein. There are no understandings, agreements or representations with respect to the Work not specified herein. The Author shall not be bound by any additional provisions that may appear in any communication from You. This License may not be modified without the mutual written agreement of the Author and You.

#### **GNU General Public License**

The Telex Radio Dispatch software contains open source software licensed under the GNU General Public License, and the license terms below in this schedule (copied from the following website: http://www.gnu.org/licenses/oldlicenses/gpl-2.0.html) apply to that open source software.

#### Linux Kernel

NOTE! This copyright does \*not\* cover user programs that use kernel services by normal system calls - this is merely considered normal use of the kernel, and does \*not\* fall under the heading of "derived work". Also note that the GPL below is copyrighted by the Free Software Foundation, but the instance of code that it refers to (the Linux kernel) is copyrighted by me and others who actually wrote it.

Also note that the only valid version of the GPL as far as the kernel is concerned is \_this\_ particular version of the license (ie v2, not v2.2 or v3.x or whatever), unless explicitly otherwise stated.

Linus Torvalds

Refer to the GNU General Public License for the rest of the license information.

#### **U-Boot**

U-Boot is Free Software. It is copyrighted by Wolfgang Denk and many others who contributed code (refer to the actual source code for details). You can redistribute U-Boot and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation. Most of it can also be distributed at your option, under any later version of the GNU General Public License - refer to individual files for exceptions.

NOTE! This license does \*not\* cover the so-called "standalone" applications that use U-Boot services by means of the jump table provided by U-Boot exactly for this purpose - this is merely considered normal use of U-Boot, and does \*not\* fall under the heading of "derived work".

The header files "include/image.h" and "include/asm-\*/u-boot.h" define interfaces to U-Boot. LCCluding these (unmodified) header files in another file is considered normal use of U-Boot, and does \*not\* fall under the heading of "derived work".

Also note that the GPL below is copyrighted by the Free Software Foundation, but the instance of code that it refers to (the U-Boot source code) is copyrighted by me and others who actually wrote it.

Wolfgang Denk

Refer to the GNU General Public License for the rest of the license information.

#### busybox

A note on GPL versions:

BusyBox is distributed under the General Public License (included in its entirety, below). Version 2 is the only version of this license which this version of BusyBox (or modified versions derived from this one) may be distributed under.

Refer to the GNU General Public License for the rest of the license information.

#### dbus

Bus is licensed to you under your choice of the Academic Free License, or the GNU General Public License. Both licenses are included here. Some of the standalone binaries are under the GPL only; in particular, but not limited to, tools/dbus-cleanup-sockets.c and test/decodegcov.c. Each source code file is marked with the proper copyright information - if you find a file that isn't marked please bring it to our attention.

Refer to the GNU General Public License for the rest of the license information.

### freetype

The FreeType 2 font engine is copyrighted work and cannot be used legally without a software license. In order to make this project usable to a vast majority of developers, we distribute it under two mutually exclusive open-source licenses. This means that \*you\* must choose \*one\* of the two licenses described below, then obey all its terms and conditions when using FreeType 2 in any of your projects or products.

The FreeType License, found in the file `FTL.TXT', which is similar to the original BSD license \*with\* an advertising clause that forces you to explicitly cite the FreeType project in your product's documentation. All details are in the license file. This license is suited to products which don't use the GNU General Public License.

The GNU General Public License, found in 'GPL.TXT' (any later version can be used also), for programs which already use the GPL Note that the FTL is incompatible with the GPL due to its advertisement clause.

The contributed PCF driver comes with a license similar to that of the X Window System. It is compatible to the above two licenses (refer to file <code>src/pcf/readme</code>).

Refer to the GNU General Public License for the rest of the license information.

# **GNU General Public License**

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, LCC.

51 Franklin Street, Fifth Floor, Boston, MA 02110-1301, USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

## **Preamble**

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any

other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Lesser General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

# Terms and Conditions for copying, distribution and modification

1.

This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you". Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

#### 2.

You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

- You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.
- You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.
- If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

# 3.

You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

- Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

#### 6.

Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

#### 7.

If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously

your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

#### 8

If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

#### 9.

The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

#### **NO WARRANTY**

# 11.

BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE

PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE. YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS). EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. END OF TERMS AND CONDITIONS

# **How to Apply These Terms to Your New Programs**

If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms.

To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the "copyright" line and a pointer to where the full notice is found.

One line to give the program's name and an idea of what it does. Copyright (C) year, name of author

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. Refer to the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, LCC., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301, USA.

Also add information on how to contact you by electronic and paper mail. If the program is interactive, make it output a short notice like this when it starts in an interactive mode: Gnomovision, Copyright (C) year name of author

Gnomovision comes with ABSOLUTELY NO WARRANTY; for details type 'show w'. This is free software, and you are welcome to redistribute it under certain conditions; type 'show c' for details.

The hypothetical commands 'show w' and 'show c' should show the appropriate parts of the General Public License. Of course, the commands you use may be called something other than 'show w' and 'show c'; they could even be mouseclicks or menu items - whatever suits your program.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the program, if necessary.

Here is a sample; alter the names:

Yoyodyne, LCC., hereby disclaims all copyright interest in the program 'Gnomovision' (which makes passes at compilers) written by James Hacker.

Signature of Ty Coon, 1 April 1989

Ty Coon, President of Vice

This General Public License does not permit incorporating your program into proprietary programs. If your program is a subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is what you want to do, use the GNU Lesser General Public License instead of this License.

#### **GNU Lesser General Public License**

The Telex Radio Dispatch software contains open source software licensed under the GNU Lesser General Public License, and the license terms below in this schedule (copied from the following website: <a href="http://www.gnu.org/licenses/">http://www.gnu.org/licenses/</a> old-licenses/lgpl-2.1.html) apply to that open source software.

Copyright (C) 1991, 1999 Free Software Foundation, LCC. 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

[This is the first released version of the Lesser GPL. It also counts as the successor of the GNU Library Public License, version 2, hence the version number 2.1.]

### **Preamble**

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public Licenses are intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users.

This license, the Lesser General Public License, applies to some specially designated software packages - typically libraries - of the Free Software Foundation and other authors who decide to use it. You can use it too, but we suggest you first think carefully about whether this license or the ordinary General Public License is the better strategy to use in any particular case, based on the explanations below.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid distributors to deny you these rights or to ask you to surrender these rights. These restrictions translate to certain responsibilities for you if you distribute copies of the library or if you modify it.

For example, if you distribute copies of the library, whether gratis or for a fee, you must give the recipients all the rights that we gave you. You must make sure that they, too, receive or can get the source code. If you link other code with the library, you must provide complete object files to the recipients, so that they can relink them with the library after making changes to the library and recompiling it. And you must show them these terms so they know their rights.

We protect your rights with a two-step method: (1) we copyright the library, and (2) we offer you this license, which gives you legal permission to copy, distribute and/or modify the library.

To protect each distributor, we want to make it very clear that there is no warranty for the free library. Also, if the library is modified by someone else and passed on, the recipients should know that what they have is not the original version, so that the original author's reputation will not be affected by problems that might be introduced by others.

Finally, software patents pose a constant threat to the existence of any free program. We wish to make sure that a company cannot effectively restrict the users of a free program by obtaining a restrictive license from a patent holder. Therefore, we insist that any patent license obtained for a version of the library must be consistent with the full freedom of use specified in this license.

Most GNU software, including some libraries, is covered by the ordinary GNU General Public License. This license, the GNU Lesser General Public License, applies to certain designated libraries, and is quite different from the ordinary General Public License. We use this license for certain libraries in order to permit linking those libraries into non-free programs.

When a program is linked with a library, whether statically or using a shared library, the combination of the two is legally speaking a combined work, a derivative of the original library. The ordinary General Public License therefore permits such linking only if the entire combination fits its criteria of freedom. The Lesser General Public License permits more lax criteria for linking other code with the library.

We call this license the "Lesser" General Public License because it does Less to protect the user's freedom than the ordinary General Public License. It also provides other free software developers Less of an advantage over competing non-free programs. These disadvantages are the reason we use the ordinary General Public License for many libraries. However, the Lesser license provides advantages in certain special circumstances.

For example, on rare occasions, there may be a special need to encourage the widest possible use of a certain library, so that it becomes a de-facto standard. To achieve this, non-free programs must be allowed to use the library. A more frequent case is that a free library does the same job as widely used non-free libraries. In this case, there is little to gain by limiting the free library to free software only, so we use the Lesser General Public License.

In other cases, permission to use a particular library in non-free programs enables a greater number of people to use a large body of free software. For example, permission to use the GNU C Library in non-free programs enables many more people to use the whole GNU operating system, as well as its variant, the GNU/Linux operating system.

Although the Lesser General Public License is Less protective of the users' freedom, it does ensure that the user of a program that is linked with the Library has the freedom and the wherewithal to run that program using a modified version of the Library.

The precise terms and conditions for copying, distribution and modification follow. Pay close attention to the difference between a "work based on the library" and a "work that uses the library". The former contains code derived from the library, whereas the latter must be combined with the library in order to run.

# Terms and Conditions for copying, distribution and modification

1.

This License Agreement applies to any software library or other program which contains a notice placed by the copyright holder or other authorized party saying it may be distributed under the terms of this Lesser General Public License (also called "this License"). Each licensee is addressed as "you".

A "library" means a collection of software functions and/or data prepared so as to be conveniently linked with application programs (which use some of those functions and data) to form executables.

The "Library", below, refers to any such software library or work which has been distributed under these terms. A "work based on the Library" means either the Library or any derivative work under copyright law: that is to say, a work containing the Library or a portion of it, either verbatim or with modifications and/or translated straightforwardly into another language. (Hereinafter, translation is included without limitation in the term "modification".)

"Source code" for a work means the preferred form of the work for making modifications to it. For a library, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the library.

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running a program using the Library is not restricted, and output from such a program is covered only if its contents constitute a work based on the Library (independent of the use of the Library in a tool for writing it). Whether that is true depends on what the Library does and what the program that uses the Library does.

You may copy and distribute verbatim copies of the Library's complete source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and distribute a copy of this License along with the Library.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

3.

You may modify your copy or copies of the Library or any portion of it, thus forming a work based on the Library, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

- The modified work must itself be a software library.
- You must cause the files modified to carry prominent notices stating that you changed the files and the date of any change.
- You must cause the whole of the work to be licensed at no charge to all third parties under the terms of this License.
- If a facility in the modified Library refers to a function or a table of data to be supplied by an application program that uses the facility, other than as an argument passed when the facility is invoked, then you must make a good faith effort to ensure that, in the event an application does not supply such function or table, the facility still operates, and performs whatever part of its purpose remains meaningful. (For example, a function in a library to compute square roots has a purpose that is entirely well-defined independent of the application. Therefore, Subsection 2d requires that any application-supplied function or table used by this function must be optional: if the application does not supply it, the square root function must still compute square roots.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Library, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Library, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Library.

In addition, mere aggregation of another work not based on the Library with the Library (or with a work based on the Library) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

4.

You may opt to apply the terms of the ordinary GNU General Public License instead of this License to a given copy of the Library. To do this, you must alter all the notices that refer to this License, so that they refer to the ordinary GNU General Public License, version 2, instead

of to this License. (If a newer version than version 2 of the ordinary GNU General Public License has appeared, then you can specify that version instead if you wish.) Do not make any other change in these notices.

Once this change is made in a given copy, it is irreversible for that copy, so the ordinary GNU General Public License applies to all subsequent copies and derivative works made from that copy. This option is useful when you wish to copy part of the code of the Library into a program that is not a library.

#### 5.

You may copy and distribute the Library (or a portion or derivative of it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange.

If distribution of object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place satisfies the requirement to distribute the source code, even though third parties are not compelled to copy the source along with the object code.

A program that contains no derivative of any portion of the Library, but is designed to work with the Library by being compiled or linked with it, is called a "work that uses the Library". Such a work, in isolation, is not a derivative work of the Library, and therefore falls outside the scope of this License.

However, linking a "work that uses the Library" with the Library creates an executable that is a derivative of the Library (because it contains portions of the Library), rather than a "work that uses the library". The executable is therefore covered by this License. Section 6 states terms for distribution of such executables.

When a "work that uses the Library" uses material from a header file that is part of the Library, the object code for the work may be a derivative work of the Library even though the source code is not. Whether this is true is especially significant if the work can be linked without the Library, or if the work is itself a library. The threshold for this to be true is not precisely defined by law.

If such an object file uses only numerical parameters, data structure layouts and accessors, and small macros and small inline functions (ten lines or less in length), then the use of the object file is unrestricted, regardless of whether it is legally a derivative work. (Executables containing this object code plus portions of the Library will still fall under Section 6.)

Otherwise, if the work is a derivative of the Library, you may distribute the object code for the work under the terms of Section 6. Any executables containing that work also fall under Section 6, whether or not they are linked directly with the Library itself.

#### 7.

As an exception to the Sections above, you may also combine or link a "work that uses the Library" with the Library to produce a work containing portions of the Library, and distribute that work under terms of your choice, provided that the terms permit modification of the work for the customer's own use and reverse engineering for debugging such modifications.

You must give prominent notice with each copy of the work that the Library is used in it and that the Library and its use are covered by this License. You must supply a copy of this License. If the work during execution displays copyright notices, you must include the copyright notice for the Library among them, as well as a reference directing the user to the copy of this License. Also, you must do one of these things:

- Accompany the work with the complete corresponding machine-readable source code for the Library including whatever changes were used in the work (which must be distributed under Sections 1 and 2 above); and, if the work is an executable linked with the Library, with the complete machine-readable "work that uses the Library", as object code and/or source code, so that the user can modify the Library and then relink to produce a modified executable containing the modified Library. (It is understood that the user who changes the contents of definitions files in the Library will not necessarily be able to recompile the application to use the modified definitions.)
- Use a suitable shared library mechanism for linking with the Library. A suitable mechanism is one that (1) uses at run time a copy of the library already present on the user's computer system, rather than copying library functions into the executable, and (2) will operate properly with a modified version of the library, if the user installs one, as long as the modified version is interface-compatible with the version that the work was made with.
- Accompany the work with a written offer, valid for at least three years, to give the same user the materials specified in Subsection 6a, above, for a charge no more than the cost of performing this distribution.
- If distribution of the work is made by offering access to copy from a designated place, offer equivalent access to copy the above specified materials from the same place.
- Verify that the user has already received a copy of these materials or that you have already sent this user a copy.

For an executable, the required form of the "work that uses the Library" must include any data and utility programs needed for reproducing the executable from it. However, as a special exception, the materials to be distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

It may happen that this requirement contradicts the license restrictions of other proprietary libraries that do not normally accompany the operating system. Such a contradiction means you cannot use both them and the Library together in an executable that you distribute.

8.

You may place library facilities that are a work based on the Library side-by-side in a single library together with other library facilities not covered by this License, and distribute such a combined library, provided that the separate distribution of the work based on the Library and of the other library facilities is otherwise permitted, and provided that you do these two things:

Accompany the combined library with a copy of the same work based on the Library, uncombined with any other library facilities. This must be distributed under the terms of the Sections above.

Give prominent notice with the combined library of the fact that part of it is a work based on the Library, and explaining where to find the accompanying uncombined form of the same work.

#### 9.

You may not copy, modify, sublicense, link with, or distribute the Library except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense, link with, or distribute the Library is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

# 10.

You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Library or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Library (or any work based on the Library), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Library or works based on it.

#### 11.

Each time you redistribute the Library (or any work based on the Library), the recipient automatically receives a license from the original licensor to copy, distribute, link with or modify the Library subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties with this License.

#### 12.

If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Library at all. For example, if a patent license would not permit royalty-free redistribution of the Library by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Library.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

#### 13.

If the distribution and/or use of the Library is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Library under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

#### 14.

The Free Software Foundation may publish revised and/or new versions of the Lesser General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Library specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Library does not specify a license version number, you may choose any version ever published by the Free Software Foundation.

#### 15.

If you wish to incorporate parts of the Library into other free programs whose distribution conditions are incompatible with these, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this.

Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

# **NO WARRANTY**

#### 16.

BECAUSE THE LIBRARY IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE LIBRARY, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE LIBRARY "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE LIBRARY IS WITH YOU. SHOULD THE LIBRARY PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

# **17.**

IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE LIBRARY AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE LIBRARY (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE LIBRARY TO OPERATE WITH ANY OTHER SOFTWARE), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. END OF TERMS AND CONDITIONS

#### How to apply these terms to your new libraries

If you develop a new library, and you want it to be of the greatest possible use to the public, we recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

To apply these terms, attach the following notices to the library. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the "copyright" line and a pointer to where the full notice is found.

One line to give the library's name and an idea of what it does. Copyright (C) year, name of author

This library is free software; you can redistribute it and/or modify it under the terms of the GNU Lesser General Public License as published by the Free Software Foundation; either version 2.1 of the License, or (at your option) any later version.

This library is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. Refer to the GNU Lesser General Public License for more details. You should have received a copy of the GNU Lesser General Public License along with this library; if not, write to the Free Software Foundation, LCC., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA

Also add information on how to contact you by electronic and paper mail.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the library, if necessary. Here is a sample; alter the names:

Yoyodyne, LCC., hereby disclaims all copyright interest in the library 'Frob' (a library for tweaking knobs) written by James Random Hacker.

Signature of Ty Coon, 1 April 1989

Ty Coon, President of Vice

That's all there is to it!

# **Independent JPEG Group License**

The Telex Radio Dispatch software contains open source software licensed under the Independent JPEG Group License, and the license terms below in this schedule (copied from the following website: https://spdx.org/licenses/IJG) apply to that open source software.

# Legal issues

In plain English:

- 1. We don't promise that this software works. (But if you find any bugs, please let us know!)
- 2. You can use this software for whatever you want. You don't have to pay us.
- 3. You may not pretend that you wrote this software. If you use it in a program, you must acknowledge somewhere in your documentation that you've used the IJG code.

# In legalese:

The authors make NO WARRANTY or representation, either express or implied, with respect to this software, its quality, accuracy, merchantability, or fitness for a particular purpose. This software is provided "AS IS", and you, its user, assume the entire risk as to its quality and accuracy.

This software is copyright (C) 1991-1998, Thomas G. Lane. All rights reserved except as specified below.

Permission is hereby granted to use, copy, modify, and distribute this software (or portions thereof) for any purpose, without fee, subject to these conditions:

- 1. If any part of the source code for this software is distributed, then this README file must be included, with this copyright and no-warranty notice unaltered; and any additions, deletions, or changes to the original files must be clearly indicated in accompanying documentation.
- 2. If only executable code is distributed, then the accompanying documentation must state that "this software is based in part on the work of the Independent JPEG Group".
- Permission for use of this software is granted only if the user accepts full responsibility
  for any undesirable consequences; the authors accept NO LIABILITY for damages of any
  kind.

These conditions apply to any software derived from or based on the IJG code, not just to the unmodified library. If you use our work, you ought to acknowledge us.

Permission is NOT granted for the use of any IJG author's name or company name in advertising or publicity relating to this software or products derived from it. This software may be referred to only as "the Independent JPEG Group's software".

We specifically permit and encourage the use of this software as the basis of commercial products, provided that all warranty or liability claims are assumed by the product vendor.

ansi2knr.c is included in this distribution by permission of L. Peter Deutsch, sole proprietor of its copyright holder, Aladdin Enterprises of Menlo Park, CA.

ansi2knr.c is NOT covered by the above copyright and conditions, but instead by the usual distribution terms of the Free Software Foundation; principally, that you must include source code if you redistribute it. (Refer to the file ansi2knr.c for full details.) However, since ansi2knr.c is not needed as part of any program generated from the IJG code, this does not limit you more than the foregoing paragraphs do.

The Unix configuration script "configure" was produced with GNU Autoconf. It is copyright by the Free Software Foundation but is freely distributable. The same holds for its supporting scripts (config.guess, config.sub, Itconfig, Itmain.sh). Another support script, install-sh, is copyright by M.I.T. but is also freely distributable.

It appears that the arithmetic coding option of the JPEG spec is covered by patents owned by IBM, AT&T, and Mitsubishi. Hence arithmetic coding cannot legally be used without obtaining one or more licenses. For this reason, support for arithmetic coding has been removed from the free JPEG software. (Since arithmetic coding provides only a marginal gain over the unpatented Huffman mode, it is unlikely that very many implementations will support it.) So far as we are aware, there are no patent restrictions on the remaining code.

The IJG distribution formerly included code to read and write GIF files. To avoid entanglement with the Unisys LZW patent, GIF reading support has been removed altogether, and the GIF writer has been simplified to produce "uncompressed GIFs". This technique does not use the LZW algorithm; the resulting GIF files are larger than usual, but are readable by all standard GIF decoders.

We are required to state that "The Graphics Interchange Format(c) is the Copyright property of CompuServe LCCorporated. GIF(sm) is a Service Mark property of CompuServe LCCorporated."

## MICROSOFT PUBLIC LICENSE (Ms-PL)

The Telex Radio Dispatch C-Soft application contains open source software licensed under the Microsoft Public License (Ms-PL), and the license terms below in this schedule (copied from the following websites: <a href="http://www.microsoft.com/en-us/openness/licenses.aspx">http://www.microsoft.com/en-us/openness/licenses.aspx</a> and <a href="https://github.com/unitycontainer/commonservicelocator/blob/master/LICENSE">http://www.microsoft.com/en-us/openness/licenses.aspx</a> and <a href="https://github.com/unitycontainer/commonservicelocator/blob/master/LICENSE">https://github.com/unitycontainer/commonservicelocator/blob/master/LICENSE</a>) apply to that open source software.

This license governs use of the accompanying software. If you use the software, you accept this license. If you do not accept the license, do not use the software.

#### 1. **Definitions**

The terms "reproduce," "reproduction," "derivative works," and "distribution" have the same meaning here as under U.S. copyright law.

A "contribution" is the original software, or any additions or changes to the software.

A "contributor" is any person that distributes its contribution under this license.

"Licensed patents" are a contributor's patent claims that read directly on its contribution.

#### 2. Grant of Rights

(A) Copyright Grant- Subject to the terms of this license, including the license conditions and limitations in section 3, each contributor grants you a non-exclusive, worldwide, royalty-free copyright license to reproduce its contribution, prepare derivative works of its contribution, and distribute its contribution or any derivative works that you create.
(B) Patent Grant- Subject to the terms of this license, including the license conditions and limitations in section 3, each contributor grants you a non-exclusive, worldwide, royalty-free license under its licensed patents to make, have made, use, sell, offer for sale, import, and/or otherwise dispose of its contribution in the software or derivative

# 3. Conditions and Limitations

works of the contribution in the software.

- (A) No Trademark License- This license does not grant you rights to use any contributors' name, logo, or trademarks.
- (B) If you bring a patent claim against any contributor over patents that you claim are infringed by the software, your patent license from such contributor to the software ends automatically.
- (C) If you distribute any portion of the software, you must retain all copyright, patent, trademark, and attribution notices that are present in the software.

(E) The software is licensed "as-is." You bear the risk of using it. The contributors give no express warranties, guarantees, or conditions. You may have additional consumer rights under your local laws which this license cannot change. To the extent permitted under your local laws, the contributors exclude the implied warranties of merchantability, fitness for a particular purpose and non-infringement.

# The MIT License (MIT)

The Telex Radio Dispatch software contains open source software licensed under The MIT License (MIT), and the license terms below in this schedule (copied from the following website: http://opensource.org/licenses/MIT) apply to that open source software.

### expat

Copyright (c) 1998, 1999, 2000 Thai Open Source Software Center Ltd and Clark Cooper Copyright (c) 2001, 2002, 2003, 2004, 2005, 2006 Expat maintainers.

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

#### **Font Awesome**

https://github.com/FortAwesome/Font-Awesome/blob/master/LICENSE.txt Copyright <YEAR> <COPYRIGHT HOLDER>

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

### **jQuery**

Copyright JS Foundation and other contributors, https://js.foundation/.
This software consists of voluntary contributions made by many individuals. For exact contribution history, refer to the revision history available at https://github.com/jquery/jquery.

The following license applies to all parts of this software except as documented below:

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

All files located in the node modules and external directories are externally maintained libraries used by this software which have their own licenses; we recommend you read them, as their terms may differ from the terms above.

### jQuery UI

Copyright jQuery Foundation and other contributors, https://jquery.org/
This software consists of voluntary contributions made by many individuals. For exact contribution history, refer to the revision history available at <a href="https://github.com/jquery/jquery-ui">https://github.com/jquery/jquery-ui</a>.

The following license applies to all parts of this software except as documented below:

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

Copyright and related rights for sample code are waived via CC0. Sample code is defined as all source code contained within the demos directory.

CC0: http://creativecommons.org/publicdomain/zero/1.0/

All files located in the node modules and external directories are externally maintained libraries used by this software which have their own licenses; we recommend you read them, as their terms may differ from the terms above.

### **¡Query File Upload Plugin**

Copyright (c) 2017 jQuery-File-Upload Authors

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE

AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

#### Microsoft.PowerShell.5.ReferenceAssembles

https://github.com/PowerShell/PowerShell-Tests/blob/master/LICENSE Copyright (c) 2015 Microsoft Corporation.

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

# The MIT License (MIT)

Copyright (c) <year> <copyright holders>

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

### MvvmLight and MvvmLightLibs

# https://github.com/lbugnion/mvvmlight/blob/master/GalaSoft.MvvmLight/GalaSoft.MvvmLight %20(PCL)/License.txt

Copyright (c) 2009-2018 Laurent Bugnion (GalaSoft), laurent@galasoft.ch Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY. WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM. OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

### SharpZipLib

https://github.com/icsharpcode/SharpZipLib/blob/master/LICENSE.txt

Copyright © 2000-2018 SharpZipLib Contributors

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

#### Mozilla Public License v1.1

The Telex Radio Dispatch software contains open source software licensed under the Mozilla Public License v1.1, and the license terms below in this Schedule 3 (copied from the following website: http://www.mozilla.org/MPL/1.1/index.txt) apply to that open source software.

#### **Definitions**

- "Commercial Use" means distribution or otherwise making the Covered Code available to a third party.
- "Contributor" means each entity that creates or contributes to the creation of Modifications.
- "Contributor Version" means the combination of the Original Code, prior Modifications used by a Contributor, and the Modifications made by that particular Contributor.
- "Covered Code" means the Original Code or Modifications or the combination of the Original Code and Modifications, in each case including portions thereof.
- "Electronic Distribution Mechanism" means a mechanism generally accepted in the software development community for the electronic transfer of data.
- "Executable" means Covered Code in any form other than Source Code.
- "Initial Developer" means the individual or entity identified as the Initial Developer in the Source Code notice required by Exhibit A.
- "Larger Work" means a work which combines Covered Code or portions thereof with code not governed by the terms of this License.
- "License" means this document.
  - "Licensable" means having the right to grant, to the maximum extent possible, whether at the time of the initial grant or subsequently acquired, any and all of the rights conveyed herein.
- Modifications" means any addition to or deletion from the substance or structure of either the Original Code or any previous Modifications. When Covered Code is released as a series of files, a Modification is:
- 1. Any addition to or deletion from the contents of a file containing Original Code or previous Modifications.
- 2. Any new file that contains any part of the Original Code or previous Modifications.
- "Original Code" means Source Code of computer software code which is described in the Source Code notice required by Exhibit A as Original Code, and which, at the time of its release under this License is not already Covered Code governed by this License.
  - "Patent Claims" means any patent claim(s), now owned or hereafter acquired, including without limitation, method, process, and apparatus claims, in any patent Licensable by grantor.
- "Source Code" means the preferred form of the Covered Code for making modifications to it, including all modules it contains, plus any associated interface definition files, scripts used to control compilation and installation of an Executable, or source code differential comparisons against either the Original Code or another well known, available Covered Code of the Contributor's choice. The Source Code can be in a compressed or archival form, provided the appropriate decompression or de-archiving software is widely available for no charge.
- "You" (or "Your") means an individual or a legal entity exercising rights under, and complying with all of the terms of, this License or a future version of this License issued under Section 6.1. For legal entities, "You" includes any entity which controls. is controlled by, or is common control with you. For purposes of this definition, "control" means (a) the power, direct or indirect, to cause the direction or management of such entity, whether by contract or otherwise, or (b) ownership of more than fifty percent (50%) of the outstanding shares or beneficial ownership of such entity.

### **Source Code License**

### The Initial Developer Grant

The Initial Developer hereby grants You a world-wide, royalty-free, nonexclusive license, subject to third party intellectual property claims:

- under intellectual property rights (other than patent or trademark) Licensable by Initial Developer to use, reproduce, modify, display, perform, sublicense and distribute the Original Code (or portions thereof) with or without Modifications, and/or as part of a Larger Work; and
- under Patents Claims infringed by the making, using or selling of Original Code, to make, have made, use, practice, sell, and offer for sale, and/or otherwise dispose of the Original Code (or portions thereof).
- the licenses granted in this Section (1) and (2) are effective on the date Initial Developer first distributes Original Code under the terms of this License.
- 4. Notwithstanding Section (2) above, no patent license is granted: 1) for code that You delete from the Original Code; 2) separate from the Original Code; or 3) for infringements caused by: i) the modification of the Original Code or ii) the combination of the Original Code with other software or devices.

### **Contributor Grant**

Subject to third party intellectual property claims, each Contributor hereby grants You a world-wide, royalty-free, non-exclusive license

- under intellectual property rights (other than patent or trademark) Licensable by Contributor, to use, reproduce, modify, display, perform, sublicense and distribute the Modifications created by such Contributor (or portions thereof) either on an unmodified basis, with other Modifications, as Covered Code and/or as part of a Larger Work; and
- under Patent Claims infringed by the making, using, or selling of Modifications made by that Contributor either alone and/or in combination with its Contributor Version (or portions of such combination), to make, use, sell, offer for sale, have made, and/or otherwise dispose of: 1) Modifications made by that Contributor (or portions thereof); and 2) the combination of Modifications made by that Contributor with its Contributor Version (or portions of such combination).
- the licenses granted in Sections (1) and (2) are effective on the date Contributor first makes Commercial Use of the Covered Code.
- 4. Notwithstanding Section (2) above, no patent license is granted: 1) for any code that Contributor has deleted from the Contributor Version; 2) separate from the Contributor Version; 3) for infringements caused by: i) third party modifications of Contributor Version or ii) the combination of Modifications made by that Contributor with other software (except as part of the Contributor Version) or other devices; or 4) under Patent Claims infringed by Covered Code in the absence of Modifications made by that Contributor.

# **Distributions Obligations**

### **Application of License**

The Modifications which You create or to which You contribute are governed by the terms of this License, including without limitation Section Contributor Grant. The Source Code version of Covered Code may be distributed only under the terms of this License or a future version of this License released under Section New Versions, and You must include a copy of this License with every copy of the Source Code You distribute. You may not offer or impose any

terms on any Source Code version that alters or restricts the applicable version of this License or the recipients' rights hereunder. However, You may include an additional document offering the additional rights described in Section Required Notices.

### **Availability of Source Code**

Any Modification which You create or to which You contribute must be made available in Source Code form under the terms of this License either on the same media as an Executable version or via an accepted Electronic Distribution Mechanism to anyone to whom you made an Executable version available; and if made available via Electronic Distribution Mechanism, must remain available for at least twelve months after the date it initially became available, or at least six months after a subsequent version of that particular Modification has been made available to such recipients. You are responsible for ensuring that the Source Code version remains available even if the Electronic Distribution Mechanism is maintained by a third party.

### **Description of Modifications**

You must cause all Covered Code to which You contribute to contain a file documenting the changes You made to create that Covered Code and the date of any change. You must include a prominent statement that the Modification is derived, directly or indirectly, from Original Code provided by the Initial Developer and including the name of the Initial Developer in (a) the Source Code, and (b) in any notice in an Executable version or related documentation in which You describe the origin or ownership of the Covered Code.

### **Intellectual Property Matters**

Third Party Claims

If Contributor has knowledge that a license under a third party's intellectual property rights is required to exercise the rights granted by such Contributor under Sections The Initial Developer Grant or Contributor Grant, Contributor must include a text file with the Source Code distribution titled "LEGAL" which describes the claim and the party making the claim in sufficient detail that a recipient will know whom to contact. If Contributor obtains such knowledge after the Modification is made available as described in Section Availability of Source Code, Contributor shall promptly modify the LEGAL file in all copies Contributor makes available thereafter and shall take other steps (such as notifying appropriate mailing lists or news groups) reasonably calculated to inform those who received the Covered Code that new knowledge has been obtained.

## Contributor APIs

If Contributor's Modifications include an application programming interface and Contributor has knowledge of patent licenses which are reasonably necessary to implement that API, Contributor must also include this information in the LEGAL file.

### Representation

Contributor represents that, except as disclosed pursuant to Section (1) above, Contributor believes that Contributor's Modifications are Contributor's original creation(s) and/or Contributor has sufficient rights to grant the rights conveyed by this License.

# **Required Notices**

You must duplicate the notice in Exhibit A in each file of the Source Code. If it is not possible to put such notice in a particular Source Code file due to its structure, then You must include such notice in a location (such as a relevant directory) where a user would be likely to look for

such a notice. If you created one or more Modification(s) You may add your name as a Contributor to the notice described in Exhibit A. You must also duplicate this License in any documentation for the Source Code where You describe recipients' rights or ownership rights relating to Covered Code. You may choose to offer, and to charge a fee for, warranty, support, indemnity or liability obligations to one or more recipients of Covered Code. However, You may do so only on Your own behalf, and not on behalf of the Initial Developer or any Contributor. You must make it absolutely clear than any such warranty, support, indemnity or liability obligation is offered by You alone, and You hereby agree to indemnify the Initial Developer and every Contributor for any liability incurred by the Initial Developer or such Contributor as a result of warranty, support, indemnity or liability terms You offer.

### **Distribution of Executable Versions**

You may distribute Covered Code in Executable form only if the requirements of Section 3.1-3.5 have been met for that Covered Code, and if You include a notice stating that the Source Code version of the Covered Code is available under the terms of this License, including a description of how and where You have fulfilled the obligations of Section 3.2. The notice must be conspicuously included in any notice in an Executable version, related documentation or collateral in which You describe recipients' rights relating to the Covered Code.

You may distribute the Executable version of Covered Code or ownership rights under a license of Your choice, which may contain terms different from this License, provided that You are in compliance with the terms of this License and that the license for the Executable version does not attempt to limit or alter the recipient's rights in the Source Code version from the rights set forth in this License. If You distribute the Executable version under a different license You must make it absolutely clear that any terms which differ from this License are offered by You alone, not by the Initial Developer or any Contributor. You hereby agree to indemnify the Initial Developer and every Contributor for any liability incurred by the Initial Developer or such Contributor as a result of any such terms You offer.

### Larger Works

You may create a Larger Work by combining Covered Code with other code not governed by the terms of this License and distribute the Larger Work as a single product. In such a case, You must make sure the requirements of this License are fulfilled for the Covered Code.

# Inability to Comply Due to Statute or Regulation

If it is impossible for You to comply with any of the terms of this License with respect to some or all of the Covered Code due to statute, judicial order, or regulation then You must: (a) comply with the terms of this License to the maximum extent possible; and (b) describe the limitations and the code they affect. Such description must be included in the LEGAL file described in Section Intellectual Property Matters and must be included with all distributions of the Source Code. Except to the extent prohibited by statute or regulation, such description must be sufficiently detailed for a recipient of ordinary skill to be able to understand it.

### Application of this License

This License applies to code to which the Initial Developer has attached the notice in Exhibit A and to related Covered Code.

### Versions of the License

#### **New Versions**

Netscape Communications Corporation ("Netscape") may publish revised and/or new versions of the License from time to time. Each version will be given a distinguishing version number.

#### **Effect of New Versions**

Once Covered Code has been published under a particular version of the License, You may always continue to use it under the terms of that version. You may also choose to use such Covered Code under the terms of any subsequent version of the License published by Netscape. No one other than Netscape has the right to modify the terms applicable to Covered Code created under this License.

#### **Derivative Works**

If You create or use a modified version of this License (which you may only do in order to apply it to code which is not already Covered Code governed by this License), You must (a) rename Your license so that the phrases "Mozilla", "MOZILLAPL", "MOZPL", "Netscape", "MPL", "NPL" or any confusingly similar phrase do not appear in your license (except to note that your license differs from this License) and (b) otherwise make it clear that Your version of the license contains terms which differ from the Mozilla Public License and Netscape Public License. (Filling in the name of the Initial Developer, Original Code or Contributor in the notice described in Exhibit A shall not of themselves be deemed to be modifications of this License.)

### **Disclaimer of Warranty**

COVERED CODE IS PROVIDED UNDER THIS LICENSE ON AN "AS IS" BASIS, WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, WARRANTIES THAT THE COVERED CODE IS FREE OF DEFECTS, MERCHANTABLE, FIT FOR A PARTICULAR PURPOSE OR NON-INFRINGING. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE COVERED CODE IS WITH YOU. SHOULD ANY COVERED CODE PROVE DEFECTIVE IN ANY RESPECT, YOU (NOT THE INITIAL DEVELOPER OR ANY OTHER CONTRIBUTOR) ASSUME THE COST OF ANY NECESSARY SERVICING, REPAIR OR CORRECTION. THIS DISCLAIMER OF WARRANTY CONSTITUTES AN ESSENTIAL PART OF THIS LICENSE. NO USE OF ANY COVERED CODE IS AUTHORIZED HEREUNDER EXCEPT UNDER THIS DISCLAIMER.

#### **Termination**

#### 1.

This License and the rights granted hereunder will terminate automatically if you fail to comply with terms herein and fail to cure such breach within 30 days of becoming aware of the breach. All sublicenses to the Covered Code which are properly granted shall survive any termination of this License. Provisions which, by their nature, must remain in effect beyond the termination of this License shall survive.

#### 2.

If You initiate litigation by asserting a patent infringement claim (excluding declatory judgment actions) against Initial Developer or a Contributor (the Initial Developer or Contributor against whom You file such action is referred to as "Participant") alleging that:

- such Participant's Contributor Version directly or indirectly infringes any patent, then any and all rights granted by such Participant to You under Sections The Initial Developer Grant and/or Contributors Grant of this License shall, upon 60 days notice from Participant terminate prospectively, unless if within 60 days after receipt of notice You either: (i) agree in writing to pay Participant a mutually agreeable reasonable royalty for Your past and future use of Modifications made by such Participant, or (ii) withdraw Your litigation claim with respect to the Contributor Version against such Participant. If within 60 days of notice, a reasonable royalty and payment arrangement are not mutually agreed upon in writing by the parties or the litigation claim is not withdrawn, the rights granted by Participant to You under Sections The Initial Developer Grant and/or Contributors Grant automatically terminate at the expiration of the 60 day notice period specified
- 2. any software, hardware, or device, other than such Participant's Contributor Version, directly or indirectly infringes any patent, then any rights granted to You by such Participant under Sections The Initial Developer Grant (2) and Contributors Grant (2) are revoked effective as of the date You first made, used, sold, distributed, or had made, Modifications made by that Participant.

### 3.

If You assert a patent infringement claim against Participant alleging that such Participant's Contributor Version directly or indirectly infringes any patent where such claim is resolved (such as by license or settlement) prior to the initiation of patent infringement litigation, then the reasonable value of the licenses granted by such Participant under Sections The Initial Developer Grant or Contributors Grant shall be taken into account in determining the amount or value of any payment or license.

# 4.

In the event of termination under Sections 2. (1) or 2. (2) above, all end user license agreements (excluding distributors and resellers) which have been validly granted by You or any distributor hereunder prior to termination shall survive termination.

# **Limitation of Liability**

UNDER NO CIRCUMSTANCES AND UNDER NO LEGAL THEORY, WHETHER TORT (INCLUDING NEGLIGENCE), CONTRACT, OR OTHERWISE, SHALL YOU, THE INITIAL DEVELOPER, ANY OTHER CONTRIBUTOR, OR ANY DISTRIBUTOR OF COVERED CODE, OR ANY SUPPLIER OF ANY OF SUCH PARTIES, BE LIABLE TO ANY PERSON FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES OF ANY CHARACTER INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF GOODWILL, WORK STOPPAGE, COMPUTER FAILURE OR MALFUNCTION, OR ANY AND ALL OTHER COMMERCIAL DAMAGES OR LOSSES, EVEN IF SUCH PARTY SHALL HAVE BEEN INFORMED OF THE POSSIBILITY OF SUCH DAMAGES.

THIS LIMITATION OF LIABILITY SHALL NOT APPLY TO LIABILITY FOR DEATH OR PERSONAL INJURY RESULTING FROM SUCH PARTY'S NEGLIGENCE TO THE EXTENT APPLICABLE LAW PROHIBITS SUCH LIMITATION. SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THIS EXCLUSION AND LIMITATION MAY NOT APPLY TO YOU.

#### U.S. Government end users

The Covered Code is a "commercial item," as that term is defined in 48 C.F.R. 2.101 (Oct. 1995), consisting of "commercial computer software" and "commercial computer software documentation," as such terms are used in 48 C.F.R.12.212 (Sept. 1995). Consistent with 48 C.F.R. 12.212 and 48 C.F.R.227.7202-1 through 227.7202-4 (June 1995), all U.S. Government End Users acquire Covered Code with only those rights set forth herein.

#### Miscellaneous

This License represents the complete agreement concerning subject matter hereof. If any provision of this License is held to be unenforceable, such provision shall be reformed only to the extent necessary to make it enforceable.

This License shall be governed by California law provisions (except to the extent applicable law, if any, provides otherwise), excluding its conflict-of-law provisions. With respect to disputes in which at least one party is a citizen of, or an entity chartered or registered to do business in the United States of America, any litigation relating to this License shall be subject to the jurisdiction of the Federal Courts of the Northern District of California, with venue lying in Santa Clara County, California, with the losing party responsible for costs, including without limitation, court costs and reasonable attorneys' fees and expenses. The application of the United Nations Convention on Contracts for the International Sale of Goods is expressly excluded. Any law or regulation which provides that the language of a contract shall be construed against the drafter shall not apply to this License.

### **Responsibility for Claims**

As between Initial Developer and the Contributors, each party is responsible for claims and damages arising, directly or indirectly, out of its utilization of rights under this License and You agree to work with Initial Developer and Contributors to distribute such responsibility on an equitable basis. Nothing herein is intended or shall be deemed to constitute any admission of liability.

#### **Multiple-Licensed Code**

Initial Developer may designate portions of the Covered Code as "Multiple-Licensed". "Multiple-Licensed" means that the Initial Developer permits you to utilize portions of the Covered Code under Your choice of the MPL or the alternative licenses, if any, specified by the Initial Developer in the file described in Exhibit A.

### **EXHIBIT A - Mozilla Public License**

The contents of this file are subject to the Mozilla Public License; you may not use this file except in compliance with the License. You may obtain a copy of the License at http://www.mozilla.org/MPL/Software distributed under the License is distributed on an "AS IS" basis, WITHOUT WARRANTY OF ANY KIND, either express or implied. Refer to the License for the specific language governing rights and limitations under the License.

The Original Code is Open Phone Abstraction Library 3.10.5- Release May 3, 2012 The Initial Developer of the Original Code is Equivalence Pty.Ltd.

### **OpenSSL License**

The Telex Radio Dispatch software contains open source software licensed under the OpenSSL License, and the license terms below in this schedule (copied from the following website: https://www.openssl.org/source/license.html) apply to that open source software.

#### License Issues

The OpenSSL toolkit stays under a double license, i.e. both the conditions of the OpenSSL License and the original SSLeay license apply to the toolkit. See below for the actual license texts.

Copyright (c) 1998-2017 The OpenSSL Project. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistribution of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/ or other materials provided with the distribution.
- All advertising materials mentioning features or use of this software must display the following acknowledgment: "This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit. (http://www.openssl.org/)"
- The names "OpenSSL Toolkit" and "OpenSSL Project" must not be used to endorse or promote products derived from this software without prior written permission. For written permission, please contact openssl-core@openssl.org.
- 5. Products derived from this software may not be called "OpenSSL" nor may "OpenSSL" appear in their names without prior written permission of the OpenSSL Project.
- Redistributions of any form whatsoever must retain the following acknowledgment:

"This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit (http://www.openssl.org/)"

THIS SOFTWARE IS PROVIDED BY THE OpenSSL PROJECT "AS ISI" AND ANY EXPRESSED OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE OpenSSL PROJECT OR ITS CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

This product includes cryptographic software written by Eric Young (eay@cryptsoft.com). This product includes software written by Tim Hudson (tjh@cryptsoft.com).

### **SSLeay License**

The Telex Radio Dispatch software contains open source software licensed under the SSLeay License, and the license terms below in this schedule (copied from the following website: https://www.openssl.org/source/license.html) apply to that open source software.

#### License Issues

The OpenSSL toolkit stays under a double license, i.e. both the conditions of the OpenSSL License and the original SSLeay license apply to the toolkit. See below for the actual license texts.

#### **Original SSLeay License**

Copyright (C) 1995-1998 Eric Young (<a href="mailto:eay@cryptsoft.com">eay@cryptsoft.com</a>) All rights reserved.

This package is an SSL implementation written by Eric Young (eay@cryptsoft.com). The implementation was written so as to conform with Netscapes SSL.

This library is free for commercial and non-commercial use as long as the following conditions are adhered to. The following conditions apply to all code found in this distribution, be it the RC4, RSA, lhash, DES, etc., code; not just the SSL code. The SSL documentation included with this distribution is covered by the same copyright terms except that the holder is Tim Hudson (tjh@cryptsoft.com).

Copyright remains Eric Young's, and as such any Copyright notices in the code are not to be removed.

If this package is used in a product, Eric Young should be given attribution as the author of the parts of the library used. This can be in the form of a textual message at program startup or in documentation (online or textual) provided with the package.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- 1. Redistribution of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- 2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/ or other materials provided with the distribution.
- 3. All advertising materials mentioning features or use of this software must display the following acknowledgement: "This product includes cryptographic software written by Eric Young (<a href="mailto:eay@cryptsoft.com">eay@cryptsoft.com</a>". (The word 'cryptographic' can be left out if the rouines from the library being used are not cryptographic related.)
- 4. If you include any Windows specific code (or a derivative thereof) from the apps directory (application code) you must include an acknowledgement:

"This product includes software written by Tim Hudson (tjh@cryptsoft.com)"

THIS SOFTWARE IS PROVIDED BY ERIC YOUNG "AS IS!" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO

EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESSINTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

The license and distribution terms for any publically available version or derivative of this code cannot be changed. i.e. this code cannot simply be copied and put under another distribution license [including the GNU Public License.]

# The X11 License (MIT/X Consortium)

The Telex Radio Dispatch software contains open source software licensed under The X11 License (MIT/X Consortium), and the license terms below in this schedule (copied from the following website: http://opensource.org/licenses/MIT) apply to that open source software.

Copyright (c) 1998-2004,2006 Free Software Foundation, LCC.

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

Except as contained in this notice, the name(s) of the above copyright holders shall not be used in advertising or otherwise to promote the sale, use or other dealings in this Software without prior written authorization.

\$Id: README,v 1.23 2006/04/22 22:19:37 tom Exp \$

### popt

Copyright (c) 1998 Red Hat Software

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

Except as contained in this notice, the name of the X Consortium shall not be used in advertising or otherwise to promote the sale, use or other dealings in this Software without prior written authorization from the X Consortium.

### The X11 License (MIT/X Consortium)

Copyright (c) <year> <copyright holders>

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

Except as contained in this notice, the name(s) of the above copyright holders shall not be used in advertising or otherwise to promote the sale, use or other dealings in this Software without prior written authorization.

### The zlib/libpng License

The Telex Radio Dispatch software contains open source software licensed under the zlib/libpng License (Zlib)), and the license terms below in this schedule (copied from the following website: http://opensource.org/licenses/Zlib) apply to that open source software.

### libpng

This copy of the libpng notices is provided for your convenience. In case of any discrepancy between this copy and the notices in the file png.h that is included in the libpng distribution, the latter shall prevail.

### Copyright notice, Disclaimer, and License

If you modify libpng you may insert additional notices immediately following this sentence. libpng, December 3, 2004, is Copyright (c) 2004 Glenn Randers-Pehrson, and is distributed according to the same disclaimer and license as libpng with the following individual added to the list of Contributing Authors Cosmin Truta libpng, July 1, 2000, - October 3, 2002, are Copyright (c) 2000- 2002 Glenn Randers-Pehrson, and are distributed according to the same disclaimer and license as libpng with the following individuals added to the list of Contributing Authors:

Simon-Pierre Cadieux
Eric S. Raymond
Gilles Vollant
and with the following additions to the disclaimer:

There is no warranty against interference with your enjoyment of the library or against infringement. There is no warranty that our efforts or the library will fulfill any of your particular purposes or needs. This library is provided with all faults, and the entire risk of satisfactory quality, performance, accuracy, and effort is with the user.

libpng versions 0.97, January 1998, through 1.0.6, March 20, 2000, are Copyright (c) 1998, 1999 Glenn Randers-Pehrson, and are distributed according to the same disclaimer and license as libpng-0.96, with the following individuals added to the list of Contributing Authors: Tom Lane

Glenn Randers-Pehrson

Willem van Schaik

libpng versions 0.89, June 1996, through 0.96, May 1997, are Copyright (c) 1996, 1997 Andreas Dilger Distributed according to the same disclaimer and license as libpng-0.88, with the following individuals added to the list of Contributing Authors:

John Bowler

Kevin Bracey

Sam Bushell

Magnus Holmgren

**Greg Roelofs** 

Tom Tanner

libpng versions 0.5, May 1995, through 0.88, January 1996, are Copyright (c) 1995, 1996 Guy Eric Schalnat, Group 42, LCC. For the purposes of this copyright and license, "Contributing Authors" is defined as the following set of individuals:

Andreas Dilger

Dave Martindale

Guy Eric Schalnat

Paul Schmidt

Tim Wegner

The PNG Reference Library is supplied "AS IS". The Contributing Authors and Group 42, LCC. disclaim all warranties, expressed or implied, including, without limitation, the warranties of merchantability and of fitness for any purpose. The Contributing Authors and Group 42, LCC. assume no liability for direct, indirect, incidental, special, exemplary, or consequential damages, which may result from the use of the PNG Reference Library, even if advised of the possibility of such damage.

Permission is granted to anyone to use this software for any purpose, including commercial applications, and to alter it and redistribute it freely, subject to the following restrictions:

- 1. The origin of this software must not be misrepresented; you must not claim that you wrote the original software. If you use this software in a product, an acknowledgment in the product documentation would be appreciated but is not required.
- 2. Altered source versions must be plainly marked as such, and must not be misrepresented as being the original software.
- 3. This Copyright notice may not be removed or altered from any source or altered source distribution.

666 en | Appendix L - End user license agreement

The Contributing Authors and Group 42, LCC. specifically permit, without fee, and encourage the use of this source code as a component to supporting the PNG file format in commercial products. If you use this source code in a product, acknowledgment is not required but would be appreciated.

A "png get copyright" function is available, for convenient use in "about" boxes and the like: printf("%s",png get copyright(NULL));

Also, the PNG logo (in PNG format, of course) is supplied in the files "pngbar.png" and "pngbar.jpg (88x31) and "pngnow.png" (98x31).

Libpng is OSI Certified Open Source Software. OSI Certified Open Source is a certification mark of the Open Source Initiative.

Glenn Randers-Pehrson glennrp at users.sourceforge.net December 3, 2004

### Tiny XML

### http://www.grinninglizard.com/tinyxmldocs/index.html

Copyright (c) 2000-2006 Lee Thomason (www.grinninglizard.com)

This software is provided 'as-is', without any express or implied warranty. In no event will the authors be held liable for any damages arising from the use of this software.

Permission is granted to anyone to use this software for any purpose, including commercial applications, and to alter it and redistribute it freely, subject to the following restrictions:

- 1. The origin of this software must not be misrepresented; you must not claim that you wrote the original software. If you use this software in a product, an acknowledgment in the product documentation would be appreciated but is not required.
- 2. Altered source versions must be plainly marked as such, and must not be misrepresented as being the original software.
- 3. This notice may not be removed or altered from any source distribution.

### zlib

(C) 1995-2004 Jean-loup Gailly and Mark Adler

This software is provided 'as-is', without any express or implied warranty. In no event will the authors be held liable for any damages arising from the use of this software.

Permission is granted to anyone to use this software for any purpose, including commercial applications, and to alter it and redistribute it freely, subject to the following restrictions:

- 1. The origin of this software must not be misrepresented; you must not claim that you wrote the original software. If you use this software in a product, an acknowledgment in the product documentation would be appreciated but is not required.
- 2. Altered source versions must be plainly marked as such, and must not be misrepresented as being the original software.
- This notice may not be removed or altered from any source distribution.

Jean-loup Gailly - jloup@gzip.org Mark Adler - madler@alumni.caltech.edu If you use the zlib library in a product, we would appreciate \*not\* receiving lengthy legal documents to sign. The sources are provided for free but without warranty of any kind. The library has been entirely written by Jean-loup Gailly and Mark Adler; it does not include third-party code.

If you redistribute modified sources, we would appreciate that you include in the file ChangeLog history information documenting your changes. Please read the FAQ for more information on the distribution of modified source versions.

# The zlib/libpng License

Copyright (c) <year> <copyright holders>

This software is provided 'as-is', without any express or implied warranty. In no event will the authors be held liable for any damages arising from the use of this software.

Permission is granted to anyone to use this software for any purpose, including commercial applications, and to alter it and redistribute it freely, subject to the following restrictions:

- 1. The origin of this software must not be misrepresented; you must not claim that you wrote the original software. If you use this software in a product, an acknowledgment in the product documentation would be appreciated but is not required.
- 2. Altered source versions must be plainly marked as such, and must not be misrepresented as being the original software.
- 3. This notice may not be removed or altered from any source distribution.

Bosch Security Systems, LLC Technical Manual 2021-06 | 14 | F.01U.218.561



# **TELEX**

12000 Portland Avenue South Burnsville MN 55337 USA

# www.telex.com

© Bosch Security Systems, LLC, 2021