



Model 6200PCRD PCB

Installation Manual

P.N. 803809

1 Installation:

Installing and removing line cards can be completed in the field by qualified personnel. The steps for this process are listed below.

- 1) Remove power from the console.
- 2) Remove the pan head screws holding the rear panel to the top and bottom chassis. A Phillips screwdriver will be required. Also remove the screws holding the line cards.
- 3) Remove the rear panel and remove hole cover knock out for the line card position you wish to install.
- 4) Insert the card into the slot making sure that the line connectors are flush with the back of the C-6200.
- 5) Place the rear cover back on; replace all screws removed in the first step.
- 6) Apply power to the unit and configure the new cards using your WEB browser.

TELEX Communications, Inc.

Vega Signaling Products

8601 East Cornhusker Highway, Lincoln, Nebraska, 68507
Phone: (402) 465-7026 / (800) 752-7560 Fax: (402) 467-3279
E-mail: vega@telex.com, Web: www.vega-signaling.com

June 19, 2003