

# How to update Nexus PC Model 4106 drivers for better operation of Sound Card.

This application note is written to help customers update installed soundcard drivers to fix distorted TX audio when using the HB-3+. This does not affect any Nexus PC operating with the ADHB-4.

**NOTE:** This is for the Nexus PC model 4106 only using an HB-3+.

## Steps

1. Log in as NexusIP Admin
2. Check to see if your PC model is subject
  - a. Click on the folder in the bottom left of the screen
  - b. Click on the C: drive
  - c. Open the folder called "Telex NexusIP"
  - d. Open the "Telex Image Info.txt" file
  - e. If the first line is **KBM-4106-NexusIP-Win7-64-A through D** then this application note will apply to this PC.
3. Make sure the PC has access to the internet.
4. Goto: <https://www.telexradiodispatch.com/beta/Telex-Product-Downloads/IP-Products/Nexus-PC/>
5. Locate the driver for the sound card.
  - a. The filename is SBA4\_SII\_PCDRV\_L02\_2\_18\_0019.exe
  - b. Download the file to a known location.
6. Now install the sound card driver by opening the exe for it.
7. The PC will uninstall the old driver and restart.
8. Complete the install steps and it will restart again.
9. Start C-Soft and test for good audio, resetting of levels may be required.

**Technical Support:**

**Email:** [telexdispatchtechsupport@us.bosch.com](mailto:telexdispatchtechsupport@us.bosch.com)

**Phone:** 800-898-6723

**Fax:** 402-467-3279

**Bosch Security Systems, Inc.  
Communications System Division**

8601 East Cornhusker Highway  
Lincoln Nebraska 68507

**Phone: (800) 752-7560 Fax: (402) 467-3279**

**Email: [Telexdispatch@us.bosch.com](mailto:Telexdispatch@us.bosch.com)**

**Web: [www.telex.com](http://www.telex.com)**

**Downloads: [www.telexradiodispatch.com/](http://www.telexradiodispatch.com/)**