

Related Product:

C-6200 with line cards


Question:

What are the correct locations for J9 and J18 on the Dual Tone line cards?

Solution:

While all manual versions have correctly described jumper configuration for Line 1 TX path J9 and J18, early versions of the PCB (P/N 750597, A through E) had silkscreen that incorrectly labeled J9 and J18.

Changes to J9 were in actuality being done to J18 and vice versa, the latest PCB revision F has the silkscreen correctly located as shown in the silkscreen picture below.



Suggestions or comments:

Contact technical support with suggestions or comments concerning this application note.

Technical Support:

Email: Telexdispatchtechsupport@us.bosch.com

Fax: 1-402-467-3279

Phone: 1-800-898-6723

Bosch Security
Systems, Inc.
8601 East Cornhusker Highway
Lincoln Nebraska
68507

Phone: (800) 752-7560

Fax: (402) 467-3279

Email:

Telexdispatch@us.bosch.com

Web:

www.telex.com