


Adding a 32key programmable keyboard to IP-3002, IP-3008 or IP-3018 console


1. Turn the console upside down

2. Unscrew two Philips screws and remove side cover



3. Connect the ribbon cable

4. Join the keyboard with the console



5. Put back the side cover and tighten all four screws

